

COM303: Digital Signal Processing

Lecture 22: Digital Communication Systems (I)

overview

- ▶ the communication channel
- ▶ bandwidth constraints
- power constraints

1

a comparison of data rates

- ► Transatlantic cable:
 - 1866: 8 words per minute (\approx 5 bps)
 - 1956: AT&T, coax, 48 voice channels (≈3Mbps)
 - ullet 2005: Alcatel Tera10, fiber, 8.4 Tbps (8.4 imes 10¹² bps)
 - 2012: fiber, 60 Tbps
- Voiceband modems
 - 1950s: Bell 202, 1200 bps
 - 1990s: V90, 56Kbps
 - 2008: ADSL2+, 24Mbps

a comparison of data rates


- ► Transatlantic cable:
 - 1866: 8 words per minute (\approx 5 bps)
 - 1956: AT&T, coax, 48 voice channels (≈3Mbps)
 - ullet 2005: Alcatel Tera10, fiber, 8.4 Tbps (8.4 imes 10¹² bps)
 - 2012: fiber, 60 Tbps
- Voiceband modems
 - 1950s: Bell 202, 1200 bps
 - 1990s: V90, 56Kbps
 - 2008: ADSL2+, 24Mbps


Success factors for digital communications

- 1. power of the digital paradigm
- 2. natural integration with information theory
- 3. hardware advancement


Success factors for digital communications

- 1) power of the DSP paradigm:
 - ▶ integers are "easy" to regenerate
 - good phase control
 - adaptive algorithms






$$x(t)/G + \sigma(t)$$



$$G[x(t)/G + \sigma(t)] = x(t) + G\sigma(t)$$

5



$$\hat{x}_1(t) = G\operatorname{sgn}[x(t) + \sigma(t)]$$

E


Success factors for digital communications

- 2) algorithmic nature of DSP is a perfect match with information theory:
 - error correction (CD's and DVD's)
 - entropy coding (JPEG)

Success factors for digital communications

- 3) hardware advancement
 - general-purpose platforms
 - miniaturization
 - power efficiency

The many incarnations of a conversation



8

The analog channel

unescapable "limits" of physical channels:

- bandwidth constraint
- power constraint

both constraints will affect the final capacity of the channel

Ç

The analog channel

unescapable "limits" of physical channels:

- ▶ bandwidth constraint
- power constraint

both constraints will affect the final capacity of the channel

Ç

The analog channel

unescapable "limits" of physical channels:

- bandwidth constraint
- power constraint

both constraints will affect the final capacity of the channel

Ç

The analog channel's capacity


maximum amount of information that can be *reliably* delivered over a channel (bits per second)

The harsh truth about reliability

we cannot design a perfect (error-free) communication system because of noise but

we can design a system with arbitrary small error rate (e.g. 10^{-6})

The channel constraints



The design problem

- lacktriangle transmitted data is a sequence of digital symbols $a[n] \in \mathcal{A}$
- \blacktriangleright we will model a[n] as a zero-mean white process
- we need to transform a[n] into an analog signal s(t) that fulfills both bandwidth and power constraints

- ightharpoonup we want to transmit a data sequence a[n] over an analog channel
- we sinc-interpolate a[n] with a period T_s
- ightharpoonup if we make T_s small we can send more symbols per unit of time...
- ightharpoonup ... but the bandwidth of the signal will grow as $1/T_s$

- ightharpoonup we want to transmit a data sequence a[n] over an analog channel
- ightharpoonup we sinc-interpolate a[n] with a period T_s
- ightharpoonup if we make T_s small we can send more symbols per unit of time...
- lacksquare ... but the bandwidth of the signal will grow as $1/T_s$

- ightharpoonup we want to transmit a data sequence a[n] over an analog channel
- ightharpoonup we sinc-interpolate a[n] with a period T_s
- ightharpoonup if we make T_s small we can send more symbols per unit of time...
- lacksquare ... but the bandwidth of the signal will grow as $1/T_s$


- ightharpoonup we want to transmit a data sequence a[n] over an analog channel
- we sinc-interpolate a[n] with a period T_s
- ightharpoonup if we make T_s small we can send more symbols per unit of time...
- lacktriangle ... but the bandwidth of the signal will grow as $1/T_s$

Sinc interpolation


$$x(t) = \sum_{n = -\infty}^{\infty} x[n] \operatorname{sinc}\left(\frac{t - nT_s}{T_s}\right)$$

$$X(f) = egin{cases} (1/F_s)X(e^{j2\pi f/F_s}) & ext{for } |f| \leq rac{F_s}{2} = rac{1}{2T_s} \\ 0 & ext{otherwise} \end{cases}$$


Spectrum of interpolated signals



Spectrum of interpolated signals



Spectrum of interpolated signals



- number of symbols per second is determined by bandwidth constraint
- ▶ to increase information rate we must increase the number of possible symbols
- power is proportional to the square of the max symbol
- ▶ to keep power limited we need to pack symbols closer together
- ▶ all channels introduce noise; at the receiver we have to "guess" what was transmitted
- lack closer symbols have less noise margin, i.e., we lose reliability

- number of symbols per second is determined by bandwidth constraint
- ▶ to increase information rate we must increase the number of possible symbols
- power is proportional to the square of the max symbol
- ▶ to keep power limited we need to pack symbols closer together
- ▶ all channels introduce noise; at the receiver we have to "guess" what was transmitted
- lack closer symbols have less noise margin, i.e., we lose reliability


- number of symbols per second is determined by bandwidth constraint
- ▶ to increase information rate we must increase the number of possible symbols
- power is proportional to the square of the max symbol
- ▶ to keep power limited we need to pack symbols closer together
- ▶ all channels introduce noise; at the receiver we have to "guess" what was transmitted
- lack closer symbols have less noise margin, i.e., we lose reliability

- number of symbols per second is determined by bandwidth constraint
- ▶ to increase information rate we must increase the number of possible symbols
- power is proportional to the square of the max symbol
- ▶ to keep power limited we need to pack symbols closer together
- ▶ all channels introduce noise; at the receiver we have to "guess" what was transmitted
- lack closer symbols have less noise margin, i.e., we lose reliability


- number of symbols per second is determined by bandwidth constraint
- ▶ to increase information rate we must increase the number of possible symbols
- power is proportional to the square of the max symbol
- ▶ to keep power limited we need to pack symbols closer together
- ▶ all channels introduce noise; at the receiver we have to "guess" what was transmitted
- lacksquare closer symbols have less noise margin, i.e., we lose reliability


- number of symbols per second is determined by bandwidth constraint
- ▶ to increase information rate we must increase the number of possible symbols
- power is proportional to the square of the max symbol
- ▶ to keep power limited we need to pack symbols closer together
- ▶ all channels introduce noise; at the receiver we have to "guess" what was transmitted
- ▶ closer symbols have less *noise margin*, i.e., we lose reliability


1 bit per symbol





1 bit per symbol




















- ► from 530kHz to 1.7MHz
- each channel is 8KHz
- power limited by law:
 - daytime/nighttime
 - interference
 - health hazards


- ► from 530kHz to 1.7MHz
- ► each channel is 8KHz
- power limited by law:
 - daytime/nighttime
 - interference
 - health hazards

- ► from 530kHz to 1.7MHz
- ► each channel is 8KHz
- power limited by law:
 - daytime/nighttime
 - interference
 - health hazards

- ► from 530kHz to 1.7MHz
- ► each channel is 8KHz
- power limited by law:
 - daytime/nighttime
 - interference
 - health hazards

- ► from 530kHz to 1.7MHz
- ► each channel is 8KHz
- power limited by law:
 - daytime/nighttime
 - interference
 - health hazards

- ► from 530kHz to 1.7MHz
- each channel is 8KHz
- power limited by law:
 - daytime/nighttime
 - interference
 - health hazards




- ▶ from around 300Hz to around 3500Hz
- power limited by law to 0.2-0.7V rms
- ▶ noise is rather low: SNR usually 30dB or more

- ▶ from around 300Hz to around 3500Hz
- ▶ power limited by law to 0.2-0.7V rms
- ▶ noise is rather low: SNR usually 30dB or more

- ▶ from around 300Hz to around 3500Hz
- power limited by law to 0.2-0.7V rms
- ▶ noise is rather low: SNR usually 30dB or more

The all-digital paradigm


keep everything digital until we hit the physical channel




24

The all-digital paradigm


... and of course do the same for the receiver




Let's look again at the channel constraints




Converting the specs to a digital design



Converting the specs to a digital design



Converting the specs to a digital design



- ightharpoonup convert the bitstream into a sequence of symbols a[n] via a mapper
- ightharpoonup model a[n] as a white random sequence (add a scrambler on the bitstream to make sure)
- \triangleright now we need to convert a[n] into a continuous-time signal within the constraints

- ightharpoonup convert the bitstream into a sequence of symbols a[n] via a mapper
- ightharpoonup model a[n] as a white random sequence (add a scrambler on the bitstream to make sure)
- ightharpoonup now we need to convert a[n] into a continuous-time signal within the constraints

- ightharpoonup convert the bitstream into a sequence of symbols a[n] via a mapper
- ightharpoonup model a[n] as a white random sequence (add a scrambler on the bitstream to make sure)
- ightharpoonup now we need to convert a[n] into a continuous-time signal within the constraints


- \blacktriangleright convert the bitstream into a sequence of symbols a[n] via a mapper
- ightharpoonup model a[n] as a white random sequence (add a scrambler on the bitstream to make sure)
- ightharpoonup now we need to convert a[n] into a continuous-time signal within the constraints






First problem: the bandwidth constraint





First problem: the bandwidth constraint





Shaping the bandwidth

Our problem:

- bandwidth constraint requires us to control the spectral support of a signal
- ▶ we need to be able to "shrink" the support of a full-band signal
- ▶ the answer is *multirate* techniques

Shaping the bandwidth

Our problem:


- ▶ bandwidth constraint requires us to control the spectral support of a signal
- ▶ we need to be able to "shrink" the support of a full-band signal
- ► the answer is *multirate* techniques

Shaping the bandwidth


Our problem:

- ▶ bandwidth constraint requires us to control the spectral support of a signal
- ▶ we need to be able to "shrink" the support of a full-band signal
- ▶ the answer is *multirate* techniques


ideal digital interpolator





Upsampling by K = 3





Upsampling by K = 3

















let $W = F_{\text{max}} - F_{\text{min}}$; pick F_s so that:

- $ightharpoonup F_s > 2F_{\text{max}}$ (obviously)
- $ightharpoonup F_s = KW, K \in \mathbb{N}$

- ightharpoonup we can simply upsample by K

let $W = F_{\text{max}} - F_{\text{min}}$; pick F_s so that:

- $ightharpoonup F_s > 2F_{\text{max}}$ (obviously)
- $ightharpoonup F_s = KW, K \in \mathbb{N}$

ightharpoonup we can simply upsample by K

let $W = F_{\text{max}} - F_{\text{min}}$; pick F_s so that:

- $ightharpoonup F_s > 2F_{\text{max}}$ (obviously)
- $ightharpoonup F_s = KW, K \in \mathbb{N}$

ightharpoonup we can simply upsample by K

let $W = F_{\text{max}} - F_{\text{min}}$; pick F_s so that:

- $ightharpoonup F_s > 2F_{\text{max}}$ (obviously)
- $ightharpoonup F_s = KW, K \in \mathbb{N}$

- ▶ we can simply upsample by K

Baud rate


- ▶ upsampling does not change the *data* rate, only the sample rate
- ightharpoonup we produce (and transmit) W symbols per second
- ► W is sometimes called the Baud rate of the system and is equal to the available bandwidth


Baud rate


- ▶ upsampling does not change the *data* rate, only the sample rate
- ightharpoonup we produce (and transmit) W symbols per second
- ▶ W is sometimes called the Baud rate of the system and is equal to the available bandwidth


Baud rate

- ▶ upsampling does not change the *data* rate, only the sample rate
- ▶ we produce (and transmit) W symbols per second
- ▶ *W* is sometimes called the Baud rate of the system and is equal to the available bandwidth













Transmitter design, continued




$$H_{\mathcal{K},eta}(e^{j\omega}) = egin{cases} 1 & |\omega| \leq rac{\pi(1-eta)}{\mathcal{K}} \ rac{1}{2}\left(1+\cos\left(rac{\mathcal{K}|\omega|-(1-eta)\pi}{eta}
ight)
ight) & rac{\pi(1-eta)}{\mathcal{K}} \leq |\omega| \leq rac{\pi(1+eta)}{\mathcal{K}} \ 0 & |\omega| > rac{\pi(1+eta)}{\mathcal{K}} \end{cases}$$











$$h_{K,eta}[nK] = egin{cases} 1 & n=0 \ 0 & ext{otherwise} \end{cases}$$

$$h_{K,\beta}[nK] \propto \frac{1}{(\beta n)^2}$$

Raised Cosine: $1/n^2$ decay



Spectral shaping with raised cosine





Overview:

- Noise and probability of error
- ► Signaling alphabet and power
- QAM signaling

Overview:

- Noise and probability of error
- ► Signaling alphabet and power
- QAM signaling

Overview:

- Noise and probability of error
- ► Signaling alphabet and power
- QAM signaling

- ightharpoonup transmitter sends a sequence of symbols a[n]
- ightharpoonup receiver obtaines a sequence $\hat{a}[n]$
- even if no distortion we can't avoid noise: $\hat{a}[n] = a[n] + \eta[n]$
- when noise is large, we make an error

- ightharpoonup transmitter sends a sequence of symbols a[n]
- ightharpoonup receiver obtaines a sequence $\hat{a}[n]$
- even if no distortion we can't avoid noise: $\hat{a}[n] = a[n] + \eta[n]$
- when noise is large, we make an error

- ightharpoonup transmitter sends a sequence of symbols a[n]
- receiver obtaines a sequence $\hat{a}[n]$
- even if no distortion we can't avoid noise: $\hat{a}[n] = a[n] + \eta[n]$
- when noise is large, we make an error

- ightharpoonup transmitter sends a sequence of symbols a[n]
- receiver obtaines a sequence $\hat{a}[n]$
- even if no distortion we can't avoid noise: $\hat{a}[n] = a[n] + \eta[n]$
- when noise is large, we make an error

Probability of error

depends on:

- power of the noise wrt power of the signal
- decoding strategy
- ► *alphabet* of transmission symbols

Probability of error

depends on:

- power of the noise wrt power of the signal
- decoding strategy
- ► *alphabet* of transmission symbols

Probability of error

depends on:

- power of the noise wrt power of the signal
- decoding strategy
- ► *alphabet* of transmission symbols

Signaling alphabets

- we have a (randomized) bitstream coming in
- we want to send some upsampled and interpolated samples over the channel
- how do we go from bitstream to samples?

Signaling alphabets

- ▶ we have a (randomized) bitstream coming in
- ▶ we want to send some upsampled and interpolated samples over the channel
- ▶ how do we go from bitstream to samples?

Signaling alphabets

- we have a (randomized) bitstream coming in
- we want to send some upsampled and interpolated samples over the channel
- ▶ how do we go from bitstream to samples?

Mappers and slicers

mapper:

- split incoming bitstream into chunks
- ightharpoonup assign a symbol a[n] from a finite alphabet $\mathcal A$ to each chunk


slicer:


- receive a value $\hat{a}[n]$
- ▶ decide which symbol from A is "closest" to $\hat{a}[n]$
- piece back together the corresponding bitstream


mapper:

- ▶ split incoming bitstream into single bits
- ▶ a[n] = G if the bit is 1, a[n] = -G if the bit is 0

slicer:







let's look at the probability of error after making some hypotheses:

- $\hat{\mathbf{a}}[\mathbf{n}] = \mathbf{a}[\mathbf{n}] + \eta[\mathbf{n}]$
- bits in bitstream are equiprobable
- ▶ noise and signal are independent
- lacktriangle noise is additive white Gaussian noise with zero mean and variance σ_0

$$\begin{split} P_{\mathsf{err}} &= P[\; \eta[n] < -G \; | \; \textit{n-}\mathsf{th \; bit \; is } 1 \;] P[\; \textit{n-}\mathsf{th \; bit \; is } 1 \;] + \\ & P[\; \eta[n] > G \; | \; \textit{n-}\mathsf{th \; bit \; is } 0 \;] \; P[\; \textit{n-}\mathsf{th \; bit \; is } 0 \;] \\ &= (P[\; \eta[n] < -G \;] + P[\; \eta[n] > G \;])/2 \\ &= P[\; \eta[n] > G \;] \\ &= \int_G^\infty \frac{1}{\sqrt{2\pi\sigma_0^2}} e^{-\frac{\tau^2}{2\sigma_0^2}} d\tau \\ &= Q(G/\sigma_0) = \frac{1}{2} \mathrm{erfc}((G/\sigma_0)/\sqrt{2}) \end{split}$$

53

$$\begin{split} P_{\mathsf{err}} &= P[\; \eta[n] < -G \; | \; \textit{n-th bit is 1} \;] P[\; \textit{n-th bit is 1} \;] + \\ &P[\; \eta[n] > G \; | \; \textit{n-th bit is 0} \;] P[\; \textit{n-th bit is 0} \;] \\ &= (P[\; \eta[n] < -G \;] + P[\; \eta[n] > G \;])/2 \\ &= P[\; \eta[n] > G \;] \\ &= \int_G^\infty \frac{1}{\sqrt{2\pi\sigma_0^2}} e^{-\frac{\tau^2}{2\sigma_0^2}} d\tau \\ &= Q(G/\sigma_0) = \frac{1}{2} \mathrm{erfc}((G/\sigma_0)/\sqrt{2}) \end{split}$$

$$P_{\text{err}} = P[\ \eta[n] < -G \ | \ n\text{-th bit is 1}\]P[\ n\text{-th bit is 1}\]+$$

$$P[\ \eta[n] > G \ | \ n\text{-th bit is 0}\]P[\ n\text{-th bit is 0}\]$$

$$= (P[\ \eta[n] < -G\] + P[\ \eta[n] > G\])/2$$

$$= P[\ \eta[n] > G\]$$

$$= \int_G^\infty \frac{1}{\sqrt{2\pi\sigma_0^2}} e^{-\frac{\tau^2}{2\sigma_0^2}} d\tau$$

$$= Q(G/\sigma_0) = \frac{1}{2} \text{erfc}((G/\sigma_0)/\sqrt{2})$$

$$\begin{split} P_{\mathsf{err}} &= P[\; \eta[n] < -G \; | \; \textit{n-th bit is 1} \;] P[\; \textit{n-th bit is 1} \;] + \\ &P[\; \eta[n] > G \; | \; \textit{n-th bit is 0} \;] P[\; \textit{n-th bit is 0} \;] \\ &= (P[\; \eta[n] < -G \;] + P[\; \eta[n] > G \;])/2 \\ &= P[\; \eta[n] > G \;] \\ &= \int_G^\infty \frac{1}{\sqrt{2\pi\sigma_0^2}} e^{-\frac{\tau^2}{2\sigma_0^2}} d\tau \\ &= Q(G/\sigma_0) = \frac{1}{2} \mathrm{erfc}((G/\sigma_0)/\sqrt{2}) \end{split}$$

53

$$\begin{split} P_{\mathsf{err}} &= P[\; \eta[n] < -G \; \mid \; \textit{n-}\mathsf{th} \; \mathsf{bit} \; \mathsf{is} \; 1 \;] P[\; \textit{n-}\mathsf{th} \; \mathsf{bit} \; \mathsf{is} \; 1 \;] + \\ & P[\; \eta[n] > G \; \mid \; \textit{n-}\mathsf{th} \; \mathsf{bit} \; \mathsf{is} \; 0 \;] \; P[\; \textit{n-}\mathsf{th} \; \mathsf{bit} \; \mathsf{is} \; 0 \;] \\ &= (P[\; \eta[n] < -G \;] + P[\; \eta[n] > G \;])/2 \\ &= P[\; \eta[n] > G \;] \\ &= \int_G^\infty \frac{1}{\sqrt{2\pi\sigma_0^2}} e^{-\frac{\tau^2}{2\sigma_0^2}} d\tau \\ &= Q(G/\sigma_0) = \frac{1}{2} \mathsf{erfc}((G/\sigma_0)/\sqrt{2}) \end{split}$$

transmitted power

$$\sigma_s^2 = G^2 P[n\text{-th bit is 1}] + G^2 P[n\text{-th bit is 0}]$$

= G^2

$$P_{\text{err}} = Q(\sigma_s/\sigma_0) = Q(\sqrt{\text{SNR}})$$

transmitted power

$$\sigma_s^2 = G^2 P[n\text{-th bit is 1}] + G^2 P[n\text{-th bit is 0}]$$

= G^2

$$P_{\text{err}} = Q(\sigma_s/\sigma_0) = Q(\sqrt{\text{SNR}})$$


transmitted power

$$\sigma_s^2 = G^2 P[n\text{-th bit is 1}] + G^2 P[n\text{-th bit is 0}]$$

= G^2

$$P_{\mathsf{err}} = Q(\sigma_s/\sigma_0) = Q(\sqrt{\mathsf{SNR}})$$

Probability of error



- ▶ to reduce the probability of error increase SNR
- can't control noise so we must increase G
- ▶ increasing *G* increases the power
- we can't go above the channel's power constraint!

- ▶ to reduce the probability of error increase SNR
- can't control noise so we must increase G
- ▶ increasing *G* increases the power
- we can't go above the channel's power constraint!

- ▶ to reduce the probability of error increase SNR
- can't control noise so we must increase G
- ▶ increasing *G* increases the power
- we can't go above the channel's power constraint!

- ▶ to reduce the probability of error increase SNR
- can't control noise so we must increase G
- ▶ increasing *G* increases the power
- we can't go above the channel's power constraint!

Multilevel signaling

- binary signaling is not very efficient (one bit at a time)
- ▶ to increase the throughput we can use multilevel signaling
- many ways to do so, we will just scratch the surface

Multilevel signaling

- binary signaling is not very efficient (one bit at a time)
- ▶ to increase the throughput we can use multilevel signaling
- many ways to do so, we will just scratch the surface

Multilevel signaling

- binary signaling is not very efficient (one bit at a time)
- ▶ to increase the throughput we can use multilevel signaling
- ▶ many ways to do so, we will just scratch the surface

PAM

mapper:


- ▶ split incoming bitstream into chunks of *M* bits
- ▶ chunks define a sequence of integers $k[n] \in \{0, 1, ..., 2^M 1\}$
- ▶ $a[n] = G((-2^M + 1) + 2k[n])$ (odd integers around zero)

slicer:

$$a'[n] = \arg\min_{a \in \mathcal{A}} [|\hat{a}[n] - a|]$$


58

PAM, M = 2, G = 1




- ightharpoonup distance between points is 2G
- using odd integers creates a zero-mean sequence

PAM, M = 2, G = 1



- ightharpoonup distance between points is 2G
- using odd integers creates a zero-mean sequence

PAM, M = 2, G = 1



- ightharpoonup distance between points is 2G
- using odd integers creates a zero-mean sequence

From PAM to QAM

- error analysis for PAM along the lines of binary signaling
- ▶ can we increase the throughput even further?
- ▶ here's a wild idea, let's use complex numbers

From PAM to QAM

- error analysis for PAM along the lines of binary signaling
- ▶ can we increase the throughput even further?
- here's a wild idea, let's use complex numbers

From PAM to QAM

- error analysis for PAM along the lines of binary signaling
- ▶ can we increase the throughput even further?
- ▶ here's a wild idea, let's use complex numbers

QAM

mapper:


- ▶ split incoming bitstream into chunks of *M* bits, *M* even
- ▶ use M/2 bits to define a PAM sequence $a_r[n]$
- use the remaining M/2 bits to define an independent PAM sequence $a_i[n]$

slicer:


$$a'[n] = \arg\min_{a \in \mathcal{A}} [|\hat{a}[n] - a|]$$

61


QAM, M = 2, G = 1





QAM, M = 4, G = 1





QAM, M = 8, G = 1


















$$\hat{a}[n] = a[n] + \eta[n]$$
 $P_{\mathsf{err}} = 1 - P[|\operatorname{\mathsf{Re}}(\eta[n])| < G \ \land \ |\operatorname{\mathsf{Im}}(\eta[n])| < G]$
 $= 1 - \int_D f_\eta(z) \, dz$

QAM, probability of error, circular approximation



$$P_{ ext{err}}pprox 1-\int_{|z|< G}f_{\eta}(z)\,dz \qquad \qquad f_{\eta}(z)=rac{1}{\pi\sigma_0^2}e^{-rac{|z|^2}{\sigma_0^2}}$$
 $z
ightarrow
ho e^{j heta} = 1-\int_0^{2\pi}d heta\int_0^Grac{
ho}{\pi\sigma_0^2}e^{-rac{
ho^2}{\sigma_0^2}}d
ho = e^{-rac{G^2}{\sigma_0^2}}$

$$P_{\text{err}} \approx 1 - \int_{|z| < G} f_{\eta}(z) dz \qquad f_{\eta}(z) = \frac{1}{\pi \sigma_0^2} e^{-\frac{|z|^2}{\sigma_0^2}}$$

$$z \to \rho e^{j\theta}$$

$$= 1 - \int_0^{2\pi} d\theta \int_0^G \frac{\rho}{\pi \sigma_0^2} e^{-\frac{\rho^2}{\sigma_0^2}} d\rho$$

$$= e^{-\frac{G^2}{\sigma_0^2}}$$

$$P_{ ext{err}}pprox 1-\int_{|z|< G} f_{\eta}(z)\,dz \qquad \qquad f_{\eta}(z)=rac{1}{\pi\sigma_0^2}\mathrm{e}^{-rac{|z|^2}{\sigma_0^2}}$$
 $z
ightarrow
ho e^{j heta} = 1-\int_0^{2\pi}d heta\int_0^G rac{
ho}{\pi\sigma_0^2}\mathrm{e}^{-rac{
ho^2}{\sigma_0^2}}d
ho = \mathrm{e}^{-rac{G^2}{\sigma_0^2}}$

$$P_{ ext{err}}pprox 1-\int_{|z|< G}f_{\eta}(z)\,dz \qquad \qquad f_{\eta}(z)=rac{1}{\pi\sigma_0^2}\mathrm{e}^{-rac{|z|^2}{\sigma_0^2}}$$
 $z
ightarrow
ho e^{j heta} = 1-\int_0^{2\pi}d heta\int_0^Grac{
ho}{\pi\sigma_0^2}\mathrm{e}^{-rac{
ho^2}{\sigma_0^2}}d
ho = \mathrm{e}^{-rac{G^2}{\sigma_0^2}}$

transmitted power (all symbols equiprobable and independent):

$$\sigma_s^2 = G^2 \frac{1}{2^M} \sum_{a \in \mathcal{A}} |a|^2$$
$$= G^2 \frac{2}{3} (2^M - 1)$$

$$P_{
m err}pprox e^{-rac{G^2}{\sigma_0^2}}pprox e^{-3\,{
m SNR}/2^{(M+1)}}$$

transmitted power (all symbols equiprobable and independent):

$$\sigma_s^2 = G^2 \frac{1}{2^M} \sum_{a \in \mathcal{A}} |a|^2$$

$$= G^2 \frac{2}{3} (2^M - 1)$$


$$P_{
m err}pprox {
m e}^{-rac{G^2}{\sigma_0^2}}pprox {
m e}^{-3\,{
m SNR}/2^{(M+1)}}$$

transmitted power (all symbols equiprobable and independent):


$$\sigma_s^2 = G^2 \frac{1}{2^M} \sum_{a \in \mathcal{A}} |a|^2$$
$$= G^2 \frac{2}{3} (2^M - 1)$$

$$P_{
m err} pprox {
m e}^{-rac{G^2}{\sigma_0^2}} pprox {
m e}^{-3\,{
m SNR}/2^{(M+1)}}$$


Probability of error



Probability of error



Probability of error



- \triangleright pick a probability of error you can live with (e.g. 10^{-6})
- ▶ find out the SNR imposed by the channel's power constraint

$$M = \log_2 \left(1 - \frac{3}{2} \frac{\mathsf{SNR}}{\mathsf{ln}(p_{\mathsf{e}})} \right)$$

▶ final throughput will be *MW*

- \triangleright pick a probability of error you can live with (e.g. 10^{-6})
- ▶ find out the SNR imposed by the channel's power constraint

$$M = \log_2 \left(1 - \frac{3}{2} \frac{\mathsf{SNR}}{\mathsf{ln}(p_e)} \right)$$

▶ final throughput will be *MW*

- \triangleright pick a probability of error you can live with (e.g. 10^{-6})
- ▶ find out the SNR imposed by the channel's power constraint

$$M = \log_2 \left(1 - \frac{3}{2} \frac{\mathsf{SNR}}{\mathsf{ln}(p_\mathsf{e})} \right)$$

▶ final throughput will be *MW*

- \triangleright pick a probability of error you can live with (e.g. 10^{-6})
- ▶ find out the SNR imposed by the channel's power constraint

$$M = \log_2 \left(1 - \frac{3}{2} \frac{\mathsf{SNR}}{\mathsf{ln}(p_\mathsf{e})} \right)$$

► final throughput will be *MW*

where we stand:

- we know how to fit the bandwidth constraint
- with QAM, we know how many bits per symbol we can use given the power constraint
- we know the theoretical throughput of the transmitter

but how do we transmit complex symbols over a real channel?

where we stand:

- we know how to fit the bandwidth constraint
- with QAM, we know how many bits per symbol we can use given the power constraint
- we know the theoretical throughput of the transmitter

but how do we transmit complex symbols over a real channel

where we stand:

- we know how to fit the bandwidth constraint
- with QAM, we know how many bits per symbol we can use given the power constraint
- ▶ we know the theoretical throughput of the transmitter

but how do we transmit complex symbols over a real channel


where we stand:

- we know how to fit the bandwidth constraint
- with QAM, we know how many bits per symbol we can use given the power constraint
- we know the theoretical throughput of the transmitter

but how do we transmit complex symbols over a real channel?




QAM transmitter design




 $b[n] = b_r[n] + jb_i[n]$ is a complex-valued baseband signal...

Fulfilling the bandwidth constraint



QAM transmitter, final design



The transmitted passband signal

$$c[n] = b[n] e^{j\omega_c n}$$

$$s[n] = \text{Re}\{c[n]\}$$

$$= \text{Re}\{(b_r[n] + jb_i[n])(\cos \omega_c n + j\sin \omega_c n)\}$$

$$= b_r[n] \cos \omega_c n - b_i[n] \sin \omega_c n$$

The transmitted passband signal

$$c[n] = b[n] e^{j\omega_c n}$$

$$s[n] = \text{Re}\{c[n]\}$$

$$= \text{Re}\{(b_r[n] + jb_i[n])(\cos \omega_c n + j\sin \omega_c n)\}$$

$$= b_r[n] \cos \omega_c n - b_i[n] \sin \omega_c n$$

The transmitted passband signal


$$c[n] = b[n] e^{j\omega_c n}$$

$$s[n] = \text{Re}\{c[n]\}$$


$$= \text{Re}\{(b_r[n] + jb_i[n])(\cos \omega_c n + j\sin \omega_c n)\}$$

$$= b_r[n] \cos \omega_c n - b_i[n] \sin \omega_c n$$


From complex baseband to real passband signal



From complex baseband to real passband signal




From complex baseband to real passband signal




Can we go back?

receiver obtains s[n] can we recover the complex baseband b[n] from s[n]?

easiest way: Hilbert demodulation






$$H(e^{j\omega}) = egin{cases} -j & \omega \geq 0 \ j & \omega < 0 \end{cases}$$


$$H_{\mathcal{A}}(e^{j\omega})=1+jH(e^{j\omega})=egin{cases} 2 & \omega\geq 0 \ 0 & \omega<0 \end{cases}$$

80


Hilbert demodulation (recap)





$$y[n] = x[n]\cos(\omega_c n)$$



$$jy[n]*h[n]+y[n]$$








The transmitted passband signal


$$c[n] = b[n] e^{j\omega_c n}$$


$$= (b_r[n] + jb_i[n])e^{j\omega_c n}$$

$$s[n] = \text{Re}\{c[n]\}$$


$$= b_r[n] \cos \omega_c n - b_i[n] \sin \omega_c n$$








QAM transmitter, final design



QAM receiver, idealized design



- ▶ analog telephone channel: $F_{min} = 450Hz$, $F_{max} = 2850Hz$
- usable bandwidth: $W = 2400 \, \mathrm{Hz}$, center frequency $F_c = 1650 \, \mathrm{Hz}$
- ▶ pick $F_s = 3 \cdot 2400 = 7200$ Hz, so that K = 3
- $\omega_c = 0.458\pi$

- ▶ analog telephone channel: $F_{min} = 450$ Hz, $F_{max} = 2850$ Hz
- lacktriangle usable bandwidth: $W=2400 {
 m Hz}$, center frequency $F_c=1650 {
 m Hz}$
- ▶ pick $F_s = 3 \cdot 2400 = 7200$ Hz, so that K = 3
- $\omega_c = 0.458\pi$

- ▶ analog telephone channel: $F_{min} = 450$ Hz, $F_{max} = 2850$ Hz
- lacktriangle usable bandwidth: $W=2400{
 m Hz}$, center frequency $F_c=1650{
 m Hz}$
- ▶ pick $F_s = 3 \cdot 2400 = 7200$ Hz, so that K = 3
- $\omega_c = 0.458\pi$

- ▶ analog telephone channel: $F_{min} = 450$ Hz, $F_{max} = 2850$ Hz
- lacktriangle usable bandwidth: $W=2400{
 m Hz}$, center frequency $F_c=1650{
 m Hz}$
- ▶ pick $F_s = 3 \cdot 2400 = 7200$ Hz, so that K = 3
- $\sim \omega_c = 0.458\pi$

- maximum SNR: 22dB
- ▶ pick $P_{\text{err}} = 10^{-6}$
- ▶ using QAM, we find

$$M = \log_2\left(1 - \frac{3}{2} \frac{10^{22/10}}{\ln(10^{-6})}\right) \approx 4.1865$$

so we pick M=4 and use a 16-point constellation

ightharpoonup final data rate is WM = 9600 bits per second

- ▶ maximum SNR: 22dB
- ▶ pick $P_{\text{err}} = 10^{-6}$
- using QAM, we find

$$M = \log_2\left(1 - \frac{3}{2} \frac{10^{22/10}}{\ln(10^{-6})}\right) \approx 4.186$$

so we pick M=4 and use a 16-point constellation

ightharpoonup final data rate is WM = 9600 bits per second

- maximum SNR: 22dB
- ▶ pick $P_{\text{err}} = 10^{-6}$
- ▶ using QAM, we find

$$M = \log_2\left(1 - \frac{3}{2} \frac{10^{22/10}}{\ln(10^{-6})}\right) \approx 4.1865$$

so we pick M = 4 and use a 16-point constellation

ightharpoonup final data rate is WM = 9600 bits per second

- maximum SNR: 22dB
- ▶ pick $P_{\text{err}} = 10^{-6}$
- ▶ using QAM, we find

$$M = \log_2\left(1 - \frac{3}{2} \frac{10^{22/10}}{\ln(10^{-6})}\right) \approx 4.1865$$

so we pick M = 4 and use a 16-point constellation

• final data rate is WM = 9600 bits per second

- we used very specific design choices to derive the throughput
- what is the best one can do?
- ► Shannon's capacity formula is the upper bound

$$C = W \log_2 (1 + SNR)$$

- ▶ for instance, for the previous example $C \approx 17500$ bps
- ▶ the gap can be narrowed by more advanced coding techniques

- we used very specific design choices to derive the throughput
- ▶ what is the best one can do?
- ► Shannon's capacity formula is the upper bound

$$C = W \log_2 (1 + SNR)$$

- for instance, for the previous example $C \approx 17500$ bps
- ▶ the gap can be narrowed by more advanced coding techniques

- we used very specific design choices to derive the throughput
- ▶ what is the best one can do?
- ► Shannon's capacity formula is the upper bound

$$C = W \log_2 (1 + SNR)$$

- lacktriangle for instance, for the previous example C pprox 17500 bps
- ▶ the gap can be narrowed by more advanced coding techniques

- we used very specific design choices to derive the throughput
- ▶ what is the best one can do?
- ► Shannon's capacity formula is the upper bound

$$C = W \log_2 (1 + SNR)$$

- for instance, for the previous example $C \approx 17500$ bps
- ▶ the gap can be narrowed by more advanced coding techniques

- we used very specific design choices to derive the throughput
- ▶ what is the best one can do?
- ► Shannon's capacity formula is the upper bound

$$C = W \log_2 (1 + SNR)$$

- for instance, for the previous example $C \approx 17500$ bps
- ▶ the gap can be narrowed by more advanced coding techniques