

Hiking Monitor — ESP32 DevKitC-32 Pin Assignments

Board: ESP32 DevKitC-32, 38-pin, CP2102, USB-C **Orientation:** USB-C connector at top. Left pin 1 and right pin 38 are at the top.

Assignment	Left pin	Left	Right	Right pin	Assignment
3.3V rail	1	3V3	GND	38	GND rail
	2	EN	GPIO23	37	DIN (e-ink)
	3	GPIO36 <i>(input only)</i>	GPIO22	36	SCL (BME280, LTR-390)
	4	GPIO39 <i>(input only)</i>	GPIO1 (TXD)	35	
	5	GPIO34 <i>(input only)</i>	GPIO3 (RXD)	34	
ADC (batt voltage)	6	GPIO35 <i>(input only)</i>	GPIO21	33	SDA (BME280, LTR-390)
Button	7	GPIO32	GND	32	GND rail
	8	GPIO33	GPIO19	31	
	9	GPIO25	GPIO18	30	CLK (e-ink)
	10	GPIO26	GPIO5	29	CS (e-ink)
	11	GPIO27	GPIO17	28	DC (e-ink)
	12	GPIO14	GPIO16	27	RST (e-ink)

Assignment	Left pin	Left	Right	Right pin	Assignment
	13	GPIO12	GPIO4	26	BUSY (e-ink)
	14	GND	GPIO0 ⚠	25	
	15	GPIO13	GPIO2 ⚠	24	
	16	GPIO9 ⚡	GPIO15 ⚠	23	
	17	GPIO10 ⚡	GPIO8 ⚡	22	
	18	GPIO11 ⚡	GPIO7 ⚡	21	
5V (TP4056 out)	19	VIN (5V)	GPIO6 ⚡	20	

⚡ = connected to flash memory — do not use ⚠ = strapping pin — avoid driving at boot