

### SERVICE HINTS -

#### **BODY ECU**

13–GROUND : Continuity with horn SW on

## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C19	34	H5	32 (3RZ-FE, 2RZ-FE)	H10	32 (3RZ-FE, 2RZ-FE)
H5	30 (5VZ-FE)	H10	30 (5VZ-FE)		

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1E	23	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)	
1H	23	Cowl Wire and J/B No.1 (Lower Finish Panel)	

## **MEMO**