

# EB tresos<sup>®</sup> AutoCore Generic 8 COM Services documentation

product release 8.8.3





Elektrobit Automotive GmbH Am Wolfsmantel 46 91058 Erlangen, Germany Phone: +49 9131 7701 0

Fax: +49 9131 7701 6333

Email: info.automotive@elektrobit.com

#### **Technical support**

https://www.elektrobit.com/support

#### Legal disclaimer

Confidential information.

ALL RIGHTS RESERVED. No part of this publication may be copied in any form, by photocopy, microfilm, retrieval system, or by any other means now known or hereafter invented without the prior written permission of Elektrobit Automotive GmbH.

All brand names, trademarks, and registered trademarks are property of their rightful owners and are used only for description.

Copyright 2021, Elektrobit Automotive GmbH.



## **Table of Contents**

| 1. | Overvi | ew of EB tresc  | os AutoCore Generic 8 COM Services documentation | 17 |
|----|--------|-----------------|--|----|
| 2. | Suppo  | rted features . |  | 18 |
|    | 2.1.   | Supported Co    | om features                                      | 18 |
|    | 2.2.   | Supported Ipo   | duM features                                     | 18 |
|    | 2.3.   | Supported Ld    | dCom features                                    | 18 |
|    | 2.4.   | Supported Po    | duR features                                     | 18 |
| 3. | ACG8   | COM Services    | s release notes                                  | 19 |
|    | 3.1.   | Overview        |  | 19 |
|    | 3.2.   | Scope of the    | release  | 19 |
|    |        | 3.2.1. Config   | guration tool                                    | 19 |
|    |        | 3.2.2. AUTO     | SAR modules                                      | 19 |
|    |        | 3.2.3. EB (El   | lektrobit) modules                               | 20 |
|    |        | 3.2.4. MCAL     | modules and EB tresos AutoCore OS                | 20 |
|    | 3.3.   | Module releas   | se notes   | 20 |
|    |        | 3.3.1. Com r    | module release notes                             | 20 |
|    |        | 3.3.1.1.        | . Change log                                     | 21 |
|    |        | 3.3.1.2.        | . New features                                   | 33 |
|    |        | 3.3.1.3.        | . EB-specific enhancements                       | 34 |
|    |        | 3.3.1.4.        | . Deviations                                     | 36 |
|    |        | 3.3.1.5.        | . Limitations                                    | 48 |
|    |        | 3.3.1.6.        | Open-source software                             | 52 |
|    |        | 3.3.2. lpduM    | 1 module release notes                           | 52 |
|    |        | 3.3.2.1.        | . Change log                                     | 53 |
|    |        | 3.3.2.2.        | . New features                                   | 64 |
|    |        | 3.3.2.3.        | . EB-specific enhancements                       | 65 |
|    |        | 3.3.2.4.        | . Deviations                                     | 67 |
|    |        | 3.3.2.5.        | . Limitations                                    | 72 |
|    |        | 3.3.2.6.        | Open-source software                             | 73 |
|    |        | 3.3.3. LdCon    | m module release notes                           | 73 |
|    |        |                 | . Change log                                     |    |
|    |        | 3.3.3.2.        | . New features                                   | 77 |
|    |        | 3.3.3.3.        | . EB-specific enhancements                       | 78 |
|    |        | 3.3.3.4.        | . Deviations                                     | 78 |
|    |        | 3.3.3.5.        | . Limitations                                    | 80 |
|    |        | 3.3.3.6.        | Open-source software                             | 80 |
|    |        | 3.3.4. Mirror   | module release notes                             | 80 |
|    |        | 3.3.4.1.        | . Change log                                     | 80 |
|    |        | 3.3.4.2.        | . New features                                   | 83 |
|    |        | 3.3.4.3.        | . EB-specific enhancements                       | 83 |



| 3.3.4.4. Deviations  | 83       |
|--|----------|
| 3.3.4.5. Limitations   | 83       |
| 3.3.4.6. Open-source software  | 84       |
| 3.3.5. PduR module release notes   | 84       |
| 3.3.5.1. Change log  | 84       |
| 3.3.5.2. New features  | 94       |
| 3.3.5.3. EB-specific enhancements  | 95       |
| 3.3.5.4. Deviations  | 97       |
| 3.3.5.5. Limitations   | 105      |
| 3.3.5.6. Open-source software  | 106      |
| 4. ACG8 COM Services user guide  | 107      |
| 4.1. Overview  |          |
| 4.2. Background information  | 107      |
| 4.2.1. Network-independent and network-dependent communication in AUTOSAR    | 107      |
| 4.2.1.1. Modules and dependencies of the network-independent communication s | tack 107 |
| 4.2.1.2. Data transmission in the network-independent communication stack    |          |
| 4.2.1.2.1. Signals and signal groups   | 109      |
| 4.2.1.2.2. Transmission modes and transfer properties                        |          |
| 4.2.1.2.3. I-PDU groups  | 110      |
| 4.3. LdCom module user guide   |          |
| 4.3.1. Overview  |          |
| 4.3.2. Background Information  | 111      |
| 4.3.2.1. Functional overview   |          |
| 4.3.3. Configuring the LdCom module  |          |
| 5. ACG8 COM Services module references                                       | 113      |
| 5.1. Overview  |          |
| 5.1.1. Notation in EB module references                                      |          |
| 5.1.1.1. Default value of configuration parameters                           |          |
| 5.1.1.2. Range information of configuration parameters                       |          |
| 5.2. Com   |          |
| 5.2.1. Configuration parameters  |          |
| 5.2.1.1. ComDefensiveProgramming   |          |
| 5.2.1.2. ComConfig   |          |
| 5.2.1.3. ComGwMapping  |          |
| 5.2.1.4. ComGwDestination  |          |
| 5.2.1.5. ComGwDestinationDescription   |          |
| 5.2.1.6. ComFilter   |          |
| 5.2.1.7. ComGwSignal   |          |
| 5.2.1.8. ComGwSource   |          |
| 5.2.1.9. ComGwSignal   |          |
| 5.2.1.10. ComGwSourceDescription   |          |
| 5.2.1.11. ComlPdu  | 129      |



| 5.2.1.12. ComiPduCounter                       | 133 |
|--|-----|
| 5.2.1.13. ComlPduReplication                   | 135 |
| 5.2.1.14. ComTxlPdu                            | 135 |
| 5.2.1.15. ComTxModeFalse                       | 137 |
| 5.2.1.16. ComTxMode                            | 137 |
| 5.2.1.17. ComTxModeTrue                        | 140 |
| 5.2.1.18. ComTxMode                            | 140 |
| 5.2.1.19. ComlPduGroup                         | 142 |
| 5.2.1.20. ComSignal                            | 143 |
| 5.2.1.21. ComFilter                            | 151 |
| 5.2.1.22. ComSignalGroup                       | 154 |
| 5.2.1.23. ComGroupSignal                       | 159 |
| 5.2.1.24. ComFilter                            | 164 |
| 5.2.1.25. ComTimeBase                          | 166 |
| 5.2.1.26. ComTxMainFunctions                   | 168 |
| 5.2.1.27. Com_MainFunctionTx                   | 168 |
| 5.2.1.28. ComRxMainFunctions                   | 169 |
| 5.2.1.29. Com_MainFunctionRx                   | 169 |
| 5.2.1.30. ComIPduCalloutsTx                    | 170 |
| 5.2.1.31. ComIPduCalloutsRx                    | 170 |
| 5.2.1.32. ComGeneral                           | 171 |
| 5.2.1.33. VendorSpecific                       | 173 |
| 5.2.1.34. ComGeneratedRxSignal                 | 212 |
| 5.2.1.35. CommonPublishedInformation           | 214 |
| 5.2.1.36. PublishedInformation                 | 217 |
| 5.2.2. Recommended configurations              | 217 |
| 5.2.2.1. ComRecConfigurationMax                | 217 |
| 5.2.2.1.1. ComGeneral                          | 218 |
| 5.2.2.1.2. VendorSpecific                      | 218 |
| 5.2.2.2. ComRecConfigurationMedium             | 219 |
| 5.2.2.2.1. ComGeneral                          | 220 |
| 5.2.2.2. VendorSpecific                        | 220 |
| 5.2.2.3. ComRecConfigurationSmall              | 221 |
| 5.2.2.3.1. ComGeneral                          | 222 |
| 5.2.2.3.2. VendorSpecific                      |     |
| 5.2.2.4. ComRecConfigurationStandard           | 223 |
| 5.2.2.4.1. ComGeneral                          | 224 |
| 5.2.2.4.2. VendorSpecific                      |     |
| 5.2.3. Application programming interface (API) |     |
| 5.2.3.1. Type definitions                      |     |
| 5.2.3.1.1. Com_lpduGroupIdType                 |     |
| 5.2.3.1.2. Com_lpduGroupVector                 |     |
| — · · · · · · · · · · · · · · · · · · ·        |     |



| 5.2.3.1.3. Com_PduGroupIdType                     | 226   |
|---|-------|
| 5.2.3.1.4. Com_RxCalloutType                      | 226   |
| 5.2.3.1.5. Com_ServiceIdType                      | 226   |
| 5.2.3.1.6. Com_SignalGroupIdType                  | 226   |
| 5.2.3.1.7. Com_SignalIdType                       | 227   |
| 5.2.3.1.8. Com_StatusType                         | . 227 |
| 5.2.3.1.9. Com_TxCalloutType                      | 227   |
| 5.2.3.2. Macro constants                          | 227   |
| 5.2.3.2.1. COMServiceId_ClearlpduGroupVector      | 227   |
| 5.2.3.2.2. COMServiceId_CopyRxData                | 227   |
| 5.2.3.2.3. COMServiceId_CopyTxData                | 228   |
| 5.2.3.2.4. COMServiceId_DeInit                    | 228   |
| 5.2.3.2.5. COMServiceId_GetConfigurationId        | 228   |
| 5.2.3.2.6. COMServiceId_GetRxIPduBuffer           | 228   |
| 5.2.3.2.7. COMServiceId_GetStatus                 | 228   |
| 5.2.3.2.8. COMServiceId_GetVersionInfo            | 229   |
| 5.2.3.2.9. COMServiceId_Init                      | 229   |
| 5.2.3.2.10. COMServiceId_InternalAPI              | . 229 |
| 5.2.3.2.11. COMServiceId_InvalidateShadowSignal   | 229   |
| 5.2.3.2.12. COMServiceId_InvalidateSignal         | . 229 |
| 5.2.3.2.13. COMServiceId_InvalidateSignalGroup    | 230   |
| 5.2.3.2.14. COMServiceId_IpduGroupControl         | . 230 |
| 5.2.3.2.15. COMServiceId_MainFunctionRouteSignals | 230   |
| 5.2.3.2.16. COMServiceId_MainFunctionRx           | 230   |
| 5.2.3.2.17. COMServiceId_MainFunctionTx           | 230   |
| 5.2.3.2.18. COMServiceId_ReceiveDynSignal         | 231   |
| 5.2.3.2.19. COMServiceId_ReceiveShadowSignal      | 231   |
| 5.2.3.2.20. COMServiceId_ReceiveSignal            | 231   |
| 5.2.3.2.21. COMServiceId_ReceiveSignalGroup       | . 231 |
| 5.2.3.2.22. COMServiceId_ReceiveSignalGroupArray  | 231   |
| 5.2.3.2.23. COMServiceId_ReceptionDMControl       | 232   |
| 5.2.3.2.24. COMServiceId_RxIndication             | 232   |
| 5.2.3.2.25. COMServiceId_SendDynSignal            | 232   |
| 5.2.3.2.26. COMServiceId_SendSignal               | 232   |
| 5.2.3.2.27. COMServiceId_SendSignalGroup          |       |
| 5.2.3.2.28. COMServiceId_SendSignalGroupArray     | 233   |
| 5.2.3.2.29. COMServiceId_SetIpduGroup             | 233   |
| 5.2.3.2.30. COMServiceId_StartOfReception         | . 233 |
| 5.2.3.2.31. COMServiceId_SwitchIpduTxMode         | 233   |
| 5.2.3.2.32. COMServiceId_TpRxIndication           | 233   |
| 5.2.3.2.33. COMServiceId_TpTxConfirmation         | . 234 |
| 5.2.3.2.34. COMServiceId_TriggerIPDUSend          | 234   |



| 5.2.3.2.35. COMServiceId_TriggerTransmit    | 234 |
|---|-----|
| 5.2.3.2.36. COMServiceId_TxConfirmation     | 234 |
| 5.2.3.2.37. COMServiceId_UpdateShadowSignal | 234 |
| 5.2.3.2.38. COM_E_PARAM                     | 235 |
| 5.2.3.2.39. COM_E_PARAM_POINTER             | 235 |
| 5.2.3.2.40. COM_E_SIGNAL_TOO_WIDE           | 235 |
| 5.2.3.2.41. COM_E_UNINIT                    | 235 |
| 5.2.3.2.42. COM_INSTANCE_ID                 | 235 |
| 5.2.3.3. Functions                          | 236 |
| 5.2.3.3.1. Com_ClearlpduGroupVector         | 236 |
| 5.2.3.3.2. Com_CopyRxData                   | 236 |
| 5.2.3.3.3. Com_CopyTxData                   | 237 |
| 5.2.3.3.4. Com_Delnit                       | 238 |
| 5.2.3.3.5. Com_GetConfigurationId           | 238 |
| 5.2.3.3.6. Com_GetRxIPduBuffer              | 238 |
| 5.2.3.3.7. Com_GetStatus                    | 239 |
| 5.2.3.3.8. Com_GetVersionInfo               | 239 |
| 5.2.3.3.9. Com_Init                         | 239 |
| 5.2.3.3.10. Com_lpduGroupControl            | 240 |
| 5.2.3.3.11. Com_lsValidConfig               | 240 |
| 5.2.3.3.12. Com_MainFunctionRouteSignals    | 241 |
| 5.2.3.3.13. Com_MainFunctionRx              | 241 |
| 5.2.3.3.14. Com_MainFunctionTx              | 242 |
| 5.2.3.3.15. Com_ReceiveDynSignal            | 242 |
| 5.2.3.3.16. Com_ReceiveShadowSignal         | 243 |
| 5.2.3.3.17. Com_ReceiveSignal               | 243 |
| 5.2.3.3.18. Com_ReceiveSignalGeneric        | 244 |
| 5.2.3.3.19. Com_ReceiveSignalGroup          | 245 |
| 5.2.3.3.20. Com_ReceiveSignalGroupArray     | 245 |
| 5.2.3.3.21. Com_ReceptionDMControl          | 246 |
| 5.2.3.3.22. Com_RxIndication                | 246 |
| 5.2.3.3.23. Com_SendDynSignal               | 247 |
| 5.2.3.3.24. Com_SendSignal                  | 247 |
| 5.2.3.3.25. Com_SendSignalGroup             | 248 |
| 5.2.3.3.26. Com_SendSignalGroupArray        | 249 |
| 5.2.3.3.27. Com_SetIpduGroup                | 249 |
| 5.2.3.3.28. Com_StartOfReception            | 250 |
| 5.2.3.3.29. Com_SwitchIpduTxMode            | 250 |
| 5.2.3.3.30. Com_TpRxIndication              | 251 |
| 5.2.3.3.31. Com_TpTxConfirmation            | 251 |
| 5.2.3.3.32. Com_TriggerIPDUSend             | 252 |
| 5.2.3.3.33. Com_TriggerTransmit             | 252 |



| 5.2.3.3.34. Com_TxConfirmation            | 253 |
|---|-----|
| 5.2.3.3.35. Com_UpdateShadowSignal        | 253 |
| 5.2.4. Integration notes                  | 254 |
| 5.2.4.1. Exclusive areas                  | 254 |
| 5.2.4.1.1. COM_EXCLUSIVE_AREA_0           | 254 |
| 5.2.4.1.2. COM_EXCLUSIVE_AREA_1           | 254 |
| 5.2.4.2. Production errors                | 255 |
| 5.2.4.3. Memory mapping                   | 255 |
| 5.2.4.4. Integration requirements         | 256 |
| 5.2.4.4.1. Com.EB.IntReq.Preemption01     | 256 |
| 5.2.4.4.2. Com.EB.IntReq.Preemption02     | 256 |
| 5.2.4.4.3. Com.EB.IntReq.Preemption02.TP  | 258 |
| 5.2.4.4.4. Com.EB.IntReq.Preemption03     | 259 |
| 5.2.4.4.5. Com.EB.IntReq.MainRxSchedule04 | 260 |
| 5.2.4.4.6. Com.EB.IntReq.UpdateBit05      | 260 |
| 5.2.4.4.7. Com.EB.IntReq.Preemption06     | 261 |
| 5.2.4.4.8. Com.EB.IntReq.Preemption07     | 261 |
| 5.3. IpduM                                | 262 |
| 5.3.1. Configuration parameters           | 262 |
| 5.3.1.1. CommonPublishedInformation       | 263 |
| 5.3.1.2. IpduMDefensiveProgramming        | 266 |
| 5.3.1.3. IpduMConfig                      | 269 |
| 5.3.1.4. IpduMContainedRxPdu              | 270 |
| 5.3.1.5. IpduMContainedTxPdu              | 271 |
| 5.3.1.6. IpduMContainerRxPdu              | 274 |
| 5.3.1.7. IpduMContainerTxPdu              | 276 |
| 5.3.1.8. IpduMRxPathway                   | 279 |
| 5.3.1.9. IpduMRxIndication                | 280 |
| 5.3.1.10. lpduMRxDynamicPart              | 281 |
| 5.3.1.11. IpduMSegment                    | 282 |
| 5.3.1.12. lpduMRxStaticPart               | 283 |
| 5.3.1.13. IpduMSegment                    | 284 |
| 5.3.1.14. IpduMSelectorFieldPosition      | 285 |
| 5.3.1.15. IpduMTxPathway                  | 286 |
| 5.3.1.16. IpduMTxRequest                  | 286 |
| 5.3.1.17. IpduMSelectorFieldPosition      | 289 |
| 5.3.1.18. lpduMTxDynamicPart              | 290 |
| 5.3.1.19. lpduMSegment                    | 292 |
| 5.3.1.20. lpduMTxStaticPart               | 293 |
| 5.3.1.21. IpduMSegment                    | 295 |
| 5.3.1.22. IpduMGeneral                    | 296 |
| 5.3.1.23. IpduMRxProcessing               | 307 |



| 5.3.1.24. IpduMTxProcessing                    | 308   |
|--|-------|
| 5.3.1.25. IpduMPublishedInformation            | . 309 |
| 5.3.1.26. IpduMRequestMessageConfiguration     | 310   |
| 5.3.1.27. IpduMRequestMessageMapInfo           | . 311 |
| 5.3.1.28. PublishedInformation                 | . 312 |
| 5.3.2. Application programming interface (API) | 312   |
| 5.3.2.1. Macro constants                       | 312   |
| 5.3.2.1.1. IPDUM_E_GLOBAL_ECUID                | 312   |
| 5.3.2.1.2. IPDUM_SID_PROCESS_REQUEST_PDU       | 313   |
| 5.3.2.2. Functions                             | 313   |
| 5.3.2.2.1. lpduM_GetVersionInfo                | 313   |
| 5.3.2.2.2. lpduM_Init                          | 313   |
| 5.3.2.2.3. IpduM_MainFunctionRx                | . 314 |
| 5.3.2.2.4. lpduM_MainFunctionTx                | 314   |
| 5.3.2.2.5. IpduM_ProcessRequestPdu             | . 314 |
| 5.3.2.2.6. lpduM_RxIndication                  | . 315 |
| 5.3.2.2.7. lpduM_Transmit                      | 315   |
| 5.3.2.2.8. IpduM_TriggerTransmit               | . 316 |
| 5.3.2.2.9. IpduM_TxConfirmation                | 317   |
| 5.3.3. Integration notes                       | 317   |
| 5.3.3.1. Exclusive areas                       | 317   |
| 5.3.3.1.1. SCHM_IPDUM_EXCLUSIVE_AREA_0         | . 317 |
| 5.3.3.2. Production errors                     | . 317 |
| 5.3.3.3 Memory mapping                         | . 318 |
| 5.3.3.4. Integration requirements              | 318   |
| 5.3.3.4.1. lim.lpduM.EB_INTREQ_IpduM_0001      | . 318 |
| 5.3.3.4.2. lim.lpduM.EB_INTREQ_IpduM_0002      | . 318 |
| 5.3.3.4.3. lim.lpduM.EB_INTREQ_IpduM_0003      | . 319 |
| 5.4. LdCom                                     | 319   |
| 5.4.1. Configuration parameters                | . 319 |
| 5.4.1.1. CommonPublishedInformation            | 320   |
| 5.4.1.2. LdComConfig                           | 323   |
| 5.4.1.3. LdComlPdu                             | 323   |
| 5.4.1.4. LdComGeneral                          | 327   |
| 5.4.1.5. PublishedInformation                  | 328   |
| 5.4.1.6. VendorSpecific                        | 328   |
| 5.4.2. Application programming interface (API) | 329   |
| 5.4.2.1. Type definitions                      | 330   |
| 5.4.2.1.1. LdCom_ApilfRxType                   | . 330 |
| 5.4.2.1.2. LdCom_ApilfTxType                   | . 330 |
| 5.4.2.1.3. LdCom_ApiTpRxType                   | . 330 |
| 5.4.2.1.4. LdCom_ApiTpTxType                   | . 330 |
|  |       |



| 5.4.2.1.5. LdC      | om_RteCbkCopyRxDataFpType        | 331  |
|---------------------|----------------------------------|------|
| 5.4.2.1.6. LdCo     | om_RteCbkCopyTxDataFpType        | 331  |
| 5.4.2.1.7. LdCo     | om_RteCbkRxIndicationFpType      | 331  |
| 5.4.2.1.8. LdCo     | om_RteCbkStartOfReceptionFpType  | 331  |
| 5.4.2.1.9. LdCo     | om_RteCbkTpRxIndicationFpType    | 331  |
| 5.4.2.1.10. Ld0     | Com_RteCbkTpTxConfirmationFpType | 332  |
| 5.4.2.1.11. LdC     | Com_RteCbkTriggerTransmitFpType  | 332  |
| 5.4.2.1.12. Ld0     | Com_RteCbkTxConfirmationFpType   | 332  |
| 5.4.2.2. Macro cons | stants                           | 332  |
| 5.4.2.2.1. LDC      | OM_E_INIT_FAILED                 | 332  |
| 5.4.2.2.2. LDC      | OM_E_INVALID_PDU_SDU_ID          | 332  |
| 5.4.2.2.3. LDC      | OM_E_INVALID_SIGNAL_ID           | 332  |
| 5.4.2.2.4. LDC      | OM_E_PARAM_POINTER               | 333  |
| 5.4.2.2.5. LDC      | OM_E_UNINIT                      | 333  |
| 5.4.2.2.6. LDC      | OM_INSTANCE_ID                   | 333  |
| 5.4.2.2.7. LDC      | OM_ONLINE                        | 333  |
| 5.4.2.2.8. LDC      | COM_SID_COPYRXDATA               | 333  |
| 5.4.2.2.9. LDC      | OM_SID_COPYTXDATA                | 333  |
| 5.4.2.2.10. LD      | COM_SID_DEINIT                   | 334  |
| 5.4.2.2.11. LD0     | COM_SID_GETVERSIONINFO           | 334  |
| 5.4.2.2.12. LD      | COM_SID_IFTRANSMIT               | 334  |
| 5.4.2.2.13. LD      | COM_SID_INIT                     | 334  |
| 5.4.2.2.14. LD      | COM_SID_RXINDICATION             | 334  |
| 5.4.2.2.15. LD      | COM_SID_STARTOFRECEPTION         | 334  |
| 5.4.2.2.16. LD      | COM_SID_TPRXINDICATION           | 335  |
| 5.4.2.2.17. LD      | COM_SID_TPTRANSMIT               | 335  |
| 5.4.2.2.18. LD      | COM_SID_TPTXCONFIRMATION         | 335  |
| 5.4.2.2.19. LD      | COM_SID_TRIGGERTRANSMIT          | 335  |
|                     | COM_SID_TXCONFIRMATION           |      |
|                     | COM_UNINIT                       |      |
| 5.4.2.2.22. Ld0     | Com_Transmit                     | 336  |
| 5.4.2.3. Functions  |                                  | 336  |
| 5.4.2.3.1. LdC      | om_CopyRxData                    | 336  |
| 5.4.2.3.2. LdC      | om_CopyTxData                    | 337  |
| 5.4.2.3.3. LdC      | om_Delnit                        | 338  |
| 5.4.2.3.4. LdC      | om_GetVersionInfo                | 339  |
| 5.4.2.3.5. LdC      | om_lfTransmit                    | 339  |
| 5.4.2.3.6. LdC      | om_Init                          | 340  |
| 5.4.2.3.7. LdC      | om_lsValidConfig                 | 340  |
| 5.4.2.3.8. LdC      | om_RxIndication                  | 341  |
| 5.4.2.3.9. LdC      | om_StartOfReception              | 341  |
| 5 4 2 3 10 1 40     | Com TnPvIndication               | 3/12 |



| 5.4.2.3.11. LdCom_TpTransmit                   | 342 |
|--|-----|
| 5.4.2.3.12. LdCom_TpTxConfirmation             | 343 |
| 5.4.2.3.13. LdCom_TriggerTransmit              | 343 |
| 5.4.2.3.14. LdCom_TxConfirmation               | 344 |
| 5.4.3. Integration notes                       | 344 |
| 5.4.3.1. Exclusive areas                       | 344 |
| 5.4.3.2. Production errors                     | 345 |
| 5.4.3.3. Memory mapping                        | 345 |
| 5.4.3.4. Integration requirements              | 345 |
| 5.5. Mirror                                    | 345 |
| 5.5.1. Configuration parameters                | 345 |
| 5.5.1.1. CommonPublishedInformation            | 346 |
| 5.5.1.2. MirrorDefensiveProgramming            | 349 |
| 5.5.1.3. MirrorConfigSet                       | 352 |
| 5.5.1.4. MirrorDestNetwork                     | 353 |
| 5.5.1.5. MirrorDestNetworkIp                   | 353 |
| 5.5.1.6. MirrorDestPdu                         | 356 |
| 5.5.1.7. MirrorDestNetworkFlexRay              | 357 |
| 5.5.1.8. MirrorDestPdu                         | 358 |
| 5.5.1.9. MirrorDestNetworkCan                  | 359 |
| 5.5.1.10. MirrorDestPdu                        | 361 |
| 5.5.1.11. MirrorDestNetworkCdd                 | 362 |
| 5.5.1.12. MirrorDestPdu                        | 364 |
| 5.5.1.13. MirrorSourceNetwork                  | 365 |
| 5.5.1.14. MirrorSourceNetworkCan               | 365 |
| 5.5.1.15. MirrorSourceCanFilter                | 367 |
| 5.5.1.16. MirrorSourceCanFilterMask            | 367 |
| 5.5.1.17. MirrorSourceCanFilterRange           | 368 |
| 5.5.1.18. MirrorSourceCanMaskBasedIdMapping    | 370 |
| 5.5.1.19. MirrorSourceCanSingleIdMapping       | 371 |
| 5.5.1.20. MirrorSourceNetworkLin               | 372 |
| 5.5.1.21. MirrorSourceLinFilter                | 374 |
| 5.5.1.22. MirrorSourceLinFilterMask            | 374 |
| 5.5.1.23. MirrorSourceLinFilterRange           | 375 |
| 5.5.1.24. MirrorSourceLinToCanIdMapping        | 376 |
| 5.5.1.25. MirrorSourceNetworkFlexRay           | 377 |
| 5.5.1.26. MirrorSourceFlexRayFilter            | 379 |
| 5.5.1.27. MirrorGeneral                        | 381 |
| 5.5.1.28. PublishedInformation                 | 390 |
| 5.5.2. Application programming interface (API) | 391 |
| 5.5.2.1. Macro constants                       | 391 |
| 55211 MIRROR DET REPORT ERROR                  | 391 |



| į      | 5.5.2.1.2. MIRROR_E_INIT_FAILED                   | 391 |
|--------|---|-----|
| į      | 5.5.2.1.3. MIRROR_E_INTERMEDIATE_BUFFER_OVERRUN   | 391 |
| į.     | 5.5.2.1.4. MIRROR_E_INVALID_CALL                  | 391 |
| į      | 5.5.2.1.5. MIRROR_E_INVALID_CHANNEL               | 391 |
| į      | 5.5.2.1.6. MIRROR_E_INVALID_CLUSTER_ID            | 392 |
| į      | 5.5.2.1.7. MIRROR_E_INVALID_CONTROLLER_ID         | 392 |
| į      | 5.5.2.1.8. MIRROR_E_INVALID_NETWORK_ID            | 392 |
| į      | 5.5.2.1.9. MIRROR_E_INVALID_PARAM                 | 392 |
| į      | 5.5.2.1.10. MIRROR_E_INVALID_PDU_SDU_ID           | 392 |
| į.     | 5.5.2.1.11. MIRROR_E_INVALID_STATUS               | 392 |
|        | 5.5.2.1.12. MIRROR_E_NESTED_REPORT_FRAMES         | 392 |
| į.     | 5.5.2.1.13. MIRROR_E_PARAM_POINTER                | 393 |
| į      | 5.5.2.1.14. MIRROR_E_QUEUE_OVERRUN                | 393 |
| į.     | 5.5.2.1.15. MIRROR_E_REINIT                       | 393 |
| į      | 5.5.2.1.16. MIRROR_E_TRANSMIT_FAILED              | 393 |
| į      | 5.5.2.1.17. MIRROR_E_UNINIT                       | 393 |
| į      | 5.5.2.1.18. MIRROR_INSTANCE_ID                    | 393 |
| į      | 5.5.2.1.19. MIRROR_SID_DEINIT                     | 394 |
| į.     | 5.5.2.1.20. MIRROR_SID_GETDESTINATIONNETWORK      | 394 |
| į.     | 5.5.2.1.21. MIRROR_SID_GETNETWORKHANDLE           | 394 |
| į.     | 5.5.2.1.22. MIRROR_SID_GETNETWORKID               | 394 |
|        | 5.5.2.1.23. MIRROR_SID_GETNETWORKTYPE             | 394 |
|        | 5.5.2.1.24. MIRROR_SID_GETVERSIONINFO             | 394 |
|        | 5.5.2.1.25. MIRROR_SID_INIT                       | 395 |
|        | 5.5.2.1.26. MIRROR_SID_ISMIRRORACTIVE             | 395 |
| į.     | 5.5.2.1.27. MIRROR_SID_ISSOURCENETWORKSTARTED     | 395 |
|        | 5.5.2.1.28. MIRROR_SID_MAINFUNCTION               | 395 |
|        | 5.5.2.1.29. MIRROR_SID_OFFLINE                    | 395 |
|        | 5.5.2.1.30. MIRROR_SID_PDURIFRXINDICATION         | 395 |
| į.     | 5.5.2.1.31. MIRROR_SID_REPORTCANFRAME             | 396 |
| į.     | 5.5.2.1.32. MIRROR_SID_REPORTFLEXRAYCHANNELSTATUS | 396 |
| į.     | 5.5.2.1.33. MIRROR_SID_REPORTFLEXRAYFRAME         | 396 |
|        | 5.5.2.1.34. MIRROR_SID_REPORTLINFRAME             | 396 |
| į.     | 5.5.2.1.35. MIRROR_SID_STARTALLSOURCENETWORKS     | 396 |
| į.     | 5.5.2.1.36. MIRROR_SID_STARTSOURCENETWORK         | 396 |
| į.     | 5.5.2.1.37. MIRROR_SID_STOPALLSOURCENETWORKS      | 396 |
| į.     | 5.5.2.1.38. MIRROR_SID_STOPSOURCENETWORK          | 397 |
| į.     | 5.5.2.1.39. MIRROR_SID_TXCONFIRMATION             | 397 |
| 5.5.2. | 2. Functions                                      | 397 |
| į      | 5.5.2.2.1. Mirror_DeInit                          | 397 |
| į      | 5.5.2.2.2. Mirror_GetDestNetwork                  | 397 |
|        | 5.5.2.2.3. Mirror, GotNotworkHandlo               | 308 |



| 5.5.2.2.4. Mirror GetNetworkId                | 398 |
|---|-----|
| 5.5.2.2.5. Mirror_GetNetworkType              |     |
| 5.5.2.2.6. Mirror_GetVersionInfo              |     |
| 5.5.2.2.7. Mirror_Init                        |     |
| 5.5.2.2.8. Mirror IsMirrorActive              | 400 |
| 5.5.2.2.9. Mirror_IsSourceNetworkStarted      | 400 |
| 5.5.2.2.10. Mirror_MainFunction               | 401 |
| 5.5.2.2.11. Mirror_Offline                    | 401 |
| 5.5.2.2.12. Mirror_PduRlfRxIndication         |     |
| 5.5.2.2.13. Mirror_ReportCanFrame             | 402 |
| 5.5.2.2.14. Mirror_ReportFlexRayChannelStatus | 402 |
| 5.5.2.2.15. Mirror_ReportFlexRayFrame         | 403 |
| 5.5.2.2.16. Mirror_ReportLinFrame             | 403 |
| 5.5.2.2.17. Mirror_StartAllSourceNetworks     | 404 |
| 5.5.2.2.18. Mirror_StartSourceNetwork         | 404 |
| 5.5.2.2.19. Mirror_StopAllSourceNetworks      | 405 |
| 5.5.2.2.20. Mirror_StopSourceNetwork          | 405 |
| 5.5.2.2.21. Mirror_TxConfirmation             | 405 |
| 5.5.3. Integration notes                      | 406 |
| 5.5.3.1. Exclusive areas                      | 406 |
| 5.5.3.2. Production errors                    | 406 |
| 5.5.3.3. Memory mapping                       | 406 |
| 5.5.3.4. Integration requirements             | 407 |
| 5.6. PduR                                     | 407 |
| 5.6.1. Configuration parameters               | 407 |
| 5.6.1.1. CommonPublishedInformation           | 408 |
| 5.6.1.2. PublishedInformation                 | 411 |
| 5.6.1.3. PduRBswModules                       | 412 |
| 5.6.1.4. PduRGeneral                          | 420 |
| 5.6.1.5. PduRRoutingTables                    | 432 |
| 5.6.1.6. PduRRoutingPathGroup                 | 433 |
| 5.6.1.7. PduRRoutingTable                     | 434 |
| 5.6.1.8. PduRRoutingPath                      | 435 |
| 5.6.1.9. PduRDestPdu                          | 436 |
| 5.6.1.10. PduRDefaultValue                    |     |
| 5.6.1.11. PduRDefaultValueElement             | 438 |
| 5.6.1.12. PduRSrcPdu                          | 439 |
| 5.6.1.13. PduRTpBufferTable                   | 440 |
| 5.6.1.14. PduRTpBuffer                        |     |
| 5.6.1.15. PduRTxBufferTable                   | 441 |
| 5.6.1.16. PduRTxBuffer                        | 442 |
| 5.6.2. Recommended configurations             | 443 |



|     | 5.6.2.1. PduRRecConfigurationCanEcu        | 443 |
|-----|--|-----|
|     | 5.6.2.1.1. Com                             | 443 |
|     | 5.6.2.1.2. Dcm                             | 444 |
|     | 5.6.2.1.3. CanIf                           | 445 |
|     | 5.6.2.1.4. CanTp                           | 445 |
|     | 5.6.2.1.5. lpduM                           | 446 |
|     | 5.6.2.2. PduRRecConfigurationEthernetEcu   | 446 |
|     | 5.6.2.2.1. Com                             | 447 |
|     | 5.6.2.2.2 Dcm                              | 447 |
|     | 5.6.2.2.3. SoAd                            | 448 |
|     | 5.6.2.2.4. DoIP                            | 449 |
|     | 5.6.2.2.5. lpduM                           | 449 |
|     | 5.6.2.3. PduRRecConfigurationFrEcu         | 450 |
|     | 5.6.2.3.1. Com                             | 450 |
|     | 5.6.2.3.2. Dcm                             | 451 |
|     | 5.6.2.3.3. Frlf                            | 451 |
|     | 5.6.2.3.4. FrTp                            | 452 |
|     | 5.6.2.3.5. lpduM                           | 453 |
|     | 5.6.2.4. PduRRecConfigurationGatewayEcu    | 453 |
|     | 5.6.2.4.1. Com                             | 454 |
|     | 5.6.2.4.2. Dcm                             | 454 |
|     | 5.6.2.4.3. CanIf                           | 455 |
|     | 5.6.2.4.4. LinIf                           | 456 |
|     | 5.6.2.4.5. Frlf                            | 456 |
|     | 5.6.2.4.6. CanTp                           | 457 |
|     | 5.6.2.4.7. LinTp                           | 457 |
|     | 5.6.2.4.8. FrTp                            | 458 |
|     | 5.6.2.4.9. SoAd                            | 459 |
|     | 5.6.2.4.10. DoIP                           | 459 |
|     | 5.6.2.4.11. lpduM                          | 460 |
|     | 5.6.2.4.12. PduRGeneral                    | 460 |
|     | 5.6.2.5. PduRRecConfigurationLinEcu        | 461 |
|     | 5.6.2.5.1. Com                             | 461 |
|     | 5.6.2.5.2. Dcm                             | 462 |
|     | 5.6.2.5.3. LinIf                           | 462 |
|     | 5.6.2.5.4. LinTp                           | 463 |
|     | 5.6.2.5.5. lpduM                           | 464 |
| 5.6 | 3. Application programming interface (API) | 464 |
|     | 5.6.3.1. Macro constants                   | 464 |
|     | 5.6.3.1.1. PDUR_E_CONFIG_PTR_INVALID       | 464 |
|     | 5.6.3.1.2. PDUR_E_INVALID_REQUEST          | 464 |
|     | 5.6.3.1.3. PDUR_E_NULL_POINTER             | 465 |



| 5.6.3.1.4. PDUR_E_PDU_ID_INVALID                       | 465 |
|--|-----|
| 5.6.3.1.5. PDUR_E_PDU_INSTANCES_LOST                   | 465 |
| 5.6.3.1.6. PDUR_E_ROUTING_PATH_GROUP_ID_INVALID        | 465 |
| 5.6.3.1.7. PDUR_E_TP_TX_REQ_REJECTED                   | 465 |
| 5.6.3.1.8. PDUR_INSTANCE_ID                            | 465 |
| 5.6.3.1.9. PDUR_INVALID_CONFIGURATION_ID               | 466 |
| 5.6.3.1.10. PDUR_SID_DISABLE_ROUTING                   | 466 |
| 5.6.3.1.11. PDUR_SID_ENABLE_ROUTING                    | 466 |
| 5.6.3.1.12. PDUR_SID_GET_CONF_ID                       | 466 |
| 5.6.3.1.13. PDUR_SID_GET_VER_INF                       | 466 |
| 5.6.3.1.14. PDUR_SID_IFGW_RXIND_DF                     | 466 |
| 5.6.3.1.15. PDUR_SID_IFGW_RXIND_SB                     | 466 |
| 5.6.3.1.16. PDUR_SID_IFGW_RXIND_TF                     | 467 |
| 5.6.3.1.17. PDUR_SID_IFGW_TRIGTX_SB                    | 467 |
| 5.6.3.1.18. PDUR_SID_IFGW_TRIGTX_TF                    | 467 |
| 5.6.3.1.19. PDUR_SID_INIT                              | 467 |
| 5.6.3.1.20. PDUR_SID_LOTP_COPY_RX_DATA                 | 467 |
| 5.6.3.1.21. PDUR_SID_LOTP_COPY_TX_DATA                 | 467 |
| 5.6.3.1.22. PDUR_SID_LOTP_RXIND                        | 468 |
| 5.6.3.1.23. PDUR_SID_LOTP_STRT_OF_RCPTN                | 468 |
| 5.6.3.1.24. PDUR_SID_LOTP_TX_CONF                      | 468 |
| 5.6.3.1.25. PDUR_SID_LO_RXIND                          | 468 |
| 5.6.3.1.26. PDUR_SID_LO_TRIGTX                         | 468 |
| 5.6.3.1.27. PDUR_SID_LO_TXCONF                         | 468 |
| 5.6.3.1.28. PDUR_SID_UP_CANCELRXREQ                    | 468 |
| 5.6.3.1.29. PDUR_SID_UP_CANCELTXREQ                    |     |
| 5.6.3.1.30. PDUR_SID_UP_CHANGEPARAREQ                  | 469 |
| 5.6.3.1.31. PDUR_SID_UP_TX                             | 469 |
| 5.6.3.1.32. PduR_GetVersionInfo                        |     |
| 5.6.3.1.33. SchM_Enter_PduR_SCHM_PDUR_EXCLUSIVE_AREA_1 |     |
| 5.6.3.1.34. SchM_Enter_PduR_SCHM_PDUR_EXCLUSIVE_AREA_2 |     |
| 5.6.3.1.35. SchM_Exit_PduR_SCHM_PDUR_EXCLUSIVE_AREA_1  |     |
| 5.6.3.1.36. SchM_Exit_PduR_SCHM_PDUR_EXCLUSIVE_AREA_2  | 470 |
| 5.6.3.2. Objects                                       |     |
| 5.6.3.2.1. PduR_GConfigPtr                             |     |
| 5.6.3.2.2. PduR_State                                  |     |
| 5.6.3.3. Functions                                     |     |
| 5.6.3.3.1. PduR_GetConfigurationId                     |     |
| 5.6.3.3.2. PduR_Init                                   |     |
| 5.6.3.3.3. PduR_IsValidConfig                          |     |
| 5.6.3.3.4. PduR_LoRxIndication                         |     |
| 5.6.3.3.5 PduR_LoTpCopyRxData                          | 472 |



| 5.6.3.3.6. PduR_LoTpCopyTxData                                   | 473 |
|--|-----|
| 5.6.3.3.7. PduR_LoTpRxIndication                                 | 474 |
| 5.6.3.3.8. PduR_LoTpStartOfReception                             | 475 |
| 5.6.3.3.9. PduR_LoTpTxConfirmation                               | 476 |
| 5.6.3.3.10. PduR_LoTriggerTransmit                               | 476 |
| 5.6.3.3.11. PduR_LoTxConfirmation                                | 477 |
| 5.6.3.3.12. PduR_UpCancelReceive                                 | 477 |
| 5.6.3.3.13. PduR_UpCancelTransmit                                | 477 |
| 5.6.3.3.14. PduR_UpChangeParameter                               | 478 |
| 5.6.3.3.15. PduR_UpTransmit                                      | 478 |
| 5.6.4. Integration notes   | 479 |
| 5.6.4.1. Exclusive areas   | 479 |
| 5.6.4.1.1. SCHM_PDUR_EXCLUSIVE_AREA_0                            | 479 |
| 5.6.4.2. Production errors                                       | 479 |
| 5.6.4.3. Memory mapping  | 479 |
| 5.6.4.4. Integration requirements                                | 480 |
| 5.6.4.4.1. PduR.EB.IntReq.RestrictTpGwToSF                       | 480 |
| 5.6.4.4.2. PduR.EB.IntReq.BlockLoTpCopyTxDataForTpMulticast      | 481 |
| 5.6.4.4.3. PduR.EB.IntReq.BlockLoTpCopyTxDataForDirectTpGw       | 481 |
| 5.6.4.4.4. PduR.EB.IntReq.BlockLoTpTxConfirmationForDirectTpGw   | 481 |
| 5.6.4.4.5. PduR.EB.IntReq.BlockLoTpTxConfirmationForTpMulticast  | 481 |
| 5.6.4.4.6. PduR.EB.IntReq.RestrictNto1toSingleActivatedRPath     | 481 |
| 5.6.4.4.7. PduR.EB.IntReq.QualityMultiCore                       | 482 |
| 5.6.4.4.8. PduR.EB.IntReq.PartitionIndicesInClientServerEntities | 482 |
| 5.6.4.4.9. PduR.EB.IntReq.ProtectionMechanismMulticore           | 482 |
| 5.6.4.4.10. PduR.EB.IntReq.TriggerTransmitWithMultiCore          | 483 |
| 6 Bibliography   | 484 |



## Overview of EB tresos AutoCore Generic 8 COM Services documentation

Welcome to the EB tresos AutoCore Generic 8 COM Services (ACG8 COM Services) product documentation.

#### This document provides:

- Chapter 2, "Supported features": list of features supported by the ACG8 COM Services
- ► Chapter 3, "ACG8 COM Services release notes": release notes for the ACG8 COM Services modules
- ▶ <u>Chapter 4, "ACG8 COM Services user guide"</u>: background information and instructions
- ► <u>Chapter 5, "ACG8 COM Services module references"</u>: information about configuration parameters and the application programming interface



## 2. Supported features

## 2.1. Supported Com features

Support for post-build: Support for handling post-build loadable and selectable configuration.

## 2.2. Supported IpduM features

**Support for post-build:** Support for handling post-build loadable configuration.

## 2.3. Supported LdCom features

LdCom provides an alternative to the Com module. LdCom implements an interaction layer mechanism focusing on non-cyclic communication without serializing, filtering and conversion. The following main features according to the AUTOSAR specification are provided:

- Signal-oriented interface: Provision of a signal-oriented interface for use by the AUTOSAR Rte module for the reception and the transmission of data. Depending on the configuration of the LdCom module, this interface adheres to the interface (IF) style API (providing the data in a single API call) or to the transport protocol (TP) style API (providing the data in small chunks using multiple API calls). In contrast to the interface provided by the Com module, however, this interface is limited to the transmission of byte stream signals only.
- Transmission of large data of dynamic length: Support for efficient sending and receiving of potentially large data of dynamic length without buffering within the module itself.
- Support for post-build: Support for handling post-build loadable configuration.

## 2.4. Supported PduR features

Support for post-build: Support for handling post-build loadable and selectable configuration.



## 3. ACG8 COM Services release notes

## 3.1. Overview

This chapter provides the ACG8 COM Services product specific release notes. General release notes that are applicable to all products are provided in the EB tresos AutoCore Generic documentation. Refer to the general release notes in addition to the product release notes documented here.

## 3.2. Scope of the release

## 3.2.1. Configuration tool

Your release of EB tresos AutoCore is compatible with the release of the EB tresos Studio configuration tool:

EB tresos Studio: 28.1.0 b210701-0227

### 3.2.2. AUTOSAR modules

The following table lists the AUTOSAR modules that are part of this ACG8 COM Services release.

| Module name  | AUTOSAR version and revision | SWS version and revision | Module version | Supplier                        |
|--------------|------------------------------|--------------------------|----------------|---------------------------------|
| Com          | 4.0.3 []                     | 4.2.0 [0000]             | 6.3.50         | Elektrobit Automotive GmbH      |
| <u>IpduM</u> | 4.0.3 []                     | 2.2.0 [0000]             | 3.3.40         | Elektrobit Automo-<br>tive GmbH |
| LdCom        | 4.0.3 []                     | 4.2.1 [0000]             | 1.0.26         | Elektrobit Automo-<br>tive GmbH |
| Mirror       | 4.3.1 []                     | 4.3.1 [0000]             | 1.0.17         | Elektrobit Automotive GmbH      |



| Module name | AUTOSAR version and revision | SWS version and revision | Module version | Supplier                        |
|-------------|------------------------------|--------------------------|----------------|---------------------------------|
| PduR        | 4.0.3 []                     | 3.2.0 [0000]             | 5.3.46         | Elektrobit Automo-<br>tive GmbH |

Table 3.1. Hardware-Independent Modules specified by the AUTOSAR standard

## 3.2.3. EB (Elektrobit) modules

The following table lists all modules which are part of this release but are not specified by the AUTOSAR standard. These modules include tooling developed by EB or they may hold files shared by all other modules.

| Module name             | Module version | Supplier |
|-------------------------|----------------|----------|
| No EB modules available |                |          |

Table 3.2. Modules not specified by the AUTOSAR standard

## 3.2.4. MCAL modules and EB tresos AutoCore OS

For information about MCAL modules and OS, refer to the respective documentation, which is available as PDF at \$TRESOS\_BASE/doc/3.0\_EB\_tresos\_AutoCore\_OS and \$TRESOS\_BASE/doc/5.0\_MCAL\_-modules<sup>1</sup>. It is also available in the online help in EB tresos Studio. Browse to the folders EB tresos AutoCore OS and MCAL modules.

## 3.3. Module release notes

#### 3.3.1. Com module release notes

AUTOSAR R4.0 Rev 3

AUTOSAR SWS document version: 4.2.0

Module version: 6.3.50.B439717

<sup>&</sup>lt;sup>1</sup>\$TRESOS\_BASE is the location at which you installed EB tresos Studio.



Supplier: Elektrobit Automotive GmbH

#### 3.3.1.1. Change log

This chapter lists the changes between different versions.

#### Module version 6.3.50

2021-06-25

Internal module improvement. This module version update does not affect module functionality

#### Module version 6.3.49

2021-03-05

- ▶ ASCCOM-2763 Fixed known issue: Discontinued reception of large I-PDUs
- Updated preprocessor include guards to be PC-lint compatible
- ASCCOM-2758 Fixed known issue: Configuration error for group signals with different endianess

#### Module version 6.3.48

2020-10-23

Internal module improvement. This module version update does not affect module functionality

#### Module version 6.3.47

2020-09-25

- ASCCOM-2705 Fixed known issue: Compilation error occurs when exactly one PostBuild variant is configured
- ASCCOM-2712 Fixed known issue: UINT64/SINT64 ComSignals and ComGroupSignals are not routed correctly by signal gateway

#### Module version 6.3.46

2020-06-19

ASCCOM-2662 Fixed known issue: Possible compilation error with compile option "-C99"



- Improved description of configuration parameter ComDeferTx2MainFunc
- Implemented options for handling of I-PDUs with reduced length

2020-01-24

ASCCOM-2641 Fixed known issue: Compilation error occurs when PostBuild variants are configured

#### Module version 6.3.44

2019-10-11

- Implemented non-functional code improvements
- ASCCOM-2602 Fixed known issue: Null pointer gets dereferenced during initialization of ComGroupSignals
- Implemented improvements for the post build selectable support
- Improved extended basic support for uint64 and sint64 signal types
- ASCCOM-2564 Fixed known issue: Incorrect serialization and deserialization of UINT64 ComSignals

#### Module version 6.3.43

2019-07-05

Implemented non-functional code improvements

#### Module version 6.3.42

2019-06-14

- Implemented improvements for flexible allocation of PDUs to multiple Tx respectively Rx main functions
- ASCCOM-2558 Fixed known issue: Incorrect signal gateway behavior in case of multicore support
- ASCCOM-2529 Fixed known issue: Out-of-bounds write access for routed dynamic length signals due to corrupted dynamic signal length on big-endian platforms
- ASCCOM-2530 Fixed known issue: I-PDU transmission repetitions are triggered falsely in case of a dynamic length signal write access

#### Module version 6.3.41

2019-04-18



Implemented support for the post build selectable

#### Module version 6.3.40

2019-02-15

Improved memory mapping

#### Module version 6.3.39

2018-10-26

- Implemented support of opaque signals / group signals up to 65535 bytes
- Implemented optimization: Allow disabling of read and write functions

#### Module version 6.3.38

2018-09-28

Implemented extended basic support for uint64 and sint64 signal types

#### Module version 6.3.37

2018-06-22

- ▶ Improved handle ID wizard for Tx-I-PDUs which takes the priority of CAN messages into account
- ▶ Implemented defer Com transmission into Tx main function support
- Improved usage of critical sections for Com\_SendDynSignal
- Implemented version compatibility check for EcuC library

#### Module version 6.3.36

2018-05-25

- Implemented COM TP-API support
- Implemented COM API Com\_GetRxIPduBuffer which returns information about the receive IPdu buffer of a Rx IPdu

#### Module version 6.3.35

2018-05-07



ASCCOM-2420 Fixed known issue: Wrongly generated code after reopening the project in EB tresos Studio

#### Module version 6.3.34

2018-04-20

- Implemented non-functional code improvements to fix Misra violations
- Implemented improvements for flexible allocation of PDUs to multiple Tx respectively Rx main functions including signal gateway
- ► ASCCOM-2410 Fixed known issue: Wrong COM\_EXCLUSIVE\_AREA is used

#### Module version 6.3.33

2018-03-16

Implemented improvements for PduLengthType uint32 support

#### Module version 6.3.32

2018-02-16

- Implemented improvements for flexible allocation of PDUs to multiple Tx respectively Rx main functions
- ASCCOM-2359 Fixed known issue: Group signals are not routed by signal gateway
- ASCCOM-2360 Fixed known issue: Group signals are not routed by signal gateway
- ASCCOM-2375 Fixed known issue: Fragmented signal group is embedded wrongly into Tx-I-PDU
- Implemented improvements for routing of I-PDUs with different unused area values in between fragmented signal groups
- Implemented improvements for routing of group signals where the signal group has parameter ComSignalGroupArrayAccess set to true
- Implemented improvements for flexible allocation of PDUs to multiple Tx respectively Rx main functions including signal gateway

#### Module version 6.3.31

2017-12-15

ASCCOM-2299 Fixed known issue: Compilation error of Com MainFunctionRouteSignals.c



2017-09-22

- Implemented improvements for flexible allocation of PDUs to several Tx respectively Rx main functions including signal gateway
- Switch from MISRA-C:2004 to MISRA-C:2012
- Introduced basic support for float64, uint64 and sint64 signal types

#### Module version 6.3.29

2017-08-25

ASCCOM-2256 Fixed known issue: Wrong signal packing behaviour for 8-bit unaligned (group) signals with big endian

#### Module version 6.3.28

2017-07-28

- Implemented non-functional code improvements
- Implemented improvements for flexible allocation of PDUs to several Tx respectively Rx main functions (without singal gateway)

#### Module version 6.3.27

2017-06-30

- Implemented non-functional code improvements
- Added support for additional ComTransferProperties TRIGGERED\_ON\_CHANGE\_WITHOUT\_-REPETITION and TRIGGERED\_WITHOUT\_REPETITION
- Added support for flexible allocation of PDUs to several Tx respectively Rx main functions

#### Module version 6.3.26

2017-03-31

Implemented non-functional code improvements

Module version 6.3.25

2017-03-03



- Improved description of configuration parameter ComTxModeTimeOffset
- Implemented non-functional code improvements
- ASCCOM-2202 Fixed known issue: Wrong invocation of ComNotification callbacks on transmission side (for non-AUTOSAR use-case only)
- Improved usage of critical sections

2017-02-03

- Implemented non-functional code improvements
- Implemented non-functional code improvements for optimizations
- Implemented non-functional code improvements

#### Module version 6.3.23

2016-12-02

Implemented non-functional code improvements

#### Module version 6.3.22

2016-11-04

- ASCCOM-2157 Fixed known issue: Out of bounds access of unaligned Tx 16 bit signals / group signals
- Implemented non-functional code improvements
- Implemented non-functional code improvements to avoid compiler warnings

#### Module version 6.3.21

2016-09-23

Added support for routing of fragmented/interlaced signal groups

#### Module version 6.3.20

2016-09-09

Added support for fragmented/interlaced signal groups



Adapted resource file for the scheduling of main functions to the split of IpduM\_MainFunction() into IpduM MainFunctionRx() and IpduM MainFunctionTx().

#### Module version 6.3.19

2016-08-05

Implemented non-functional code improvements

#### Module version 6.3.18

2016-07-01

Implemented non-functional code improvements

#### Module version 6.3.17

2016-05-25

► ASCCOM-2104 Fixed known issue: Unintended restarting of reception deadline monitoring with Com\_lpduGroupControl()

#### Module version 6.3.16

2016-04-01

Implemented non-functional code improvements

#### Module version 6.3.15

2016-02-05

- ASCCOM-2084 Fixed known issue: Nested MemMap section if TS\_MERGED\_COMPILE is activated
- ► Added support for Debug & Trace with custom header file configurable via parameter BaseDbgHeader-File

#### Module version 6.3.14

2015-11-06



ASCCOM-2071 Fixed known issue: Missing includes is source files in case option TS\_MERGED\_COM-PILE is disabled

#### Module version 6.3.13

2015-10-09

- Implemented non-functional code improvements to avoid compiler warnings (Green Hills compiler for RH850 derivative) and static code analysis tools warnings
- ASCCOM-2054 Fixed known issue: Com receives incorrect values for Big-endian (group) signals if their msb is set to a multiple of eight
- Implemented non-functional code improvements to avoid compiler warnings

#### Module version 6.3.12

2015-06-19

- Implemented non-functional code improvements to avoid compiler warnings for specific optimization configurations
- ASCCOM-2021 Fixed known issue: Wrong signal handling on CPUs with big endianness architecture

#### Module version 6.3.11

2015-05-22

- ASCCOM-2015 Fixed known issue: Compilation error due to wrong usage of MemMap
- ASCCOM-2018 Fixed known issue: Wrong API name in integration requirement EB INTREQ Com 0001

#### Module version 6.3.10

2015-04-24

Added support for ACG7 Transformer (COM)

Note: With this feature, the handle ID policy for signals has changed. The conversion to the new handle ID policy can be simply applied by calling the *Calculate Handle IDs wizard* as described in EB tresos Studio user's guide.

#### Module version 6.3.9

2015-02-20



- Use AUTOSAR 4.x compliant memory section names for section CONFIG\_DATA\_UNSPECIFIED
- ASCCOM-1981 Fixed known issue: Invalid length calculation for dynamic length signals
- Implemented non-functional code improvements to fix Misra violations
- Implemented non-functional code improvements to ease readability

2015-01-07

- Added support for configurable mapping of PduR\_IsValidConfig function to dedicated memory section
- Implemented non-functional code improvements for optimizations
- Implemented non-functional code improvements to fix Misra violations
- Implemented non-functional code improvements and update integration requirement EB\_INTREQ\_Com\_-0002
- Implemented that reception filter MASKED\_NEW\_DIFFERS\_MASKED\_OLD always passes the filter criteria after a reception deadline monitoring timeout. For further details please refer to AUTOSAR Com SWS 4.1.1 SWS Com 00793 and Bugzilla #52102
- Added support for ComInitialValueOnly
- Implemented range limitations for filter parameters. For further details please refer to AUTOSAR Com SWS 4.1.1, Bugzilla #52038 and #67828
- ► Changed signature of Com\_RxlpduCallout and Com\_TxlpduCallout. For further details please refer to AUTOSAR Com SWS 4.1.1, Bugzilla RfC #52342
- Removed AUTOSAR 3.x compliant symbolic name value macros and updated the logic to only provide AUTOSAR 4.0.2 compliant macros if macro COM\_PROVIDE\_LEGACY\_SYMBOLIC\_NAMES is defined

#### Module version 6.3.7

2014-10-03

Added support for dynamic length signals

#### Module version 6.3.6

2014-08-07

- ► ASCCOM-1814 Fixed known issue: Build error due to missing file Com\_PBcfg.c if code generation for Com is disabled and only post-build configuration is compiled
- Improved optimization: Allow disabling of Transmission Mode Selection
- Added support for signal group array access.



- ASCCOM-1856 Fixed known issue: Transmission of a signal gateway destination I-PDU fails if I-PDU shall be transmitted because of a change of signal group values
- ASCCOM-1836 Fixed known issue: Initial TMS evaluation fails for filter parameter with values larger than 0x7FFFFFFF
- ASCCOM-1874 Fixed known issue: Wrong warning if a byte array is larger than 8 bytes
- ASCCOM-1875 Fixed known issue: Error is issued when config time support is enabled and ComIPduTriggerTransmitCallout is configured
- Added support I-PDUs larger than 254 Bytes

2014-04-25

- ASCCOM-1770 Fixed known issue: Build fails if source files shall be built separately
- ASCCOM-1781 Fixed known issue: Sign extension for Rx-signals may fail if generated Rx-signal API is used
- ASCCOM-1785 Fixed known issue: Com module configuration generator may generate incorrect compiler abstractions for type definitions of module internal data types
- Implemented non-functional code improvements to fix Misra violations
- ASCCOM-1790 Fixed known issue: Missing checks of configuration parameters for transmission modes
- ▶ Implemented non-functional code improvements to avoid compiler warning in Com\_MainFunction-RouteSignals.c
- ▶ ASCCOM-1803 Fixed known issue: Nested MemMap section if TS MERGED COMPILE is activated
- ► ASCCOM-1813 Fixed known issue: Choice container ComGwDestination is not set to changeable at post-build time

#### Module version 6.3.4

2013-10-11

- Implemented non-functional code improvements to use critical sections symmetrically
- Implemented non-functional code improvements to reduce function parameter in order to meet HIS metrics
- Implemented non-functional code improvements to fix Misra violations
- Replaced Rte memory sections and compile abstractions with Com memory sections and compile abstractions
- Improved allocation of post-build memory to ensure proper alignment
- Improved configuration checks of ComTransferProperty



- Implemented non-functional code improvements to defensive programming
- Implemented non-functional code improvements for optimizations
- Changed data type of Com\_StatusType from uint8 to an enumeration (used by API Com\_GetStatus())
- ▶ Updated behavior of Com\_SendSignalGroup() regarding the calculation of the transmission mode of the related I-PDU
- ▶ Updated checks for timing parameters that resulting number of ticks matches are exact to configured values (according to TPS\_ECUC\_08010 of Specification of ECU Configuration AUTOSAR 4.1.1)
- ▶ Updated calculation of mask for filter MASKED NEW DIFFERS MASKED OLD
- Improved MCG to generate XML code for Binary Code Generation
- Added consistency checks for Com configuration
- Implemented non-functional code improvements to clean up service IDs
- Changed VSMDs to adhere to additional VSMD rules specified for AUTOSAR 4.1.1 related to attribute post-build changeable

2013-06-28

- ► ASCCOM-1685 Fixed known issue: Com\_TriggerTransmit() incorrectly returns E\_OK when all I-PDU groups to which an I-PDU belongs are stopped
- Changed timing behavior of starting of periodic I-PDUs according to the clarification in Bugzilla #52352
- ▶ Implemented a default value 0 for ComTxModeTimeOffset according to the clarification in Bugzilla #52352
- ASCCOM-1666 Fixed known issue: Restriction on I-PDU Trigger Transmit Callout
- ► ASCCOM-1699 Fixed known issue: Com\_RxIndication() accesses invalid memory if called while uninitialized

#### Module version 6.3.2

2013-05-10

Implemented check of published information signature to prevent loading of incompatible post-build configuration

#### Module version 6.3.1

2013-02-08



Updated default value of filter of Tx-signals according to COM676 and COM677

#### Module version 6.3.0

2012-10-12

- Updated to AUTOSAR 4.0 Handle ID policy
- Added support of configuration parameter ComRetryFailedTransmitRequests
- ► Changed the top-level structure of the SWC description in the arxml files from /AUTOSAR/Com to / AUTOSAR\_Com
- Added support for extended handling of configuration parameter ComFirstTimeout
- ► Added support of configuration parameter ComEnableMDTForCyclicTransmission (disable MDT for cyclic transmission)
- Added new API Com SwitchIpduTxMode()
- ► Added separate I-PDU callout for Com TriggerTransmit()
- Added support of reception of shorter I-PDUs (see deviation Restricted support of small Rx-I-PDUs)

#### Module version 6.2.2

2012-08-17

Added definition of Exclusive Area Activation in Basic Software Module Description

#### Module version 6.2.1

2012-06-20

Added support of usage of PbcfgM module

#### Module version 6.2.0

2012-03-16

- Modified SchM Enter/Exit() calls to match AUTOSAR 4.0
- ► Added support for Tx-timeout handling for transmission mode NONE
- Updated naming scheme for #defines for symbolic name values to AUTOSAR 4.0 Rev 3 naming scheme
- Updated initial value for Rx-signals and signal groups when Rx Deadline Monitoring expired and I-PDU group is stopped
- Updated Com configuration to AUTOSAR 4.0 Rev 3



Improved error message in case invalid references are configured

#### Module version 6.1.1

2012-02-17

Internal module improvement. This module version update does not affect module functionality

#### Module version 6.1.0

2012-01-20

- ► Changed I-PDU group control API (removed AUTOSAR 3.x API, introduced AUTOSAR 4.x API)
- Updated Minimum Delay Time Monitoring behavior according to AUTOSAR 4.0
- ASCCOM-1435 Fixed known issue: Minimum Delay Time Monitoring is not canceled when Transmission Deadline Monitoring expires
- ► ASCCOM-1437 Fixed known issue: Possible omission of transmission of an I-PDU if ComTransferProperty = TRIGGERED ON CHANGE is used
- Added generation of BSWMD

#### Module version 6.0.1

2011-09-30

- ASCCOM-1318 Fixed known issue: Compilation fails when Com.h and PduR.h is included in the same file
- ► Changed optimization configuration from ComTxFilterMaskedNewDiffersMaskOldEnable to Com\_TxF\_MaskNewDiffersMaskOld\_En
- Added reception of Rx-PDUs which are longer than configured

#### Module version 6.0.0

2011-09-02

Initial AUTOSAR 4.0 version

#### 3.3.1.2. New features

No new features have been added since the last release.



#### 3.3.1.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

[HisCom0029] Compile-time signal endianness optimization (extension to AUTOSAR specification)

#### Description:

If (at compile time) the ComSignalEndianness (COM157) is identical for every ComSignal of the COM module, the Com module does the following:

- lt uses only the code required for this endianness.
- lt does not make runtime checks for the signal endianness.
- It does not store the endianness of every ComSignal individually.
- ▶ [HisCom0009] The Com ReceiveSignal API as defined in COM198 is implemented as access macro

#### Description:

If this optimization is used, macros and a function is generated which extract the value of a signal from the I-PDU.

#### Rationale:

If these macros or the generated <code>Com\_ReceiveSignal</code> API are used, the access to the value of the signal is faster.

Optional reception filter for Signal Gateway

#### Description:

According to AUTOSAR, an Rx-signal is always gated via the Com Signal Gateway if a gateway relation for that signal exists. The update-bit is not considered here. In this implementation the AUTOSAR-conform behavior is achieved when the vendor-specific parameter <code>ComSigGwRxFilterEnable</code> is set to false which is the default value. However, when <code>ComSigGwRxFilterEnable</code> is set to true, the signal is only gated via the Com Signal Gateway, when the filter of the Rx-signal evaluates to true.

#### Rationale:

Gated signals can be filtered.

Optional Tx-signals with size zero

#### Description:

A zero size signal is a signal which is not represented in an I-PDU. However, an application can send a value which is evaluated by a filter configured for that signal. This feature is enabled when the vendor-specific parameter <code>ComTxZeroSignalEnable</code> is set to true and the default value is false.



Rationale:

Trigger-sending of an I-PDU without changing a value within the I-PDU.

Support for signal group array access

Description:

The new APIs Com\_SendSignalGroupArray() and Com\_ReceiveSignalGroupArray() access the signal group value in the I-Pdu buffer.

Rationale:

Allows efficient access to signal groups, especially if the serialized data are also provide/required by another module, e.g. E2E module.

Support for I-PDUs larger than specified by AUTOSAR

Description:

In contrast to AUTOSAR which restricts the configuration of signals / group signals into I-PDUs to at most 254 Bytes / large I-PDUs to at most 4095 bytes, the COM module supports I-PDUs up to 8191 Bytes. Further, the COM module allows the configuration of opaque signals / group signals (ComSignalType equals OPAQUE) with a length up to 65535 Bytes.

With EcuC parameter PduLengthTypeEnum configured to UINT32, the module is basically allowed to handle PDUs with user data of more than 64 KiB. With the length restriction imposed by 8191 bytes for non opaque signals / group signals (ComSignalType does not equal OPAQUE) neither the UINT16 nor the UINT32 range can be exploited. With the length restriction imposed by 65535 bytes for opaque signals / group signals the UINT32 range can not be exploited.

Rationale:

Communication with Ethernet frames requires increased length of I-PDUs.

Support for ACG7 Transformer (COM)

Description:

The ACG7 Transformer (COM) uses the post-build configuration and the serialization / de-serialization functions of the Com module.

Rationale:

Ensures consistent configuration between the Com and ComXf and allows the efficient serialization / deserialization for signals and group signals due to the updated read / write library.

Options for handling of I-PDUs with reduced length



#### Description:

If the Com module receives a shorter I-PDU than the configured/expected only the fully received signals and signal groups are handled. Partly or not at all received signals / signal groups are not updated. Additionally to AUTOSAR, the EB COM module provides options which includes handling of partially received signals and signal groups.

These options are set via the EB COM module configuration parameter <code>ComHandleSmallerRxPdus</code>. This parameter defines the update behavior of values of signal / signal group when receiving smaller I-PDUs than expected.

For further details please check the EB COM module configuration parameter ComHandleSmallerRx-Pdus description.

Rationale:

Allows reception of shorter I-PDUs with unaligned signals.

#### 3.3.1.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

Only post-build configuration is supported

Description:

The Com module only supports configuration variant VARIANT-POST-BUILD. VARIANT-PRE-COMPILE and VARIANT-LINK-TIME are not supported.

Requirements:

COM606, COM607

Signal invalidation is not supported (but is supported via RTE) (reference to product description: ASCPD-15)

Description:

Signal invalidation is not supported. However, the EB tresos AutoCore RTE is extended in order to provide the signal invalidation functionality based on the configuration of the Com module.

Requirements:

COM099, COM286, COM680, COM681, COM736, COM683, COM737, COM717, COM718, COM334, COM024, COM203, COM642, COM643, COM288, COM644, COM557, COM645, COM536, COM315\_-Conf, COM391 Conf, COM314 Conf COM738, COM682, COM483, COM396, COM005, COM731



Signal-based gateway: Optimization issue rate conversion not supported

Description:

COM386: Optimization issue: An I-PDU can be configured to be handled en bloc if it contains signals to be routed completely via a transmit I-PDU through a retention of the signal order and the signals endianness (related use case: rate conversion).

The implementation lacks this optimization since AUTOSAR defines no configuration parameter to define to handle the I-PDU en bloc. Workaround: In case the I-PDU which should be gated is not used on the ECU, the whole I-PDU could be defined as a array. Note: If the size is greater than 8 bytes, the init value can not be defined with the AUTOSAR configuration parameters. If you use such a configuration, the PDU is directly copied to the Tx-PDU. Nevertheless, in case the signals shall be extracted by the Com module for an application, rate conversion can also be done. But in this case all signals are extracted from the Rx-PDU and packed into the Tx-PDU.

Requirements:

COM386

Signal-based gateway: The ComBitSize of a received ComSignal can differ from the routed ComSignal

Description:

In contrast to AUTOSAR which specifies that the <code>ComBitSize</code> of the received and the routed <code>ComSignal</code> shall not differ, the Com module allows a <code>ComBitSize</code> of the routed <code>ComSignal</code>. This <code>ComBitSize</code> is greater than the <code>ComBitSize</code> of the received <code>ComSignal</code> with the constraint that both must be of the same <code>DataType</code>.

Requirements:

COM384

SigGW: ComGwSourceDescription and ComGwDestinationDescription are not supported (reference to product description: ASCPD-17)

Description:

AUTOSAR SWS COM548\_Conf and COM549\_Conf define a <code>ComgwSourceDescription</code> and <code>ComgwDestinationDescription</code>. These descriptions allow adding/changing gateway relations post-build without the configuration of new signals <code>ComgwSourceDescription</code> and <code>ComgwDestinationDescription</code> that are not supported.

Requirements:

COM548\_Conf, COM259\_Conf\_2, COM158\_Conf\_2, COM157\_Conf\_2, COM437\_Conf\_2, COM127\_-Conf\_2, COM257\_Conf\_2, COM550\_Conf\_0, COM549\_Conf, COM259\_Conf\_3, COM157\_Conf\_3, COM170\_Conf\_2, COM232\_Conf\_2, COM257\_Conf\_3, COM550\_Conf\_1, COM339\_Conf\_1, COM146\_-



Conf\_1, COM235\_Conf\_1, COM317\_Conf\_1, COM318\_Conf\_1, COM313\_Conf\_1, COM312\_Conf\_1, COM147\_Conf\_1

Com\_SendSignal() does not return COM\_SERVICE\_NOT\_AVAILABLE in case the value of the signal does not fit into the PDU

### Description:

The function <code>Com\_SendSignal()</code> does not return <code>COM\_SERVICE\_NOT\_AVAILABLE</code> in case the value of the signal does not fit into the PDU, but an error is reported to DET. However, the SWS states: Return value: <code>E\_OK</code> - service has been accepted <code>COM\_SERVICE\_NOT\_AVAILABLE</code> - corresponding I-PDU group was stopped (or service failed due to development error). Therefore a <code>COM\_SERVICE\_NOT\_AVAILABLE</code> should be returned.

### Requirements:

#### COM197

The content of unfiltered elements of ComSignal in I-PDUs which are received deferred is not preserved until the next call to Com MainFunctionRx

#### Description

In case the upper layer calls <code>Com\_ReceiveSignal</code> or <code>Com\_ReceiveSignalGroup</code> after an I-PDU with <code>ComIPduProcessing</code> deferred was received (a lower layer called <code>RxIndication()</code>), but before the deferred indications were signaled to the upper layer in <code>Com\_MainFunctionRx</code>. This implementation does not behave like described in a note in the <code>Com</code> specification, but as follows: The content of the <code>old</code> I-PDU is not preserved until the next call to <code>Com\_MainFunctionRx</code>. Immediately after the reception of the new I-PDU, the <code>Com\_ReceiveSignal</code> and <code>Com\_ReceiveSignalGroup</code> API provides the data of the new I-PDU's content. The only exception are non-group signals with a filter. As the filter is evaluated in the <code>Com\_MainFunctionRx()</code>, the signal's value is retained until then.

# Requirements:

# COM198, COM201

► The Com does not check if an I-PDU is started if Com TxConfirmation is called

### Description

In contrast to AUTOSAR which states in Table 5 that a call to  $Com_TxConfirmation()$  shall be ignored in case of a stopped I-PDU, this version does not check if an I-PDU is started or stopped when the lower layer calls  $Com_TxConfirmation()$ .

#### Rationale:

In order not to lose speed to this check, it is assumed that no sporadic Tx-Confirmation appear once an Tx-I-PDU has been stopped.



# Requirements:

#### COM124

► I-PDUs of gated signals are not sent out from the Com\_MainFunctionRouteSignals() but from Com\_-MainFunctionTx()

#### Description:

In COM466 it is stated that I-PDUs that contain gated signals with triggered transfer property shall be sent from the  $Com\_MainFunctionRouteSignals()$  according to their transmission modes. In the implementation, an I-PDU is never sent from the  $Com\_MainFunctionRouteSignals()$ . In case a gated signal has the triggered transfer property, the I-PDU is sent out in the following  $Com\_MainFunctionTx()$ . However, both  $Com\_MainFunctionRouteSignals()$  and  $Com\_MainFunctionTx()$  are scheduled functions which therefore do not have the event-based character as does  $Com\_SendSignal()$  with the triggered transfer property.

Note: The transmission request from the signal gateway is also cleared, independent if a transmission request was issued and/or a transmission request failed if the following conditions are met:

- ComRetryFailedTransmitRequest is enabled.
- A transmission deadline monitoring is configured for the I-PDU and the deadline monitoring expires in the following Com MainFunctionTx().

#### Requirements:

#### COM539

Data sequence control and Communication protection not supported (reference to product description: ASCPD-22, ASCPD-23)

### Description:

Data sequence control (I-PDU counter) and communication protection (replication of I-PDUs) are not supported.

#### Requirements:

COM687, COM688, COM587, COM588, COM590, COM727, COM596, COM597, COM726, COM592\_-Conf, COM003\_Conf, COM593\_Conf, COM594\_Conf, COM595\_Conf, COM599\_Conf, COM600\_Conf, COM601\_Conf, partly COM787, COM731

Transmit Cancellation not supported (reference to product description: ASCPD-24)

#### Description:

The cancellation of transmission requests is not supported.



Requirements:

COM708, COM670, COM709\_Conf

No support of Debug & Trace

Description:

Tracing of global variables is not supported.

Requirements:

COM745, COM746, COM747, COM748

Non-compliant deviations in vendor-specific module definition file

Description:

The vendor-specific module definition file (VSMD) has non-compliant deviations to the AUTOSAR specification:

Violations against Rule EcucSws\_6008: The LOWER-MULTIPLICITY of an element in the VSMD must be bigger or equal and the UPPER-MULTIPLICITY must be equal or less than in the StMD

- StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComIPduTriggerTransmitCallout Rationale: Configuration shall be equal with ComCallout, see also <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=53200#c50">http://www.autosar.org/bugzilla/show\_bug.cgi?id=53200#c50</a>.
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComTimeBase

Rationale: Optionality of the ComTimeBase container is used to enable or disable the multiple main function support.

Violations against Rule EcucSws\_1007: For integer and float parameters the MIN values must be >= and the MAX values <= as in the StMD.

- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterMask
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestination/ComGwDestination/ComFilter/ComFilterMax
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterMin
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterOffset
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterPeriod



- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterX
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComTxIPdu/ComTxModeFalse/ComTx-Mode/ComTxModeTimeOffset
- StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComTxIPdu/ComTxModeTrue/ComTx-Mode/ComTxModeTimeOffset
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComBitPosition
- ▶ **StMD-Node**: /AUTOSAR/Com/ComConfig/ComSignal/ComSignalLength
- StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComUpdateBitPosition
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilter/ComFilterMask
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilter/ComFilterMax
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilter/ComFilterMin
- ➤ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilter/ComFilterX
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComUp-dateBitPosition
- ▶ **StMD-Node**: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComBitPosition
- ▶ **StMD-Node**: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComSignal-Length
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterMask
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterMax
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterMin
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterX

Rationale: Limitations are necessary to ensure valid configuration of filters (see Limitation: Restriction on ComFilter values). The range of ComTxModeTimeOffset has been extended to allow a backward compatible configuration for starting of I-PDU groups. Value range for parameters ComBitPosition, ComUpdateBitPosition, and ComSignalLength of ComSignals and ComSignalGroups has been extended to support I-PDUs larger than 254 Bytes.

Violations against Rule EcucSws\_1014: Additional vendor specific parameter definitions (using ParameterTypes), container definitions and references shall be added to the VSMD according to the alphabetical order.



- StMD-Node: /AUTOSAR/Com
- ▶ **StMD-Node**: /AUTOSAR/ComConfig/ComSignal
- ► StMD-Node: /AUTOSAR/ComGeneral

Rationale: Additional vendor specific parameter definitions have a specific order in the GUI which may differ to the alphabetical order.

Violations against Rule TpsEcuc\_06051\_ASR41: The implementationConfigClass of an EcucParameter-Def or EcucAbstractReferenceDef in VSMD shall be the same or higher (where PreCompile configuration class is considered to be the lowest and PostBuild the highest) as in StMD with respect to the selected subset defined by the actually implemented supportedConfigVariant.

► StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComIPduDirection

Rationale: The function signature of a ComlPduCallout and the ComlPduTriggerTransmitCallout in general depends on the ComlPduDirection. In case of variant handling enabled, all callout entries of all variants are configured within Rx or Tx callout tables. Due to these dependencies and in order to enable valid xdm config checks the configuration class of ComlPduDirection is set as link time.

Violations against Rule EcucSws\_6051: The implementationConfigClass in VSMD must be the same as in StMD with respect to the selected subset defined by the actually implemented ModuleDef.supportedConfigVariant if the scope of the ConfigParameter or ConfigReference in StMD is ECU.

- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterAlgorithm
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterMask
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterMax
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterMin
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterOffset
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwDestination/ComGwDestinationDescription/ComFilter/ComFilterX
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComGwMapping/ComGwSource/ComG-wSourceDescription/ComSignalLength
- ▶ **StMD-Node**: /AUTOSAR/Com/ComConfig/ComIPdu/ComIPduCallout
- StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComIPduCancellationSupport
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComIPduDirection
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComIPduHandleId



- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComIPduTriggerTransmitCallout
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComPduIdRef
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComIPdu/ComTxIPdu/ComTxIPduUnusedAreasDe-fault
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComIPduGroup/ComIPduGroupHandleId
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFirstTimeout
- ▶ **StMD-Node**: /AUTOSAR/Com/ComConfig/ComSignal/ComHandleId
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComRxDataTimeoutAction
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComSignalDataInvalidValue
- ➤ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComSignalLength
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilterAlgorithm
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilterMask
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilterMax
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilterMin
- StMD-Node: /AUTOSAR/Com/ComConfig/ComSignal/ComFilterOffset
- ▶ **StMD-Node**: /AUTOSAR/Com/ComConfig/ComSignal/ComFilterX
- StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComFirstTimeout
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComHandleId
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComRxDataTimeoutAction
- ▶ StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComHandleId
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComSignal-DataInvalidValue
- ▶ **StMD-Node**: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComSignal-Length
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterAlgorithm
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterMask
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterMax
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterMin
- ► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterOffset



► StMD-Node: /AUTOSAR/Com/ComConfig/ComSignalGroup/ComGroupSignal/ComFilter/ComFilterX

Rationale: A specific EB post build variant handling concept is implemented in the Com module, hence the parameter class in IMPLEMENTATIONCONFIGCLASS of variant VariantPostBuild is set to PostBuild instead of Link. (see Deviation: Only post-build configuration is supported and Limitation: Limitation on Com containers and configuration parameters for Post-Build variant handling support).

No consistency check between code files and header files

#### Description:

The inter-module version checks as specified by the Com SWS are not implemented.

#### Rationale:

- The required compile-time version checks would result in an inflexible, hardly integratable basic software stack.
- EB tresos AutoCore is an already integrated product.
- The project handling of EB tresos Studio provides means to enforce that only modules with the same EB tresos AutoCore release version can be added to the project.

#### Requirements:

#### COM673

Behavior of Com IpduGroupControl

# Description:

According to COM787, the Com module shall initialize the following attributes of an I-PDU as result of a call Com IpduGroupControl (independent from parameter Initialize):

- 1. ComMinimumDelayTime of I-PDUs in transmission mode  $\tt DIRECT$  or  $\tt MIXED$
- 2. Timeout attributes of I-PDUs for deadline monitoring aspect: all timeout timers (ComFirstTimeout, ComTimeout) shall restart.
- 3. All included update-bits shall be cleared.
- 4. Reset OCCURRENCE of filter with ComfilterAlgorithm ONE\_EVERY\_N.
- 5. Set the I-PDU counter to 0 for I-PDUs with ComIPduDirection configured to SEND.
- 6. Accept for I-PDUs with ComIPduDirection configured to RECEIVED any next incoming I-PDU counter.

However the implementation does not support I-PDU counter, therefore the items 5 and 6 are not initialized. See also deviation *Data sequence control and Communication protection not supported*. The items 1, 3 and 4 are only initialized as the result of a call Com IpduGroupControl with parameter Initialize set



to true. In contrast to COM222, the shadow buffers of included RECEIVED signal groups keeps unchanged if Com IpduGroupControl is called (independent from parameter Initialize).

Additionally to the described behavior above, ComTxModeTimePeriod and ComTxModeTimeOffset of I-PDUs in PERIODIC or MIXED transmission mode are always respected (independent from parameter Initialize).

#### Rationale:

Requirement COM787 is not backward compatible, see also Bugzilla issue <a href="http://www.autosar.org/bugzil-la/show\_bug.cgi?id=48891">http://www.autosar.org/bugzil-la/show\_bug.cgi?id=48891</a>.

The description of parameter Initialize of the API Com\_IpduGroupControl (COM751) says: "flag to request initialization of the I-PDUs which are newly started". That describes well the implemented behavior, but does not imply that I-PDU attributes are initialized, although parameter Initialize set to false.

The description of ComTxModeTimeOffset refers to Com\_IpduGroupControl in general and is not limited to parameter Initialize set to true.

Requirements:

COM787, COM222

No generation of symbolic name value into Com Cfg.h

# Description:

Several requirements claim that the symbolic names for the Com Handle IDs shall be published via Com\_-Cfg.h. However, the symbolic name values are provided in Com\_SymbolicNames\_PBcfg.h which is also included in Com.h.

# Rationale:

- ► Requirement is a deviation against TPS\_ECUC\_02108 of Specification of ECU Configuration which says that the symbolic name values shall be generated into the module header file.
- ▶ Requirement is a deviation against SWS\_BSW\_00200 of SWS General Specification of Basic Software Modules AUTOSAR 4.1 Rev 1, which says that symbolic name values shall be imported through the header of the BSW module that provides the value.
- Shall be removed in future AUTOSAR releases, see <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?">http://www.autosar.org/bugzilla/show\_bug.cgi?</a>
  <a href="mailto:id=60888">id=60888</a>

### Requirements:

COM174, COM126, COM163, COM044, COM521

No support of dynamic length signals in signal groups

| _   |     |     |    |        |    |
|-----|-----|-----|----|--------|----|
| - 1 | es) | cri | nt | $\cap$ | n. |
|     |     |     |    |        |    |



Dynamic length signals are only supported as signals. They are not supported in a group signal.

Rationale:

The implementation uses <code>Com\_UpdateShadowSignal()</code> and <code>Com\_ReceiveShadowSignal()</code> for the access of group signals. Since AUTOSAR does not define an equivalent API for access dynamic group signals, it is not possible to support dynamic length signals for group signals.

Requirements:

COM127

No support of zero size signals / group signals with transfer property PENDING

Description:

In contrast to AUTOSAR which allows zero size signals / group signals for transfer properties TRIGGERED, PENDING, and TRIGGERED\_WITHOUT\_REPETITION, only transfer property TRIGGERED and TRIGGERED\_WITHOUT\_REPETITION is supported.

Requirements:

COM762

No need for configuration of ComTxModeTrue or ComTxModeFalse

Description:

In contrast to AUTOSAR which states that every ComTxModeTrue or ComTxModeFalse that is a potential result of a configured/ calculated TMS must be configured, the COM module assumes ComTransmission-Mode NONE if one of these transmission modes is not configured but evaluated as a result of TMS. Note that at least one of the containers ComTxModeTrue or ComTxModeFalse must be configured at all.

Requirements:

COM465

Overlapping of ComSignals / ComGroupSignals

Description:

In contrast to AUTOSAR which states that ComSignal / ComGroupSignal are not allowed to overlap each other, the COM module allows the configuration of overlapped ComSignals / ComGroupSignals.

Requirements:

COM102

Configurable callback / callout functions are not provided in Com\_Cbk.h



#### Description:

In contrast to AUTOSAR which states that the configurable callback and callout functions shall be provided in header file Com\_Cbk.h, the COM module does not declare these functions. Instead, it declares and calls these external functions in an internal Com compilation unit.

Rationale:

These functions are usually generated / implemented by the Rte which also generates adequate function declarations. The linker then is able to resolve the function calls and the adequate function definitions in Rte. See also RTE Specification 4.2.1 Section 5.9.2.1 Call-backs for communication over AUTOSAR COM.

Requirements:

COM731

Optimization parameter ComSignalGwEnable for scaling down signal gateway to no size

Description:

In contrast to AUTOSAR which states that the signal gateway of the AUTOSAR COM module shall scale down to no size if no signal routing functionality is needed, the integrator shall disable the vendor specific optimization parameter ComSignalGwEnable to get the same effect.

Requirements:

COM370

Runtime error COM\_E\_SKIPPED\_TRANSMISSION is not supported

Description:

In case a large I-PDU is currently transmitted and the same I-PDU is triggered for transmission again, the AUTOSAR COM skips the additionally send request but does not report the runtime error COM\_E\_-SKIPPED\_TRANSMISSION.

Requirements:

SWS\_Com\_00863

PduR ComTpTransmit is called for large I-PDUs

Description:

AUTOSAR specifies that for transmissions of large I-PDUs the PduR API PduR\_ComTransmit has to be called. PduR\_ComTpTransmit is used instead for large I-PDUs and PduR\_ComTransmit for normal I-PDUs.

Requirements:



COM759, COM760, COM467, COM773, COM698, COM138

### 3.3.1.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

Implementation-specific restrictions

# Description:

There are some implementation-specific restrictions which are listed for completeness only, as they are most probably irrelevant for the intended use of the module:

- The maximum number of signals allowed is 65534.
- The maximum number of Rx/Tx I-PDUs allowed is 65534.
- ▶ The maximum number of callouts configured is 65534.
- The sum of the lengths of all byte-arrays which are sent via the Com module must not exceed 65535 bytes.
- The number of signals and signal group members, signal groups, notifications per I-PDU must not exceed 254.
- Discrepancy between ISO C90 standard and AUTOSAR ranges for signed integers

### Description:

C90 only allows signed integer values to have the following range:

- sint8: -127 / 127, or -(2^7 -1) / 2^7-1
- sint16 -32767 / 32767, or -(2^15 -1) / 2^15+1
- sint32 -2147483647 / 214743647, or -(2^31 -1) / 2^31 -1
- sint64 -9223372036854775807 / 9223372036854775807, or -(2^63 -1) / 2^63 -1

AUTOSAR, in the opposite, allows negative numbers to be one less:

- sint8: -128 / 127, or -(2^7) / 2^7-1
- sint16 -32768 / 32767, or -(2^15) / 2^15+1
- sint32 -2147483648 / 214743647, or -(2^31) / 2^31-1
- sint64 -9223372036854775808 / 9223372036854775807, or -(2^63) / 2^63-1

# Rationale:



In AUTOSAR, it is defined that AUTOSAR only supports platforms which use the 2's complement as basis for their architecture (and therefore support the AUTOSAR number range). This implementation implements the full AUTOSAR number range. C90-compliant compilers may legally facilitate code which shows undefined behavior in case the number-range as defined in C90 is left. That is if the minimum signed integer numbers as defined by AUTOSAR are used. Therefore this implementation relies upon the following:

- A platform is used which uses the 2's complement or a platform is used which can handle the whole AUTOSAR number range.
- A C-compiler is used which can handle the AUTOSAR-defined minimum signed integer numbers and facilitates code which behaves properly.
- ▶ Limitation/extension on configuration of ComFirstTimeout

### Description:

According to the AUTOSAR SWS Com requirement COM716, the AUTOSAR Com module shall not monitor the reception of this signal or of a signal group from the start of the corresponding I-PDU until the first reception. This behavior applies if the configuration parameter ComFirstTimeout for a signal or signal group is omitted or configured to 0.

The implementation behaves as following regarding the configuration parameter ComFirstTimeout for a signal or signal group:

- If configured to 0: as defined in COM716
- ▶ If omitted: ComTimeout is used for ComFirstTimeout

The default behavior for ComFirstTimeout is disabled.

#### Rationale:

- ► Eases configuration (otherwise ComFirstTimeout has to be configured for every signal/signal group)
- Does not restrict a use-case since configuration for starting of reception deadline monitoring with first reception of the I-PDU is possible.

#### Requirements:

#### COM716

Restriction on ComFilter values

# Description:

In contrast to AUTOSAR 4.0 Rev 3 where the ComFilter values (i.e. ComFilterX, ComFilterMask, ComFilterMax, ComFilterMin) for Com signals/signal groups shall have a configurable value range



within [0, 18446744073709551615], the Com supports for <code>ComFilterMax</code> and <code>ComFilterMin</code> a value range within [-2147483648, 4294967295] and for <code>ComFilterX</code> and <code>ComFilterMask</code> a value range within [-9223372036854775807, 18446744073709551615]. That is, only the least significant 32 or 64 bits are significant. Note: A Bugzilla item exists for this issue: <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?">http://www.autosar.org/bugzilla/show\_bug.cgi?</a> id=52038.

#### Rationale:

- Eases configuration
- For 64 bit signals/group signals the ComFilterAlgorithms are restricted where only ComFilterX and ComFilterMask are required to be set to a different range than ComFilterMax and ComFilter—Min
- There is no use-case for a filter ONE\_EVERY\_N where ComFilterOffset and ComFilterPeriod have to be higher than 2^32-1.

#### Requirements:

COM147\_Conf, COM235\_Conf, COM317\_Conf, COM318\_Conf

Restriction on 64 bit signals/group signals

### Description:

The following restrictions for signals/group signals with ComSignalType configured to UINT64 apply:

- ► The ComBitPosition is restricted to be byte aligned.
- ► The ComBitSize is restricted to be a multiple of 8 bit.
- ► The ComfilterAlgorithm is limited to ALWAYS, NEVER, ONE\_EVERY\_N, MASKED\_NEW\_DIF-FERS X and MASKED NEW EQUALS X.
- For the ComfilterAlgorithms MASKED\_NEW\_DIFFERS\_X and MASKED\_NEW\_EQUALS\_X, only the bits with respect to the configured ComBitSize are taken into account for the filter evaluation.
- ▶ The ComfilterAlgorithm for zero size signals / group signals is limited to ALWAYS and NEVER.

The following restrictions for signals/group signals with ComSignalType configured to SINT64 apply:

- The ComBitPosition is restricted to be byte aligned.
- The ComBitSize is restricted to be 64 bit (zero size signals / group signals are not supported).
- The ComfilterAlgorithm is limited to ALWAYS, NEVER, ONE\_EVERY\_N, MASKED\_NEW\_DIF-FERS\_X and MASKED\_NEW\_EQUALS\_X.

#### Requirements:

COM675, COM602, COM170\_Conf, COM352, COM325, COM764, COM273, COM603, COM302, COM303, COM763, COM222 COM324, COM793



Limitation on transmission behaviour for large Tx I-PDUs

# Description:

The transmission behaviour of large Tx I-PDUs is limited to the following points:

- only one transmission mode can be enabled.
- only transmission mode DIRECT with no repetitions (ComTxModeNumberOfRepetitions set to 0) is allowed.
- all large Tx I-PDU transmission requests are deferred to the next execution of the Com transmission main function (parameter ComDeferTx2MainFunc must be enabled).
- all update-bits of all contained signals and signal groups of large Tx I-PDUs are only cleared if PduR\_-ComTpTransmit returned E\_OK and the I-PDU was successfully confirmed (parameter ComTxIP-duClearUpdateBit must be configured to Confirmation).

Due to that limitation no transmission mode selection based on Tx transmission filter evaluation is possible for large Tx I-PDUs.

### Requirements:

COM694, COM602, COM325, COM380, COM439, COM231, COM330, COM767, COM734, COM768, COM762, COM135, COM741, COM769, COM742, COM770, COM326, COM676, COM678, COM679, COM245, COM763, COM238, COM244, COM495, COM582, COM467, COM279, COM305, COM494, COM392, COM776, COM787, COM222, COM223, COM228, COM229, COM789, COM696, COM308, COM739, COM388, COM492, COM784, COM813, COM605, COM032, COM779, COM625, COM629

Limitation on Com containers and configuration parameters for Post-Build variant handling support

# Description:

In contrast to AUTOSAR 4.3.0, the following listed Com containers and configuration parameters do not support Post-Build Variant Value and/or Post-Build Variant Multiplicity.

#### Rationale:

In order to be conform with the Rte which does not support post build variant handling a specific EB post build variant handling concept for the Com module and the related Com variant handling containers and configuration parameters is implemented. Hence, the following Com containers and configuration parameters do not support Post-Build Variant Multiplicity and/or Post-Build Variant Value:

ComlPduGroupRef

Rationale: Not compatible with the EB Com post build variant handling concept.

ComlPduSignalGroupRef

Rationale: Not compatible with the EB Com post build variant handling concept.



# ComIPduSignalRef

Rationale: Not compatible with the EB Com post build variant handling concept.

ComlPduGroup

Rationale: Not compatible with the EB Com post build variant handling concept.

ComlPduGroupGroupRef

Rationale: Not compatible with the EB Com post build variant handling concept.

ComSignal

Rationale: Not compatible with the EB Com post build variant handling concept.

ComSignal.ComSystemTemplateSystemSignalRef

Rationale: Not compatible with the EB Com post build variant handling concept.

ComSignalGroup

Rationale: Not compatible with the EB Com post build variant handling concept.

ComSignalGroup.ComSystemTemplateSignalGroupRef

Rationale: Not compatible with the EB Com post build variant handling concept.

ComGroupSignal

Rationale: Not compatible with the EB Com post build variant handling concept.

ComGroupSignal.ComSystemTemplateSystemSignalRef

Rationale: Not compatible with the EB Com post build variant handling concept.

# Requirements:

COM206\_Conf, COM519\_Conf, COM518\_Conf, COM341\_Conf, COM185\_Conf, COM344\_Conf, COM002\_Conf\_0, COM345\_Conf, COM001\_Conf, COM520\_Conf, COM002\_Conf\_1

# 3.3.1.6. Open-source software

Com does not use open-source software.

# 3.3.2. IpduM module release notes

AUTOSAR R4.0 Rev 3



AUTOSAR SWS document version: 2.2.0

Module version: 3.3.40.B439717

Supplier: Elektrobit Automotive GmbH

# 3.3.2.1. Change log

This chapter lists the changes between different versions.

#### Module version 3.3.40

2021-06-25

Internal module improvement. This module version update does not affect module functionality

#### Module version 3.3.39

2021-05-28

- ASCIPDUM-1115 Fixed known issue: Incorrect memory allocated for TX container instances if the Pdu-LengthType is uint32
- ASCIPDUM-1116 Fixed known issue: Undefined behavior when PduLengthType is uint32
- ASCIPDUM-1118 Fixed known issue: NULL pointer dereferenced with Flexible MainFunction Allocation and no TxPathways

### Module version 3.3.38

2021-04-30

Internal module improvement. This module version update does not affect module functionality

#### Module version 3.3.37

2021-03-05

ASCIPDUM-1111 Fixed known issue: Underallocated static container not trimmed in case of partial update

#### Module version 3.3.36

2021-02-12

Internal module improvement. This module version update does not affect module functionality



2021-01-22

Internal module improvement. This module version update does not affect module functionality

#### Module version 3.3.34

2020-12-11

Added support for Variant Handling

#### Module version 3.3.33

2020-09-25

- ASCIPDUM-1096 Fixed known issue: IPDUM\_TRIGGERTRANSMIT Container with static Contained PDUs are not triggered if all IpduMContainedTxPdus were updated
- Added support for ASR4.4 IpduMContainerRxAcceptContainedPdu=IPDUM ACCEPT ALL behavior

### Module version 3.3.32

2020-07-31

Internal module improvement. This module version update does not affect module functionality

### Module version 3.3.31

2020-06-19

Internal module improvement. This module version update does not affect module functionality

#### Module version 3.3.30

2020-05-22

- ASCIPDUM-1081 Fixed known issue: SduLength incorrectly established for Static Containers
- ASCIPDUM-1080 Fixed known issue: IpduM fails to generate if IpduMContainedTxPduPriority is not set and IpduMContainedTxPduPriorityHandling is TRUE

#### Module version 3.3.29

2020-04-24

Internal module improvement. This module version update does not affect module functionality



2020-03-25

- ► ASCIPDUM-1062 Fixed known issue: The transmission of a multiplexed I-PDU might be blocked within the IpduM
- ASCIPDUM-1063 Fixed known issue: Return value for IpduM\_Transmit is not specified in case of JIT update failure

#### Module version 3.3.27

2020-02-21

ASCIPDUM-1034 Fixed known issue: Off-by-one Error Causing an Out-Of-Bounds Read access

# Module version 3.3.26

2020-01-24

- ASCIPDUM-1029 Fixed known issue: Undefined data in dynamic AND/OR static PDU provided
- ASCIPDUM-1044 Fixed known issue: Transmission of containers stops after erroneous double transmission
- ASCIPDUM-1048 Fixed known issue: Parameter IpduMDequeueInTxConf is lacking constraint in the description
- ASCIPDUM-1049 Fixed known issue: TxConfirmation is denied when transmission is interrupted by IpduM\_TriggerTransmit()

#### Module version 3.3.25

2019-10-31

- ASCIPDUM-989 Fixed known issue: Generation error of IpduM where the container TxPdu has multiple PduR destinations
- ASCIPDUM-1028 Fixed known issue: Deferred IpduMContainerRxPdus can become corrupted with IpduMDedicatedIpduProcessingSupport

# Module version 3.3.23

2019-09-06

Internal module improvement. This module version update does not affect module functionality



2019-08-12

- ASCIPDUM-1021 Fixed known issue: High latency during transmission of TriggerTransmit-Queued Container PDUs
- ASCIPDUM-1022 Fixed known issue: Missing TxConfirmation for LAST\_IS\_BEST queued Contained PDUs

### Module version 3.3.21

2019-07-05

Internal module improvement. This module version update does not affect module functionality.

#### Module version 3.3.20

2019-06-14

- ► ASCIPDUM-1007 Fixed known issue: Duplicated container PDU is transmitted when IpduM\_TriggerTransmit interrupts IpduM\_Transmit
- ASCIPDUM-1012 Fixed known issue: Buffer overflow allows code injection
- ASCIPDUM-1009 Fixed known issue: Integer overflow might result in unexpected behavior of the ECU
- ASCIPDUM-1013 Fixed known issue: Out-of-bounds memory access for reception of a Container PDU with length 1

# Module version 3.3.19

2019-05-21

Internal module improvement. This module version update does not affect module functionality.

#### Module version 3.3.18

2019-04-18

Internal module improvement. This module version update does not affect module functionality.

# Module version 3.3.17

2019-03-22

ASCIPDUM-999 Fixed known issue: Undefined behavior if a contained PDU with a PDU length of zero is transmitted



2019-02-15

Internal module improvement. This module version update does not affect module functionality.

#### Module version 3.3.15

2018-12-13

Added support for priority handling of Tx ContainedIPdus with LastIsBest collection semantics

### Module version 3.3.14

2018-10-26

- PduR\_lpduMTriggerTransmit and PduR\_lpduMTxConfirmation are called inside ExclusiveArea
- ► ASCIPDUM-969 Fixed known issue: Deferred Rx container PDUs are incorrectly processed in IpduM\_MainFunctionRx()
- ASCIPDUM-964 Fixed known issue: Send timeout is wrongly considered for LAST IS BEST container PDUs

#### Module version 3.3.13

2018-09-28

Internal module improvement. This module version update does not affect module functionality

# Module version 3.3.12

2018-07-27

Add support for Contained to Container PDU Mapping Based on Static Configuration.

# Module version 3.3.11

2018-06-22

Internal module improvement. This module version update does not affect module functionality

#### Module version 3.3.10

2018-05-25



Internal module improvement. This module version update does not affect module functionality

### Module version 3.3.9

2018-04-20

- Internal module improvement. This module version update does not affect module functionality
- Added PbcfgM support
- ► Improved size announcement for trigger transmit Container Tx
- Add support for UINT32 PduLengthType.

### Module version 3.3.8

2018-02-16

- Create per-Partition BswImplementation and BswInternalBehavior elements in BSWMD
- ASCIPDUM-885 Fixed known issue: Compilation fails for enabled IpduMDedicatedIpduProcessingSupport

#### Module version 3.3.7

2018-01-19

- ASCIPDUM-885 Fixed known issue: Out-of-bounds access for deferred container Rx PDUs
- Flexible allocation of PDUs to MainFunctions

# Module version 3.3.6

2017-12-15

- ► ASCIPDUM-881 Fixed known issue: Container PDU is not transmitted when recovered from bus off situation
- Use BinarySearch for matching ContainedPdu ID
- ASCIPDUM-884 Fixed known issue: Generator error for timeout timers divisible by IpduMTxTimeBase

### Module version 3.3.5

2017-11-17

- ASCIPDUM-872 Fixed known issue: Missing TxConfirmation of contained PDUs
- ASCIPDUM-873 Fixed known issue: Loss of data for bursts of contained PDUs



Deferred finalization (frozen) for TriggerTransmit Container PDU

#### Module version 3.3.4

2017-10-20

ASCIPDUM-871 Fixed known issue: IpduM\_MainFunctionRx() blocks the interrupt too long

#### Module version 3.3.3

2017-09-22

ASCIPDUM-856 Fixed known issue: Multi-PDU-to-container handling is not post-build capable

#### Module version 3.3.2

2017-08-25

Internal module improvement. This module version update does not affect module functionality

#### Module version 3.3.1

2017-07-28

- Improve sending of container PDU due to send timeout trigger
- ASCIPDUM-837 Fixed known issue: Container PDU delayed with transmission confirmation timeout time
- Internal module improvement. This module version update does not affect module functionality

# Module version 3.3.0

2017-06-30

- Internal module improvement. This module version update does not affect module functionality
- Lower layer module isn't informed about the transmit request in case the trigger transmit mode is used for the container PDU
- ► ASCIPDUM-831 Fixed known issue: Transmission timer is not initialized when adding a contained I-PDU to a new container PDU

#### Module version 3.2.18

2017-06-02



- ► ASCIPDUM-804 Fixed known issue: Contained PDU is not transmitted in case of IPDUM\_COL-LECT\_LAST\_IS\_BEST
- ASCIPDUM-805 Fixed known issue: Container PDU transmitted with wrong contained PDUs in case of IPDUM\_COLLECT\_LAST\_IS\_BEST
- ASCIPDUM-808 Fixed known issue: Container PDU is not transmitted on the network for a long period
- ► ASCIPDUM-811 Fixed known issue: Container PDU transmits wrong contained PDUs in case of IP-DUM\_COLLECT\_QUEUED
- ASCIPDUM-814 Fixed known issue: Container PDU transmitted twice followed by the loss of the next instance of the container PDU
- ASCIPDUM-817 Fixed known issue: Corruption of run-time data during IpduM\_TxConfirmation()
- ▶ IPDUM\_GET\_SHORT\_HEADER\_ID depends on CPU\_BYTE\_ORDER
- Removed restriction to little-endian byte order for contained I-PDU headers (Multiple-PDU-to-Container handling)

2017-05-05

Internal module improvement. This module version update does not affect module functionality

# Module version 3.2.16

2017-03-31

- ► ASCIPDUM-768 Fixed known issue: Invalid memory access when Container Tx PDU length exceeds configured PduLength
- Internal module improvement. This module version update does not affect module functionality

# Module version 3.2.15

2017-03-03

- ASCIPDUM-758 Fixed known issue: Header ID and DLC are processed incorrectly on big-endian platform
- Internal module improvement. This module version update does not affect module functionality
- Internal module improvement. This module version update does not affect module functionality

Module version 3.2.14

2017-02-03



- ASCIPDUM-749 Fixed known issue: IpduM\_MainFunctionRx() and IpduM\_MainFunctionTx() violate cycle time
- ASCIPDUM-754 Fixed known issue: Incorrect association of container PDU and contained PDUs
- ▶ ASCIPDUM-750 Fixed known issue: Dereferenced null pointer in IpduM MainFunctionRx()
- Internal module improvement. This module version update does not affect module functionality

2017-01-05

- ASCIPDUM-739 Fixed known issue: Out of bounds access during reception
- Added Support for queuing of container PDUs.

#### Module version 3.2.12

2016-11-04

Corrected setting of transmission timer of container PDU

# Module version 3.2.11

2016-09-23

Incorporated Bugzilla RfC 71983: Introduce separate main functions for reception and transmission

#### Module version 3.2.10

2016-07-01

Added Multiple-PDU-to-Container handling for Tx

# Module version 3.2.9

2016-02-05

Added support for Debug & Trace with custom header file configurable via parameter BaseDbgHeader-File

#### Module version 3.2.8

2015-06-19



- Added Multiple-PDU-to-Containerhandling for Rx
- ► ASCIPDUM-586 Fixed known issue: The IpduM module reports an error for legal setting of IpduMInitializationBySignalValue and IpduMEnableJitUpdate

2015-01-07

- ▶ Removed AUTOSAR 3.x compliant symbolic name value macros and updated the logic to only provide AUTOSAR 4.0.2 compliant macros if macro IPDUM\_PROVIDE\_LEGACY\_SYMBOLIC\_NAMES is defined
- ► Changed signature of Com Rx callout IpduM\_ProcessRequestPduaccording to AUTOSAR bugzilla Rfc #52342

#### Module version 3.2.6

2014-10-02

- Implemented Just-In-Timeupdate of parts
- Added initialization of multiplexed I-PDU with initialization data of dynamic and static part from COM module

#### Module version 3.2.5

2014-04-25

Internal module improvement. This module version update does not affect module functionality

# Module version 3.2.4

2013-10-11

- ► ASCIPDUM-452 Fixed known issue: EB-specific feature calls Com\_TriggerIPDUSend() with wrong PDU-ID
- Changed the module structures for optimal memory usage
- Updated symbolic name value naming schema according to AUTOSAR 4.0 Rev 3

# Module version 3.2.3

2013-06-14

Added nonfunctional code improvements for shared data handling



- ► ASCIPDUM-425 Fixed known issue: If IpduMTxConfirmationTimeoutis set to zero, confirmation calls to the PduR are blocked
- ► ASCIPDUM-429 Fixed known issue: The IpduM generates code even if the configured destination field does not fit in the I-PDU
- ASCIPDUM-412 Fixed known issue: The IpduM code generation fails if the IpduM configuration refers to a PduR destination PDU that has disabled confirmation PDU-ID and disabled IpduM Tx confirmation
- ► ASCIPDUM-437 Fixed known issue: The IpduM generates erroneous code if IpduMDestinationBitis not byte-aligned while byte copy is enabled or IpduMDestinationBitis not set to zero while zero copy is enabled

2013-02-07

ASCIPDUM-342 Fixed known issue: The PduR IpduM transmission confirmation function is called with the wrong PDU-ID

### Module version 3.2.1

2012-10-12

- Changed the top-level structure of the software-component description in the ARXML files from /AU-TOSAR/IpduMto /AUTOSAR IpduM
- Updated to AUTOSAR 4.0 Rev 3

#### Module version 3.2.0

2012-09-28

- ASCIPDUM-315 Fixed known issue: Transmission of incorrect data in case of zero size transmit queues
- Implemented AUTOSAR 4.0 ComStack Handle ID policy

#### Module version 3.1.2

2012-08-17

Implemented definition of Exclusive Areain Basic Software Module Description

#### Module version 3.1.1

2012-06-22



Internal module improvement. This module version update does not affect module functionality

#### Module version 3.1.0

2012-03-16

- Updated the include structure regarding the symbolic name value header files
- Updated SchM\_Enter/Exit() calls to match AUTOSAR 4.0

#### Module version 3.0.4

2012-02-17

Added BSWMD support

#### Module version 3.0.3

2012-01-20

Improved speed of the template generator

# Module version 3.0.2

2011-12-09

Internal module improvement. This module version update does not affect module functionality

# Module version 3.0.1

2011-09-30

► ASCIPDUM-210 Fixed known issue: The unattended wizard *Calculate Handle IDs*does not generate Handle IDs for the IpduM

# Module version 3.0.0

2011-09-02

Initial AUTOSAR 4.0 version

# 3.3.2.2. New features

Support for Post-build Selectable.



# 3.3.2.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

Priority queuing for transmission of dynamic PDUs

## Description:

The IpduM is able to provide a priority queue for each transmit path. IpduMQueueSize specifies the queue size. A value of 0 means not using a queue at all. IpduMTxDynamicPriority defines the priority of each PDU. 0 stands for the highest priority.

Requesting service messages to request the transmission of a specific PDU from another ECU

### Description:

To support a special type of multiplexed messages called requesting service messages, the functionality of the AUTOSAR IpduM is extended. A requesting service message is identified by a selector value set to 1. On reception of a requesting service message, the ECU sends out the requested Com I-PDU. The requested Com I-PDU is specified by a global PDU-ID in the data field of the dynamic part of the requesting service message.

Automatic selector for automatic setting of the selector value by the IpduM

#### Description:

IpduM is extended to support automatic setting of selector value. The configuration parameter IpduMTx-AutomaticSelector is used to support this feature. If this parameter is enabled, the selector values for the transmit PDUs are set by the IpduM itself and if disabled, the selector value is not set by the IpduM. The selector value is also configurable using IpduMTxSelectorValue. During reception, the dynamic part is accepted and assembled only if the selector value is valid.

Code and run-time optimizations

### Description:

The code and run-time has been optimized. This optimization includes:

Detection of development errors

Disabling this feature reduces the ROM consumption and reduces the execution time of the module code.

Usage of static parts

Disabling this feature reduces the execution time and reduces the ROM consumption of the module code.

Version information API

Disabling this API reduces the ROM consumption of the module code.



# Zero Copy

Enabling this feature reduces the execution time and reduces the ROM consumption of the module code.

Byte-wise copy

Enabling this feature reduces the execution time and reduces the ROM consumption of the module code.

Dynamic part queue

Disabling this feature reduces the execution time and reduces the ROM consumption of the module code.

Automatic selector

Disabling this feature reduces the execution time and reduces the ROM consumption of the module code.

Static memory allocation

Decreasing this parameter reduces the RAM consumption of the module configuration.

Optional initialization of static and dynamic parts

# Description:

For the enabled <code>IpduMInitializationBySignalValue</code>, the static and dynamic parts are initialized in retrieving signal values from the upper layer module by <code>IpduM\_Init</code>. Otherwise the static and dynamic parts are only initialized by the unused area pattern configured.

#### Rationale:

The pre-compile switch was introduced to allow backward compatibility of the mandatory parameter Ip-duMInitialDynamicPart.

Optional Just-In-Time update

# Description:

For the enabled <code>IpduMEnableJitUpdate</code>, the Just-In-Time update functionality is provided in general. For the individual static and dynamic parts, the parameter <code>IpduMJitUpdate</code> has to be handled according to the SWS.

# Rationale:

The pre-compile switch was introduced to allow backward compatibility of the mandatory parameter Ip-duMInitialDynamicPart.



- Possibility to select whether dequeuing of IpduMContainerTxPdus with IpduMContainerTxTriggerMode set to IPDUM\_DIRECT happens in the context of IpduM\_MainFunctionTx() or IpduM\_TxConfirmation() by the configuration parameter IpduMDequeueInTxConf. Queued ContainerTxPdus with IpduMContainerTxTriggerMode set to IPDUM\_TRIGGERTRANSMIT are dequeued in IpduM\_TxConfirmation() regardless of the value of the parameter.
- Binary Search algorithm for matching contained PDU header ID

# Description:

For matching contained PDUs header ID the <code>IpduM</code> module makes use of <code>Binary Search</code> algorithm in order to reduce runtime consumption. This is needed especially when a container PDU with <code>IpduMContainerRxAcceptContainedPdu</code> set to <code>IPDUM\_ACCEPT\_ALL</code> is received.

# 3.3.2.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

IpduM supports only little endian byte order for IpduM segments

### Description:

For the configuration parameter <code>IpduMByteOrder[IPDUM162\_Conf]</code> in the configuration container <code>IpduMRxIndication</code> and <code>IpduMTxRequest</code> only the value <code>LITTLE\_ENDIAN</code> is allowed. This also violates <code>IPDUM166]</code> which requests that Com and <code>IpduM</code> must have the same setting regarding the endianness.

#### Rationale:

The EB tresos Studio Com importer is able to convert BIG\_ENDIAN segments to LITTLE\_ENDIAN segments. For direct configuration and import from ECU configuration files this limitation has to be considered, but does not restrict any PDU layout.

# Requirements:

IPDUM166, IPDUM162\_Conf

IpduMRxDirectComInvocation not supported

# Description:

The configurable optimization *direct invocation of the COM module (bypassing the PduR)* as defined in *IPDUM140* is not implemented.

#### Rationale:

This optimization violates the AUTOSAR layered architecture.

# Requirements:



# IPDUM140, IPDUM142\_Conf

PduR\_IpduMRxIndication(), PduR\_IpduMTransmit(), PduR\_IpduMTriggerTransmit(), and
PduR IpduMTxConfirmation() are mandatory

# Description:

PduR\_IpduMTxIndication(), PduR\_IpduMTransmit(), PduR\_IpduMTriggerTransmit(), and PduR\_IpduMTxConfirmation() are mandatory and not optional interfaces as specified by requirement IPDUM105.

#### Rationale:

PduR\_IpduMTxIndication(), PduR\_IpduMTransmit(), PduR\_IpduMTriggerTransmit(), and PduR\_IpduMTxConfirmation() can only be optional when following optimizations are implemented:

- The IpduM Tx path can be disabled when PDUs are only received via the IpduM.
- The IpduM Rx path can be disabled when PDUs are only sent via the IpduM.

These optimizations are not implemented by the IpduM.

Requirements:

IPDUM105, IPDUM104

No AUTOSAR Debugging support

Description:

The requirements associated with AUTOSAR Debugging are not supported. This comprises all requirements mentioned within the section *Debugging*.

Rationale:

EB tresos Debug and Trace is intended to be used.

Requirements:

IPDUM144, IPDUM145, IPDUM146, IPDUM147

No consistency check between code files and header files

Description:

The inter-module version checks as specified in the IpduM SWS are not implemented.

Rationale:

Module consistency check is not within the responsibility of the basic software, but part of the configuration management and delivery process.



Requirements:

IPDUM165, IPDUM170

Support of configuration variant post-build (reference to product description: ASCPD-77)

Description:

The IpduM module only supports configuration variant post-build.

Requirements:

IPDUM095

Usage of EB convention for file structure.

Description:

The IpduM module follows the EB-specific implementation method for file inclusion. Implementation is distributed over several implementation files.

Requirements:

IPDUM149, IPDUM150

► Configuration parameter IpduMTxConfirmationPduId is not OPTIONAL.

Description:

As per AUTOSAR\_SWS\_IPDUMultiplexer V4.0.3, IpduMTxConfirmationPduId can be optional. But it is also mentioned that the existence of this parameter is essential for the PduR generation tool to actually find a symbolicNameValue for the outgoing PDU. Also disabling the parameter demands lots of rework in the generator.

Requirements:

IPDUM158\_Conf

Non-compliant deviations in vendor-specific module definition file

Description:

The vendor-specific module definition file (VSMD) has non-compliant deviations to the AUTOSAR specification:

Violations against Rule EcucSws\_1014: Additional vendor specific parameter definitions (using ParameterTypes), container definitions and references shall be added to the VSMD according to the alphabetical order.

StMD-Node: /AUTOSAR/IpduM



- StMD-Node: /AUTOSAR/IpduM/IpduMConfig/IpduMRxPathway/IpduMRxIndication/IpduMRxDynamicPart/IpduMSegment
- ► StMD-Node: /AUTOSAR/IpduM/IpduMConfig/IpduMRxPathway/IpduMRxIndication/IpduMRxStaticPart/IpduMSegment
- ▶ **StMD-Node**: /AUTOSAR/IpduM/IpduMConfig/IpduMTxPathway/IpduMTxRequest
- ► StMD-Node: /AUTOSAR/IpduM/IpduMConfig/IpduMTxPathway/IpduMTxRequest/IpduMTxDynamicPart/IpduMSegment
- ► StMD-Node: /AUTOSAR/IpduM/IpduMConfig/IpduMTxPathway/IpduMTxRequest/IpduMTxStaticPart/IpduMSegment
- ► StMD-Node: /AUTOSAR/IpduM/IpduMGeneral

Rationale: Additional vendor specific parameter definitions have a specific order in the GUI which may differ to the alphabetical order.

Unsupported parameter IpduMConfigurationTimeBase

# Description:

This configuration parameter is replaced by the 2 configurable parameters IpduMRxTimeBase and IpduMTxTimeBase, and IpduMDedicatedIpduProcessingSupport is enabled, additionally by IpduMTimeBase.

See Bugzilla RfC 71983 for further information.

See ASCIPDUM-772.

Requirements:

IPDUM131 Conf

Unsupported API IpduM\_MainFunction

Description:

The IpduM MainFunction is split into IpduM MainFunctionRx and IpduM MainFunctionTx.

See Bugzilla RfC 71983 for further information.

Requirements:

IPDUM103, IPDUM101

IpduMDequeueInTxConf selects when dequeuing happens

# Description:

If IpduMDequeueInTxConf is FALSE, dequeuing happens only in IpduM MainFunctionTx().



Applies only to IpduMContainerTxPdus with IpduMContainerTxTriggerMode set to IPDUM\_DIRECT.

Queued ContainerTxPdus with IpduMContainerTxTriggerMode set to IPDUM\_TRIGGERTRANSMIT are dequeued in IpduM\_TxConfirmation() regardless of the value of the parameter.

Requirements:

IpduM.ASR42.SWS\_IpduM\_00190

IpduMDequeueInTxConf selects when dequeuing happens

Description:

If IpduMDequeueInTxConf is TRUE, dequeuing happens also in IpduM TxConfirmation().

Requirements:

IpduM.ASR42.SWS\_IpduM\_00190

Dequeuing in case of overflow

Description:

By the requirement SWS\_lpduM\_00199 it is specified that the oldest instance shall be overwritten if the queue is full. SWS\_lpduM\_00190 does state that the next oldest one shall be processed without handling the overflow case. As it is not considered normal operation and it would increase complexity, in case of an overflow the newest container would be dequeued before the oldest one.

Requirements:

IpduM.ASR42.SWS\_IpduM\_00190

Max value of IpduMContainerQueueSize

Description:

The upper limit of the configuration parameter IpduMContainerQueueSize is 254 due to the fact that the number of instances is stored in a uint8, for both RX and TX.

Requirements:

IpduM.ASR42.ECUC\_IpduM\_00185\_RX\_Conf, IpduM.ASR42.ECUC\_IpduM\_00185\_TX\_Conf

▶ PduR IpduMTriggerTransmit transmit data for each contained

Description:

The container is triggered based on PduLength of the contained PDUs and when preparing for transmission data for each contained is obtained from PduR (through PduR IpduMTriggerTransmit).



Requirements:

IpduM.ASR44.SWS\_IpduM\_00231

### 3.3.2.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

IpduM Handle ID assignment

#### Description:

- ▶ IpduMConfig/IpduMRxPathway/\*/IpduMRxIndication/IpduMRxHandleId has to be assigned zero-based and dense.
- ▶ IpduMConfig/IpduMTxPathway/\*/ IpduMTxRequest/IpduMTxStaticPart/IpduMTxStaticHandleId has to be assigned zero-based and dense.
- ▶ IpduMConfig/IpduMTxPathway/\*/IpduMTxRequest/IpduMTxDynamicPart/\*/ IpduMTxDynamicHandleId has to be assigned dense and start with max(IpduMTxStaticHandleId)+1.
- ► IpduMConfig/IpduMContainedTxPdu/\*/IpduMContainedTxPduHandleId has to be assigned dense and start from the last IpduMTxPathway/IpduMTxRequest/IpduMTxDynamic-Part/IpduMTxDynamicHandleId.
- ▶ IpduMConfig/IpduMContainerTxPdu/\*/IpduMContainerTxHandleId has to be assigned dense and start from the number of IpduMTxPathways.
- ▶ IpduMConfig/IpduMContainerRxPdu/\*/IpduMContainerRxHandleId has to be assigned dense and start from the last IpduMRxPathway/IpduMRxHandleId, IpduMContainerRxPdus with IpduMContainerPduProcessing configured as IPDUM\_PROCESSING\_DEFERRED first.

#### Rationale:

Code size reduction and run-time improvement.

IpduM module expects restricted multiplicity of container PduRRoutingTable

# Description:

The IpduM module expects the upper multiplicity of container PduRRoutingTable restricted to 1.

Rationale:



The post-build time loadable and selectable concepts are supported through variant handling, where multiple routing tables are not applied.

Configuration separation

Description:

In the current version the configuration is generated in a monolithic manner, not separately for each core.

Uniqueness of contained PDU header IDs

Description:

The IpduMContainedPduHeaderIds must be unique for contained Tx PDUs in the context of the associated IpduMContainerTxPdu.

The IpduMContainedPduHeaderIds must be unique for contained Rx PDUs if IpduMGeneral/IpduMRx-ContainerAcceptAllNoRefOnly is FALSE.

Rx/Tx PathWay PduLengthType

Description:

The PduLengthType is limited to uint16 for Rx and Tx PathWays. Even though the PduLengthType can be set to uint32 the IpduM module does not offer support for Rx and Tx PathWay PDUs of size greater than uint16.

Contained PDUs with length 0 not forwarded

Description:

The IpduM module silently drops Contained PDUs with an SduLength of 0.

Rationale:

The SWS does not define how to handle PDUs with a length of 0. During transmission the call to IpduM Transmit() is ignored and the value E OK is returned.

# 3.3.2.6. Open-source software

IpduM does not use open-source software.

# 3.3.3. LdCom module release notes

AUTOSAR R4.0 Rev 3



AUTOSAR SWS document version: 4.2.1

Module version: 1.0.26.B439717

Supplier: Elektrobit Automotive GmbH

# 3.3.3.1. Change log

This chapter lists the changes between different versions.

#### Module version 1.0.26

2021-03-05

Updated preprocessor include guards to be PC-lint compatible

# Module version 1.0.25

2020-06-19

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.24

2020-02-21

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.23

2019-10-11

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.22

2019-06-14

Added support for custom header files for LdCom callbacks

#### Module version 1.0.21

2019-02-15

Internal module improvement. This module version update does not affect module functionality



2018-10-26

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.19

2018-06-22

▶ Provided REFINED-MODULE-DEF-REF in VSMD refining the StMD

# Module version 1.0.18

2018-02-16

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.17

2017-09-22

- Internal module improvement. This module version update does not affect module functionality
- Switch from MISRA-C:2004 to MISRA-C:2012

# Module version 1.0.16

2017-03-03

Improve initialization of module (name of configuration can be used as symbol for LdCom\_Init())

# Module version 1.0.15

2017-02-03

Internal module improvement. This module version update does not affect module functionality

# Module version 1.0.14

2017-01-05

Internal module improvement. This module version update does not affect module functionality

# Module version 1.0.13

2016-12-02



Internal module improvement. This module version update does not affect module functionality

# Module version 1.0.12

2016-11-04

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.11

2016-10-07

Internal module improvement. This module version update does not affect module functionality

# Module version 1.0.10

2016-09-09

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.9

2016-08-05

Internal module improvement. This module version update does not affect module functionality

# Module version 1.0.8

2016-07-01

Internal module improvement. This module version update does not affect module functionality

# Module version 1.0.7

2016-05-25

Internal module improvement. This module version update does not affect module functionality

# Module version 1.0.6

2016-04-29

Internal module improvement. This module version update does not affect module functionality



2016-04-01

Fixed known issue: Missing memory section for external declared Dummy Callback functions

#### Module version 1.0.4

2016-02-05

► Added support for Debug & Trace with custom header file configurable via parameter BaseDbgHeader-File

#### Module version 1.0.3

2015-06-19

Internal module improvement. This module version update does not affect module functionality

#### Module version 1.0.2

2015-02-20

Adapted syntax of Rte callbacks of communication interface modules to AUTOSAR 4.2.1

# Module version 1.0.1

2015-01-07

- Provide LdCom Transmit API for IF usage
- ASCLDCOM-26 Fixed known issue: Invalid reference of global PDUs for PduR module
- ASCLDCOM-27 Fixed known issue: Undeclared APIs for PduR module

# Module version 1.0.0

2014-10-02

Initial AUTOSAR 4.2 version

# 3.3.3.2. New features

No new features have been added since the last release.



# 3.3.3.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

This module provides no EB-specific enhancements.

# 3.3.3.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

Unsupported Signalld

Description:

Instead of the signal ID, the LdCom is called by the LdComHandleld by the RTE.

Requirements:

SWS\_LDCOM\_00009 SWS\_LDCOM\_00010 SWS\_LDCOM\_00018

Unsupported error codes

Description:

The following error codes listed in requirement SWS\_LDCOM\_00018 are not supported due to the reason given below:

► LDCOM\_E\_INVALID\_SIGNAL\_ID: Listed for completeness. See deviation 'dev.LdCom.Unsupport-edSignalId'.

Requirements:

SWS LDCOM 00018

Distinguish name of LdCom\_Transmit for both API archetypes

Description:

The function LdCom\_Transmit is defined with a different API name for modules supporting communication interface as well as transport protocol I-PDUs, namely LdCom\_IfTransmit and LdCom\_TpTransmit. A macro maps LdCom Transmit to LdCom IfTransmit.

Rationale:

The mapping is made to go conform with the Rte module calling LdCom\_Transmit with an LdComHandleId related to communication interface I-PDUs. The TP handling introduced later on within the Rte module gets direct use of separate TP-API LdCom TpTransmit (with separate LdComHandleId's).



Separate APIs are implemented in order to support the call of PduR\_LdComTransmit, respectively PduR\_LdComTpTransmit, for both API archetypes the PduR module gets use of. This eases usage of separate handle ID ranges required by the PduR module.

Requirements:

SWS LDCOM 00026 SWS LDCOM 00012 SWS LDCOM 00035

Support of configuration variant post-build

# Description:

The LdCom module supports only configuration variant post-build. This is handled in restricting the range of configuration parameter IMPLEMENTATION\_CONFIG\_VARIANT to VariantPostBuild leading to violation of rule EcucSws\_6051.

Requirements:

SWS\_LDCOM\_00043

Reentrancy of Tp call-back functions and notifications

Description:

The Reentrancy of the Tp call-back functions and notifications of the LdCom module:

- LdCom\_CopyTxData
- LdCom\_TpTxConfirmation
- LdCom\_StartOfReception
- LdCom\_CopyRxData
- LdCom\_TpRxIndication

are reentrant for different Pdulds and non reentrant for the same Pduld. However, the AUTOSAR LdCom specification defines those as reentrant only, which is not consistent.

Rationale:

The Tp call-back functions and notifications of the LdCom module calls Rte Tp call-back functions and notifications which are specified as reentrant for different Pdulds and non reentrant for the same Pduld.

Requirements:

SWS\_LDCOM\_00027, SWS\_LDCOM\_00028, SWS\_LDCOM\_00029, SWS\_LDCOM\_00030, SWS\_LDCOM\_00031



# 3.3.3.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

No limitation is known.

# 3.3.3.6. Open-source software

LdCom does not use open-source software.

# 3.3.4. Mirror module release notes

Module version: 1.0.17.B439717

Supplier: Elektrobit Automotive GmbH

# 3.3.4.1. Change log

This chapter lists the changes between different versions.

#### Module version 1.0.17

2021-06-25

Internal module improvement. This module version update does not affect module functionality.

# Module version 1.0.16

2021-05-28

ASCMIRROR-51 added support for FlexRay source networks.

# Module version 1.0.15

2021-03-05

Internal module improvement. This module version update does not affect module functionality.



2020-09-25

Internal module improvement. This module version update does not affect module functionality.

#### Module version 1.0.13

2020-07-31

Internal module improvement. This module version update does not affect module functionality.

# Module version 1.0.12

2020-06-19

Internal module improvement. This module version update does not affect module functionality.

# Module version 1.0.11

2020-05-22

ASCMIRROR-39 Fixed known issue: Extra byte might be present when mirroring a LIN frame with a status other than OK.

#### Module version 1.0.10

2020-02-21

Internal module improvement. This module version update does not affect module functionality.

# Module version 1.0.9

2020-01-24

Added new info in the generation phase in case in of the CAN controllers use interrupt instead of polling.

# Module version 1.0.8

2019-12-06

Internal module improvement. This module version update does not affect module functionality.



2019-11-28

Implemented call out function. Added a call out function in case a received frame can't be inserted in the intermediate buffer for each network type.

#### Module version 1.0.6

2019-10-11

- ASCMIRROR-25 Fixed known issue: The initialization of the Mirror module might enter an infinite loop.
- ASCMIRROR-28 Fixed known issue: The Mirror module might activate a queue buffer using the time stamp of an already copied frame.
- ASCMIRROR-30 Introduced new limitation: Limitation regarding multiple controllers of the same type preempting each other.

#### Module version 1.0.5

2019-09-06

ASCMIRROR-24 Fixed known issue: Compilation error due to mismatching memory sections.

#### Module version 1.0.4

2019-06-14

- ASCMIRROR-18 Fixed known issue: Mirror module reports the same error twice to the DET.
- ASCMIRROR-19 Fixed known issue: Mirror module stores less frames than full capacity.

#### Module version 1.0.3

2019-05-17

Internal module improvement. This module version update does not affect module functionality.

#### Module version 1.0.2

2019-04-18

ASCMIRROR-12 Fixed known issue: Rte\_Mirror\_Type.h has the wrong name and causes compile error.



2019-03-22

Internal module improvement. This module version update does not affect module functionality.

#### Module version 1.0.0

2019-02-15

Initial release

# 3.3.4.2. New features

- The module has the ability to have call out function in case a received frame can't be inserted in the intermediate buffer for each network type.
- ► The FlexRay source networks are supported and fully functional.

# 3.3.4.3. EB-specific enhancements

This module is not part of the AUTOSAR specification.

# 3.3.4.4. Deviations

This module is not part of the AUTOSAR specification.

#### 3.3.4.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

Limitation on the initialization sequence of the modules

Description:

In order to ensure functional consistency, the modules Canlf, Linlf and PduR must be initialized before the Mirror module.

Limitation on multicore usage

Description:



In order to use the Mirror module in a multicore system, each type of network controllers must be mapped on the same core. e.g (all CAN controllers to be configured on the same core).

Limitation on controllers interrupt priority

# Description:

The Mirror module doesn't support interrupts with different priorities from the same controller type. e.g (all CAN controllers interrupts must have the same priority).

# 3.3.4.6. Open-source software

Mirror does not use open-source software.

# 3.3.5. PduR module release notes

AUTOSAR R4.0 Rev 3

► AUTOSAR SWS document version: 3.2.0

Module version: 5.3.46.B439717

Supplier: Elektrobit Automotive GmbH

# 3.3.5.1. Change log

This chapter lists the changes between different versions.

#### Module version 5.3.46

2021-06-25

Internal module improvement. This module version update does not affect module functionality

#### Module version 5.3.45

2021-03-05

- Updated preprocessor include guards to be PC-lint compatible
- Upgraded quality on TP gateway queueing
- Added XML-tags to BSWMD for upgraded Rte module



2020-10-23

- ASCPDUR-2875 Fixed known issue: Multi-core support only: Missing integration requirement for TP gateway
- ASCPDUR-2907 Fixed known issue: Possible compilation error with compile option "-ansi"

#### Module version 5.3.43

2020-06-19

- Implemented smarter buffer selection algorithm for routing on-the-fly
- ASCPDUR-2857 Fixed known issue: Wrong return value for requested available data by CopyTxData

#### Module version 5.3.42

2020-01-24

- ASCPDUR-2787 Fixed known issue: Compilation error occurs when PostBuild variants are configured
- ASCPDUR-2788 Fixed known issue: Race condition for concurrent StartOfReception calls

#### Module version 5.3.41

2019-10-11

- ASCPDUR-2750 Fixed known issue: Variables are not assigned to a memory section
- Implemented support on multicast of TP-PDUs with highest wins strategy

# Module version 5.3.40

2019-09-06

ASCPDUR-2727 Fixed known issue: Out-of-bounds RAM access within PduR Init

#### Module version 5.3.39

2019-08-09

- Allow multiple frames for multicast gateway transmission if only one destination PDU is reachable
- ASCPDUR-2709 Fixed known issue: Linking error occurs due to constants placed in wrong memory section.
- ASCPDUR-2712 Fixed known issue: Compilation error with routing path groups and static PDU lengths
- ASCPDUR-2722 Fixed known issue: Invalid RAM access with routing path groups



2019-07-05

- Implemented support of routing path groups
- ASCPDUR-2700 Fixed known issue: Blocked buffer and unsent PDU with Tp gateway queueing for N:1 routing paths

#### Module version 5.3.37

2019-06-14

Implemented support of Post-Build variants (previously known as post-build selectable configuration sets by AUTOSAR)

#### Module version 5.3.36

2019-04-18

Updated schema file for Post-Build variants

#### Module version 5.3.35

2019-03-22

Implemented full support of N:1 TP gateway routing paths with enabled TP gateway queuing

# Module version 5.3.34

2019-02-15

Updated API selection in gateway table of cross-partition routing paths

# Module version 5.3.33

2019-01-25

ASCPDUR-2623 Fixed known issue: Linking errors for enabled multi-core feature

#### Module version 5.3.32

2018-12-21

- Added support for TP Gateway Queuing
- Implemented support for BSW distribution to multiple partitions



2018-07-27

ASCPDUR-2490 Fixed known issue: Compile error in ASR 3.2 wrapper APIs for disabled merged compile option

#### Module version 5.3.30

2018-06-22

- Allow initial usage of PduLengthType set to uint32
- ASCPDUR-2476 Fixed known issue: Tp sessions of N:1 routing paths corrupt each other
- ASCPDUR-2482 Fixed known issue: Runtime Error due to misaligned Tp session data in RAM

# Module version 5.3.29

2018-04-20

► ASCPDUR-2420 Fixed known issue: Generation aborts without error message for incompletely configured routing path

#### Module version 5.3.28

2018-02-16

Internal module improvement. This module version update does not affect module functionality

# Module version 5.3.27

2017-09-22

- ▶ Added support for call of Up\_TxConfirmation in a multicast transmission
- ▶ Switch from MISRA-C:2004 to MISRA-C:2012

# Module version 5.3.26

2017-08-25

Internal module improvement. This module version update does not affect module functionality

# Module version 5.3.25

2017-07-28



ASCPDUR-2283 Fixed known issue: PduR generates wrong buffer assignments for If-gateway relations

#### Module version 5.3.24

2017-06-30

Abolished memory size limitation of 64 KiB

#### Module version 5.3.23

2017-05-05

Internal module improvement. This module version update does not affect module functionality

#### Module version 5.3.22

2017-03-31

Added support of N:1 PDU routing

#### Module version 5.3.21

2016-07-01

ASCPDUR-2165 Fixed known issue: Wrong buffer size request for ASR 3.2 upper layer TP module

# Module version 5.3.20

2016-05-25

Avoid compiler warning similar to dead assignment to "AvailableBufferSize" eliminated

#### Module version 5.3.19

2016-04-29

► Added handling for AUTOSAR 3.2 upper layer TP module in dependence on existence of BUFREQ\_E\_-BUSY on Rx side

# Module version 5.3.18

2016-04-01

ASCPDUR-2154 Fixed known issue: Open section PDUR\_START\_SEC\_CODE within an already opened section for ASR 3.2 wrapper



2015-11-06

Create/extend recommended configurations for Ethernet

#### Module version 5.3.16

2015-06-19

Internal module improvement. This module version update does not affect module functionality

#### Module version 5.3.15

2015-02-20

Implemented non-functional code improvements to fix Misra violation

#### Module version 5.3.14

2015-01-07

- Added support for configurable mapping of PduR IsValidConfig function to dedicate memory section
- Removed AUTOSAR 3.x compliant symbolic name value macros and updated the logic to only provide AUTOSAR 4.0.2 compliant macros if macro PDUR\_PROVIDE\_LEGACY\_SYMBOLIC\_NAMES is defined

# Module version 5.3.13

2014-10-02

ASCPDUR-2077 Fixed known issue: Missing memory section for external declared AUTOSAR 3.2 wrapper functions

#### Module version 5.3.12

2014-04-25

- ▶ Improved robustness of multicast transmission for SduLength 0
- ▶ ASCPDUR-2036 Fixed known issue: Handle ID wizard fails when PduRZeroCostOperation is enabled
- ▶ Replaced enumeration type of PduR StateType in defining literals according to company guidelines
- ASCPDUR-2045 Fixed known issue: XDM checks to prevent incorrect configuration are missing
- ▶ Implemented call of LoTp\_Transmit by successful PduR\_LoTpRxIndication if TP threshold was not reached for routing on the fly



- ► ASCPDUR-2063 Fixed known issue: Build error due to missing file PduR\_PBcfg.c if code generation for PduR is disabled and only post-build configuration is compiled
- Improved robustness of retry mechanism for TP multicast gateway
- ▶ ASCPDUR-2075 Fixed known issue: Nested MemMap section if TS MERGED COMPILE is activated

2013-10-11

- ► ASCPDUR-1984 Fixed known issue: Resources are not released if PduR\_LoTpRxIndication follows
  PduR LoTpTxConfirmation for routing on the fly
- Improved nonfunctional code of TP gateway regarding shared data handling
- ASCPDUR-2003 Fixed known issue: Retry fails for a TP gateway to multiple destinations
- ASCPDUR-2006 Fixed known issue: TP buffer smaller than TpThreshold is assigned by an unknown message length request for routing on the fly

#### Module version 5.3.10

2013-09-13

Updated descriptions in release notes

# Module version 5.3.9

2013-08-16

- ASCPDUR-1890 Fixed known issue: Invalid pointer in interface gateway causes incorrect runtime behavior even if development error detection is enabled
- ► ASCPDUR-1913 Fixed known issue: PduR\_LoTpTxConfirmation and PduR\_LoTpCopyTxData call wrong PDU-ID for multicast transmission
- Implemented <code>0xFFFF</code> as invalid return value of <code>PduR\_GetConfigurationId()</code> in case of an error.

  Therefore this value has been excluded from the valid ranges of configuration IDs in the configuration
- Improved handling of disabled TxPdulds of upper layer modules
- Implemented generation of symbolic name values
- Improved nonfunctional code of AUTOSAR 4.0 to 3.2 TP API Wrapper
- Improved nonfunctional code of If gateway regarding shared data handling
- Added Debug & Trace code instrumentation
- Improved nonfunctional code of TP multicast regarding shared data handling



ASCPDUR-1943 Fixed known issue: Compilation error for If gateway when all lower layer modules are optimized for static payload

#### Module version 5.3.8

2013-06-14

- ► ASCPDUR-1852 Fixed known issue: Calling PduR\_LoTriggerTransmit() does not pass the initial default values to the lower layer module
- ► ASCPDUR-1858 Fixed known issue: PduR\_LoTriggerTransmit() uses the wrong PDU for multicast transmission

#### Module version 5.3.7

2013-05-10

- Added checks of published information signature to prevent loading of incompatible post-build configura-
- Improved error message in case Handle IDs are not set properly

#### Module version 5.3.6

2013-04-12

- ► ASCPDUR-1785 Fixed known issue: Incorrect data will be copied when PduR\_LoTpCopyTxData() is called via direct gateway
- ► ASCPDUR-1783 Fixed known issue: PduR\_LoTpCopyRxData() returns an incorrect buffer size when requested from AUTOSAR 3.2 upper layer
- ASCPDUR-1805 Fixed known issue: Handle ID calculation fails if PduRZeroCostOperation is enabled

# Module version 5.3.5

2013-02-08

- Updated the Basic Software Module Description for memory mapping macros
- ► Removed BUFREQ E BUSY from CopyRxData
- Added wrapper to AUTOSAR 3.2 upper layers with TP interface
- ASCPDUR-1754 Fixed known issue: A segmentation fault is reported for multicast transmission to lower layer modules with unsupported retry mechanism
- ▶ ASCPDUR-1753 Fixed known issue: Possible misalignment in PduR RAM may cause an exception on some CPUs



2013-01-11

- ► ASCPDUR-1714 Fixed known issue: The containers PduRTpBuffer and PduRTxBuffer can be changed at post-build time even though this is not supported
- ► ASCPDUR-1677 Fixed known issue: Invalid reference to SCHM\_PDUR\_EXCLUSIVE\_AREA\_0 in PduR\_Bswmd.arxml
- ► ASCPDUR-1722 Fixed known issue: PduR\_LoTpCopyTxData() returns wrong value in a multicast transmission if the available data size is requested with SduLength 0

#### Module version 5.3.3

2012-12-14

► ASCPDUR-1510 Fixed known issue: A compilation error may occur when zero cost optimization, i.e. the parameter PduRZeroCostOperation is enabled

#### Module version 5.3.2

2012-11-14

- ASCPDUR-1645 Fixed known issue: Upper layer APIs are called with wrong TxPduId
- Implemented AUTOSAR 4.0 TP gateway and multicast functionality

#### Module version 5.3.1

2012-10-12

Changed the top-level structure of the software-component description in the arxml files from /AUTOSAR/PduR to /AUTOSAR PduR

# Module version 5.3.0

2012-09-14

- Updated to AUTOSAR 4.0 ComStack Handle ID policy
- Updated CancelReceive, CancelTransmit and ChangeParameter functionality to Rev 3

Module version 5.2.0

2012-08-17



- Implemented AUTOSAR 4.0 TP APIs for single cast
- Removed Dem handling according to AUTOSAR 4.0 Rev 3

2012-06-15

- ASCPDUR-1520 Fixed known issue: Generated Basic Software Module Description (BSWMD) of PduR is invalid
- Implemented support for the post-build configuration manager

#### Module version 5.1.1

2012-04-20

► ASCPDUR-1495 Fixed known issue: Double inclusion of memory section PDUR\_START\_SEC\_CODE/
PDUR STOP SEC CODE may lead to build or runtime errors

#### Module version 5.1.0

2012-03-16

- Added generation of BSWMD
- ▶ Modified SchM Enter/Exit() calls to match AUTOSAR 4.0
- ▶ Updated naming scheme of symbolic name values to AUTOSAR 4.0 Rev 3
- Implemented DET call to uninitialized PduR GetConfigurationId

# Module version 5.0.4

2012-02-17

ASCPDUR-1455 Fixed known issue: If multicast is configured to only one lower layer communication interface module, a compilation error is reported

#### Module version 5.0.3

2012-01-20

- ► ASCPDUR-1435 Fixed known issue: Corrupted I-PDU may be copied to destination by TriggerTransmit
- Implemented zero cost operation



- ► ASCPDUR-1443 Fixed known issue: The PduR will not compile if an upper layer module does not provide a TxConfirmation function
- Defined APIs for interaction with upper or lower layer modules are defined in single file (PduR\_AdjLay-erApi.c)
- Implemented separate enabling/disabling of Handle ID calculation for each adjacent module

2011-12-09

- ASCPDUR-1394 Fixed known issue: If multicast is configured with only one lower layer transport protocol module, a compilation error is reported
- ► ASCPDUR-1423 Fixed known issue: An error is reported if LinTp functions CancelTransmit(), CancelReceive() and ChangeParameter() are disabled

#### Module version 5.0.1

2011-09-30

- ► ASCPDUR-1351 Fixed known issue: When gatewaying non TP-PDUs, the SduLength is not updated in the PduInfoPtr parameter passed to PduR <Lo>TriggerTransmit()
- ► ASCPDUR-1356 Fixed known issue: ChangeParameter functionality for Dcm is not supported but is enabled in recommended configuration for PduR
- ASCPDUR-1354 Fixed known issue: LoTp module does not compile due to missing type definition
- ► ASCPDUR-1357 Fixed known issue: Auxiliary function PduR\_DtctRxPathOvrAllLoTpConfigs is not linkable
- ASCPDUR-1220 Fixed known issue: If Com.h and PduR.h are included in the same translation unit, a linker error may occur
- ASCPDUR-1359 Fixed known issue: PduR incorrectly routes I-PDUs that are not configured in PduR to upper layer modules

#### Module version 5.0.0

2011-09-02

Initial AUTOSAR 4.0 version

#### 3.3.5.2. New features

No new features have been added since the last release.



# 3.3.5.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

Optimization Impact of pre-compile time switches in parameter description of XDM

# Description:

The impact of enabling/disabling of any pre-compile time switch on resource consumption with respect to RAM Usage (configuration), ROM Usage (configuration), RAM Usage (static code), ROM Usage (static code) and Execution time is stated.

Support RAM sizes usage of more than 64 KiB

The RAM size is not limited by 64 KiB, if the configuration parameter PduRMemorySizeExtension is set to TRUE.

Connection to AUTOSAR 3.2 upper layer modules with TP interface

# Description:

Routing to an AUTOSAR 3.2 upper layer module with TP interface can be configured the same way as for an AUTOSAR 4.0 module. The configuration parameters PduRMaxRxPduId and PduRMaxTxPduId have to be set in the PduRBswModules container of the PduR module appropriately. To avoid wasting RAM, the Handle IDs within the upper layer module should be zero-based and dense.

The configuration parameter PduRASR32RevisionCompatibility enables or disables the passing of return values of AUTOSAR 3.2 upper layer modules for dedicated AUTOSAR 3.2 revisions on Rx side.

Smarter buffer selection algorithm for routing on-the-fly

#### Description:

Parameter PduRRotfBufferAssignmentStrategy allows to select different buffer assignment strategies for routing on-the-fly.

Configuring to NEXT\_TO\_TPTHRESHOLD handles Autosar specified case with the available TP buffer next in size greater or equal than PduRTpThreshold selected.

Configuring to NEXT\_TO\_SDULENGTH chooses the available TP buffer next in size smaller or equal than TpSduLength of StartOfReception. If no Tp buffer in the range of PduRTpThreshold and TpSduLength is available, the next in size greater than TpSduLength is selected.

Multicast of TP-PDUs with highest wins strategy

By enabling PduRMulticastTpHighestWinsStrategy the multicast (gateway) TP-PDUS are handled with the highest wins strategy instead of the lowest wins strategy. With the lowest wins strategy a single failing destination (e.g. FlexRay looses synchronization) causes the complete transmission to be aborted. With the highest wins strategy, single failing destinations allow non-failing destinations to proceed. While



the AUTOSAR 4.0.3 version relies on the lowest wins strategy, the later AUTOSAR versions rely on the more optimistic approach of a highest wins strategy.

Allow multiple frames for multicast gateway transmission if only one destination PDU is reachable

Multicast gateway transmission (from a transport protocol module to transport protocol modules) is specified by AUTOSAR 4.0.3 for single frames only. With the routing path groups functionality, destination PDUs can be disabled at runtime. If only one destination is enabled at run-time, it is considered as a 1:1 gateway relation further on and, thus, allowing usage of multiple frames (FF and CFs).

Support of N:1 PDU routing

Support of N:1 PDU routing is introduced according to AUTOSAR 4.3.0.

The gateway routing in an N:1 manner is supported in enabling PduRNtolRoutingSupport.

With enabled N:1 routing by parameter PduRNtolRoutingSupport and enabled Tp gateway queueing by PduRTpGwQueueEnable, respective N:1 TP gateway routing paths can be configured with a queue depth greater than one (configurable with PduRTpGwQueueDepth).

TP Gateway Queuing

Enabling general parameter PduRTpGwQueueEnable allows to queue incoming TP gateway requests. The number of requests that can be handled is given by PduRTpGwQueueDepth for considered routing path.

Incoming TP gateway requests for the same N-SDU ID are queued unless a TxConfirmation finishes the ongoing transmission. The queued requests are processed once the previous transmission has completed.

Decoupling functionality for gateway and multicast operations

Enabling general parameter PduRMultiCoreSupport allows to decouple PduR functionality for multicore purpose and distribute BSW to multiple partitions.

Optimization for gateway I-PDUs of static size

Description:

If all I-PDUs of a lower layer communication interface module that are routed via a Tx-buffer to a lower layer module are of fixed size, the PduR module allows optimization in enabling parameter PduRStaticPduLengthSupport of the associated source module of the PduRBswModules container.

Zero Cost Operation for IF and TP modules

Enabling this functionality by configuration parameter PduRZeroCostOperation defines a macro layer for communication interface modules and/or transport protocol modules if only one related upper/lower module in the PduRBswModules container is enabled. E.g. the communication interface functionality is replaced by a macro layer if Canlf and Com are the only one enabled.



# 3.3.5.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

Minimum routing capability

# Description:

The minimum routing capability is not supported (reference to product description: ASCPD-14)

This comprises also the following:

- ► The undefined enumeration value PDUR REDUCED for the PduR StateType (PDUR0742).
- ► The unused production error code PDUR E INIT FAILED (PDUR100).

Additionally, the restrictively specified configuration class PreCompile of parameter PduRIsMinimum-Routing violates the post-build loadable concept by rule EB08 for the container list PduRRoutingTables and PduRRoutingTable.

#### Requirements:

PDUR285, PDUR286, PDUR324, PDUR327, PDUR329, PDUR100, PDUR221, PDUR0742, PDUR106, PDUR306\_Conf

Symbolic source module PDU IDs are generated to PduR SymbolicNames PBcfg.h

# Description:

The requirement [ecuc\_sws\_2108] states that symbolic source module PDU IDs should be generated to the PduR module's header file. An example below the requirement shows that these IDs should be generated to <Module>\_cfg.h. The EB module configuration generator does not generate the source module PDU IDs into the file PduR\_Cfg.h. Instead of this, the source module PDU IDs are generated to the file PduR\_SymbolicNames\_PBcfg.h. Furthermore the file PduR\_SymbolicNames\_PBcfg.h is included by the header file PduR\_PBcfg.h.

#### Rationale:

- The generated symbolic source module PDU IDs are not used within the EB AUTOSAR modules
- Changes in the symbolic source module PDU IDs cause other modules which include header files from the module PduR to recompile unnecessarily.

# Requirements:

ecuc\_sws\_2108

Lo Transmit called by PduR LoTxConfirmation for triggered data provision of non-empty FIFO

#### Description:



The Lo\_Transmit is called by PduR\_LoTxConfirmation instead of PduR\_LoTriggerTransmit in case of a gateway to a communication interface module with triggered data provision when the FIFO buffer is non-empty.

Requirements:

PDUR640, PDUR0666 (second part of the requirement)

Rationale:

The gateway to a communication interface module is provided the way of AUTOSAR 3.x.

Transmit cancellation from upper communication interface module not supported (reference to product description: ASCPD-24)

Description:

The PduR deviates from the description in AUTOSAR R4.0 Rev 2 SWS section 7.2. *Cancel transmission* in that it allows no transmit cancellation for communication interface modules.

Requirements:

PDUR0721, PDUR0723, PDUR0700, PDUR0701, PDUR424, PDUR0769, PDUR0710

Unsupported cancel transmit functionality for multicasted SF-TP PDUs

Description:

PduR <Up>CancelTransmit function does not support multicast SF-TP PDUs.

Requirements:

PDUR0724, PDUR0701, PDUR0729, PDUR0730

File structure differs to AUTOSAR specification

Description:

The code file structure differs by requirement PDUR226 since a different strategy is applied where PduR\_-Cfg.c is not needed but PduR\_Lcfg.c.

The header file structure differs by requirement PDUR132 in the following:

- PduR.h does not include PduR Lcfg.h.
- PduR.h does not include directly PduR Types.h and PduR Cfg.h.
- PduR\_Cfg.h does not include the <module>\_PduR.h and <module>\_Cbk.h.
- Det.h is not included directly to the implementation.

# Requirements:



PDUR226, PDUR132

Usage of AUTOSAR 3.1 reentrancy

Description:

Instead of the new reentrancy concept for APIs introduced in AUTOSAR 4.0, the AUTOSAR 3.1 reentrancy concept is used.

Rationale:

The reentrancy concept of the PduR in AUTOSAR 4.0.2/4.0.3 shows several critical lacks and is removed in AUTOSAR 4.1.1. See <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=51758">http://www.autosar.org/bugzilla/show\_bug.cgi?id=51758</a>.

Requirements:

PDUR630, PDUR622, PDUR624

Prioritization of multicast destination I-PDUs

Description:

The prioritization of multicast destination I-PDUs is not handled by the generator. This comprises the requirements:

- PDUR635: If there is a multicast (1:n, n>1) transmission, the PDU Router module shall call them in routing path ID order with the lowest ID first.
- PDUR618: In case an I-PDU is multicasted or gatewayed to more than one destination, the configuration parameter routing path's Handle ID denotes the order in which the destinations are served. The lowest Handleld is served first.

#### Rationale:

PDUR618: The requirement is removed with Bugzilla entry <a href="http://www.autosar.org/bugzilla/show\_-bug.cgi?id=52882">http://www.autosar.org/bugzilla/show\_-bug.cgi?id=52882</a>.

Requirements:

PDUR635, PDUR618

Unsupported error codes

Description:

The following error codes listed in requirement PDUR100 are not supported due to the reason given below:

PDUR\_E\_PARAM\_INVALID: No need to apply this error code. See Bugzilla entry <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=51765">http://www.autosar.org/bugzilla/show\_bug.cgi?id=51765</a>.



- PDUR\_E\_DUPLICATE\_IPDU\_ID: Incomplete, ambiguous and unclear definition of requirement PDUR622 and reentrancy at all. See Bugzilla entry <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?">http://www.autosar.org/bugzilla/show\_bug.cgi?</a> id=51758.
- PDUR\_E\_IPDU\_TOO\_LONG: No need to apply this error code. See Bugzilla entry <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=51765">http://www.autosar.org/bugzilla/show\_bug.cgi?id=51765</a>.
- ▶ PDUR\_E\_INIT\_FAILED: The feature minimum routing is not supported.

# Requirements:

#### PDUR100, PDUR624

Distinguish name of PduR <Up>Transmit when Up allows both API archetypes

#### Description:

The function PduR\_<User:Up>Transmit shall be defined with a different API name for modules that support communication interface as well as transport protocol I-PDUs. For example PduR\_ComTransmit and PduR\_ComTpTransmit.

#### Requirements:

#### **PDUR406**

Imprecise description of requirement PDUR662

# Description:

Requirement PDUR662: If the destination communication interface module is requesting the I-PDU buffer that uses PduR\_<DstLo>TriggerTransmit and the buffer is not available the return value E\_NOT\_-OK shall be used.

#### Rationale:

Discussions on that issue, especially what is meant by *buffer is not available*, are still ongoing. See Bugzilla entry <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=52286">http://www.autosar.org/bugzilla/show\_bug.cgi?id=52286</a> or <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=52286">http://www.autosar.org/bug.cgi?id=52286</a> or <a href="http://www.autosar.org/bug.cgi?id=52286">http://www.autosar.org/bug.cgi?id=52286</a> or <a href="http://www.autosar.org/bug.cgi?id=52286">http://www.autosar.org/bug.cgi?id=52286</a>

EB-interpretation with respect to the considered RfC: For a destination communication interface module requesting buffer through a call of  $PduR\_<DstLo>TriggerTransmit$  for an I-PDU which has PduRTxBufferDepth>1, the first buffer initialized by the default values with  $PduR\_Init()$  is returned with  $E\_OK$ . The same applies to an I-PDU which has PduRTxBufferDepth=1 configured.

# Requirements:

#### PDUR662

Deviation of service IDs



#### Description:

The specification of service IDs has been changed several times. The specification according to AUTOSAR 3.1 is used instead.

Requirements:

PDUR0780, PDUR0781, PDUR0782

Changed signature of PduR\_<User:Up>Transmit

# Description:

By requirement PDUR406, the function PduR\_<User:Up>Transmit is defined as Std\_ReturnType PduR\_<User:Up>Transmit( PduIdType id, PduInfoType\* info). In contrast to this, the EB-implementation defines the function as Std\_ReturnType PduR\_<User:Up>Transmit( PduIdType id, const PduInfoType\* info).

#### Rationale:

Usage of the qualifier const for PduInfoType: All the adjacent modules apply this qualifier for PduInfoType and also the GenericComServices\_Transmit. See <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=51374">http://www.autosar.org/bugzilla/show\_bug.cgi?id=51374</a>).

# Requirements:

#### PDUR406

Changed signature of PduR\_<User:LoTp>CopyRxData

# Description:

By requirement PDUR512, the function PduR\_<User:LoTp>CopyRxData is defined as BufReq\_ReturnType PduR\_<User:LoTp>CopyRxData(PduIdType id, PduInfoType\* info, PduLengthType\* bufferSizePtr). In contrast to this, the EB-implementation defines the function as BufReq\_ReturnType PduR\_<User:LoTp>CopyRxData(PduIdType id, const PduInfoType\* info, PduLengthType\* bufferSizePtr).

#### Rationale:

Due to the generic usage of <code>GenericComServices\_CopyRxData</code>, the <code>CopyRxData</code> APIs shall be unified as described by Bugzilla entry <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=56021">http://www.autosar.org/bugzilla/show\_bug.cgi?id=56021</a> in providing the qualifier <code>const</code> to the type <code>PduInfoType\*</code>.

# Requirements:

# PDUR512

Unsupported TP (multicast) gateway requirements



Description:

The following requirements associated with the TP (multicast) gateway are not supported:

#### Rationale:

PDUR624: It is assumed that the requirement is meant for single cast. The requirement is removed by AUTOSAR Bugzilla RfC #55453: <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=55453">http://www.autosar.org/bugzilla/show\_bug.cgi?id=55453</a>.

PDUR0779: The requirement is removed with AUTOSAR 4.1 by AUTOSAR Bugzilla RfC #51765: <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=51765">http://www.autosar.org/bugzilla/show\_bug.cgi?id=51765</a>. The considered error could only happen if the TP is wrongly implemented.

Requirements:

PDUR624, PDUR0779

No AUTOSAR Debugging support

Description:

The requirements associated with AUTOSAR Debugging are not supported. This comprises all requirements mentioned within the section *Debugging*.

Rationale:

EB tresos Debug & Trace is intended to be used.

Requirements:

PDUR487, PDUR488, PDUR489, PDUR490

No consistency check between code files and header files

Description:

According to the PduR SWS, the PduR module shall perform inter-module version checks.

Rationale:

Module consistency check is not within the responsibility of the basic software but part of configuration management and delivery process.

Requirements:

**PDUR0774** 

Unsupported AUTOSAR configuration parameter PduRRetransmission

Description:



Optimizing the static BSW with respect to retransmission of transport protocol modules as part of a direct-gateway is not provided.

Requirement:

PDUR332 Conf

▶ Unsupported AUTOSAR configuration parameter PduRUseTag

Description:

The AUTOSAR configuration parameter PduRUseTag is not supported.

Rationale:

A different strategy is applied in using property files for all adjacent modules. This allows to overrule the generated API names without usage of PduRUseTag.

Requirement:

PDUR319\_Conf

Unsupported AUTOSAR configuration parameter PduRBswModuleRef

Description:

The AUTOSAR configuration parameter PduRBswModuleRef is not supported.

Rationale:

A different strategy is applied in using property files for all adjacent modules. The information necessary is provided therein, e.g. API names of a CDD.

Requirement:

PDUR294\_Conf, PDUR504

Unsupported AUTOSAR configuration parameter PduRMaxTxBufferNumber

Description:

The AUTOSAR configuration parameter PduRMaxTxBufferNumber is not supported.

Rationale:

There is no stringent need for the AUTOSAR parameter PduRMaxTxBufferNumber, see AUTOSAR Bugzilla RfC #59190: http://www.autosar.org/bugzilla/show\_bug.cgi?id=59190.

Requirement:



PDUR331\_Conf

Unsupported AUTOSAR configuration parameter PduRMaxTpBufferNumber

Description:

The AUTOSAR configuration parameter PduRMaxTpBufferNumber is not supported.

Rationale:

There is no stringent need for the AUTOSAR parameter PduRMaxTpBufferNumber, see AUTOSAR Bugzilla RfC #59190: http://www.autosar.org/bugzilla/show\_bug.cgi?id=59190.

Requirement:

PDUR330\_Conf

Support of configuration variant post-build (reference to product description: ASCPD-77)

Description:

The PduR module supports only configuration variant post-build. This is handled in restricting the range of configuration parameter IMPLEMENTATION\_CONFIG\_VARIANT to VariantPostBuild leading to violation of rule EcucSws 6051.

Requirements:

PDUR425, PDUR287, PDUR619

Allow configuration class PostBuild to some AUTOSAR parameters of class PreCompile

Description:

Some AUTOSAR configuration parameters are restricted to configuration class PreCompile for all variants. The following parameters are provided with added configuration class PostBuild and thus violate rule EcucSws\_6051 due to the following reason:

- PduRConfigurationId: Allow post-build loadable concept as stated by AUTOSAR Bugzilla RfC #53197, see <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=53197">http://www.autosar.org/bugzilla/show\_bug.cgi?id=53197</a>.
- PduRIsEnabledAtInit: Allow post-build loadable concept as stated by AUTOSAR Bugzilla RfC #53197, see <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=53197">http://www.autosar.org/bugzilla/show\_bug.cgi?id=53197</a>.
- PduRTpThreshold: Allow post-build loadable concept as stated by AUTOSAR Bugzilla RfC #53197, see <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=53197">http://www.autosar.org/bugzilla/show\_bug.cgi?id=53197</a>.
- PduRTransmissionConfirmation: Wrongly classified as stated by AUTOSAR Bugzilla RfC #58298, see <a href="http://www.autosar.org/bugzilla/show\_bug.cgi?id=58298">http://www.autosar.org/bugzilla/show\_bug.cgi?id=58298</a>.

Requirements:



PDUR327\_Conf, PDUR329\_Conf, PDUR320\_Conf

Software and specification version number solely defined within PduR Version.h.m4

Description:

Requirement PDUR0762 is specified in providing a software and specification version number to all PDU Router header files, not a single one.

Rationale:

A different strategy is applied defining the software and specification number within single header file PduR Version.h.m4. This comprises EB coding guidelines BSWM GEN 007 and BSWM GEN 009.

Requirements:

PDUR0762

# 3.3.5.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

Restricted number of destination modules for TP multicast transmission

Description:

The TP multicast transmission (1:n, n>1) of an I-PDU from a local module to n transport protocol modules is restricted to n < 16 destinations.

Rationale:

This reduces the consumption of RAM.

Requirements:

PDUR634

Restricted multiplicity of container PduRRoutingTable

Description:

The upper multiplicity of container PduRRoutingTable is restricted to 1.

Rationale:

There is always exactly one PduRRoutingTable as assumed by the IpduM module and also ensured by the xdm check.



Restricted support of PDUs with more than 64 KiB of user data

# Description:

With EcuC parameter PduLengthTypeEnum configured to UINT32, the module is basically allowed to handle PDUs with user data of more than 64 KiB.

For TP-PDUs, this is restricted to

- singlecast transmission and
- singlecast reception.

NonTp-PDUs are not allowed to handle more than 64 KiB of user data at all.

# Rationale:

In order to support the SomelpTp module, which is designed to handle TP-PDUs greater than 64 KiB, only the use cases singlecast transmission and singlecast reception are required.

TP gateway as well as TP multicast is not a use case in combination with the SomelpTp module.

For nonTP-PDUs, the PduRPduMaxLength is limited to 255 by AUTOSAR.

# 3.3.5.6. Open-source software

PduR does not use open-source software.



# 4. ACG8 COM Services user guide

# 4.1. Overview

The ACG8 COM Services user's guide provides information about the concepts of network-independent communication services in the AUTOSAR context. Before you read this user's guide, read the general concepts about communication stacks in AUTOSAR that are described in the EB tresos AutoCore Generic documentation.

Section 4.2, "Background information" describes the concept of the network-independent communication in the AUTOSAR context.

# 4.2. Background information

This chapter provides general information about network-independent communication concepts in the AUTOSAR context. If you are not familiar with the general concepts of communication in AUTOSAR, read the general information provided in the EB tresos AutoCore Generic documentation first.

# 4.2.1. Network-independent and network-dependent communication in AUTOSAR

The AUTOSAR communication stack can be divided into a *network-independent* and a *network-dependent* part.

The following sections provide further details about network-independent communication:

- Section 4.2.1.1, "Modules and dependencies of the network-independent communication stack" describes the modules and dependencies of the network-independent communication stack.
- Section 4.2.1.2, "Data transmission in the network-independent communication stack" describes the data transmission in the network-independent communication stack.

You find information about the network-dependent communication in the user's guides in the network-dependent product documentation.

# 4.2.1.1. Modules and dependencies of the network-independent communication stack



This chapter describes the modules of the network-independent part of the communication stack together with their dependencies. Since the modules of the network-independent part of the communication stack do not depend on the communication protocols, only generic versions of these modules are present in EB tresos AutoCore. The following text gives you a short overview of these modules.

# PDU Router (PduR):

The PDU Router module provides two major services:

- 1. It dispatches PDUs received via the underlying modules (i.e., Interface and Transport Layer modules) to the higher layers (Com, Dcm) and vice versa.
- 2. The PDU Router *performs gateway functionalities* between communication networks by forwarding PDUs from one Interface to another of either the same (e.g., FlexRay to FlexRay) or of a different type (e.g., CAN to FlexRay). Routing decisions in the PDU Router are based on a static routing table and on the identifiers of the PDUs.

#### PDU Multiplexer (IpduM)

The PDU Multiplexer module takes care of *multiplexing parts of a PDU*. Hereby, the value of a dedicated part of the PDU (the *multiplexer switch*) is used to define the semantic content of the remainder of the PDU. This works just like the tag element in a variant record or a union in programming languages. In the reception case, multiplexed PDUs are forwarded from the PduR to the IpduM for demultiplexing. Once demultiplexed, the IpduM hands the PDUs back to the PduR. In the sending case, the PduR obtains a PDU from Com and hands this PDU to the IpduM for multiplexing. The IpduM returns the multiplexed PDU to the PduR, which routes the multiplexed PDU to its final destination.

Note that the multiplexing features of the IpduM are limited to Com I-PDUs (i.e., I-PDUs sent or received by Com).

#### Communication (Com):

The Com module provides signal-based inter-ECU communication to the upper layer (Rte). On the sender side Com packs multiple signals into a PDU and forwards this PDU to the PduR in order to issue the PDU's transmission via the respective Interface module. On the receiver side, the Com module obtains a PDU from the PDU router, extracts the signals contained in the PDU, and forwards the extracted signals to the upper software layer (Rte).

# Diagnostic Communication Manager (Dcm):

The Diagnostic Communication Manager module is a sub-module of the AUTOSAR diagnostic stack. The Dcm module provides *services which allow a tester device to control diagnostic functions* in an ECU via the communication network (i.e., CAN, LIN, FlexRay). Hereby the Dcm supports the diagnostic protocols OBD [3] and UDS [2].

# 4.2.1.2. Data transmission in the network-independent communication stack

This chapter enables you to understand the data transmission of the network-independent communication stack. Specifically the topics signals and signal groups, transmission modes and I-PDU groups are addressed.



#### 4.2.1.2.1. Signals and signal groups

This chapter provides information about signals and signal groups exchanged by the <code>Com module</code>. At the API provided by the <code>Com module</code>, sender and receiver exchange signals as basic communication objects. Supported data types of these signals are *primitive* data types (e.g., int, char, etc.) as well as *opaque* data types (transmitted as an array of bytes). The <code>Com API</code> functions <code>Com\_SendSignal()</code> and <code>Com\_ReceiveSignal()</code> enable the transmission and reception of signals.

In order to simplify the *atomic* transmission and reception of structured data types (i.e., structs of the C programming language), Com provides facilities to group multiple signals into a signal group. The value of a signal, which is part of a signal group, can be updated via the API call Com\_UpdateShadowSignal(). The atomic transfer of all updated signals of a group into the corresponding I-PDU can be issued via the API call Com\_SendSignalGroup(). At the receiver side the Com module provides the API function Com\_-ReceiveSignalGroup() to atomically receive all signals contained in the group and the API call Com\_-ReceiveShadowSignal() to read the value of a single signal of this group.

For both signal and signal group transmission, the Com module takes care of the

- endianness conversion from the sending ECU's endianness to the endianness defined for the transmission (network endianness),
- the packing of multiple signals into a single I-PDU,
- and the transmission of this I-PDU depending on the configured transmission mode (see <u>Section 4.2.1.2.2</u>, <u>"Transmission modes and transfer properties"</u>).

At the receiving ECU, the Com module

- unpacks the signals from the received I-PDU,
- performs an endianness conversion from the network endianness into the endianness of the receiving ECU,
- and carries out a sign extension of the received value for signals of signed type.

#### 4.2.1.2.2. Transmission modes and transfer properties

The way an I-PDU is sent out by the Com module is called the *I-PDU transmission mode*. Com supports up to two transmission modes per I-PDU. During run-time a switch between these two transmission modes is possible.

Depending on the transmission mode, the sending of an I-PDU may be triggered

by the lower layer (transmission mode *none* 1)

<sup>&</sup>lt;sup>1</sup>In case of transmission mode none, Com does not initiate the transmission of the I-PDU by calling PduR\_ComTransmit(), but the transmission is triggered by the temporal schedule of the interface module(s) (i.e., by the job list of the FrIf or the schedule table of the



- by Com-internal timers (transmission mode *periodic*),
- or by signals with *triggered* transfer property (see below) (transmission mode *direct* or *n-times*<sup>2</sup>).

Even a combination of periodic and direct/n-times transmission mode is supported (transmission mode mixed).

In addition to the I-PDU transmission modes of <code>Com</code>, two different transfer properties for signals are supported, namely triggered transfer and pending transfer. In direct/n-times or mixed transmission mode, updating a signal with triggered transfer property via the API call <code>Com\_SendSignal()</code> immediately transmits the corresponding I-PDU. As opposed to that, updating a signal with pending transfer property does not trigger an immediate transmission.

#### 4.2.1.2.3. I-PDU groups

In the Com module multiple I-PDUs can be grouped into an  $\emph{I-PDU}$  group. This grouping takes place in a recursive manner, which means that one I-PDU group consisting of multiple I-PDUs can itself be a member of some other I-PDU group. The transmission and reception of configured I-PDU groups can be started and stopped via the API call  $Com_{pdu}GroupControl()$ . You can configure the BswM module to use this grouping feature, for example, to stop the transmission of all I-PDUs when the ComM module reports the internal state silent communication by calling  $BswM_ComM_CurrentMode()$ . It does so by stopping an I-PDU group that contains all transmit I-PDUs of an ECU.

Stopping an I-PDU on the sender side yields the following behavior:

- The signal's values updated via Com\_SendSignal() are still stored within the respective I-PDU buffer, but no transmission of the I-PDU is initiated.
- The transmission deadline monitoring for this I-PDU (and thus for the contained signals) is disabled.

Stopping an I-PDU on the receiver side leads to the following behavior:

- ▶ Upon an invocation of Com\_RxIndication() no data is copied into the I-PDU buffer of Com.
- Therefore calls to Com\_ReceiveSignal() yield the last signal value received prior to the call of Com\_IpduGroupControl().
- The reception deadline monitoring for this I-PDU (and thus for the contained signals) is disabled.

LinIf. These temporal schedules invoke the PduR\_<Net>IfTriggerTransmit() at the appropriate point in time, which then calls Com TriggerTransmit() in order to retrieve the data from Com's I-PDU buffers.,

<sup>&</sup>lt;sup>2</sup>The n-times transmission mode is a special case of the direct transmission mode. In this mode the first transmission is triggered by the update of a signal with triggered transfer property. After this first transmission Com issues n subsequent transmissions with a given retransmission period (n and the retransmission period are configureable on a per I-PDU basis).



# 4.3. LdCom module user guide

#### 4.3.1. Overview

This user guide describes the LdCom module. From this user guide you will learn more about the basic functionality of the LdCom. You will also learn which related modules are necessary to configure the LdCom module. The LdCom module reference provides further information on configuring the LdCom itself.

This user guide is intended for readers who have good knowledge of AUTOSAR and about the purpose of the LdCom. The information provided here should help you to integrate the LdCom in your AUTOSAR project.

- Section <u>Section 4.3.2, "Background Information"</u> provides an overview of the basic functionality of the LdCom.
- Section <u>Section 4.3.3, "Configuring the LdCom module"</u> provides information on related modules that are needed in order to configure the LdCom.
- For details on configuring the LdCom itself, refer to the parameter descriptions provided in the LdCom module reference Chapter 5, "ACG8 COM Services module references".

### 4.3.2. Background Information

The general concept about data transformation and large data transfer is described in the EB tresos AutoCore Generic documentation. If you are not familiar with this topic, see the section Data transformation that is part of the Concepts chapter in the generic documentation.

#### 4.3.2.1. Functional overview

The LdCom module provides an interaction layer mechanism which is optimized for the transmission of large byte array signals (see [4]). It is intended to be used with Data Transformation where arbitrarily complex data elements are serialized to a byte array.

It is used together with the module PduR to efficiently map one byte array signal to one PDU and transmit it via the PduR module for following communication paradigms:

Interface-like communication

LdCom provides APIs to transmit and receive unsegmented Pdus via PduR.

Transmission can be configurable to be done immediately (signal is copied within LdCom\_IfTransmit()) or to be triggered (e.g. from lower layer or due to a deferred transmission within a cyclic task) by using



the function LdCom\_TriggerTransmit() . That is, the signal is not copied within the function call of LdCom IfTransmit() but with a later call of the callback function LdCom TriggerTransmit() .

Transport Protocol-like communication

LdCom provides APIs to transmit and receive segmented Pdus via PduR. This allows the transmission of signals which are larger than the maximum frame size of the underlying bus.

### 4.3.3. Configuring the LdCom module

To configure the LdCom module, add the module to your project using EB tresos Studio. Parameter descriptions are provided to guide the configuration. You find these in the module references section of this document. You also find these in the parameter description in EB tresos Studio.

To use the LdCom module, you must configure additional modules as outlined below:

- ▶ RTE: The system description must contain a byte array system signal which is then referenced by LdCom in config parameter LdComSystemTemplateSignalRef. This system signal must not require additional features that are usually accomplished by the Com module (e.g. deadline monitoring). The Rte will search through all configured system signal references in LdCom and generates the respective function calls to LdCom for each configured system signal.
- Com Services: The PduR module has to configure LdCom as additional upper layer and add references to LdCom PDUs to its PduRRoutingTable.



# 5. ACG8 COM Services module references

### 5.1. Overview

This chapter provides module references for the ACG8 COM Services product modules. These include a detailed description of all configuration parameters. Furthermore this chapter lists the application programming interface with all data types, constants and functions.

The content of the sections is sorted alphabetically according the EB tresos AutoCore Generic module names.

For further information on the functional behavior of these modules, refer to the chapter ACG8 COM Services user's guide.

#### 5.1.1. Notation in EB module references

EB notation may differ from the AUTOSAR standard notation in the software specification documents (SWS). This section describes the notation of *default value* and *range* fields in the EB module references.

#### 5.1.1.1. Default value of configuration parameters

If there is no default value specified for a parameter, the default value field is omitted to prevent ambiguity with parameters that have — as default values.

Example: The parameter BswMCompuConstText of the BswM module of EB tresos AutoCore Generic 8 Mode Management has no default value field, therefore it is omitted.

#### 5.1.1.2. Range information of configuration parameters

The range of a configuration parameter contains an upper and a lower boundary. However, in special cases the range of allowed values can be computed by means of an XPath function that is evaluated at configuration time. An XPath function can either be a standard xpath:<function>() or a custom cxpath:<function>() function. The range of a configuration parameter may be computed based on other configuration parameters that are referenced from the XPath function. For more information on custom XPath functions, see section Custom XPath Functions API of the EB tresos Studio developer's guide.



Example: The parameter BswMCompuConstText of the BswM module of EB tresos AutoCore Generic 8 Mode Management has the custom XPath function <code>cxpath:getCompuMethodsVT()</code> in the range field which provides the allowed values.

# 5.2. Com

# **5.2.1. Configuration parameters**

| Containers included             |              |   |  |
|---------------------------------|--------------|---|--|
| Container name                  | Multiplicity | Description   |  |
| ComDefensiveProgramming         | 11           | Label: Defensive Programming Options  Parameters for defensive programming  |  |
| ComConfig                       | 1n           | This container contains the configuration parameters and sub containers of the AUTOSAR COM module. This container is a MultipleConfigurationContainer, i.e. this container and its sub-containers exist once per configuration set. |  |
| ComGeneral                      | 11           | Contains the general configuration parameters of the module.  |  |
| CommonPublishedInforma-<br>tion | 11           | Label: Common Published Information  Common container, aggregated by all modules. It contains published information about vendor and versions.  |  |
| PublishedInformation            | 11           | Label: EB Published Information Additional published parameters not covered by Common-PublishedInformation container.   |  |

| Parameters included           |    |  |
|-------------------------------|----|--|
| Parameter name Multiplicity   |    |  |
| IMPLEMENTATION_CONFIG_VARIANT | 11 |  |

| Parameter Name | IMPLEMENTATION_CONFIG_VARIANT |
|----------------|-------------------------------|
| Label          | Config Variant                |



| Multiplicity  | 11               |
|---------------|------------------|
| Туре          | ENUMERATION      |
| Default value | VariantPostBuild |
| Range         | VariantPostBuild |

## **5.2.1.1. ComDefensiveProgramming**

| Parameters included       |              |  |
|---------------------------|--------------|--|
| Parameter name            | Multiplicity |  |
| ComDefProgEnabled         | 11           |  |
| ComPrecondAssertEnabled   | 11           |  |
| ComPostcondAssertEnabled  | 11           |  |
| ComStaticAssertEnabled    | 11           |  |
| ComUnreachAssertEnabled   | 11           |  |
| ComInvariantAssertEnabled | 11           |  |

| Parameter Name      | ComDefProgEnabled   |                  |  |
|---------------------|---|------------------|--|
| Label               | Enable Defensive Programming  |                  |  |
| Description         | Enables or disables the defensive programming feature for the module Com.  Note: This feature is dependent on the use of the development error detection module. To use the defensive programming feature, proceed as follows:  1. Enable development error detection |                  |  |
|                     | <ol> <li>Enable defensive programming</li> <li>Enable assertions as required</li> </ol>   |                  |  |
| Multiplicity        | 11  |                  |  |
| Туре                | BOOLEAN   |                  |  |
| Default value       | false   |                  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH  |                  |  |

| Parameter Name | ComPrecondAssertEnabled        |
|----------------|--------------------------------|
| Label          | Enable Precondition Assertions |



| Description         | Enables handling of precondition assertion checks reported from the module Com. |                  |  |
|---------------------|---|------------------|--|
|                     | Dependency on parameter(s):   |                  |  |
|                     | ► Enable Development Error Detection (ComConfigurationUseDet): must be enabled  |                  |  |
|                     | ► Enable Defensive Programming (ComDefProgEnabled): must be enabled             |                  |  |
| Multiplicity        | 11  |                  |  |
| Туре                | BOOLEAN   |                  |  |
| Default value       | false   |                  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH  |                  |  |

| Parameter Name      | ComPostcondAssertEnabled   |                  |  |
|---------------------|--|------------------|--|
| Label               | Enable Postcondition Assertions  |                  |  |
| Description         | Enables handling of postcondition assertion checks reported from the module Com.   |                  |  |
|                     | Dependency on parameter(s):  ■ Enable Development Error Detection (ComConfigurationUseDet): must be enabled  ■ Enable Defensive Programming (ComDefProgEnabled): must be enabled |                  |  |
| Multiplicity        | 11   |                  |  |
| Туре                | BOOLEAN  |                  |  |
| Default value       | false  |                  |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH   |                  |  |

| Parameter Name | ComStaticAssertEnabled   |
|----------------|--|
| Label          | Enable Static Assertions   |
| Description    | Enables handling of static assertion checks reported from the module Com.  Dependency on parameter(s):  Enable Development Error Detection (ComConfigurationUseDet): must be enabled |



|                     | ► Enable Defensive Programming (ComDefProgEnabled): must be enabled |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name      | ComUnreachAssertEnabled   |                  |  |
|---------------------|---|------------------|--|
| Label               | Enable Unreachable Code Assertions  |                  |  |
| Description         | Enables handling of unreachable code assertion checks reported from the module Com. |                  |  |
|                     | Dependency on parameter(s):   |                  |  |
|                     | ► Enable Development Error Detection (ComConfigurationUseDet): must be enabled      |                  |  |
|                     | ► Enable Defensive Programming (ComDefProgEnabled): must be enabled                 |                  |  |
| Multiplicity        | 11  |                  |  |
| Туре                | BOOLEAN   |                  |  |
| Default value       | false   |                  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH  |                  |  |

| Parameter Name      | ComInvariantAssertEnabled   |                  |
|---------------------|---|------------------|
| Label               | Enable Invariant Assertions   |                  |
| Description         | Enables handling of invariant assertion checks reported from functions of the module Com. |                  |
|                     | Dependency on parameter(s):   |                  |
|                     | ► Enable Development Error Detection (ComConfigurationUseDet): must be enabled            |                  |
|                     | ► Enable Defensive Programming (ComDefProgEnabled): must be enabled                       |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |



| Origin | Elektrobit Automotive GmbH |
|--------|----------------------------|
|--------|----------------------------|

## 5.2.1.2. ComConfig

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| ComGwMapping        | 0n           |   |
| ComlPdu             | 1n           | Contains the configuration parameters of the AUTOSAR COM module's I-PDUs.   |
| ComlPduGroup        | 1n           | Contains the configuration parameters of the AUTOSAR COM module's I-PDU groups.   |
| ComSignal           | 0n           | Contains the configuration parameters of the AUTOSAR COM module's signals.  |
| ComSignalGroup      | 0n           | Contains the configuration parameters of the AUTOSAR COM module's signal groups.  |
| ComTimeBase         | 01           | Contains the timebase parameters for Tx, Rx and routing. If this parameter is omitted ComTxMainFunctions and ComRx-MainFunctions can be configured.   |
| ComTxMainFunctions  | 11           | Contains the transmission main functions of COM module.   |
| ComRxMainFunctions  | 11           | Contains the reception main functions of COM module.  |
| ComIPduCalloutsTx   | 11           | Contains ComlPdu transmission callout entries from all Post-Build-Selectable Variants of the COM module.  Only the reception function prototype (P2CONST PduInfoPtr) gets generated if the same ComlPdu callout entry is configured in the ComlPduCalloutsTx list and the ComlPduCalloutsRx list. |
| ComIPduCalloutsRx   | 11           | Contains ComIPdu reception callout entries from all Post-Build-Selectable Variants of the COM module.  Only the reception function prototype (P2CONST PduInfoPtr) gets generated if the same ComIPdu callout entry is configured in the ComIPduCalloutsTx list and the ComIPduCalloutsRx list.    |

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| ComConfigurationId  | 11           |  |



| Parameter Name      | ComConfigurationId                       |                  |
|---------------------|--|------------------|
| Description         | This ID is returned by a call to Com_Get | ConfigurationId. |
| Multiplicity        | 11                                       |                  |
| Туре                | INTEGER                                  |                  |
| Default value       | 0  |                  |
| Range               | <=4294967295                             |                  |
|                     | >=0                                      |                  |
| Configuration class | VariantPostBuild: VariantPostBuild       |                  |
| Origin              | AUTOSAR_ECUC                             |                  |

## 5.2.1.3. ComGwMapping

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| ComGwDestination    | 1n           | Each instance of this choice container allows to define one routing destination either by reference to an already configured COM signal / signal group or by a destination description container. |
| ComGwSource         | 11           | This choice container allows the definition of the gateway source signal either by reference to an already configured COM signal / signal group or by a source description container.             |

### 5.2.1.4. ComGwDestination

| Containers included         |              |   |
|-----------------------------|--------------|---|
| Container name              | Multiplicity | Description   |
| ComGwDestinationDescription | 11           | Description of a gateway destination. This container allows defining a gateway destination without the configuration of a complete COM signal. This allows adding / changing gateway relations post build without the configuration of new signals. |
| ComGwSignal                 | 11           | This container allows specifying a gateway source or destination respectively with a reference to a ComSignal, a ComGroupSignal or a ComSignalGroup.  |



## 5.2.1.5. ComGwDestinationDescription

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| ComFilter           | 01           | This container contains the configuration parameters of the AUTOSAR COM module's Filters.Note: On sender side the container is used to specify the transmission mode conditions. |

| Parameters included  |              |  |
|----------------------|--------------|--|
| Parameter name       | Multiplicity |  |
| ComBitPosition       | 11           |  |
| ComSignalEndianness  | 11           |  |
| ComSignalInitValue   | 01           |  |
| ComTransferProperty  | 01           |  |
| ComUpdateBitPosition | 01           |  |
| ComGwlPduRef         | 11           |  |

| Parameter Name      | ComBitPosition   |  |
|---------------------|--|--|
| Description         | Starting position within the I-PDU. This parameter refers to the position in the I-PDU and not in the shadow buffer. If the endianness conversion is configured to Opaque the parameter ComBitPosition shall define the bit0 of the first byte like in little endian byte order. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Range               | <=2031<br>>=0  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name | ComSignalEndianness  |  |
|----------------|--|--|
| Description    | Defines the endianness of the signal's network representation. |  |
| Multiplicity   | 11   |  |
| Туре           | ENUMERATION  |  |
| Range          | BIG_ENDIAN   |  |



|                     | LITTLE_ENDIAN                      |  |
|---------------------|------------------------------------|--|
|                     | OPAQUE                             |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | ComSignalInitValue   |   |
|---------------------|--|---|
| Description         | Initial value for this signal. In case of UINT8_N the default value is a string of length ComSignalLength with all bytes set to 0x00. In case of UINT8_DYN the initial size shall be 0. In case the ComSignalType is:  |   |
|                     | UINT8, UINT16, UINT32, UINT SINT64: the string shall be interpret Type in the AUTOSAR EcuC specifi   | ted as defined in the chapter Integer                           |
|                     | FLOAT32, FLOAT64: the string shater Float Type in the AUTOSAR Ecu  | all be interpreted as defined in the chap-<br>iC specification. |
|                     | ▶ BOOLEAN: the string shall be interpreted as defined in the chapter Boolean Type in the AUTOSAR EcuC specification.   |   |
|                     | ■ UINT8_N, UINT8_DYN: the string shall be interpreted as a decimal representation of the characters separated by blanks, e.g. "97 98 100" means a string "abd", where the char "a" is in byte 0(lowest address), "b" is in byte 1, and "d" is in byte 2 and (highest address). For the ComSignalType UINT8DYN the dynamic length shall be set to the number of configured characters. An empty string "" shall be interpreted as 0-sized dynamic signal. |   |
| Multiplicity        | 01   |   |
| Туре                | STRING   |   |
| Default value       | 0  |   |
| Configuration class | VariantPostBuild: VariantPostBuild   |   |
| Origin              | AUTOSAR_ECUC   |   |

| Parameter Name | ComTransferProperty  |
|----------------|--|
| Description    | Defines if a write access to this signal can trigger the transmission of the corresponding I-PDU. If the I-PDU is triggered, depends also on the transmission mode of the corresponding I-PDU. |
| Multiplicity   | 01   |
| Туре           | ENUMERATION  |
| Default value  | TRIGGERED  |
| Range          | PENDING  |



|                     | TRIGGERED                              |  |
|---------------------|--|--|
|                     | TRIGGERED_ON_CHANGE                    |  |
|                     | TRIGGERED_ON_CHANGE_WITHOUT_REPETITION |  |
|                     | TRIGGERED_WITHOUT_REPETITION           |  |
| Configuration class | PostBuild: VariantPostBuild            |  |
| Origin              | AUTOSAR_ECUC                           |  |

| Parameter Name      | ComUpdateBitPosition  |                  |
|---------------------|---|------------------|
| Description         | Bit position of update-bit inside I-PDU. If this attribute is omitted then there is no update-bit. This setting must be consistently on sender and on receiver side. Range: 063 for CAN and LIN 02031 for FlexRay |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=2031  |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComGwlPduRef   |  |
|---------------------|--|--|
| Description         | Reference to an I-PDU of a Signal Gateway source or destination description. |  |
| Multiplicity        | 11   |  |
| Туре                | REFERENCE  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

### 5.2.1.6. ComFilter

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| ComFilterAlgorithm  | 11           |
| ComFilterMask       | 01           |
| ComFilterMax        | 01           |



| Parameters included |    |
|---------------------|----|
| ComFilterMin        | 01 |
| ComFilterOffset     | 01 |
| ComFilterPeriod     | 01 |
| ComFilterX          | 01 |

| Parameter Name      | ComFilterAlgorithm  |                  |
|---------------------|---|------------------|
| Description         | The range of values is specified in the [17] specification, chapter 2.2.2, Reception Filtering. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | ALWAYS  |                  |
|                     | MASKED_NEW_DIFFERS_MASKED_OLD   |                  |
|                     | MASKED_NEW_DIFFERS_X  |                  |
|                     | MASKED_NEW_EQUALS_X   |                  |
|                     | NEVER   |                  |
|                     | NEW_IS_OUTSIDE  |                  |
|                     | NEW_IS_WITHIN   |                  |
|                     | ONE_EVERY_N   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComFilterMask  |                  |
|---------------------|--|------------------|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |                  |
| Multiplicity        | 01   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=18446744073709551615   |                  |
|                     | >=0  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name | ComFilterMax |
|----------------|--------------|
|----------------|--------------|



| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |  |
|---------------------|--|--|
| Multiplicity        | 01   |  |
| Туре                | INTEGER  |  |
| Range               | <=18446744073709551615   |  |
|                     | >=0  |  |
| Configuration class | PostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | ComFilterMin   |                  |  |
|---------------------|--|------------------|--|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |                  |  |
| Multiplicity        | 01   | 01               |  |
| Туре                | INTEGER  |                  |  |
| Range               | <=18446744073709551615   |                  |  |
|                     | >=0  |                  |  |
| Configuration class | PostBuild:   | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC   |                  |  |

| Parameter Name      | ComFilterOffset     | ComFilterOffset   |  |
|---------------------|---------------------|---|--|
| Description         |                     | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. Range = 0(ComFilterPeriod-1) |  |
| Multiplicity        | 01                  | 01  |  |
| Туре                | INTEGER             | INTEGER   |  |
| Range               | <=18446744073709551 | <=18446744073709551615  |  |
|                     | >=0                 |   |  |
| Configuration class | PostBuild:          | PostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC        |   |  |

| Parameter Name | ComFilterPeriod  |
|----------------|--|
| Description    | This parameter defines the period of the ComFilterAlgorithm ONE_EVERY_N. |
| Multiplicity   | 01   |
| Туре           | INTEGER  |
| Range          | <=18446744073709551615   |



|                     | >=0                         |  |
|---------------------|-----------------------------|--|
| Configuration class | PostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                |  |

| Parameter Name      | ComFilterX   |                  |  |
|---------------------|--|------------------|--|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |                  |  |
| Multiplicity        | 01   |                  |  |
| Туре                | INTEGER  |                  |  |
| Range               | <=18446744073709551615   |                  |  |
|                     | >=0  |                  |  |
| Configuration class | PostBuild:   | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC   |                  |  |

# 5.2.1.7. ComGwSignal

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| ComGwSignalRef      | 11           |  |

| Parameter Name      | ComGwSignalRef  |  |
|---------------------|---|--|
| Description         | Reference to an object of a gateway relation. Either to a ComSignal, Com-GroupSignal or to a SignalGroup. |  |
| Multiplicity        | 11  |  |
| Туре                | CHOICE-REFERENCE  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

#### 5.2.1.8. ComGwSource

| Containers included |              |             |
|---------------------|--------------|-------------|
| Container name      | Multiplicity | Description |



| Containers included    |    |   |
|------------------------|----|---|
| ComGwSignal            | 11 | This container allows specifying a gateway source or destination respectively with a reference to a ComSignal, a ComGroupSignal or a ComSignalGroup.  |
| ComGwSourceDescription | 11 | Description of a gateway source. This container allows defining a gateway source without the configuration of a complete COM signal. This allows adding / changing gateway relations post build without the configuration of new signals. |

## 5.2.1.9. ComGwSignal

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| ComGwSignalRef      | 11           |  |

| Parameter Name      | ComGwSignalRef  |  |
|---------------------|---|--|
| Description         | Reference to an object of a gateway relation. Either to a ComSignal, Com-GroupSignal or to a SignalGroup. |  |
| Multiplicity        | 11  |  |
| Туре                | CHOICE-REFERENCE  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

## 5.2.1.10. ComGwSourceDescription

| Parameters included         |              |  |
|-----------------------------|--------------|--|
| Parameter name              | Multiplicity |  |
| ComBitPosition              | 11           |  |
| ComBitSize                  | 01           |  |
| ComSignalEndianness         | 11           |  |
| ComSignalLength             | 01           |  |
| ComSignalType               | 11           |  |
| <u>ComUpdateBitPosition</u> | 01           |  |



| Parameters included |    |
|---------------------|----|
| <u>ComGwlPduRef</u> | 11 |

| Parameter Name      | ComBitPosition   | ComBitPosition   |  |
|---------------------|--|------------------|--|
| Description         | Starting position within the I-PDU. This parameter refers to the position in the I-PDU and not in the shadow buffer. If the endianness conversion is configured to Opaque the parameter ComBitPosition shall define the bit0 of the first byte like in little endian byte order. |                  |  |
| Multiplicity        | 11   | 11               |  |
| Туре                | INTEGER  | INTEGER          |  |
| Range               | <=2031<br>>=0  |                  |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC   |                  |  |

| Parameter Name      | ComBitSize  |                  |
|---------------------|---|------------------|
| Description         | Size in bits, for non-array signal types. For ComSignalType UINT8_N and UINT8_DYN this size shall be configured by ComSignalLength. |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=64  |                  |
|                     | >=0   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComSignalEndianness  |                  |
|---------------------|--|------------------|
| Description         | Defines the endianness of the signal's network representation. |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Range               | BIG_ENDIAN   |                  |
|                     | LITTLE_ENDIAN  |                  |
|                     | OPAQUE   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |



| Parameter Name      | ComSignalLength  |                  |
|---------------------|--|------------------|
| Description         | Description:. For ComSignalType UINT8_N this parameter specifies the length n in bytes. For ComSignalType UINT8_DYN it specifies the maximum length in bytes. For all other types this parameter shall be ignored. Range: 08 for normal CAN/ LIN I-PDUs, 0254 for normal FlexRay I-PDUs, and 04095 for I-PDUs with ComIPduType TP. |                  |
| Multiplicity        | 01   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=4095<br>>=0  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   | ·                |

| Parameter Name      | ComSignalType   |                  |  |
|---------------------|---|------------------|--|
| Description         | The AUTOSAR type of the signal. Whether or not the signal is signed or unsigned can be found by examining the value of this attribute. This type could also be used to reserved appropriate storage in AUTOSAR COM. |                  |  |
| Multiplicity        | 11  |                  |  |
| Туре                | ENUMERATION   |                  |  |
| Range               | BOOLEAN   |                  |  |
|                     | FLOAT32   |                  |  |
|                     | FLOAT64   |                  |  |
|                     | SINT16<br>SINT32  |                  |  |
|                     |   |                  |  |
|                     | SINT64  |                  |  |
|                     | SINT8   |                  |  |
|                     | UINT16  |                  |  |
|                     | UINT32  | UINT32           |  |
|                     | UINT64  | UINT64           |  |
|                     | UINT8   |                  |  |
|                     | UINT8_DYN   | UINT8_DYN        |  |
|                     | UINT8_N   |                  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC  |                  |  |



| Parameter Name      | ComUpdateBitPosition  |                  |
|---------------------|---|------------------|
| Description         | Bit position of update-bit inside I-PDU. If this attribute is omitted then there is no update-bit. This setting must be consistently on sender and on receiver side. Range: 063 for CAN and LIN 02031 for FlexRay |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=2031  |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComGwlPduRef   |                  |
|---------------------|--|------------------|
| Description         | Reference to an I-PDU of a Signal Gateway source or destination description. |                  |
| Multiplicity        | 11   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

### 5.2.1.11. ComlPdu

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| ComlPduCounter      | 11           | This optional container contains the configuration parameters of PDU Counter. NOTE: Data sequence control is not supported in this version.      |
| ComlPduReplication  | 11           | This optional container contains the information needed for each I-PDU replicated. NOTE: Data sequence control is not supported in this version. |
| ComTxlPdu           | 11           | This container contains additional transmission related configuration parameters of the AUTOSAR COM module's I-PDUs.                             |

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |



| Parameters included           |    |  |
|-------------------------------|----|--|
| ComlPduCallout                | 01 |  |
| ComlPduCancellationSupport    | 01 |  |
| ComlPduDirection              | 11 |  |
| ComlPduHandleId               | 11 |  |
| ComIPduSignalProcessing       | 11 |  |
| ComlPduTriggerTransmitCallout | 01 |  |
| ComlPduType                   | 11 |  |
| ComlPduGroupRef               | 1n |  |
| ComlPduSignalGroupRef         | 0n |  |
| ComlPduSignalRef              | 0n |  |
| ComPduldRef                   | 11 |  |
| ComMainFunctionRef            | 11 |  |

| Parameter Name      | ComlPduCallout   |                  |
|---------------------|--|------------------|
| Description         | This parameter defines the existence and the name of a callout function for the corresponding I-PDU. If this parameter is omitted no I-PDU callout shall take place for the corresponding I-PDU. |                  |
| Multiplicity        | 01   |                  |
| Туре                | FUNCTION-NAME  |                  |
| Configuration class | Link:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComlPduCancellationSupport  |                  |
|---------------------|---|------------------|
| Description         | Defines for I-PDUs with ComIPduType NORMAL:. If the underlying IF-modul supports cancellation of transmit requests. Defines for I-PDUs with ComIPdu-Type TP: If the underlying TP-module supports RX and TX cancellation of ongoing requests. |                  |
| Multiplicity        | 01  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name   ComlPduDirection | Parameter Name | ComlPduDirection |
|-----------------------------------|----------------|------------------|
|-----------------------------------|----------------|------------------|



| Description         | The direction defines if this I-PDU, and therefore the contributing signals and signal groups, shall be sent or received. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | RECEIVE   |                  |
|                     | SEND  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComlPduHandleId  |                  |
|---------------------|--|------------------|
| Description         | The numerical value used as the ID of this I-PDU. The ComIPduHandleId is required by the API calls to receive I-PDUs from the PduR (ComIP-duDirection: Receive). For Tx-I-PDUs (ComIPduDirection: Send) this handle Id is used by the PduR to confirm the transmission of the ComIPdu. In case no Tx-Confirmation is configured for a Tx-I-PDU, the ComIPduHandleId is not used. NOTE: Handle Ids for TxConfirmation is not supported. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=65535<br>>=0   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComIPduSignalProcessing                                     |                  |
|---------------------|---|------------------|
| Description         | For the definition of the two modes Immediate and Deferred. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Default value       | IMMEDIATE   |                  |
| Range               | DEFERRED  |                  |
|                     | IMMEDIATE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComlPduTriggerTransmitCallout |
|----------------|-------------------------------|
|----------------|-------------------------------|



| Description         | If there is a trigger transmit callout defined for this I-PDU this parameter contains the name of the callout function. |                  |
|---------------------|---|------------------|
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComlPduType  |                  |
|---------------------|--|------------------|
| Description         | Defines if this I-PDU is a normal I-PDU that can be sent unfragmented or if this is a large I-PDU that shall be sent via the Transport Protocol of the underlying bus. |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Default value       | NORMAL   |                  |
| Range               | NORMAL TP  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComlPduGroupRef                                      |                  |
|---------------------|--|------------------|
| Description         | Reference to the I-PDU groups this I-PDU belongs to. |                  |
| Multiplicity        | 1n   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComlPduSignalGroupRef                                    |  |
|---------------------|--|--|
| Description         | References to all signal groups contained in this I-Pdu. |  |
| Multiplicity        | 0n   |  |
| Туре                | REFERENCE  |  |
| Configuration class | PostBuild: VariantPostBuild                              |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name | ComlPduSignalRef |
|----------------|------------------|
| Parameter Name | Communication    |



| Description         | References to all signals contained in this I-PDU. |  |
|---------------------|--|--|
| Multiplicity        | 0n   |  |
| Туре                | REFERENCE  |  |
| Configuration class | PostBuild: VariantPostBuild                        |  |
| Origin              | AUTOSAR_ECUC                                       |  |

| Parameter Name      | ComPduIdRef  |                  |
|---------------------|--|------------------|
| Description         | Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack. |                  |
| Multiplicity        | 11   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComMainFunctionRef          |  |
|---------------------|-----------------------------|--|
| Multiplicity        | 11                          |  |
| Туре                | CHOICE-REFERENCE            |  |
| Configuration class | PostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH  |  |

### 5.2.1.12. ComlPduCounter

| Parameters included             |    |  |
|---------------------------------|----|--|
| Parameter name Multiplicity     |    |  |
| ComIPduCounterErrorNotification | 01 |  |
| ComIPduCounterSize              | 11 |  |
| ComIPduCounterStartPosition     | 11 |  |
| ComlPduCounterThreshold         | 01 |  |

| Parameter Name | ComlPduCounterErrorNotification  |  |
|----------------|--|--|
| Description    | Name of Com_CbkCounterErr callback function to be called. If this. parameter is omitted no I-PDU counter mismatch notification shall take place. |  |
| Multiplicity   | 01   |  |



| Туре                | FUNCTION-NAME                      |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | ComlPduCounterSize                     |  |
|---------------------|--|--|
| Description         | Size of PDU Counter expressed in bits. |  |
| Multiplicity        | 11                                     |  |
| Туре                | INTEGER                                |  |
| Range               | <=8                                    |  |
|                     | >=1                                    |  |
| Configuration class | VariantPostBuild: VariantPostBuild     |  |
| Origin              | AUTOSAR_ECUC                           |  |

| Parameter Name      | ComlPduCounterStartPosition   |                  |
|---------------------|---|------------------|
| Description         | Position of PDU counter expressed in bits from start position of data content. of I-PDU (SDU). Note that PDU counter is not allowed to cross a byte border. The parameter ComIPduCounterStartPosition shall define the bit0 of the first byte like in little endian byte order. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=2031<br>>=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComlPduCounterThreshold                                 |  |
|---------------------|---|--|
| Description         | Threshold value of I-PDU counter algorithm, see COM590. |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER   |  |
| Default value       | 0   |  |
| Range               | <=255   |  |
|                     | >=0   |  |
| Configuration class | VariantPostBuild: VariantPostBuild                      |  |



| Origin | AUTOSAR_ECUC |  |
|--------|--------------|--|
|--------|--------------|--|

### 5.2.1.13. ComlPduReplication

| Parameters included         |    |
|-----------------------------|----|
| Parameter name Multiplicity |    |
| ComIPduReplicationQuorum    | 11 |
| ComIPduReplicaRef           | 12 |

| Parameter Name      | ComlPduReplicationQuorum                                     |  |
|---------------------|--|--|
| Description         | The number of identical I-PDUs needed for successful voting. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Range               | <=3  |  |
|                     | >=1  |  |
| Configuration class | VariantPostBuild: VariantPostBuild                           |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | ComIPduReplicaRef                             |  |
|---------------------|---|--|
| Description         | Reference to replicas PduR PDUs of this IPDU. |  |
| Multiplicity        | 12  |  |
| Туре                | REFERENCE                                     |  |
| Configuration class | PreCompile: VariantPostBuild                  |  |
| Origin              | AUTOSAR_ECUC                                  |  |

### 5.2.1.14. ComTxIPdu

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| ComTxModeFalse      | 01           | This container contains the configuration parameters of the AUTOSAR COM module's transmission modes in the case the ComFilter evaluates to false. |



| Containers included |    |  |
|---------------------|----|--|
| ComTxModeTrue       | 01 | This container contains the configuration parameters of the AUTOSAR COM module's transmission modes in the case the ComFilter evaluates to true. |

| Parameters included         |    |
|-----------------------------|----|
| Parameter name Multiplicity |    |
| ComMinimumDelayTime         | 01 |
| ComTxIPduClearUpdateBit     | 11 |
| ComTxIPduUnusedAreasDefault | 11 |

| Parameter Name      | ComMinimumDelayTime  |                  |
|---------------------|--|------------------|
| Description         | Defines the Minimum Delay Time (MDT) between successive transmissions of this I-PDU in seconds. The MDT is independent of the possible different transmission modes. There is only one minimum delay time parameter for one I-PDU. The minimum delay timer is not reset by changing the transmission mode. Hence, it is not allowed to violate the minimum delay time by transmission mode changes. It is not possible to monitor the minimum delay time for I-PDUs that are requested using the Com_TriggerTransmit API.  The EB implementation for the Minimum Delay Time Monitoring interprets the configuration parameter ComMinimumDelayTime in a way that the number between two send requests of the I-PDU is ComMinimumDelayTime / ComTxTime-Base. The minimal interval between two transmissions is [(ComMinimumDelay-Time / ComTxTimeBase -1)(ComMinimumDelayTime / ComTxTimeBase)]. |                  |
| Multiplicity        | 01   |                  |
| Туре                | FLOAT  |                  |
| Default value       | 0  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC V3.0  |                  |

| Parameter Name | ComTxlPduClearUpdateBit  |
|----------------|--|
| Description    | Defines when the update-bits of signals or signal groups, contained in this I-PDU, will be cleared. Parameter is enabled automatically if at least on signal or signal group is referenced which has the update bit enabled. |
| Multiplicity   | 11   |
| Туре           | ENUMERATION  |
| Default value  | Transmit   |



| Range               | Confirmation      |                  |
|---------------------|-------------------|------------------|
|                     | Transmit          |                  |
|                     | TriggerTransmit   |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | ComTxlPduUnusedAreasDefault   |                  |
|---------------------|---|------------------|
| Description         | The AUTOSAR COM module fills not used areas of an I-PDU with this byte pattern. This attribute is mandatory to avoid undefined behaviour. This byte-pattern will be repeated throughout the I-PDU before any init-values or update-bits were set. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Default value       | 0   |                  |
| Range               | <=255   |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

### 5.2.1.15. ComTxModeFalse

| Containers included                     |    |  |
|---|----|--|
| Container name Multiplicity Description |    | Description  |
| ComTxMode                               | 11 | This container contains the configuration parameters of the AUTOSAR COM module's transmission modes. |

### **5.2.1.16. ComTxMode**

| Parameters included          |              |
|------------------------------|--------------|
| Parameter name               | Multiplicity |
| ComTxModeMode                | 11           |
| ComTxModeNumberOfRepetitions | 11           |



| Parameters included       |    |
|---------------------------|----|
| ComTxModeRepetitionPeriod | 11 |
| ComTxModeTimeOffset       | 11 |
| ComTxModeTimePeriod       | 11 |

| Parameter Name      | ComTxModeMode   |                  |
|---------------------|---|------------------|
| Description         | The available transmission modes described in [18] shall be extended by the additional mode None. The transmission mode None shall not have any further sub-attributes in the ComTxMode object. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | DIRECT  |                  |
|                     | MIXED   |                  |
|                     | NONE  |                  |
|                     | PERIODIC  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComTxModeNumberOfRepetitions   |  |
|---------------------|--|--|
| Description         | Defines the number of repetitions for the transmission mode DIRECT and the event driven part of transmission mode MIXED. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Range               | <=255  |  |
|                     | >=0  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name | ComTxModeRepetitionPeriod  |
|----------------|--|
| Description    | Defines the repetition period in seconds of the multiple transmissions in case ComTxModeNumberOfRepetitions is configured greater than 1 and ComTx-ModeMode is configured to DIRECT or MIXED. In case of the mixed transmission mode only the event driven part is affected. |
| Multiplicity   | 11   |



| Туре                | FLOAT                              |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | ComTxModeTimeOffset  | ComTxModeTimeOffset |  |
|---------------------|--|---------------------|--|
| Description         | Defines the period in seconds between the start of the I-PDU by Com_Ip-duGroupControl and the first transmission request in case ComTxModeMode is configured to PERIODIC or MIXED. In case of the mixed transmission mode only the periodic part is affected.  In case ComTxModeTimeOffset is omitted or configured to 0, the first periodic transmission shall be transmitted within the next invocation of Com_MainFunctionTx. |                     |  |
|                     |  |                     |  |
|                     | EB implementation:   | EB implementation:  |  |
|                     | For values > 0: number of Com_MainFunctionTx invocations between the first periodic transmission and invocation of Com_IpduGroupControl is ComTxModeTimeOffset / ComTxTimeBase.  |                     |  |
|                     | For value = 0 (or omitted): first transmission request is in the next invocation of Com_MainFunctionTx.  |                     |  |
|                     | EB extension: If the value is lower 0, the I-PDU is sent out immediately (in context of Com_IpduGroupControl)  |                     |  |
| Multiplicity        | 11   |                     |  |
| Туре                | FLOAT  | FLOAT               |  |
| Default value       | 0  |                     |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild    |  |
| Origin              | AUTOSAR_ECUC   |                     |  |

| Parameter Name      | ComTxModeTimePeriod   |                  |
|---------------------|---|------------------|
| Description         | Defines the repetition period in seconds of the periodic transmission requests in case ComTxModeMode is configured to PERIODIC or MIXED. In case of the mixed transmission mode only the periodic part is affected. |                  |
| Multiplicity        | 11  |                  |
| Туре                | FLOAT   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |



### 5.2.1.17. ComTxModeTrue

| Containers included |              |  |  |
|---------------------|--------------|--|--|
| Container name      | Multiplicity | Description  |  |
| <u>ComTxMode</u>    | 11           | This container contains the configuration parameters of the AUTOSAR COM module's transmission modes. |  |

### 5.2.1.18. ComTxMode

| Parameters included          |    |  |
|------------------------------|----|--|
| Parameter name Multiplicity  |    |  |
| ComTxModeMode                | 11 |  |
| ComTxModeNumberOfRepetitions | 11 |  |
| ComTxModeRepetitionPeriod    | 11 |  |
| ComTxModeTimeOffset          | 11 |  |
| ComTxModeTimePeriod          | 11 |  |

| Parameter Name      | ComTxModeMode   |                  |
|---------------------|---|------------------|
| Description         | The available transmission modes described in [18] shall be extended by the additional mode None. The transmission mode None shall not have any further sub-attributes in the ComTxMode object. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Default value       | DIRECT  |                  |
| Range               | DIRECT  |                  |
|                     | MIXED   |                  |
|                     | NONE  |                  |
|                     | PERIODIC  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComTxModeNumberOfRepetitions   |  |
|----------------|--|--|
| Description    | Defines the number of repetitions for the transmission mode DIRECT and the |  |
|                | event driven part of transmission mode MIXED.                              |  |



| Multiplicity        | 11                                 |  |
|---------------------|------------------------------------|--|
| Туре                | INTEGER                            |  |
| Default value       | 1                                  |  |
| Range               | <=255                              |  |
|                     | >=0                                |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | ComTxModeRepetitionPeriod  |                  |
|---------------------|--|------------------|
| Description         | Defines the repetition period in seconds of the multiple transmissions in case ComTxModeNumberOfRepetitions is configured greater than 1 and ComTx-ModeMode is configured to DIRECT or MIXED. In case of the mixed transmission mode only the event driven part is affected. |                  |
| Multiplicity        | 11   |                  |
| Туре                | FLOAT  |                  |
| Default value       | 1  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name | ComTxModeTimeOffset   |
|----------------|---|
| Description    | Defines the period in seconds between the start of the I-PDU by Com_Ip-duGroupControl and the first transmission request in case ComTxModeMode is configured to PERIODIC or MIXED. In case of the mixed transmission mode only the periodic part is affected. |
|                | In case ComTxModeTimeOffset is omitted or configured to 0, the first periodic transmission shall be transmitted within the next invocation of Com_MainFunctionTx.   |
|                | EB implementation:  |
|                | For values > 0: number of Com_MainFunctionTx invocations between the first periodic transmission and invocation of Com_IpduGroupControl is ComTxModeTimeOffset / ComTxTimeBase.   |
|                | For value = 0 (or omitted): first transmission request is in the next invocation of Com_MainFunctionTx.   |
|                | EB extension: If the value is lower 0, the I-PDU is sent out immediately (in context of Com_lpduGroupControl)   |



| Multiplicity        | 11                |                  |
|---------------------|-------------------|------------------|
| Туре                | FLOAT             |                  |
| Default value       | 0                 |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | ComTxModeTimePeriod   |  |
|---------------------|---|--|
| Description         | Defines the repetition period in seconds of the periodic transmission requests in case ComTxModeMode is configured to PERIODIC or MIXED. In case of the mixed transmission mode only the periodic part is affected. |  |
| Multiplicity        | 11  |  |
| Туре                | FLOAT   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

### 5.2.1.19. ComlPduGroup

| Parameters included  |              |
|----------------------|--------------|
| Parameter name       | Multiplicity |
| ComlPduGroupHandleId | 11           |
| ComlPduGroupGroupRef | 0n           |

| Parameter Name      | ComlPduGroupHandleld  |                  |
|---------------------|---|------------------|
| Description         | The numerical value used as the ID of this I-PDU Group . The ComIP-duGroupHandleId is required by the API calls to start and stop I-PDU Groups. Range: 0 (ComSupportedIPduGroups-1) |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=65535   |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComlPduGroupGroupRef |
|----------------|----------------------|
|----------------|----------------------|



| Description         | References to all I-PDU groups that includes this I-PDU group. If this reference is omitted this I-PDU group does not belong to another I-PDU group. |                  |
|---------------------|--|------------------|
| Multiplicity        | 0n   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

# 5.2.1.20. ComSignal

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| ComFilter           | 01           | This container contains the configuration parameters of the AUTOSAR COM module's Filters.Note: On sender side the container is used to specify the transmission mode conditions. |

| Parameters included       |              |
|---------------------------|--------------|
| Parameter name            | Multiplicity |
| ComBitPosition            | 11           |
| ComBitSize                | 11           |
| ComDataInvalidAction      | 01           |
| ComErrorNotification      | 01           |
| ComFirstTimeout           | 01           |
| ComHandleId               | 11           |
| ComInitialValueOnly       | 01           |
| ComInvalidNotification    | 11           |
| ComNotification           | 01           |
| ComRxDataTimeoutAction    | 11           |
| ComSignalDataInvalidValue | 01           |
| ComSignalDirection        | 01           |
| ComSignalEndianness       | 11           |
| ComSignalInitValue        | 01           |
| ComSignalLength           | 11           |
| <u>ComSignalType</u>      | 11           |



| Parameters included              |    |
|----------------------------------|----|
| ComTimeout                       | 01 |
| ComTimeoutNotification           | 01 |
| ComTransferProperty              | 01 |
| ComUpdateBitPosition             | 01 |
| ComSystemTemplateSystemSignalRef | 01 |

| Parameter Name      | ComBitPosition   |                  |
|---------------------|--|------------------|
| Description         | Starting position within the I-PDU. This parameter refers to the position in the I-PDU and not in the shadow buffer. If the endianness conversion is configured to Opaque the parameter ComBitPosition shall define the bit0 of the first byte like in little endian byte order. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComBitSize  |                  |
|---------------------|---|------------------|
| Description         | Size in bits, for non-array signal types. For ComSignalType UINT8_N and UINT8_DYN this size shall be configured by ComSignalLength. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComDataInvalidAction  |
|----------------|---|
| Description    | This parameter defines the action performed upon reception of an invalid signal. Relating to signal groups the action in case if one of the included signals is an invalid signal. If Replace is used the ComSignalInitValue will be used for the replacement. NOTE: Signal Invalidation is not supported by the AUTOSAR COM module. Please make sure, that the RTE supports signal invalidation. |
| Multiplicity   | 01  |
| Туре           | ENUMERATION   |
| Default value  | NOTIFY  |
| Range          | NOTIFY  |



|                     | REPLACE                |  |
|---------------------|------------------------|--|
| Configuration class | Link: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC           |  |

| Parameter Name      | ComErrorNotification   |                  |
|---------------------|--|------------------|
| Description         | Only valid on sender side: Name of Com_CbkTxErr callback function to be called. If this parameter is omitted no error notification shall take place. |                  |
| Multiplicity        | 01   |                  |
| Туре                | FUNCTION-NAME  |                  |
| Configuration class | Link:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComFirstTimeout   |  |
|---------------------|---|--|
| Description         | Defines the length of the first deadline means that the service is used immediately after set toring service. The timeout period of the COM263_Conf. According to AUTOSAR AUTOSAR COM module shall not monit group respectively from the start of the cotion if the configuration parameter Complis omitted or configured to 0. The implementation parameter Compliance is of the configuration parameter Compliance in | tart (or restart) of the deadline monisuccessive periods is configured by a SWS COM requirement COM716 the or the reception of this signal or signal corresponding I-PDU until the first receptirstTimeout for a signal or signal group mentation behaves follows regarding the ut for a signal or signal group: |
| Multiplicity        | 01  |  |
| Туре                | FLOAT   |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild   |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name | ComHandleld   |
|----------------|---|
| Description    | The numerical value used as the ID. For signals it is required by the API calls Com_UpdateShadowSignal, Com_ReceiveShadowSignal and Com_InvalidateShadowSignal. For signals groups it is required by the Com_SendSignal-Group and Com_ReceiveSignalGroup calls. |
| Multiplicity   | 11  |
| Туре           | INTEGER   |



| Range               | <=65535           |                  |
|---------------------|-------------------|------------------|
|                     | >=0               |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | ComInitialValueOnly  |                  |
|---------------------|--|------------------|
| Description         | This parameter defines that the respective signal's initial value shall be put into the respective PDU but there will not be any update of the value through the RTE. Thus the Com implementation does not need to expect any API calls for this signal (group). |                  |
| Multiplicity        | 01   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name      | ComInvalidNotification  |                  |
|---------------------|---|------------------|
| Description         | Only valid on receiver side: Name of Com_CbkInv callback function to be called. Name of the function which notifies the RTE about the reception of an invalidated signal/ signal group. Only applicable if ComDataInvalidAction is configured to NOTIFY. NOTE: Signal Invalidation is not supported by the AUTOSAR COM module. Please make sure, that the RTE supports signal invalidation. NOTE: Parameter is enabled automatically when ComDataInvalidAction == NOTIFY. |                  |
| Multiplicity        | 11  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComNotification  |                  |
|---------------------|--|------------------|
| Description         | On sender side: Name of Com_CbkTxAck callback function to be called. On receiver side: Name of Com_CbkRxAck callback function to be called. If this parameter is omitted no notification shall take place. |                  |
| Multiplicity        | 01   |                  |
| Туре                | FUNCTION-NAME  |                  |
| Configuration class | Link:  | VariantPostBuild |



| Origin              | AUTOSAR_ECUC   |   |  |
|---------------------|--|---|--|
| Parameter Name      | ComRxDataTimeoutAction   |   |  |
| Description         | This parameter defines the a deadline monitoring timer.  | This parameter defines the action performed upon expiration of the reception deadline monitoring timer. |  |
| Multiplicity        | 11   |   |  |
| Туре                | ENUMERATION  |   |  |
| Range               | NONE   |   |  |
|                     | REPLACE  |   |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC   |   |  |
| Parameter Name      | ComSignalDataInvalidValue  | ComSignalDataInvalidValue   |  |
| Description         | Defines the data invalid value   | e of the signal. In case the ComSignalType is:  |  |
|                     | <ul> <li>UINT8, UINT16, UINT32, SINT8, SINT16, SINT32: the string shall be interpreted as defined in the chapter Integer Type in the AUTOSAR EcuC specification.</li> <li>FLOAT32, FLOAT64: the string shall be interpreted as defined in the chapter Float Type in the AUTOSAR EcuC specification.</li> <li>BOOLEAN: the string shall be interpreted as defined in the chapter Boolean Type in the AUTOSAR EcuC specification.</li> <li>UINT8_N, UINT8_DYN: the string shall be interpreted as a decimal representation of the characters separated by blanks, e.g. "97 98 100" means a string "abd", where the char "a" is in byte 0(lowest address), "b" is in byte 1, and "d" is in byte 2 and (highest address). For the ComSignalType UINT8DYN the dynamic length shall be set to the number of configured characters. An empty string "" shall be interpreted as 0-sized dynamic signal.</li> </ul> |   |  |
| Multiplicity        | 01   |   |  |
| Туре                | STRING   | STRING  |  |
| Configuration class | PostBuild:   | VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC   |   |  |
| Parameter Name      | ComSignalDirection   | ComSignalDirection  |  |
| Description         | Tx or Rx direction of the signal.  This parameter is required and enabled only when post build variants are configured.  |   |  |



| Multiplicity        | 01                         |                  |
|---------------------|----------------------------|------------------|
| Туре                | ENUMERATION                |                  |
| Default value       | SEND                       |                  |
| Range               | RECEIVE                    |                  |
|                     | SEND                       |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComSignalEndianness  |                  |
|---------------------|--|------------------|
| Description         | Defines the endianness of the signal's network representation. |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Range               | BIG_ENDIAN   |                  |
|                     | LITTLE_ENDIAN  |                  |
|                     | OPAQUE   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name | ComSignalInitValue   |  |
|----------------|--|--|
| Description    | Initial value for this signal. In case of UINT8_N the default value is a string of length ComSignalLength with all bytes set to 0x00. In case of UINT8_DYN the initial size shall be 0. In case the ComSignalType is:  |  |
|                | ■ UINT8, UINT16, UINT32, UINT64, SINT8, SINT16, SINT32, SINT64: the string shall be interpreted as defined in the chapter Integer Type in the AUTOSAR EcuC specification.  |  |
|                | FLOAT32, FLOAT64: the string shall be interpreted as defined in the chapter Float Type in the AUTOSAR EcuC specification.  |  |
|                | ▶ BOOLEAN: the string shall be interpreted as defined in the chapter Boolean Type in the AUTOSAR EcuC specification.   |  |
|                | ■ UINT8_N, UINT8_DYN: the string shall be interpreted as a decimal representation of the characters separated by blanks, e.g. "97 98 100" means a string "abd", where the char "a" is in byte 0(lowest address), "b" is in byte 1, and "d" is in byte 2 and (highest address). For the ComSignalType UINT8DYN the dynamic length shall be set to the number of configured characters. An empty string "" shall be interpreted as 0-sized dynamic signal. |  |



| Multiplicity        | 01                |                  |
|---------------------|-------------------|------------------|
| Туре                | STRING            |                  |
| Default value       | 0                 |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | ComSignalLength  |  |
|---------------------|--|--|
| Description         | Description:. For ComSignalType UINT8_N this parameter specifies the length n in bytes. For ComSignalType UINT8_DYN it specifies the maximum length in bytes. For all other types this parameter shall be ignored. Range: 18 for normal CAN/ LIN I-PDUs, 1254 for normal FlexRay I-PDUs, and 14095 for I-PDUs with ComIPduType TP. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name | ComSignalType   |  |
|----------------|---|--|
| Description    | The AUTOSAR type of the signal. Whether or not the signal is signed or unsigned can be found by examining the value of this attribute. This type could also be used to reserved appropriate storage in AUTOSAR COM. |  |
| Multiplicity   | 11  |  |
| Туре           | ENUMERATION   |  |
| Range          | BOOLEAN   |  |
|                | FLOAT32   |  |
|                | FLOAT64   |  |
|                | SINT16  |  |
|                | SINT32  |  |
|                | SINT64  |  |
|                | SINT8   |  |
|                | UINT16  |  |
|                | UINT32  |  |
|                | UINT64  |  |
|                | UINT8   |  |



|                     | UINT8_DYN         |                  |
|---------------------|-------------------|------------------|
|                     | UINT8_N           |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | ComTimeout   |  |
|---------------------|--|--|
| Description         | Defines the length of the deadline monitoring timeout period in seconds. The period for the first timeout period (reception deadline monitoring only) can be configured separately by COM183_Conf. |  |
| Multiplicity        | 01   |  |
| Туре                | FLOAT  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | ComTimeoutNotification  |                  |
|---------------------|---|------------------|
| Description         | On sender side: Name of Com_CbkTxTOut callback function to be called. On receiver side: Name of Com_CbkRxTOut callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Configuration class | Link:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComTransferProperty   |  |
|----------------|---|--|
| Description    | Defines if a write access to this signal can trigger the transmission of the corresponding I-PDU. If the I-PDU is triggered, depends also on the transmission mode of the corresponding I-PDU.  |  |
|                | ▶ PENDING: A write access to this signal never triggers the transmission of the corresponding I-PDU.  |  |
|                | ► TRIGGERED: Depending on the transmission mode, a write access to this signal can trigger the transmission of the corresponding I-PDU.   |  |
|                | TRIGGERED_ON_CHANGE: Depending on the transmission mode, a write access to this signal can trigger the transmission of the corresponding I-PDU, but only in case the written value is different to the locally stored (last written or init) value. |  |
| Multiplicity   | 01  |  |



| Туре                | ENUMERATION                            |           |  |
|---------------------|--|-----------|--|
| Default value       | TRIGGERED                              |           |  |
| Range               | PENDING                                |           |  |
|                     | TRIGGERED                              | TRIGGERED |  |
|                     | TRIGGERED_ON_CHANGE                    |           |  |
|                     | TRIGGERED_ON_CHANGE_WITHOUT_REPETITION |           |  |
|                     | TRIGGERED_WITHOUT_REPETITION           |           |  |
| Configuration class | VariantPostBuild: VariantPostBuild     |           |  |
| Origin              | AUTOSAR_ECUC                           |           |  |

| Parameter Name      | ComUpdateBitPosition  |  |
|---------------------|---|--|
| Description         | Bit position of update-bit inside I-PDU. If this attribute is omitted then there is no update-bit. This setting must be consistently on sender and on receiver side. Range: 063 for CAN and LIN 02031 for FlexRay |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | ComSystemTemplateSystemSignalRef  |  |
|---------------------|---|--|
| Description         | Reference to the ISignalToIPduMapping that contains a reference to the ISignal (System Template) which this ComSignal (or ComGroupSignal) represents. |  |
| Multiplicity        | 01  |  |
| Туре                | FOREIGN-REFERENCE   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

## 5.2.1.21. ComFilter

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| ComFilterAlgorithm  | 11           |
| ComFilterMask       | 11           |



| Parameters included |    |  |
|---------------------|----|--|
| ComFilterMax        | 11 |  |
| <u>ComFilterMin</u> | 11 |  |
| ComFilterOffset     | 11 |  |
| ComFilterPeriod     | 11 |  |
| ComFilterX          | 11 |  |

| Parameter Name      | ComFilterAlgorithm  |                  |
|---------------------|---|------------------|
| Description         | The range of values is specified in the [17] specification, chapter 2.2.2, Reception Filtering. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | ALWAYS  |                  |
|                     | MASKED_NEW_DIFFERS_MASKED_OLD   |                  |
|                     | MASKED_NEW_DIFFERS_X  |                  |
|                     | MASKED_NEW_EQUALS_X   |                  |
|                     | NEVER   |                  |
|                     | NEW_IS_OUTSIDE  |                  |
|                     | NEW_IS_WITHIN   |                  |
|                     | ONE_EVERY_N   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComFilterMask  |  |
|---------------------|--|--|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name | ComFilterMax  |
|----------------|---|
| Description    | The name of this attribute corresponds to the parameter name in the [17] specifi- |
|                | cation of Reception Filtering.  |



| Multiplicity        | 11                |                  |
|---------------------|-------------------|------------------|
| Туре                | INTEGER           |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | ComFilterMin   |  |
|---------------------|--|--|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | ComFilterOffset   |                  |
|---------------------|---|------------------|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. Range = 0(ComFilterPeriod-1) |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComFilterPeriod  |  |
|---------------------|--|--|
| Description         | This parameter defines the period of the ComFilterAlgorithm ONE_EVERY_N. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Configuration class | VariantPostBuild: VariantPostBuild                                       |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | ComFilterX   |  |
|---------------------|--|--|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |



| Origin | AUTOSAR_ECUC |
|--------|--------------|
|--------|--------------|

# 5.2.1.22. ComSignalGroup

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| ComGroupSignal      | 0n           | This container contains the configuration parameters of group signals. I.e. signals that are included within a signal group. |

| Parameters included                    |              |  |
|--|--------------|--|
| Parameter name                         | Multiplicity |  |
| <u>ComDataInvalidAction</u>            | 01           |  |
| ComErrorNotification                   | 01           |  |
| ComFirstTimeout                        | 01           |  |
| ComHandleId                            | 11           |  |
| ComInitialValueOnly                    | 01           |  |
| ComInvalidNotification                 | 11           |  |
| ComNotification                        | 01           |  |
| ComRxDataTimeoutAction                 | 11           |  |
| ComSignalGroupArrayAccess              | 11           |  |
| ComSignalGroupDirection                | 01           |  |
| ComTimeout                             | 01           |  |
| ComTimeoutNotification                 | 01           |  |
| ComTransferProperty                    | 01           |  |
| ComUpdateBitPosition                   | 01           |  |
| <u>ComSystemTemplateSignalGroupRef</u> | 01           |  |

| Parameter Name | ComDataInvalidAction  |
|----------------|---|
| Description    | This parameter defines the action performed upon reception of an invalid signal. Relating to signal groups the action in case if one of the included signals is an invalid signal. If Replace is used the ComSignalInitValue will be used for the replacement. NOTE: Signal Invalidation is not supported by the AUTOSAR COM module. Please make sure, that the RTE supports signal invalidation. |
| Multiplicity   | 01  |



| Туре                | ENUMERATION  |                  |
|---------------------|--------------|------------------|
| Default value       | NOTIFY       |                  |
| Range               | NOTIFY       |                  |
|                     | REPLACE      |                  |
| Configuration class | Link:        | VariantPostBuild |
| Origin              | AUTOSAR_ECUC |                  |

| Parameter Name      | ComErrorNotification   |                  |
|---------------------|--|------------------|
| Description         | Only valid on sender side: Name of Com_CbkTxErr callback function to be called. If this parameter is omitted no error notification shall take place. |                  |
| Multiplicity        | 01   |                  |
| Туре                | FUNCTION-NAME  |                  |
| Configuration class | Link:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComFirstTimeout  |                  |
|---------------------|--|------------------|
| Description         | Defines the length of the first deadline monitoring timeout period in seconds.  This timeout is used immediately after start (or restart) of the deadline monitoring service. The timeout period of the successive periods is configured by COM263_Conf. According to AUTOSAR SWS COM requirement COM716 the AUTOSAR COM module shall not monitor the reception of this signal or signal group respectively from the start of the corresponding I-PDU until the first reception if the configuration parameter ComFirstTimeout for a signal or signal group is omitted or configured to 0. The implementation behaves follows regarding the configuration parameter ComFirstTimeout for a signal group:  If configured to 0: as defined in COM716  If omitted: ComTimeout is used for ComFirstTimeou |                  |
| Multiplicity        | 01   |                  |
| Туре                | FLOAT  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name | ComHandleId   |  |
|----------------|---|--|
| Description    | The numerical value used as the ID. For signals it is required by the API calls |  |
|                | Com_UpdateShadowSignal, Com_ReceiveShadowSignal and Com_Invali-                 |  |



|                     | dateShadowSignal. For signals groups it is required by the Com_SendSignal-Group and Com_ReceiveSignalGroup calls. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=65535   |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComInitialValueOnly  |                  |
|---------------------|--|------------------|
| Description         | This parameter defines that the respective signal's initial value shall be put into the respective PDU but there will not be any update of the value through the RTE. Thus the Com implementation does not need to expect any API calls for this signal (group). |                  |
| Multiplicity        | 01   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name      | ComInvalidNotification  |                  |
|---------------------|---|------------------|
| Description         | Only valid on receiver side: Name of Com_CbkInv callback function to be called. Name of the function which notifies the RTE about the reception of an invalidated signal/ signal group. Only applicable if ComDataInvalidAction is configured to NOTIFY. NOTE: Signal Invalidation is not supported by the AUTOSAR COM module. Please make sure, that the RTE supports signal invalidation. NOTE: Parameter is enabled automatically when ComDataInvalidAction == NOTIFY. |                  |
| Multiplicity        | 11  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComNotification  |
|----------------|--|
| ·              | On sender side: Name of Com_CbkTxAck callback function to be called. On receiver side: Name of Com_CbkRxAck callback function to be called. If this parameter is omitted no notification shall take place. |



| Multiplicity        | 01            |                  |
|---------------------|---------------|------------------|
| Туре                | FUNCTION-NAME |                  |
| Configuration class | Link:         | VariantPostBuild |
| Origin              | AUTOSAR ECUC  |                  |

| Parameter Name      | ComRxDataTimeoutAction  |                  |
|---------------------|---|------------------|
| Description         | This parameter defines the action performed upon expiration of the reception deadline monitoring timer. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | NONE  |                  |
|                     | REPLACE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComSignalGroupArrayAccess  |                  |
|---------------------|--|------------------|
| Description         | Defines whether the uint8-array based access shall be used for this ComSignal-Group. This parameter is only enabled if ComBasedTransformerSupportTx or ComBasedTransformerSupportRx is true. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | ComSignalGroupDirection  |
|----------------|--|
| Description    | Tx or Rx direction of the signal group.  |
|                | This parameter is required and enabled only when post build variants are configured. |
| Multiplicity   | 01   |
| Туре           | ENUMERATION  |
| Default value  | SEND   |
| Range          | RECEIVE  |
|                | SEND   |



| Configuration class | VariantPostBuild:          | VariantPostBuild |
|---------------------|----------------------------|------------------|
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComTimeout  |                  |
|---------------------|---|------------------|
| Description         | Defines the length of the deadline monitoring timeout period in seconds. The period for the first timeout period can be configured separately by COM183_Conf. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FLOAT   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComTimeoutNotification  |                  |
|---------------------|---|------------------|
| Description         | On sender side: Name of Com_CbkTxTOut callback function to be called. On receiver side: Name of Com_CbkRxTOut callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Configuration class | Link:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComTransferProperty   |  |
|----------------|---|--|
| Description    | Defines if a write access to this signal can trigger the transmission of the corresponding I-PDU. If the I-PDU is triggered, depends also on the transmission mode of the corresponding I-PDU.  |  |
|                | PENDING: A write access to this signal never triggers the transmission of<br>the corresponding I-PDU.   |  |
|                | TRIGGERED: Depending on the transmission mode, a write access to this signal can trigger the transmission of the corresponding I-PDU.   |  |
|                | TRIGGERED_ON_CHANGE: Depending on the transmission mode, a write access to this signal can trigger the transmission of the corresponding I-PDU, but only in case the written value is different to the locally stored (last written or init) value. |  |
| Multiplicity   | 01  |  |
| Туре           | ENUMERATION   |  |
| Default value  | TRIGGERED   |  |
| Range          | PENDING   |  |



|                     | TRIGGERED                              |  |
|---------------------|--|--|
|                     | TRIGGERED_ON_CHANGE                    |  |
|                     | TRIGGERED_ON_CHANGE_WITHOUT_REPETITION |  |
|                     | TRIGGERED_WITHOUT_REPETITION           |  |
| Configuration class | VariantPostBuild: VariantPostBuild     |  |
| Origin              | AUTOSAR_ECUC                           |  |

| Parameter Name      | ComUpdateBitPosition  |  |
|---------------------|---|--|
| Description         | Bit position of update-bit inside I-PDU. If this attribute is omitted then there is no update-bit. This setting must be consistently on sender and on receiver side. Range: 063 for CAN and LIN 02031 for FlexRay |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | ComSystemTemplateSignalGroupRef   |                  |
|---------------------|---|------------------|
| Description         | Reference to the ISignalToIPduMapping that contains a reference to the ISignal-Group (SystemTemplate) which this ComSignalGroup represents. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FOREIGN-REFERENCE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

## 5.2.1.23. ComGroupSignal

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| ComFilter           | 01           | This container contains the configuration parameters of the AUTOSAR COM module's Filters.Note: On sender side the container is used to specify the transmission mode conditions. |

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |



| Parameters included              |    |  |
|----------------------------------|----|--|
| ComBitPosition                   | 11 |  |
| ComBitSize                       | 11 |  |
| ComHandleId                      | 11 |  |
| ComSignalDataInvalidValue        | 01 |  |
| ComSignalEndianness              | 11 |  |
| ComSignalInitValue               | 01 |  |
| ComSignalLength                  | 11 |  |
| ComSignalType                    | 11 |  |
| ComTransferProperty              | 11 |  |
| ComSystemTemplateSystemSignalRef | 01 |  |

| Parameter Name      | ComBitPosition   |                  |
|---------------------|--|------------------|
| Description         | Starting position within the I-PDU. This parameter refers to the position in the I-PDU and not in the shadow buffer. If the endianness conversion is configured to Opaque the parameter ComBitPosition shall define the bit0 of the first byte like in little endian byte order. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComBitSize  |                  |
|---------------------|---|------------------|
| Description         | Size in bits, for non-array signal types. For ComSignalType UINT8_N and UINT8_DYN this size shall be configured by ComSignalLength. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComHandleld   |
|----------------|---|
| Description    | The numerical value used as the ID. For signals it is required by the API calls Com_UpdateShadowSignal, Com_ReceiveShadowSignal and Com_InvalidateShadowSignal. For signals groups it is required by the Com_SendSignal-Group and Com_ReceiveSignalGroup calls. |



| Multiplicity        | 11                                 |  |
|---------------------|------------------------------------|--|
| Туре                | INTEGER                            |  |
| Range               | <=65535                            |  |
|                     | >=0                                |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | ComSignalDataInvalidValue   |  |
|---------------------|---|--|
| Description         | <ul> <li>Defines the data invalid value of the signal. In case the ComSignalType is:</li> <li>UINT8, UINT16, UINT32, UINT64, SINT8, SINT16, SINT32, SINT64: the string shall be interpreted as defined in the chapter Integer Type in the AUTOSAR EcuC specification.</li> <li>FLOAT32, FLOAT64: the string shall be interpreted as defined in the chapter Float Type in the AUTOSAR EcuC specification.</li> <li>BOOLEAN: the string shall be interpreted as defined in the chapter Boolean Type in the AUTOSAR EcuC specification.</li> <li>UINT8_N, UINT8_DYN: the string shall be interpreted as a decimal representation of the characters separated by blanks, e.g. "97 98 100" means a string "abd", where the char "a" is in byte 0(lowest address), "b" is in byte 1,</li> </ul> |  |
|                     | and "d" is in byte 2 and (highest address). For the ComSignalType UINT8 DYN the dynamic length shall be set to the number of configured characters. An empty string "" shall be interpreted as 0-sized dynamic  |  |
| Multiplicity        | 01  |  |
| Туре                | STRING  |  |
| Configuration class | PostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name | ComSignalEndianness  |
|----------------|--|
| Description    | Defines the endianness of the signal's network representation. |
| Multiplicity   | 11   |
| Туре           | ENUMERATION  |
| Default value  | LITTLE_ENDIAN  |
| Range          | BIG_ENDIAN   |
|                | LITTLE_ENDIAN  |



|                     | OPAQUE                             |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | ComSignalInitValue   |  |
|---------------------|--|--|
| Description         | Initial value for this signal. In case of UINT8_N the default value is a string of length ComSignalLength with all bytes set to 0x00. In case of UINT8_DYN the initial size shall be 0. In case the ComSignalType is:  |  |
|                     | UINT8, UINT16, UINT32, UINT64, SINT8, SINT16, SINT32, SINT64: the string shall be interpreted as defined in the chapter Integer Type in the AUTOSAR EcuC specification.  |  |
|                     | FLOAT32, FLOAT64: the string shall be interpreted as defined in the chapter Float Type in the AUTOSAR EcuC specification.  |  |
|                     | BOOLEAN: the string shall be interpreted as defined in the chapter Boolean Type in the AUTOSAR EcuC specification.   |  |
|                     | ■ UINT8_N, UINT8_DYN: the string shall be interpreted as a decimal representation of the characters separated by blanks, e.g. "97 98 100" means a string "abd", where the char "a" is in byte 0(lowest address), "b" is in byte 1, and "d" is in byte 2 and (highest address). For the ComSignalType UINT8DYN the dynamic length shall be set to the number of configured characters. An empty string "" shall be interpreted as 0-sized dynamic signal. |  |
| Multiplicity        | 01   |  |
| Туре                | STRING   |  |
| Default value       | 0  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | ComSignalLength  |                  |
|---------------------|--|------------------|
| Description         | Description:. For ComSignalType UINT8_N this parameter specifies the length n in bytes. For ComSignalType UINT8_DYN it specifies the maximum length in bytes. For all other types this parameter shall be ignored. Range: 18 for normal CAN/ LIN I-PDUs, 1254 for normal FlexRay I-PDUs, and 14095 for I-PDUs with ComIPduType TP. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |



| Origin | AUTOSAR_ECUC |
|--------|--------------|
|--------|--------------|

| Parameter Name      | ComSignalType   |                  |
|---------------------|---|------------------|
| Description         | The AUTOSAR type of the signal. Whether or not the signal is signed or unsigned can be found by examining the value of this attribute. This type could also be used to reserved appropriate storage in AUTOSAR COM. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | BOOLEAN   |                  |
|                     | FLOAT32   |                  |
|                     | FLOAT64   |                  |
|                     | SINT16  |                  |
|                     | SINT32<br>SINT64  |                  |
|                     |   |                  |
|                     | SINT8   |                  |
|                     | UINT16  |                  |
|                     | UINT32  |                  |
|                     | UINT64  |                  |
|                     | UINT8   |                  |
|                     | UINT8_DYN   |                  |
|                     | UINT8_N   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComTransferProperty  |
|----------------|--|
| Description    | Optionally defines whether this group signal shall contribute to the TRIG-GERED_ON_CHANGE transfer property of the signal group. If at least one group signal of a signal group has the ComTransferProperty configured all other group signals of that signal group shall have the attribute configured as well. PENDING: a change of the value of this group signal shall not be considered in the evaluation of the signal groups ComTransferProperty. TRIGGERED_ONCHANGE: a change of the value of this group signal shall be considered in the in the evaluation of the signal groups ComTransferProperty. |
| Multiplicity   | 11   |
| Туре           | ENUMERATION  |



| Default value       | TRIGGERED_ON_CHANGE                |  |
|---------------------|------------------------------------|--|
| Range               | PENDING                            |  |
|                     | TRIGGERED_ON_CHANGE                |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | ComSystemTemplateSystemSignalRef  |                  |
|---------------------|---|------------------|
| Description         | Reference to the ISignalToIPduMapping that contains a reference to the ISignal (System Template) which this ComSignal (or ComGroupSignal) represents. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FOREIGN-REFERENCE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

## 5.2.1.24. ComFilter

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| ComFilterAlgorithm  | 11           |
| ComFilterMask       | 11           |
| ComFilterMax        | 11           |
| ComFilterMin        | 11           |
| ComFilterOffset     | 11           |
| ComFilterPeriod     | 11           |
| ComFilterX          | 11           |

| Parameter Name | ComFilterAlgorithm  |
|----------------|---|
| Description    | The range of values is specified in the [17] specification, chapter 2.2.2, Reception Filtering. |
| Multiplicity   | 11  |
| Туре           | ENUMERATION   |
| Range          | ALWAYS  |
|                | MASKED_NEW_DIFFERS_MASKED_OLD   |



| Origin              | AUTOSAR_ECUC         |                  |
|---------------------|----------------------|------------------|
| Configuration class | VariantPostBuild:    | VariantPostBuild |
|                     | ONE_EVERY_N          |                  |
|                     | NEW_IS_WITHIN        |                  |
|                     | NEW_IS_OUTSIDE       |                  |
|                     | NEVER                |                  |
|                     | MASKED_NEW_EQUALS_X  |                  |
|                     | MASKED_NEW_DIFFERS_X |                  |

| Parameter Name      | ComFilterMask  |                  |
|---------------------|--|------------------|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComFilterMax   |                  |
|---------------------|--|------------------|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComFilterMin   |                  |
|---------------------|--|------------------|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name ComFilterOffset |
|--------------------------------|
|--------------------------------|



| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. Range = 0(ComFilterPeriod-1) |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComFilterPeriod  |                  |
|---------------------|--|------------------|
| Description         | This parameter defines the period of the ComFilterAlgorithm ONE_EVERY_N. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | ComFilterX   |                  |
|---------------------|--|------------------|
| Description         | The name of this attribute corresponds to the parameter name in the [17] specification of Reception Filtering. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

## 5.2.1.25. ComTimeBase

| Parameters included  |              |
|----------------------|--------------|
| Parameter name       | Multiplicity |
| ComGwTimeBase        | 11           |
| ComRxTimeBase        | 11           |
| <u>ComTxTimeBase</u> | 11           |

| Parameter Name | ComGwTimeBase  |  |
|----------------|--|--|
| Description    | The period between successive calls to Com_MainFunctionRouteSignals in sec-  |  |
|                | onds. This parameter may be used by the COM generator to transform the val-  |  |
|                | ues of the signal gateway related timing configuration parameters of the COM |  |



|                     | module to internal implementation specific counter or tick values. The COM module's internal timing handling is implementation specific. The COM module (generator) might rely on the fact that Com_MainFunctionRouteSignals is scheduled according to the value configured here. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | FLOAT   |                  |
| Default value       | 0.005   |                  |
| Range               | <=3600  |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | ComRxTimeBase   |                  |
|---------------------|---|------------------|
| Description         | The period between successive calls to Com_MainFunctionRx in seconds. This parameter may be used by the COM generator to transform the values of the reception related timing configuration parameters of the COM module to internal implementation specific counter or tick values. The COM module's internal timing handling is implementation specific. The COM module (generator) may rely on the fact that Com_MainFunctionRx is scheduled according to the value configured here. |                  |
| Multiplicity        | 11  |                  |
| Туре                | FLOAT   |                  |
| Default value       | 0.005   |                  |
| Range               | <=3600<br>>=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | ComTxTimeBase  |
|----------------|--|
| Description    | The period between successive calls to Com_MainFunctionTx in seconds. This parameter may be used by the COM generator to transform the values of the transmission related timing configuration parameters of the COM module to internal implementation specific counter or tick values. The COM module's internal timing handling is implementation specific. The COM module (generator) may rely on the fact that Com_MainFunctionTx is scheduled according to the value configured here. |



| Multiplicity        | 11                                 |  |
|---------------------|------------------------------------|--|
| Туре                | FLOAT                              |  |
| Default value       | 0.005                              |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

#### 5.2.1.26. ComTxMainFunctions

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| Com_MainFunctionTx  | 1n           | Contains the transmission main functions of COM module. |

## 5.2.1.27. Com\_MainFunctionTx

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| ComTxTimeBase       | 11           |
| ComPartitionRef     | 11           |

| Parameter Name      | ComTxTimeBase  |                  |
|---------------------|--|------------------|
| Description         | The period between successive calls to Com transmission main functions in seconds. This parameter is used by the COM generator to transform the values of the transmission related timing configuration parameters of the COM module to internal implementation specific counter or tick values. The COM module's internal timing handling is implementation specific. The COM module (generator) relies on the fact that the appropriate Com main function is scheduled according to the value configured here. |                  |
| Multiplicity        | 11   |                  |
| Туре                | FLOAT  |                  |
| Default value       | 0.005  |                  |
| Range               | <=3600<br>>=0  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |



| Origin | Elektrobit Automotive GmbH |
|--------|----------------------------|
|--------|----------------------------|

| Parameter Name      | ComPartitionRef  |  |
|---------------------|--|--|
| Description         | References a EcuC partition to allow grouping of Tx Com main functions according to EcucPartition elements. This grouping is used to implement dedicated BswImplementations. |  |
| Multiplicity        | 11   |  |
| Туре                | REFERENCE  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

### 5.2.1.28. ComRxMainFunctions

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| Com_MainFunctionRx  | 1n           | Contains the reception main functions of COM module. |

## 5.2.1.29. Com\_MainFunctionRx

| Parameters included    |              |
|------------------------|--------------|
| Parameter name         | Multiplicity |
| ComRxTimeBase          | 11           |
| <u>ComPartitionRef</u> | 11           |

| Parameter Name | ComRxTimeBase   |
|----------------|---|
| Description    | The period between successive calls to Com reception main functions in seconds. This parameter is used by the COM generator to transform the values of the transmission related timing configuration parameters of the COM module to internal implementation specific counter or tick values. The COM module's internal timing handling is implementation specific. The COM module (generator) relies on the fact that the appropriate Com main function is scheduled according to the value configured here. |
| Multiplicity   | 11  |
| Туре           | FLOAT   |



| Default value       | 0.005                      |                  |
|---------------------|----------------------------|------------------|
| Range               | <=3600                     |                  |
|                     | >=0                        |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComPartitionRef  |  |
|---------------------|--|--|
| Description         | References a EcuC partition to allow grouping of Rx Com main functions according to EcucPartition elements. This grouping is used to implement dedicated BswImplementations. |  |
| Multiplicity        | 11   |  |
| Туре                | REFERENCE  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

### 5.2.1.30. ComIPduCalloutsTx

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| ComIPduCalloutTx    | 0n           |  |

| Parameter Name      | ComlPduCalloutTx                    |  |
|---------------------|-------------------------------------|--|
| Description         | ComIPdu transmission callout entry. |  |
| Multiplicity        | 0n                                  |  |
| Туре                | FUNCTION-NAME                       |  |
| Configuration class | Link: VariantPostBuild              |  |
| Origin              | Elektrobit Automotive GmbH          |  |

#### 5.2.1.31. ComlPduCalloutsRx

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |



| Parameters included |    |
|---------------------|----|
| ComIPduCalloutRx    | 0n |

| Parameter Name      | ComlPduCalloutRx                 |  |
|---------------------|----------------------------------|--|
| Description         | ComlPdu reception callout entry. |  |
| Multiplicity        | 0n                               |  |
| Туре                | FUNCTION-NAME                    |  |
| Configuration class | Link: VariantPostBuild           |  |
| Origin              | Elektrobit Automotive GmbH       |  |

## 5.2.1.32. ComGeneral

| Containers included   |              |  |
|-----------------------|--------------|--|
| Container name        | Multiplicity | Description  |
| <u>VendorSpecific</u> | 11           | Contains the vendor specific configuration parameters of the AUTOSAR COM module. |

| Parameters included               |              |  |
|-----------------------------------|--------------|--|
| Parameter name                    | Multiplicity |  |
| ComConfigurationUseDet            | 01           |  |
| ComEnableMDTForCyclicTransmission | 01           |  |
| ComRetryFailedTransmitRequests    | 01           |  |
| ComSupportedIPduGroups            | 11           |  |
| <u>ComVersionInfoApi</u>          | 11           |  |
| ComEnableSignalGroupArrayApi      | 11           |  |

| Parameter Name      | ComConfigurationUseDet  |                  |
|---------------------|---|------------------|
| Description         | The error hook shall contain code to call the Det. If this parameter is configured COM_DEV_ERROR_DETECT shall be set to ON as output of the configuration tool. (as input for the source code), see COM028. |                  |
| Multiplicity        | 01  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | true  |                  |
| Configuration class | PreCompile:   | VariantPostBuild |



| Origin | AUTOSAR_ECUC |
|--------|--------------|
|--------|--------------|

| Parameter Name      | ComEnableMDTForCyclicTransmission  |  |
|---------------------|--|--|
| Description         | Enables globally for the whole Com module the minimum delay time monitoring for cyclic and repeated transmissions (ComTxModeMode=PERIODIC or ComTxModeMode=MIXED for the cyclic transmissions, ComTxModeNumberOfRepetitions > 0 for repeated transmissions). |  |
| Multiplicity        | 01   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | PreCompile: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | ComRetryFailedTransmitRequests  |  |
|---------------------|---|--|
| Description         | If this Parameter is set to true, retry of failed transmission requests is enabled. If this Parameter is not present, the default value is assumed. |  |
| Multiplicity        | 01  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | PreCompile: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | ComSupportedIPduGroups                                |                  |  |
|---------------------|---|------------------|--|
| Description         | Defines the maximum number of supported I-PDU groups. |                  |  |
| Multiplicity        | 11  | 11               |  |
| Туре                | INTEGER   | INTEGER          |  |
| Default value       | 32  |                  |  |
| Range               | <=65535   |                  |  |
|                     | >=1   |                  |  |
| Configuration class | VariantPostBuild:                                     | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC  |                  |  |

| Parameter Name | ComVersionInfoApi  |
|----------------|--|
| Description    | Activate/Deactivate the version information API (Com_GetVersionInfo). True:  |
|                | version information API activated False: version information API deactivated |



| Multiplicity        | 11                |                  |
|---------------------|-------------------|------------------|
| Туре                | BOOLEAN           |                  |
| Default value       | false             |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | ComEnableSignalGroupArrayApi  |  |
|---------------------|---|--|
| Description         | Activate/Deactivate the signal group array access APIs (Com_SendSignal-GroupArray, Com_ReceiveSignalGroupArray). true: signal group array access APIs activated; Please use the parameter ComBasedTransformerSupportTx and ComBasedTransformerSupportRx to enable and disable the APIs individually false: signal group array access APIs deactivated |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | true  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

## 5.2.1.33. VendorSpecific

| Containers included  |              |  |
|----------------------|--------------|--|
| Container name       | Multiplicity | Description  |
| ComGeneratedRxSignal | 01           | This container contains the configuration parameters for the generated functions / macros for reading signal values.  NOTE> if this container is enabled, the macros are generated.  ENABLED: Macros for signal extraction are generated.  Generation of functions depends on ComGeneratedR-cvSigEnable.  DISABLED: Neither macros nor functions for singal are generated. |
|                      |              | Optimization Effect:   |
|                      |              | Execution time reduction (code): Using these macros<br>and/or functions reduces the execution time extraction of<br>signals.   |



| Containers included |   |
|---------------------|---|
|                     | <b>ROM increase (code):</b> Using these macros and/or functions increases the ROM consumption of the module code. |

| Parameters included                      |              |
|--|--------------|
| Parameter name                           | Multiplicity |
| ComDataMemSize                           | 01           |
| <u>ComRamSizeMax</u>                     | 11           |
| ComCbkTxTOutArraySizeMax                 | 11           |
| ComCbkRxTOutArraySizeMax                 | 11           |
| ComCbkRxAckPtrArraySizeMax               | 11           |
| ComCbkTxAckPtrArraySizeMax               | 11           |
| ComCallOutFuncPtrArraySizeMax            | 11           |
| ComTriggerTxCallOutEnable                | 11           |
| ComRxDataTimeoutAction                   | 11           |
| ComRxTimeoutFactorSize                   | 11           |
| ComRxFirstTimeoutFactorSize              | 11           |
| ComTxTimeoutFactorSize                   | 11           |
| ComTxModeRepetitionPeriodFactorS         | 11           |
| ComTxModeTimeOffsetFactorSize            | 11           |
| ComTxModeTimePeriodFactorSize            | 11           |
| ComTxlpduMDTFactorSize                   | 11           |
| ComUpdateBitRxConfig                     | 11           |
| ComUpdateBitTxConfig                     | 11           |
| ComClearUpdateBitTxTransmitEnable        | 11           |
| ComClearUpdateBitTxTriggerTransmitEnable | 11           |
| ComClearUpdateBitTxTxConfirmationEnable  | 11           |
| ComTmsEnable                             | 11           |
| ComFilterReceiverEnable                  | 11           |
| ComTxDynLengthIPduEnable                 | 11           |
| ComRxDynLengthIPduEnable                 | 11           |
| ComFilterOneEveryNPeriodOffSMax          | 11           |
| ComFilterOneEveryNOccuranceMax           | 11           |



| Parameters included                 |    |
|-------------------------------------|----|
| <u>ComTxModeDirectEnable</u>        | 11 |
| <u>ComTxModeNTimesEnable</u>        | 11 |
| <u>ComTxModePeriodicEnable</u>      | 11 |
| <u>ComTxModeMixedDirectEnable</u>   | 11 |
| ComTxModeMixedNTimesEnable          | 11 |
| ComTxSigConfDeferredEnable          | 11 |
| ComTxSigConfImmediateEnable         | 11 |
| ComRxSigConfDeferredEnable          | 11 |
| ComRxSigConfImmediateEnable         | 11 |
| ComSignalGwEnable                   | 11 |
| ComCheckValueSizeEnable             | 11 |
| ComConstCfgAddressEnable            | 11 |
| ComConstCfgAddress                  | 11 |
| ComRelocatableCfgEnable             | 11 |
| Com_TxF_MaskNewDiffersMaskOld_En    | 11 |
| ComSigGwRxFilterEnable              | 11 |
| <u>ComTransfPropTriggeredEnable</u> | 11 |
| ComTransfPropTriggeredOCEnable      | 11 |
| ComTransfPropWithoutRepEnable       | 11 |
| ComRxTpAPIEnable                    | 11 |
| ComTxTpAPIEnable                    | 11 |
| ComTxBigEndianEnable                | 11 |
| ComTxLittleEndianEnable             | 11 |
| ComRxBigEndianEnable                | 11 |
| <u>ComRxLittleEndianEnable</u>      | 11 |
| ComTxZeroSignalEnable 11            |    |
| ComBasedTransformerSupportTx        | 11 |
| ComBasedTransformerSupportRx        | 11 |
| ComTxGroupSignalNoLock              | 11 |
| ComDeferTx2MainFunc                 | 11 |
| ComHandleSmallerRxPdus              | 11 |



| Parameter Name      | ComDataMemSize  |  |
|---------------------|---|--|
| Description         | Size of internal Com data in units of bytes (static memory allocation) - Memory required by post-build configuration must be smaller than this constant. If parameter is disabled, the MCG calculates itself. |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER   |  |
| Configuration class | Link: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name      | ComRamSizeMax  |   |  |
|---------------------|--|---|--|
| Description         | This parameter defines the maximum n RAM.  | This parameter defines the maximum number of values which can addressed in RAM. |  |
|                     | ► INDEX_UINT8: uint8 is used as an COM module has to be smaller that   | ray index (RAM usage of the AUTOSAR n 256 bytes)                                |  |
|                     | INDEX_UINT16: uint16 is used as TOSAR COM module has to be sm  | array index (RAM usage of the AU-<br>naller than 65536 bytes)                   |  |
|                     | INDEX_UINT32: uint32 is used as TOSAR COM module has to be sm  | array index (RAM usage of the AU-<br>naller than 4294967296 bytes)              |  |
|                     | Optimization Effect:   |   |  |
|                     | ▶ ROM reduction (config): The smaller the index the smaller the ROM consumption of the module configuration. |   |  |
| Multiplicity        | 11   |   |  |
| Туре                | ENUMERATION  |   |  |
| Default value       | INDEX_UINT16   |   |  |
| Range               | INDEX_UINT8  |   |  |
|                     | INDEX_UINT16   |   |  |
|                     | INDEX_UINT32   |   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |   |  |
| Origin              | Elektrobit Automotive GmbH   |   |  |

| Parameter Name | ComCbkTxTOutArraySizeMax  |
|----------------|---|
| Description    | This parameter defines the maximum size of the array for Com_CbkTxTOut    |
|                | callback functions (see also COM554). NOTE: if (ComTxTimeoutFactorSize == |
|                | SIZE_0_BIT) this parameter has to be INDEX_NONE.                          |



|                     | INDEX_NONE: the array is om not supported (for all signals/s  | itted and therefore Tx Deadline Monitoring is signal groups).                |
|---------------------|---|--|
|                     | ■ INDEX_UINT8: the reference of callbacks is 0xFE.  | to the array is 8 bit and the maximum number                                 |
|                     | ber of callbacks is 0xFFFE.   | e to the array is 16 bit and the maximum num-                                |
|                     | Optimization Effect:  |  |
|                     | ROM reduction (config): The smaller the index the smaller the ROM consumption of the module configuration.                  |  |
|                     | ➤ ROM reduction (code): If INDEX_NONE is used the feature is disabled which reduces the ROM consumption of the module code. |  |
|                     |   | ode): If INDEX_NONE is used the feature is secution time of the module code. |
| Multiplicity        | 11  |  |
| Туре                | ENUMERATION   |  |
| Default value       | INDEX_UINT16  |  |
| Range               | INDEX_NONE  |  |
|                     | INDEX_UINT8   |  |
|                     | INDEX_UINT16  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild   |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name | ComCbkRxTOutArraySizeMax  |
|----------------|---|
| Description    | This parameter defines the maximum size of the array for Com_CbkRxTOut callback functions (see also COM556). NOTE: if (ComRxTimeoutFactorSize == SIZE_0_BIT) this parameter has to be INDEX_NONE. |
|                | ■ INDEX_NONE: the array is omitted and therefore Rx Deadline Monitoring is not supported (for all signals/signal groups).   |
|                | ▶ INDEX_UINT8: the reference to the array is 8 bit and the maximum number of callbacks is 0xFE.   |
|                | ▶ INDEX_UINT16: the reference to the array is 16 bit and the maximum number of callbacks is 0xFFFE.   |
|                | Optimization Effect:  |



|                     | ROM reduction (config): The sma sumption of the module configuration  | ller the index the smaller the ROM con-<br>on.                   |
|---------------------|---|--|
|                     | ROM reduction (code): If INDEX_I<br>which reduces the ROM consumption | NONE is used the feature is disabled on of the module code.      |
|                     | Execution time reduction (code): disabled which reduces the execution | If INDEX_NONE is used the feature is on time of the module code. |
| Multiplicity        | 11  |  |
| Туре                | ENUMERATION   |  |
| Default value       | INDEX_UINT16  |  |
| Range               | INDEX_NONE  |  |
|                     | INDEX_UINT8   |  |
|                     | INDEX_UINT16  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild   |

| Parameter Name | ComCbkRxAckPtrArraySizeMax   |
|----------------|--|
| Description    | This parameter defines the maximum size of the array for Com_CbkRxAck call-back functions (see also COM555).                               |
|                | INDEX_NONE: the array is omitted and therefore receive notification is not supported (for all signals/signal groups).                      |
|                | ■ INDEX_UINT8: the reference to the array is 8 bit and the maximum number of callbacks is 0xFE.  |
|                | ▶ INDEX_UINT16: the reference to the array is 16 bit and the maximum number of callbacks is 0xFFFE.  |
|                | Optimization Effect:   |
|                | <b>ROM reduction (config):</b> The smaller the index the smaller the ROM consumption of the module configuration.                          |
|                | ▶ ROM reduction (code): If INDEX_NONE is used the feature is disabled which reduces the ROM consumption of the module code.                |
|                | <b>Execution time reduction (code):</b> If INDEX_NONE is used the feature is disabled which reduces the execution time of the module code. |
| Multiplicity   | 11   |
| Туре           | ENUMERATION  |
| Default value  | INDEX_UINT16   |
| Range          | INDEX_NONE   |



|                     | INDEX_UINT8                |                  |
|---------------------|----------------------------|------------------|
|                     | INDEX_UINT16               |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComCbkTxAckPtrArraySizeMax   |  |
|---------------------|--|--|
| Description         | This parameter defines the maximum size of the array for Com_CbkTxAck callback functions (see also COM468).                            |  |
|                     | ■ INDEX_NONE: the array is omitted and therefore transmit notification is not supported (for all signals/signal groups).               |  |
|                     | ▶ INDEX_UINT8: the reference to the array is 8 bit and the maximum number of callbacks is 0xFE.  |  |
|                     | ▶ INDEX_UINT16: the reference to the array is 16 bit and the maximum number of callbacks is 0xFFFE.                                    |  |
|                     | Optimization Effect:   |  |
|                     | <b>ROM reduction (config):</b> The smaller the index the smaller the ROM consumption of the module configuration.                      |  |
|                     | ▶ ROM reduction (code): If INDEX_NONE is used the feature is disabled which reduces the ROM consumption of the module code.            |  |
|                     | Execution time reduction (code): If INDEX_NONE is used the feature is<br>disabled which reduces the execution time of the module code. |  |
| Multiplicity        | 11   |  |
| Туре                | ENUMERATION  |  |
| Default value       | INDEX_UINT16   |  |
| Range               | INDEX_NONE   |  |
|                     | INDEX_UINT8  |  |
|                     | INDEX_UINT16   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | ComCallOutFuncPtrArraySizeMax  |  |
|----------------|--|--|
| Description    | This parameter defines the maximum number of Call-out function pointers in |  |
|                | Com_RxCallouts and Com_TxCallouts.   |  |



|                     | ▶ INDEX_NONE: the array is omitted and therefore Pdu callouts are not supported.  |  |
|---------------------|---|--|
|                     | ■ INDEX_UINT8: the reference to the array is 8 bit and the maximum number of Rx-Pdu callouts is 0xFE and Tx-Pdu callouts is 0xFE.       |  |
|                     | ▶ INDEX_UINT16: the reference to the array is 16 bit and the maximum number of Rx-Pdu callouts is 0xFFFE and Tx-Pdu callouts is 0xFFFE. |  |
|                     | Optimization Effect:  |  |
|                     | ➤ ROM reduction (config): The smaller the index the smaller the ROM consumption of the module configuration.                            |  |
|                     | ➤ ROM reduction (code): If INDEX_NONE is used the feature is disabled which reduces the ROM consumption of the module code.             |  |
|                     | Execution time reduction (code): If INDEX_NONE is used the feature is disabled which reduces the execution time of the module code.     |  |
| Multiplicity        | 11  |  |
| Туре                | ENUMERATION   |  |
| Default value       | INDEX_UINT16  |  |
| Range               | INDEX_NONE  |  |
|                     | INDEX_UINT8   |  |
|                     | INDEX_UINT16  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |
| Parameter Name      | ComTriggerTxCallOutEnable   |  |
| Description         | Enables the configuration of callout for Com_TriggerTransmit() API (configuration parameter ComIPduTriggerTransmitCallout).             |  |
|                     | ► TRUE: The configuration parameter ComIPduTriggerTransmitCallout is available.   |  |
|                     | FALSE: The configuration parameter ComlPduTriggerTransmitCallout is not available.  |  |
|                     | Optimization Effect:  |  |
|                     | ➤ ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.                             |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |



| Default value       | true                         |  |
|---------------------|------------------------------|--|
| Configuration class | PreCompile: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| ComRxDataTimeoutAction   |  |
|--|--|
| This parameter defines the action performed upon a reception of a timeout violation.   |  |
| RX_DATA_TIMEOUT_ACTION_NONE: for all signals no replacement takes place.   |  |
| RX_DATA_TIMEOUT_ACTION_REPLACE: for all signals a replacement with ComInitValue takes place.   |  |
| RX_DATA_TIMEOUT_ACTION_CONFIG: for each signal the action can be defined.  |  |
| Optimization Effect:   |  |
| <b>ROM reduction (config):</b> RX_DATA_TIMEOUT_ACTION_NONE and RXDATA_TIMEOUT_ACTION_REPLACE may reduce the ROM consumption of the module configuration (depends on other features if a reduction can be achieved).                  |  |
| ROM reduction (code): RX_DATA_TIMEOUT_ACTION_NONE remove code for feature; RX_DATA_TIMEOUT_ACTION_REPLACE disables fe ture partly, therefore these values of the parameter reduce the ROM cor sumption of the module code.           |  |
| Execution time reduction (code): RX_DATA_TIMEOUT_ACTION_NONE removes code for feature; RX_DATA_TIMEOUT_ACTION_REPLACE disables feature partly, therefore these values of the parameter reduce the execution time of the module code. |  |
| 11   |  |
| ENUMERATION  |  |
| RX_DATA_TIMEOUT_ACTION_CONFIG  |  |
| RX_DATA_TIMEOUT_ACTION_NONE  |  |
| RX_DATA_TIMEOUT_ACTION_REPLACE   |  |
| RX_DATA_TIMEOUT_ACTION_CONFIG  |  |
| VariantPostBuild: VariantPostBuild   |  |
| Elektrobit Automotive GmbH   |  |
|  | This parameter defines the action perfortion.  RX_DATA_TIMEOUT_ACTION_NONIPLE.  RX_DATA_TIMEOUT_ACTION_REPRODUCT.  ComInitValue takes place.  RX_DATA_TIMEOUT_ACTION_CONIDETE.  ROM reduction (config): RX_DATA_DATA_TIMEOUT_ACTION_REPLATE.  of the module configuration (dependence).  ROM reduction (code): RX_DATA_CODETE.  ROM reduction (code): RX_DATA_CODETE.  ROM reduction (code): RX_DATA_TIMEOUT.  ture partly, therefore these values of sumption of the module code.  Execution time reduction (code): removes code for feature; RX_DATA_ables feature partly, therefore these cution time of the module code.  11  ENUMERATION  RX_DATA_TIMEOUT_ACTION_CONFIGURA_DATA_TIMEOUT_ACTION_NONE  RX_DATA_TIMEOUT_ACTION_REPLATA_RX_DATA_TIMEOUT_ACTION_REPLATA_RX_DATA_TIMEOUT_ACTION_CONFIGURA_CONFIGU |



| Parameter Name      | ComRxTimeoutFactorSize   |  |  |
|---------------------|--|--|--|
| Description         | This parameter defines the size of ComRxTimeoutFactor for all Rx signals / group signals.  |  |  |
|                     | ► SIZE_0_BIT: the parameter ComRxTimeoutFactor is not available.   |  |  |
|                     | ► SIZE_8_BIT: the parameter ComRxTimeoutFactor is a 8 bit value.   |  |  |
|                     | ► SIZE_16_BIT: the parameter ComRxTimeoutFactor is a 16 bit value.   |  |  |
|                     | ► SIZE_32_BIT: the parameter ComRxTimeoutFactor is a 32 bit value.   |  |  |
|                     | Optimization Effect:   |  |  |
|                     | <b>ROM reduction (config):</b> The smaller the size the smaller the ROM consumption of the module configuration.                           |  |  |
|                     | ▶ <b>ROM reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the ROM consumption of the module code.         |  |  |
|                     | <b>Execution time reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the execution time of the module code. |  |  |
| Multiplicity        | 11   |  |  |
| Туре                | ENUMERATION  |  |  |
| Default value       | SIZE_16_BIT  |  |  |
| Range               | SIZE_0_BIT   |  |  |
|                     | SIZE_8_BIT   |  |  |
|                     | SIZE_16_BIT  |  |  |
|                     | SIZE_32_BIT  |  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |  |
| Origin              | Elektrobit Automotive GmbH   |  |  |

| Parameter Name | ComRxFirstTimeoutFactorSize  |  |
|----------------|--|--|
| Description    | This parameter defines the size of ComRxFirstTimeoutFactor for all Rx signals / group signals. |  |
|                | ► SIZE_0_BIT: the parameter ComRxFirstTimeoutFactor is not available.                          |  |
|                | ► SIZE_8_BIT: the parameter ComRxFirstTimeoutFactor is a 8 bit value.                          |  |
|                | ► SIZE_16_BIT: the parameter ComRxFirstTimeoutFactor is a 16 bit value.                        |  |
|                | SIZE_32_BIT: the parameter ComRxFirstTimeoutFactor is a 32 bit value.                          |  |
|                | Optimization Effect:   |  |



|   | <b>ROM reduction (config):</b> The smaller the size the smaller the ROM consumption of the module configuration. |  |                  |
|---|--|--|------------------|
|   |  | <b>ROM reduction (code):</b> If SIZE_0_BIT is used the feature is disabled whice reduces the ROM consumption of the module code. |                  |
| Execution time reduction (code): If SIZE_0_BIT is used the feature abled which reduces the execution time of the module code. |  |  |                  |
| Multiplicity  | 11   | 11   |                  |
| Туре  | ENUMERATION  |  |                  |
| Default value   | SIZ  | SIZE_16_BIT  |                  |
| Range   | SIZE_0_BIT   |  |                  |
|   | SIZE_8_BIT   |  |                  |
|   | SIZE_16_BIT  |  |                  |
|   | SIZE_32_BIT  |  |                  |
| Configuration class   | Va   | riantPostBuild:  | VariantPostBuild |
| Origin  | Elektrobit Automotive GmbH   |  |                  |

| Parameter Name | ComTxTimeoutFactorSize   |  |
|----------------|--|--|
| Description    | This parameter defines the size of ComTxTimeoutFactor for all Tx signals / group signals.  |  |
|                | ► SIZE_0_BIT: the parameter ComTxTimeoutFactor is not available.   |  |
|                | ► SIZE_8_BIT: the parameter ComTxTimeoutFactor is a 8 bit value.   |  |
|                | ► SIZE_16_BIT: the parameter ComTxTimeoutFactor is a 16 bit value.   |  |
|                | ► SIZE_32_BIT: the parameter ComTxTimeoutFactor is a 32 bit value.   |  |
|                | Optimization Effect:   |  |
|                | ▶ ROM reduction (config): The smaller the size the smaller the ROM consumption of the module configuration.                                |  |
|                | ▶ ROM reduction (code): If SIZE_0_BIT is used the feature is disabled which reduces the ROM consumption of the module code.                |  |
|                | <b>Execution time reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the execution time of the module code. |  |
| Multiplicity   | 11   |  |
| Туре           | ENUMERATION  |  |
| Default value  | SIZE_16_BIT  |  |



| Range               | SIZE_0_BIT                 |                  |  |
|---------------------|----------------------------|------------------|--|
|                     | SIZE_8_BIT                 |                  |  |
|                     | SIZE_16_BIT                |                  |  |
|                     | SIZE_32_BIT                |                  |  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH |                  |  |

| Parameter Name      | ComTxModeRepetitionPeriodFactorS   |  |  |
|---------------------|--|--|--|
| Description         | This parameter defines the size of ComTxModeRepetitionPeriodFactor.  |  |  |
|                     | ➤ SIZE_0_BIT: the parameter ComTxModeRepetitionPeriodFactor is not available and therefore the transmission modes "Direct/NTimes" and "Mixed". |  |  |
|                     | SIZE_8_BIT: the parameter value.   | ComTxModeRepetitionPeriodFactor is a 8 bit   |  |
|                     | SIZE_16_BIT: the parameter bit value.  | er ComTxModeRepetitionPeriodFactor is a 16   |  |
|                     | ➤ SIZE_32_BIT: the parameter bit value.  | er ComTxModeRepetitionPeriodFactor is a 32   |  |
|                     | Optimization Effect:   | Optimization Effect:   |  |
|                     | ➤ ROM reduction (config): The smaller the size the smaller the ROM consumption of the module configuration.                                    |  |  |
|                     | · · · · ·  | <b>ROM reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the ROM consumption of the module code.           |  |
|                     | · ·  | <b>Execution time reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the execution time of the module code. |  |
| Multiplicity        | 11   |  |  |
| Туре                | ENUMERATION  |  |  |
| Default value       | SIZE_16_BIT  |  |  |
| Range               | SIZE_0_BIT   |  |  |
|                     | SIZE_8_BIT SIZE_16_BIT   |  |  |
|                     |  |  |  |
|                     | SIZE_32_BIT  |  |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild   |  |



| Origin |
|--------|
|--------|

| Parameter Name      | ComTxModeTimeOffsetFactorSize  |  |
|---------------------|--|--|
| Description         | This parameter defines the size of ComTxModeTimeOffsetFactor.  |  |
|                     | SIZE_0_BIT: the parameter ComTxModeTimeOffsetFactor is not available and equal to 0.   |  |
|                     | ► SIZE_8_BIT: the parameter ComTxModeTimeOffsetFactor is a 8 bit value.  |  |
|                     | SIZE_16_BIT: the parameter ComTxModeTimeOffsetFactor is a 16 bit value.  |  |
|                     | SIZE_32_BIT: the parameter ComTxModeTimeOffsetFactor is a 32 bit value.  |  |
|                     | Optimization Effect:   |  |
|                     | ▶ ROM reduction (config): The smaller the size the smaller the ROM consumption of the module configuration.  |  |
|                     | <ul> <li>ROM reduction (code): If SIZE_0_BIT is used the feature is disabled which reduces the ROM consumption of the module code.</li> <li>Execution time reduction (code): If SIZE_0_BIT is used the feature is disabled which reduces the execution time of the module code.</li> </ul> |  |
|                     |  |  |
| Multiplicity        | 11   |  |
| Туре                | ENUMERATION  |  |
| Default value       | SIZE_16_BIT  |  |
| Range               | SIZE_0_BIT   |  |
|                     | SIZE_8_BIT   |  |
|                     | SIZE_16_BIT  |  |
|                     | SIZE_32_BIT  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | ComTxModeTimePeriodFactorSize   |  |  |
|----------------|---|--|--|
| Description    | This parameter defines the size of ComTxModeTimePeriodFactor.   |  |  |
|                | SIZE_0_BIT: the parameter ComTxModeTimePeriodFactor is not available and therefore the transmission modes "Periodic" and "Mixed". |  |  |
|                | ► SIZE_8_BIT: the parameter ComTxModeTimePeriodFactor is a 8 bit value.   |  |  |



|                     | <ul> <li>SIZE_16_BIT: the parameter ComTxModeTimePeriodFactor is a 16 bit value.</li> <li>SIZE_32_BIT: the parameter ComTxModeTimePeriodFactor is a 32 bit value.</li> <li>Optimization Effect:</li> <li>ROM reduction (config): The smaller the size the smaller the ROM consumption of the module configuration.</li> <li>ROM reduction (code): If SIZE_0_BIT is used the feature is disabled which reduces the ROM consumption of the module code.</li> </ul> |                  |
|---------------------|--|------------------|
|                     | <b>Execution time reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the execution time of the module code.   |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Default value       | SIZE_16_BIT  |                  |
| Range               | SIZE_0_BIT   |                  |
|                     | SIZE_8_BIT   |                  |
|                     | SIZE_16_BIT  |                  |
|                     | SIZE_32_BIT  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | ComTxIpduMDTFactorSize   |  |
|----------------|--|--|
| Description    | This parameter defines the size of ComTxIPduMinimumDelayTimeFactor.  |  |
|                | ► SIZE_0_BIT: the parameter ComTxlPduMinimumDelayTimeFactor is not available.                                    |  |
|                | ► SIZE_8_BIT: the parameter ComTxlPduMinimumDelayTimeFactor is a 8 bit value.                                    |  |
|                | ■ SIZE_16_BIT: the parameter ComTxlPduMinimumDelayTimeFactor is a 16 bit value.                                  |  |
|                | ■ SIZE_32_BIT: the parameter ComTxlPduMinimumDelayTimeFactor is a 32 bit value.                                  |  |
|                | Optimization Effect:   |  |
|                | <b>ROM reduction (config):</b> The smaller the size the smaller the ROM consumption of the module configuration. |  |



|                     | <b>ROM reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the ROM consumption of the module code.           |                  |
|---------------------|--|------------------|
|                     | <b>Execution time reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the execution time of the module code. |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Default value       | SIZE_16_BIT  |                  |
| Range               | SIZE_0_BIT   |                  |
|                     | SIZE_8_BIT   |                  |
|                     | SIZE_16_BIT  |                  |
|                     | SIZE_32_BIT  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | ComUpdateBitRxConfig  |
|----------------|---|
| Description    | This parameter defines the update bit behavior on receiver side.  |
|                | ■ UPDATE_BIT_ABSENT_FOR_ALL: Optimization is switched on, update bits are not supported on Rx side.   |
|                | ■ UPDATE_BIT_PRESENT_FOR_ALL: Optimization is switched on, update bits are configured for all signals / signal groups on Rx side.   |
|                | ■ UPDATE_BIT_INDIVIDUAL: Optimization is switched off, presents of update bits can be configured individually on Rx side.   |
|                | Optimization Effect:  |
|                | ROM reduction (config): UPDATE_BIT_ABSENT_FOR_ALL reduces the ROM consumption of the module configuration, UPDATE_BIT_PRESENT_FOR_ALL may reduce the ROM consumption of the module configuration. |
|                | ■ ROM reduction (code): UPDATE_BIT_ABSENT_FOR_ALL reduces the<br>ROM consumption of the module code, UPDATE_BIT_PRESENT_FOR<br>ALL reduces the ROM consumption of the module code slightly.       |
|                | Execution time reduction (code): UPDATE_BIT_ABSENT_FOR_ALL reduces the execution time of the module code, UPDATE_BIT_PRESENTFOR_ALL reduces the execution time of the module code slightly.       |
| Multiplicity   | 11  |
| Туре           | ENUMERATION   |



| Default value       | UPDATE_BIT_INDIVIDUAL      |                  |
|---------------------|----------------------------|------------------|
| Range               | UPDATE_BIT_ABSENT_FOR_ALL  |                  |
|                     | UPDATE_BIT_PRESENT_FOR_ALL |                  |
|                     | UPDATE_BIT_INDIVIDUAL      |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComUpdateBitTxConfig   |  |
|---------------------|--|--|
| Description         | This parameter defines the update bit behavior on sender side.   |  |
|                     | ■ UPDATE_BIT_ABSENT_FOR_ALL: Optimization is switched on, update bits are not supported on Tx side.  |  |
|                     | ■ UPDATE_BIT_PRESENT_FOR_ALL: Optimization is switched on, update bits are configured for all signals / signal groups on Tx side.  |  |
|                     | ■ UPDATE_BIT_INDIVIDUAL: Optimization is switched off, presents of update bits can be configured individually on Tx side.  |  |
|                     | Optimization Effect:   |  |
|                     | ▶ ROM reduction (config): UPDATE_BIT_ABSENT_FOR_ALL reduces the ROM consumption of the module configuration.   |  |
|                     | ROM reduction (code): UPDATE_BIT_ABSENT_FOR_ALL reduces the ROM consumption of the module code, UPDATE_BIT_PRESENT_FORALL reduces the ROM consumption of the module code slightly.           |  |
|                     | Execution time reduction (code): UPDATE_BIT_ABSENT_FOR_ALL reduces the execution time of the module code, UPDATE_BIT_PRESENT_FOR_ALL reduces the execution time of the module code slightly. |  |
| Multiplicity        | 11   |  |
| Туре                | ENUMERATION  |  |
| Default value       | UPDATE_BIT_INDIVIDUAL  |  |
| Range               | UPDATE_BIT_ABSENT_FOR_ALL  |  |
|                     | UPDATE_BIT_PRESENT_FOR_ALL   |  |
|                     | UPDATE_BIT_INDIVIDUAL  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | ComClearUpdateBitTxTransmitEnable |
|----------------|-----------------------------------|
|----------------|-----------------------------------|



| Description         | This parameter enables / disables clearing of update bits after a call to PduRComTransmit.                    |                  |  |
|---------------------|---|------------------|--|
|                     | ■ TRUE: Optimization is switched off, clearing of update bits after a call to<br>PduR_ComTransmit is enabled. |                  |  |
|                     | ► FALSE: Optimization is switched on, update bits are never cleared after a call to PduR_ComTransmit.         |                  |  |
|                     | Optimization Effect:  |                  |  |
|                     | Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.    |                  |  |
| Multiplicity        | 11  |                  |  |
| Туре                | BOOLEAN   |                  |  |
| Default value       | true  |                  |  |
| Configuration class | PreCompile:   | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH  |                  |  |

| Parameter Name      | ComClearUpdateBitTxTriggerTransmitEnable  |                  |
|---------------------|---|------------------|
| Description         | This parameter enables / disables clearing of update bits during a call to Com TriggerTransmit.  TRUE: Optimization is switched off, clearing of update bits during a call to Com_TriggerTransmit is enabled. |                  |
|                     |   |                  |
|                     | FALSE: Optimization is switched on, update bits are never cleared during a call to Com_TriggerTransmit.   |                  |
|                     | Optimization Effect:  |                  |
|                     | Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.  |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | true  |                  |
| Configuration class | PreCompile:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | ComClearUpdateBitTxTxConfirmationEnable  |  |
|----------------|--|--|
| Description    | This parameter enables / disables clearing of update bits during a call to Com |  |
|                | TxConfirmation.  |  |



|                     | Com_TxConfirmation is enabled.   | clearing of update bits during a call to |
|---------------------|--|--|
|                     | Optimization Effect:  Execution time reduction (code): Enabling this optimization reduces the execution time of the module code. |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | PreCompile:  | VariantPostBuild                         |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComTmsEnable  |                 |  |
|---------------------|---|-----------------|--|
| Description         | This parameter enables / disables the Transmission Mode Selection (TMS).  |                 |  |
|                     | ► TRUE: Optimization is switched off, ¬   | ΓMS is enabled. |  |
|                     | FALSE: Optimization is switched on, TMS is disabled (change between TM is not supported).   |                 |  |
|                     | Optimization Effect:  |                 |  |
|                     | ▶ <b>ROM reduction (config):</b> Enabling this optimization reduces the ROM consumption of the module configuration.  |                 |  |
|                     | <b>ROM reduction (code):</b> Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included. |                 |  |
|                     | Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.  |                 |  |
| Multiplicity        | 11  |                 |  |
| Туре                | BOOLEAN   |                 |  |
| Default value       | true  |                 |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |                 |  |
| Origin              | Elektrobit Automotive GmbH  |                 |  |

| Parameter Name ComFilterReceiverEnable |  |
|--|--|
|--|--|



| Description         | This parameter enables / disables filtering on receiver side.  |  |
|---------------------|--|--|
|                     | TRUE: Optimization is switched off, filtering on receiver side is enabled.   |  |
|                     | FALSE: Optimization is switched on, filtering on receiver side is disabled for all signals.  |  |
|                     | Optimization Effect:   |  |
|                     | ▶ <b>ROM reduction (config):</b> Enabling this optimization reduces the ROM consumption of the module configuration.   |  |
|                     | ▶ ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included. |  |
|                     | <b>Execution time reduction (code):</b> Enabling this optimization reduces the execution time of the module code.  |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComTxDynLengthIPduEnable   |                  |
|---------------------|--|------------------|
| Description         | <ul> <li>This parameter enables / disables features related to the variable length of an Tx-IPdu. This is required for dynamic length signal support.</li> <li>TRUE: Optimization is switched off, length of Tx-IPdu can vary.</li> <li>FALSE: Optimization is switched on, length of Rx-IPdu is fix as configured in EcuC.</li> <li>Optimization Effect:</li> <li>RAM reduction (code): Enabling this optimization reduces the RAM consumption of the module configuration.</li> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption (code): Enabling this optimization (code): Enabling this opti</li></ul> |                  |
|                     | sumption of the module code.   |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | true   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |



| Origin              | Elektrobit Automotive GmbH   |  |  |
|---------------------|--|--|--|
| Parameter Name      | ComRxDynLengthlPduEnable   | ComRxDynLengthIPduEnable   |  |
| Description         | ·  | This parameter enables / disables features related to the variable length of an Rx-IPdu. This is required for dynamic length signal support. |  |
|                     | by the lower layer.  | d off, length of Rx-IPdu can vary as provided  |  |
|                     | FALSE: Optimization is switched EcuC.  | ed on, length of Rx-IPdu is fix as configured in   |  |
|                     | Optimization Effect:   |  |  |
|                     | RAM reduction (code): Enab sumption of the module config   | ling this optimization reduces the RAM con-<br>juration.   |  |
|                     | <b>ROM reduction (code):</b> Enable sumption of the module code.   | oling this optimization reduces the ROM con-   |  |
| Multiplicity        | 11   |  |  |
| Туре                | BOOLEAN  |  |  |
| Default value       | true   |  |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |  |
| Parameter Name      | ComFilterOneEveryNPeriodOffSMax  |  |  |
| Description         | This parameter defines the size of the parameter ComFilterOffset and ComFilter-PeriodFactor of the filter OneEveryN. Note, the value of the parameter ComFilterOneEveryNPeriodOffSMax and ComFilterOneEveryNOccuranceMax have to be equal. |  |  |
|                     | SIZE_0_BIT: the filter OneEv   | ► SIZE 0 BIT: the filter OneEveryN is not supported.   |  |
|                     | SIZE_8_BIT: the maximum value of the parameter ComFilterOffset and ComFilterPeriodFactor is a 8 bit value.   |  |  |
|                     | ■ SIZE_16_BIT: the maximum value of the parameter ComFilterOffset and ComFilterPeriodFactor is a 16 bit value.   |  |  |
|                     | ► SIZE_32_BIT: the maximum value of the parameter ComFilterOffset and ComFilterPeriodFactor is a 32 bit value.   |  |  |
|                     | Optimization Effect:   |  |  |
|                     | ROM reduction (config): The smaller the size the smaller the ROM consumption of the module configuration.  |  |  |



|                     | ▶ <b>ROM reduction (code):</b> If SIZE_0_BIT is used the feature is disabled which reduces the ROM consumption of the module code.    |                  |
|---------------------|---|------------------|
|                     | ► Execution time reduction (code): If SIZE_0_BIT is used the feature is disabled which reduces the execution time of the module code. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Default value       | SIZE_16_BIT   |                  |
| Range               | SIZE_0_BIT  |                  |
|                     | SIZE_8_BIT  |                  |
|                     | SIZE_16_BIT   |                  |
|                     | SIZE_32_BIT   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | ComFilterOneEveryNOccuranceMax  |  |
|----------------|---|--|
| Description    | This parameter defines the size of internal parameter 'occurance' (stored in RAM) of the filter OneEveryN. Note, the value of the parameter ComFilterOneEveryNPeriodOffSMax and ComFilterOneEveryNOccuranceMax have to be equal.  SIZE_0_BIT: the filter OneEveryN is not supported.  SIZE_8_BIT: the maximum value of the parameter occurance is a 8 bit value.  SIZE_16_BIT: the maximum value of the parameter occurance is a 16 bit value.  SIZE_32_BIT: the maximum value of the parameter occurance is a 32 bit value.  Optimization Effect:  RAM reduction (config): The smaller the size the smaller the RAM con- |  |
| Multiplicity   | sumption of the module configuration.  11   |  |
| Туре           | ENUMERATION   |  |
| Default value  |   |  |
|                | SIZE_16_BIT   |  |
| Range          | SIZE_0_BIT  |  |
|                | SIZE_8_BIT  |  |



|                     | SIZE_16_BIT                |                  |  |
|---------------------|----------------------------|------------------|--|
|                     | SIZE_32_BIT                |                  |  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH |                  |  |

| Parameter Name      | ComTxModeDirectEnable  |  |
|---------------------|--|--|
| Description         | This parameter enables / disables the transmission mode Direct (parameter ComTxModeMode = DIRECT, ComTxModeNumberOfRepetitions = 0).  TRUE: Optimization is switched off, the transmission mode is supported.  FALSE: Optimization is switched on, the transmission mode is not supported.  Optimization Effect:  ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included.  Execution time reduction (code): Enabling this optimization reduces the execution time of the module code. |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | ComTxModeNTimesEnable  |  |
|----------------|--|--|
| Description    | This parameter enables / disables the transmission mode N-Times (parameter ComTxModeMode = DIRECT, ComTxModeNumberOfRepetitions > 0).  |  |
|                | <ul> <li>TRUE: Optimization is switched off, the transmission mode is supported.</li> <li>FALSE: Optimization is switched on, the transmission mode is not supported.</li> </ul>                                   |  |
|                | Optimization Effect:   |  |
|                | ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included. |  |



|                     | Execution time reduction (code): Enabling this optimization reduces the execution time of the module code. |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComTxModePeriodicEnable   |                  |
|---------------------|---|------------------|
| Description         | This parameter enables / disables the transmission mode Periodic.  TRUE: Optimization is switched off, the transmission mode is supported.  FALSE: Optimization is switched on, the transmission mode is not support-   |                  |
|                     | <ul> <li>ed.</li> <li>Optimization Effect:</li> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included.</li> </ul> |                  |
|                     | Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.  |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | true  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | ComTxModeMixedDirectEnable   |  |
|----------------|--|--|
| Description    | This parameter enables / disables the transmission mode Mixed/Direct (parameter ComTxModeMode = MIXED, ComTxModeNumberOfRepetitions = 0).  |  |
|                | <ul> <li>TRUE: Optimization is switched off, the transmission mode is supported.</li> <li>FALSE: Optimization is switched on, the transmission mode is not supported.</li> </ul> |  |
|                | Optimization Effect:   |  |



|                     | <ul> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included.</li> <li>Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.</li> </ul> |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComTxModeMixedNTimesEnable   |  |
|---------------------|--|--|
| Description         | This parameter enables / disables the transmission mode Mixed/N-Times (parameter ComTxModeMode = MIXED, ComTxModeNumberOfRepetitions > 0).  TRUE: Optimization is switched off, the transmission mode is supported.  FALSE: Optimization is switched on, the transmission mode is not supported.   |  |
|                     | <ul> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included.</li> <li>Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.</li> </ul> |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | ComTxSigConfDeferredEnable   |  |
|----------------|--|--|
| Description    | This parameter enables / disables the deferred Tx confirmation.  |  |
|                | <ul> <li>TRUE: Optimization is switched off, deferred confirmation is supported.</li> <li>FALSE: Optimization is switched on, deferred confirmation is not supported.</li> </ul> |  |
|                | Optimization Effect:   |  |



|                     | <ul> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included.</li> <li>Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.</li> </ul> |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComTxSigConfImmediateEnable  |  |
|---------------------|--|--|
| Description         | This parameter enables / disables the immediate Tx confirmation.   |  |
|                     | ► TRUE: Optimization is switched off, i  | immediate confirmation is supported.     |
|                     | · ·  | , immediate confirmation is not support- |
|                     | ed.  |  |
|                     | Optimization Effect:   |  |
|                     | ▶ ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included. |  |
|                     | Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.   |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild                         |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | ComRxSigConfDeferredEnable   |  |
|----------------|--|--|
| Description    | This parameter enables / disables the deferred Rx confirmation.  |  |
|                | <ul> <li>TRUE: Optimization is switched off, deferred confirmation is supported.</li> <li>FALSE: Optimization is switched on, deferred confirmation is not supported.</li> </ul> |  |
|                | Optimization Effect:   |  |



|                     | <ul> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included.</li> <li>Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.</li> </ul> |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComRxSigConflmmediateEnable  |  |
|---------------------|--|--|
| Description         | This parameter enables / disables the immediate Rx confirmation.  TRUE: Optimization is switched off, immediate confirmation is supported.  FALSE: Optimization is switched on, immediate confirmation is not supported.  Optimization Effect:   |  |
|                     | <ul> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code; , if both ComTmsEnable and ComFilter-ReceiverEnable are disabled, additionally no code for filtering is included.</li> <li>Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.</li> </ul> |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | ComSignalGwEnable   |  |
|----------------|---|--|
| Description    | This parameter enables / disables the signal gateway.           |  |
|                | TRUE: Optimization is switched off, signal gateway is enabled.  |  |
|                | FALSE: Optimization is switched on, signal gateway is disabled. |  |
|                | Optimization Effect:  |  |



|                     |             | <b>ROM reduction (config):</b> Enabling this optimization reduces the ROM consumption of the module configuration. |  |
|---------------------|-------------|--|--|
|                     |             | <b>ROM reduction (code):</b> Enabling this optimization reduces the ROM consumption of the module code.            |  |
|                     | <b>&gt;</b> | Execution time reduction (code): Enabling this optimization reduces the execution time of the module code.         |  |
| Multiplicity        | 11          |  |  |
| Туре                | BOOLEAN     |  |  |
| Default value       | true        |  |  |
| Configuration class | Var         | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elek        | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComCheckValueSizeEnable   |                  |
|---------------------|---|------------------|
| Description         | This is an EB extension to the AUTOSAR specification. It is an additional check in the functions Com_SendSignal() / Com_UpdateShadowSignal(). The check verifies if the value provided by an application fits into the configured size of the signal / group signal. If the value does not fit into the signal / group signal it is reported to DET. If ComCheckValueSizeEnable is set to TRUE the check is enabled, otherwise disabled. In case ComReportToDetEnable == FALSE, the configuration of ComCheckValueSizeEnable is ignored. The number of bits of the value of a signal / group signal copied into the I-Pdu is the number of bits, which are configured for the signal / group signal, independent from the configuration of ComCheckValueSizeEnable. |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | ComConstCfgAddressEnable   |  |
|----------------|--|--|
| Description    | This parameter defines if a constant starting address for the configuration of the module is used. The fix address has to be configured with ComConstCfgAddress. |  |
|                | ▶ TRUE: Optimization is switched on, configuration is placed on the configured address.  |  |
|                | FALSE: Optimization is switched off, the starting address of the configuration has to be provided for the function Com_Init().                                   |  |



|                     | Optimization Effect:  Execution time reduction (code): Enabling this optimization reduces the execution time of the module code. |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ComConstCfgAddress       | ComConstCfgAddress  |  |
|---------------------|--------------------------|---|--|
| Description         |                          | Only valid if ComConstCfgAddressEnable == TRUE. Defines the fix address where the configuration starts. |  |
| Multiplicity        | 11                       | 11  |  |
| Туре                | INTEGER                  | INTEGER   |  |
| Default value       | 0                        | 0   |  |
| Configuration class | PreCompile:              | PreCompile: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive Gn | Elektrobit Automotive GmbH  |  |

| Parameter Name      | ComRelocatableCfgEnable  |                  |
|---------------------|--|------------------|
| Description         | Enables/disable support for relocatable postbuild configuration.  True: Postbuild configuration relocatable in memory.   |                  |
|                     | False: Postbuild configuration not relocatable in memory.  Note: If PbcfgM support is enabled for Com, this feature is managed by by the parameter PbcfgMRelocatableCfgEnable. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | true   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | Com_TxF_MaskNewDiffersMaskOld_En   |  |
|----------------|--|--|
| Description    | This parameter defines if the filter MaskedNewDiffersMaskOld is available for Tx |  |
|                | (group) signals. Only valid if ComTmsEnable == TRUE.                             |  |



| Origin  Parameter Name | ComSigGwRxFilterEnable   |  |
|------------------------|--|--|
|                        | Elektrobit Automotive GmbH   |  |
| Configuration class    | PreCompile: VariantPostBuild   |  |
| Default value          | true   |  |
| Туре                   | BOOLEAN  |  |
| Multiplicity           | 11   |  |
|                        | <ul> <li>ROM reduction (code): Enabling this optimization reduces the ROM consumption of the module code.</li> </ul>   |  |
|                        | <ul> <li>TRUE: Optimization is switched off, filter for is Tx (group) signals is supported.</li> <li>FALSE: Optimization is switched on, filter for is Tx (group) signals is not supported.</li> <li>Optimization Effect:</li> </ul> |  |

| Parameter Name      | ComSigGwRxFilterEnable   |  |
|---------------------|--|--|
| Description         | This parameter defines if the Rx filter is applied to decide if the signal is gated. NOTE: Parameter is only valid/enabled if signal gateway (ComSignalGwEnable) and Rx Filter is enabled (ComFilterReceiverEnable). |  |
|                     | ► TRUE: Filtering of gated signals is s  | witched on.                              |
|                     | FALSE: Filtering of gated signals is TOSAR COM 3.x).   | switched off. (as defined in the SWS AU- |
|                     | Optimization Effect:   |  |
|                     | ■ RAM reduction (config): Disabling this feature reduces RAM consumption of the module configuration.  |  |
|                     | ▶ ROM reduction (config): Disabling this feature reduces ROM consumption of the module configuration.  |  |
|                     | ▶ <b>ROM reduction (code):</b> Disabling this feature reduces the ROM consumption of the module code.  |  |
|                     | <b>Execution time reduction (code):</b> Disabling this feature reduces the execution time of the module code.  |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |



| Parameter Name      | ComTransfPropTriggeredEnable  |  |  |
|---------------------|---|--|--|
| Description         | This parameter defines if the transfer property TRIGGERED of Tx signals is available.   |  |  |
|                     | TRUE: Optimization is switched off, s GERED can be configured.  | in the state of th |  |
|                     | FALSE: Optimization is switched on GERED can be configured.   |  |  |
|                     | Optimization Effect:  |  |  |
|                     | ► Execution time reduction (code): If set to FALSE the feature is disabled which reduces the execution time of the module code. |  |  |
|                     | <b>ROM reduction (code):</b> If set to FALSE the feature is disabled which reduces the ROM consumption of the module code.      |  |  |
| Multiplicity        | 11  |  |  |
| Туре                | BOOLEAN   |  |  |
| Default value       | true  |  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |  |
| Origin              | Elektrobit Automotive GmbH  |  |  |

| Parameter Name | ComTransfPropTriggeredOCEnable  |  |
|----------------|---|--|
| Description    | This parameter defines if the transfer property TRIGGERED_ON_CHANGE of Tx signals is available.                               |  |
|                | ■ TRUE: Optimization is switched off, signal with transfer property TRIG-GERED_ON_CHANGE can be configured.                   |  |
|                | FALSE: Optimization is switched on, no signal with transfer property TRIG-GERED_ON_CHANGE can be configured.                  |  |
|                | Optimization Effect:  |  |
|                | Execution time reduction (code): If set to FALSE the feature is disabled which reduces the execution time of the module code. |  |
|                | ▶ ROM reduction (code): If set to FALSE the feature is disabled which reduces the ROM consumption of the module code.         |  |
| Multiplicity   | 11  |  |
| Туре           | BOOLEAN   |  |
| Default value  | true  |  |



| Configuration class | VariantPostBuild:          | VariantPostBuild |
|---------------------|----------------------------|------------------|
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComTransfPropWithoutRepEnable   |  |
|---------------------|---|--|
| Description         | This parameter defines if the transfer properties _WITHOUT_REPETITION  [TRIGGERED_ON_CHANGE_WITHOUT_REPETITION, TRIG- GERED_WITHOUT_REPETITION] of Tx signals are available.  TRUE: Optimization is switched off, signal with transfer properties WITHOUT_REPETITION can be configured.  FALSE: Optimization is switched on, no signal with transfer properties WITHOUT_REPETITION can be configured.  Optimization Effect:  Execution time reduction (code): If set to FALSE the feature is disabled which reduces the execution time of the module code.  ROM reduction (code): If set to FALSE the feature is disabled which reduces the ROM consumption of the module code. |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | true  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name | ComRxTpAPIEnable  |  |
|----------------|---|--|
| Description    | This parameter enables / disables Com Rx Tp support.  |  |
|                | ▶ TRUE: Optimization is switched off, no Rx Pdu with ComlPduType TP can be configured.  |  |
|                | FALSE: Optimization is switched on, Rx Pdu with ComlPduType TP can be configured.   |  |
|                | Optimization Effect:  |  |
|                | Execution time reduction (code): If set to FALSE the feature is disabled which reduces the execution time of the module code. |  |
|                | ▶ RAM reduction (code): If set to FALSE the feature is disabled which reduces the RAM consumption of the module code.         |  |
| Multiplicity   | 11  |  |



| Туре                | BOOLEAN                            |  |
|---------------------|------------------------------------|--|
| Default value       | false                              |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH         |  |

| Parameter Name      | ComTxTpAPIEnable  |                                     |
|---------------------|---|-------------------------------------|
| Description         | This parameter enables / disables Com Tx Tp support.  |                                     |
|                     | ▶ TRUE: Optimization is switched off, no Tx Pdu with ComlPduType TP can be configured.  |                                     |
|                     | FALSE: Optimization is switched on configured.  | , Tx Pdu with ComlPduType TP can be |
|                     | Optimization Effect:  |                                     |
|                     | Execution time reduction (code): If set to FALSE the feature is disabled which reduces the execution time of the module code. |                                     |
|                     | ▶ RAM reduction (code): If set to FALSE the feature is disabled which reduces the RAM consumption of the module code.         |                                     |
| Multiplicity        | 11  |                                     |
| Туре                | BOOLEAN   |                                     |
| Default value       | false   |                                     |
| Configuration class | VariantPostBuild: VariantPostBuild  |                                     |
| Origin              | Elektrobit Automotive GmbH  |                                     |

| Parameter Name | ComTxBigEndianEnable  |  |
|----------------|---|--|
| Description    | This parameter enables / disables the Com optimization of the Tx big endian related serialization functions.  |  |
|                | ▶ TRUE: Optimization is switched off, Tx big endian related serialization functions get enabled.  |  |
|                | FALSE: Optimization is switched on, no Tx big endian related serialization functions get enabled.   |  |
|                | Optimization Effect:  |  |
|                | ▶ <b>ROM reduction (code):</b> If set to FALSE the Tx big endian related serialization functions are disabled which reduces the ROM consumption of the module code. |  |
| Multiplicity   | 11  |  |



| Туре                | BOOLEAN                            |  |
|---------------------|------------------------------------|--|
| Default value       | true                               |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH         |  |

| Parameter Name      | ComTxLittleEndianEnable   |  |  |
|---------------------|---|--|--|
| Description         | This parameter enables / disable lated serialization functions.   | This parameter enables / disables the Com optimization of the Tx little endian related serialization functions.  |  |
|                     | TRUE: Optimization is switch tions get enabled.   | The second secon |  |
|                     | FALSE: Optimization is swit functions get enabled.  |  |  |
|                     | Optimization Effect:  | Optimization Effect:   |  |
|                     | ➤ ROM reduction (code): If set to FALSE the Tx little endian related serial-<br>ization functions are disabled which reduces the ROM consumption of the<br>module code. |  |  |
| Multiplicity        | 11  | 11   |  |
| Туре                | BOOLEAN   | BOOLEAN  |  |
| Default value       | true  | true   |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH  |  |  |

| Parameter Name | ComRxBigEndianEnable   |
|----------------|--|
| Description    | This parameter enables / disables the Com optimization of the Rx big endian related extracting functions.  |
|                | TRUE: Optimization is switched off, Rx big endian related extracting functions get enabled.  |
|                | FALSE: Optimization is switched on, no Rx big endian related extracting functions get enabled.   |
|                | Optimization Effect:   |
|                | <b>ROM reduction (code):</b> If set to FALSE the Rx big endian related extracting functions are disabled which reduces the ROM consumption of the module code. |
| Multiplicity   | 11   |



| Туре                | BOOLEAN                            |  |
|---------------------|------------------------------------|--|
| Default value       | true                               |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH         |  |

| Parameter Name      | ComRxLittleEndianEnable   |  |
|---------------------|---|--|
| Description         | This parameter enables / disables the Com optimization of the Rx little endian related extracting functions.  |  |
|                     | ■ TRUE: Optimization is switched off, Rx little endian related extracting functions get enabled.  |  |
|                     | FALSE: Optimization is switched on, no Rx little endian related extracting functions get enabled.   |  |
|                     | Optimization Effect:  |  |
|                     | <b>ROM reduction (code):</b> If set to FALSE the Rx little endian related extracting functions are disabled which reduces the ROM consumption of the module code. |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | true  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name | ComTxZeroSignalEnable   |  |
|----------------|---|--|
| Description    | This parameter defines if the zero size Tx signals can be configured.   |  |
|                | ➤ TRUE: Optimization is switched off, Tx signal with size zero can be configured.   |  |
|                | FALSE: Optimization is switched on, no Tx signal with size zero can be configured.  |  |
|                | Optimization Effect:  |  |
|                | ➤ Execution time reduction (code): If set to FALSE the feature is disabled which reduces the execution time of the module code. |  |
|                | ➤ ROM reduction (code): If set to FALSE the feature is disabled which reduces the ROM consumption of the module code.           |  |



| Multiplicity        | 11                         |                  |
|---------------------|----------------------------|------------------|
| Туре                | BOOLEAN                    |                  |
| Default value       | false                      |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComBasedTransformerSupportTx  |   |  |
|---------------------|---|---|--|
| Description         | This parameter defines if support for the Tx Com based transformer is available. Note: this parameter is only enabled when ComEnableSignalGroupArrayApi == true.        |   |  |
|                     | · ·   | ■ TRUE: Optimization is switched on, a Tx signal group can also be accessed with Com based transformer concept. |  |
|                     | FALSE: Optimization is switched off, signal group update and sending only possible using the APIs Com_UpdateShadowSingal and Com_SendSignal-Group.                      |   |  |
|                     | Optimization Effect:  Execution time reduction (code): If set to TRUE the feature is enabled which reduces the execution time of the module code. (only if Rte supports |   |  |
|                     | feature)  | , , ,   |  |
| Multiplicity        | 11  | 11  |  |
| Туре                | BOOLEAN   | BOOLEAN   |  |
| Default value       | true  |   |  |
| Configuration class | PreCompile: VariantPostBuild  |   |  |
| Origin              | Elektrobit Automotive GmbH  |   |  |

| Parameter Name | ComBasedTransformerSupportRx  |  |
|----------------|---|--|
| Description    | This parameter defines if support for the Rx Com based transformer is available.  Note: this parameter is only enabled when ComEnableSignalGroupArrayApi == true. |  |
|                | ▶ TRUE: Optimization is switched on, a Rx signal group can also be accessed with Com based transformer concept.   |  |
|                | FALSE: Optimization is switched off, access to a signal group is only possible via Com_ReceiveSignalGroup and Com_ReceiveShadowSignal.                            |  |
|                | Optimization Effect:  |  |



|                     | Execution time reduction (code): If set to TRUE the feature is enabled which reduces the execution time of the module code (only if Rte supports feature) |  |
|---------------------|---|--|
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | true  |  |
| Configuration class | PreCompile: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name      | ComTxGroupSignalNoLock  |  |
|---------------------|---|--|
| Description         | This parameter defines if the shadow buffer of a Tx signal group shall be locked during the update of a group signal. With the typical AUTOSAR use case (Rte updates all group signals sequentially and calls afterwards Com_SendSignal-Group) the locking can be disabled. |  |
|                     | TRUE: Optimization is switched on, shadow buffers of Tx signal groups are not locked during the update of a group signal.   |  |
|                     | FALSE: Optimization is switched off, shadow buffers of Tx signal groups are locked during the update of a group signal.   |  |
|                     | Optimization Effect:  |  |
|                     | Execution time reduction (code): If set to TRUE the feature is enabled  |  |
|                     | which reduces the execution time of the module code.  |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name | ComDeferTx2MainFunc   |  |
|----------------|---|--|
| Description    | This parameter defines if transmission request from Com module are only issued from Com transmission main function or also from other Com APIs.   |  |
|                | TRUE: Transmission request from Com module are only issued from Com transmission main function. Please note: The transmission main function only sends out an I-PDU if the related I-PDUGroup(s) are started. Therefore, if a transmission request initiated via Com_TriggerTransmit() is deferred to the next transmission main function, it is only performed if the relat- |  |



|                     | ed I-PDUGroup(s) are started. This behavior is similar to Autosar 4.2.2 and later, see SWS_Com_00861.  FALSE: Transmission request from Com module are also issued from other APIs than Com transmission main function. Please note: If a transmission request is initiated via Com_TriggerTransmit() a transmission is always triggered independent if the related I-PDUGroup(s) are started. This behavior is the behavior as defined in Autosar 4.2.1 and earlier. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | ComHandleSmallerRxPdus   |  |
|----------------|--|--|
| Description    | This parameter defines the update behavior of values of signal / signal group when receiving smaller I-PDU than expected.  TRUNCATE_DATA_NOTIFY_ALL: Data are simply copied into Rx-Pdu buffer. If a signal / signal group is not received fully only a part of the signal / signal group is updated. All notification callbacks are invoked. This is the recommended option if: |  |
|                | ▶ It is not expected that shorter PDUs are received.   |  |
|                | Signals / signal groups are either fully received, or not at all. Notifications are not used (for the signals / signal groups which are only partly received) or it is irrelevant if they are always invoked when the Pdu is received.   |  |
|                | If the length of the shorter PDUs are know and the following procedure is used:  |  |
|                | ► In /EcuC/EcuC/EcucPduCollection:   |  |
|                | Duplicate the entry which is referenced by the RxIPdu which can be received with different length. Rational: PduR will otherwise find multiple entries when calculating handle ID for Com_RxIndication.  |  |
|                | Not necessary but might make sense: set /EcuC/EcucPduCollection/Pdu/PduLength to the expected shorter length. (Note: should not be done if SWS_Com_00794 (new update bit for old signal) is relevant for the given Pdu).   |  |
|                | ► In ComlPdu:  |  |



- Duplicate RxIPdu which can be received with different length (Please ensure that Pdu is placed at the very end of the Pdu list. Rational: Handle Id Wizard will not reorder all handle IDs).
- In the duplicated RxIPdu:
  - Change Com/ComConfig/ComIPdu/ComPduIdRef to the above newly created Pdu in EcuC.
  - In Com/ComConfig/ComIPdu/ComIPduSignalRef: Remove all references to signals which are not available in the short version.
  - In Com/ComConfig/ComIPdu/ComIPduSignalGroupRef: according to SWS\_Com\_00575 remove all references to signal groups which are not fully received within the short RxIPdu.
- In the original (= long) RxIPdu:
  - Remove all references to signals / signal groups which are referenced by the short version of the duplicated (= short) RxIP-du.
  - In Com/ComConfig/ComIPdu/ComIPduCallout: configure a callout.
- The callout shall check the length of the PDU:
  - ▶ If (length == long)
    - Call Com\_RxIndication for the short Pdu
    - Return TRUE
  - If (length == short)
    - Call Com RxIndication for the short Pdu
    - Return FALSE
  - ► If ((length != short) AND (length != long))
    - Ignore PDU?
- TRUNCATE\_DATA\_NOTIFY\_ONLY\_RECEIVED: Data are simply copied into Rx-Pdu buffer. Notifications are invoked only if a signal / signal group is received. This is the recommended option if:
  - Signals / signal groups are either fully received, or not at all. Notifications shall be invoked only if a signal / signal group is received.
  - The option with the callout as described with TRUNCATE\_DATA\_NOTI-FY\_ALL cannot be used.

In order to test the performance impact of this option please use the option TEST\_TRUNCATE\_DATA\_NOTIFY\_ONLY\_RECEIVED.



- COPY\_ONLY\_RECEIVED\_DATA\_NOTIFY\_ALL: If a signal / signal group is not received fully it is not updated. All notification callbacks are invoked. This is the recommended option if:
  - Signals / signal groups are either fully received, or not at all. Notifications shall be invoked only if a signal / signal group is received.
  - The option with the callout as described with TRUNCATE\_DATA\_NOTI-FY ALL cannot be used.

In order to test the performance impact of this option please use the option TEST\_COPY\_ONLY\_RECEIVED\_DATA\_NOTIFY\_ALL.

- COPY\_ONLY\_RECEIVED\_DATA\_NOTIFY\_ONLY\_RECEIVED: If a signal / signal group is not received fully it is not updated. Notifications are invoked only if a signal / signal group is received. This is the recommended option if:
  - Signals / signal groups are either fully received, or not at all. Notifications shall be invoked only if a signal / signal group is received.
  - The option with the callout as described with TRUNCATE\_DATA\_NOTI-FY\_ALL cannot be used.
  - One of the above mentioned option cannot be used.

    In order to test the performance impact of this option please use the option TEST COPY ONLY RECEIVED DATA NOTIFY ONLY RECEIVED.
- TEST\_TRUNCATE\_DATA\_NOTIFY\_ONLY\_RECEIVED: Data are simply copied into Rx-Pdu buffer. Notifications are invoked only if a signal / signal group is received. Checks are always performed per singal / group signal, even if received PDU has the expected length. This is the recommended option if:
  - The performace impact of the option TRUNCATE\_DATA\_NOTIFY\_ON-LY\_RECEIVED shall be tested.
  - ► The performance consumption of the Com module shall not increase if shorter PDUs are received.
- TEST\_COPY\_ONLY\_RECEIVED\_DATA\_NOTIFY\_ALL: If a signal / signal group is not received fully it is not updated. All notification callbacks are invoked. Checks are always performed per singal / group signal, even if received PDU has the expected length. This is the recommended option if:
  - ► The performace impact of the option COPY\_ONLY\_RECEIVED\_DA-TA\_NOTIFY\_ALL shall be tested.
  - ► The performance consumption of the Com module shall not increase if shorter PDUs are received.
- ► TEST\_COPY\_ONLY\_RECEIVED\_DATA\_NOTIFY\_ONLY\_RECEIVED: If a signal / signal group is not received fully it is not updated. Notifications are in-



|                     | voked only if a signal / signal group is received. Checks are always performed per singal / group signal, even if received PDU has the expected length. This is the recommended option if: |   |  |
|---------------------|--|---|--|
|                     | ► The performace impact of the option COPY_ONLY_RECEIVED_DA-<br>TA_NOTIFY_ONLY_RECEIVED shall be tested.   |   |  |
|                     | The performance consumption<br>shorter PDUs are received.  | of the Com module shall not increase if |  |
| Multiplicity        | 11   |   |  |
| Туре                | ENUMERATION  |   |  |
| Default value       | TRUNCATE_DATA_NOTIFY_ALL   |   |  |
| Range               | TRUNCATE_DATA_NOTIFY_ALL   |   |  |
|                     | TRUNCATE_DATA_NOTIFY_ONLY_RECEIVED   |   |  |
|                     | COPY_ONLY_RECEIVED_DATA_NOTIFY_ALL   |   |  |
|                     | COPY_ONLY_RECEIVED_DATA_NOTIFY_ONLY_RECEIVED   |   |  |
|                     | TEST_TRUNCATE_DATA_NOTIFY_ONLY_RECEIVED  |   |  |
|                     | TEST_COPY_ONLY_RECEIVED_DATA_NOTIFY_ALL  |   |  |
|                     | TEST_COPY_ONLY_RECEIVED_DATA_NOTIFY_ONLY_RECEIVED  |   |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild                        |  |
| Origin              | Elektrobit Automotive GmbH   |   |  |

## 5.2.1.34. ComGeneratedRxSignal

| Parameters included      |              |  |
|--------------------------|--------------|--|
| Parameter name           | Multiplicity |  |
| ComRcvRxSigLockGenerated | 11           |  |
| ComGeneratedRcvSigEnable | 11           |  |
| ComMapReceiveSignal      | 11           |  |
| ComRcvSigMacroExtPrefix  | 01           |  |

| Parameter Name | ComRcvRxSigLockGenerated   |  |
|----------------|--|--|
| Description    | If set to TRUE the reading of Rx-signal with the generated Com_ReceiveSigna  |  |
|                | API is protected with the critical section (SCHM_COM_EXCLUSIVE_AREA          |  |
|                | 0) as configured in SchM. NOTE: this configuration applies for the generated |  |
|                | macros and functions.  |  |



| Multiplicity        | 11                         |                  |
|---------------------|----------------------------|------------------|
| Туре                | BOOLEAN                    |                  |
| Default value       | true                       |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | ComGeneratedRcvSigEnable   |                  |
|---------------------|--|------------------|
| Description         | If set to STD_ON a function is generated which extracts the values of the signals. The name of the function is either Com_ReceiveSignalGenerated() or Com_ReceiveSignal() depending on the configuration of ComMapReceiveSignal. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | true   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name      | ComMapReceiveSignal  |                  |
|---------------------|--|------------------|
| Description         | Defines which function is used when Com_ReceiveSignal is called. |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Default value       | Com_ReceiveSignalGenerated                                       |                  |
| Range               | Com_ReceiveSignalGenerated                                       |                  |
|                     | Com_ReceiveSignalGeneric   |                  |
| Configuration class | PreCompile:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH                                       |                  |

| Parameter Name | ComRcvSigMacroExtPrefix  |  |
|----------------|--|--|
| Description    | The macro COM_RECEIVE_SIGNAL_ <signalid> will be mapped to the macro defined here. The following macros will be generated:</signalid>                                      |  |
|                | <pre></pre> <pre></pre>  |  |
|                | <pre><comrcvsigmacroextprefix><signalid> </signalid></comrcvsigmacroextprefix></pre> <pre><comrcvsigmacroextprefix><signalidu></signalidu></comrcvsigmacroextprefix></pre> |  |



|                     | <pre><comrcvsigmacroextprefix><signalidu></signalidu></comrcvsigmacroextprefix></pre> |  |
|---------------------|---|--|
| Multiplicity        | 01  |  |
| Туре                | FUNCTION-NAME   |  |
| Configuration class | PreCompile: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC V1.0.0   |  |

## 5.2.1.35. CommonPublishedInformation

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| ArMajorVersion      | 11           |  |
| ArMinorVersion      | 11           |  |
| ArPatchVersion      | 11           |  |
| SwMajorVersion      | 11           |  |
| SwMinorVersion      | 11           |  |
| SwPatchVersion      | 11           |  |
| ModuleId            | 11           |  |
| Vendorld            | 11           |  |
| Release             | 11           |  |

| Parameter Name      | ArMajorVersion   |
|---------------------|--|
| Label               | AUTOSAR Major Version  |
| Description         | Major version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 4  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name | ArMinorVersion        |
|----------------|-----------------------|
| Label          | AUTOSAR Minor Version |



| Description         | Minor version number of AUTOSAR specification on which the appropriate implementation is based on. |
|---------------------|--|
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 2  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name      | ArPatchVersion   |
|---------------------|--|
| Label               | AUTOSAR Patch Version  |
| Description         | Patch level version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 0  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name      | SwMajorVersion  |
|---------------------|---|
| Label               | Software Major Version  |
| Description         | Major version number of the vendor specific implementation of the module. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 6   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name | SwMinorVersion  |
|----------------|---|
| Label          | Software Minor Version  |
| Description    | Minor version number of the vendor specific implementation of the module. The numbering is vendor specific. |
| Multiplicity   | 11  |
| Туре           | INTEGER_LABEL   |
| Default value  | 3   |



| Configuration class | PublishedInformation:      |
|---------------------|----------------------------|
| Origin              | Elektrobit Automotive GmbH |

| Parameter Name      | SwPatchVersion  |
|---------------------|---|
| Label               | Software Patch Version  |
| Description         | Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 50  |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | Moduleld                                  |
|---------------------|---|
| Label               | Numeric Module ID                         |
| Description         | Module ID of this module from Module List |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL                             |
| Default value       | 50  |
| Configuration class | PublishedInformation:                     |
| Origin              | Elektrobit Automotive GmbH                |

| Parameter Name      | Vendorld  |
|---------------------|---|
| Label               | Vendor ID   |
| Description         | Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 1   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name | Release |
|----------------|---------|
|----------------|---------|



| Label               | Release Information        |  |
|---------------------|----------------------------|--|
| Multiplicity        | 11                         |  |
| Туре                | STRING_LABEL               |  |
| Default value       |                            |  |
| Configuration class | PublishedInformation:      |  |
| Origin              | Elektrobit Automotive GmbH |  |

#### 5.2.1.36. PublishedInformation

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| PbcfgMSupport       | 11           |  |

| Parameter Name      | PbcfgMSupport  |
|---------------------|--|
| Label               | PbcfgM support   |
| Description         | Specifies whether or not the Com can use the PbcfgM module for post-build support. |
| Multiplicity        | 11   |
| Туре                | BOOLEAN  |
| Default value       | true   |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

# 5.2.2. Recommended configurations

# 5.2.2.1. ComRecConfigurationMax

| Containers included |                      |
|---------------------|----------------------|
| Container name      | Container definition |



| Containers included   |       |  |
|-----------------------|-------|--|
| ComGeneral ComGeneral |       |  |
| Parameters included   |       |  |
| Parameter name        | Value |  |

#### **5.2.2.1.1. ComGeneral**

| Containers included |                           |
|---------------------|---------------------------|
| Container name      | Container definition      |
| VendorSpecific      | ComGeneral VendorSpecific |

| Parameters included    |       |
|------------------------|-------|
| Parameter name         | Value |
| ComConfigurationUseDet | true  |
| ComVersionInfoApi      | true  |

# 5.2.2.1.2. VendorSpecific

| Parameters included              |                               |  |
|----------------------------------|-------------------------------|--|
| Parameter name                   | Value                         |  |
| ComDataMemSize                   | (DISABLED)                    |  |
| ComRamSizeMax                    | INDEX_UINT16                  |  |
| ComCbkTxTOutArraySizeMax         | INDEX_UINT16                  |  |
| ComCbkRxTOutArraySizeMax         | INDEX_UINT16                  |  |
| ComCbkRxAckPtrArraySizeMax       | INDEX_UINT16                  |  |
| ComCbkTxAckPtrArraySizeMax       | INDEX_UINT16                  |  |
| ComCallOutFuncPtrArraySizeMax    | INDEX_UINT16                  |  |
| ComTriggerTxCallOutEnable        | true                          |  |
| ComRxDataTimeoutAction           | RX_DATA_TIMEOUT_ACTION_CONFIG |  |
| ComRxTimeoutFactorSize           | SIZE_16_BIT                   |  |
| ComRxFirstTimeoutFactorSize      | SIZE_16_BIT                   |  |
| ComTxTimeoutFactorSize           | SIZE_16_BIT                   |  |
| ComTxModeRepetitionPeriodFactorS | SIZE_16_BIT                   |  |



| Parameters included                  |                       |
|--------------------------------------|-----------------------|
| <u>ComTxModeTimeOffsetFactorSize</u> | SIZE_16_BIT           |
| <u>ComTxModeTimePeriodFactorSize</u> | SIZE_16_BIT           |
| ComTxIpduMDTFactorSize               | SIZE_16_BIT           |
| ComUpdateBitRxConfig                 | UPDATE_BIT_INDIVIDUAL |
| ComUpdateBitTxConfig                 | UPDATE_BIT_INDIVIDUAL |
| ComTmsEnable                         | true                  |
| ComFilterReceiverEnable              | true                  |
| ComTxDynLengthIPduEnable             | true                  |
| ComRxDynLengthIPduEnable             | true                  |
| ComFilterOneEveryNPeriodOffSMax      | SIZE_16_BIT           |
| ComFilterOneEveryNOccuranceMax       | SIZE_16_BIT           |
| ComTxModeDirectEnable                | true                  |
| ComTxModeNTimesEnable                | true                  |
| ComTxModePeriodicEnable              | true                  |
| ComTxModeMixedDirectEnable           | true                  |
| ComTxModeMixedNTimesEnable           | true                  |
| ComTxSigConfDeferredEnable           | true                  |
| ComTxSigConflmmediateEnable          | true                  |
| ComRxSigConfDeferredEnable           | true                  |
| ComRxSigConfImmediateEnable          | true                  |
| ComSignalGwEnable                    | true                  |
| ComCheckValueSizeEnable              | true                  |
| ComConstCfgAddressEnable             | false                 |
| ComConstCfgAddress                   | 0                     |
| ComRelocatableCfgEnable              | true                  |
| Com_TxF_MaskNewDiffersMaskOld_En     | true                  |

# 5.2.2.2. ComRecConfigurationMedium

| Containers included |                      |
|---------------------|----------------------|
| Container name      | Container definition |



| Containers included                 |       |  |
|-------------------------------------|-------|--|
| <u>ComGeneral</u> <u>ComGeneral</u> |       |  |
| Parameters included                 |       |  |
| Parameter name                      | Value |  |

#### 5.2.2.2.1. ComGeneral

| Containers included |                           |
|---------------------|---------------------------|
| Container name      | Container definition      |
| VendorSpecific      | ComGeneral VendorSpecific |

| Parameters included    |      |
|------------------------|------|
| Parameter name Value   |      |
| ComConfigurationUseDet | true |
| ComVersionInfoApi      | true |

# 5.2.2.2. VendorSpecific

| Parameters included           |                               |
|-------------------------------|-------------------------------|
| Parameter name                | Value                         |
| ComDataMemSize                | (DISABLED)                    |
| ComRamSizeMax                 | INDEX_UINT16                  |
| ComCbkTxTOutArraySizeMax      | INDEX_UINT16                  |
| ComCbkRxTOutArraySizeMax      | INDEX_UINT16                  |
| ComCbkRxAckPtrArraySizeMax    | INDEX_UINT16                  |
| ComCbkTxAckPtrArraySizeMax    | INDEX_UINT16                  |
| ComCallOutFuncPtrArraySizeMax | INDEX_UINT16                  |
| ComTriggerTxCallOutEnable     | true                          |
| ComRxDataTimeoutAction        | RX_DATA_TIMEOUT_ACTION_CONFIG |
| ComRxTimeoutFactorSize        | SIZE_16_BIT                   |
| ComRxFirstTimeoutFactorSize   | SIZE_16_BIT                   |
| ComTxTimeoutFactorSize        | SIZE_16_BIT                   |



| Parameters included                     |                           |
|---|---------------------------|
| <u>ComTxModeRepetitionPeriodFactorS</u> | SIZE_16_BIT               |
| ComTxModeTimeOffsetFactorSize           | SIZE_16_BIT               |
| ComTxModeTimePeriodFactorSize           | SIZE_16_BIT               |
| ComTxlpduMDTFactorSize                  | SIZE_16_BIT               |
| ComUpdateBitRxConfig                    | UPDATE_BIT_ABSENT_FOR_ALL |
| ComUpdateBitTxConfig                    | UPDATE_BIT_ABSENT_FOR_ALL |
| ComTmsEnable                            | true                      |
| ComFilterReceiverEnable                 | true                      |
| ComTxDynLengthIPduEnable                | true                      |
| ComRxDynLengthIPduEnable                | true                      |
| ComFilterOneEveryNPeriodOffSMax         | SIZE_16_BIT               |
| ComFilterOneEveryNOccuranceMax          | SIZE_16_BIT               |
| ComTxModeDirectEnable                   | true                      |
| ComTxModeNTimesEnable                   | true                      |
| ComTxModePeriodicEnable                 | true                      |
| ComTxModeMixedDirectEnable              | true                      |
| ComTxModeMixedNTimesEnable              | true                      |
| ComTxSigConfDeferredEnable              | true                      |
| ComTxSigConflmmediateEnable             | true                      |
| ComRxSigConfDeferredEnable              | true                      |
| ComRxSigConfImmediateEnable             | true                      |
| ComSignalGwEnable                       | false                     |
| ComCheckValueSizeEnable                 | false                     |
| ComConstCfgAddressEnable                | false                     |
| ComConstCfgAddress                      | 0                         |
| ComRelocatableCfgEnable                 | true                      |

# 5.2.2.3. ComRecConfigurationSmall

| Containers included |                      |
|---------------------|----------------------|
| Container name      | Container definition |



| Containers included   |  |  |
|-----------------------|--|--|
| ComGeneral ComGeneral |  |  |
| Parameters included   |  |  |
| Parameter name Value  |  |  |

#### 5.2.2.3.1. ComGeneral

| Containers included                 |                           |
|-------------------------------------|---------------------------|
| Container name Container definition |                           |
| <u>VendorSpecific</u>               | ComGeneral VendorSpecific |
|                                     |                           |

| Parameters included    |       |
|------------------------|-------|
| Parameter name         | Value |
| ComConfigurationUseDet | false |
| ComVersionInfoApi      | false |

### 5.2.2.3.2. VendorSpecific

| Parameters included                     |                             |
|---|-----------------------------|
| Parameter name                          | Value                       |
| <u>ComDataMemSize</u>                   | (DISABLED)                  |
| ComRamSizeMax                           | INDEX_UINT8                 |
| ComCbkTxTOutArraySizeMax                | INDEX_NONE                  |
| ComCbkRxTOutArraySizeMax                | INDEX_NONE                  |
| ComCbkRxAckPtrArraySizeMax              | INDEX_UINT8                 |
| ComCbkTxAckPtrArraySizeMax              | INDEX_NONE                  |
| ComCallOutFuncPtrArraySizeMax           | INDEX_NONE                  |
| ComTriggerTxCallOutEnable               | false                       |
| ComRxDataTimeoutAction                  | RX_DATA_TIMEOUT_ACTION_NONE |
| ComRxTimeoutFactorSize                  | SIZE_0_BIT                  |
| ComRxFirstTimeoutFactorSize             | SIZE_0_BIT                  |
| ComTxTimeoutFactorSize                  | SIZE_0_BIT                  |
| <u>ComTxModeRepetitionPeriodFactorS</u> | SIZE_8_BIT                  |



| Parameters included              |                           |
|----------------------------------|---------------------------|
| ComTxModeTimeOffsetFactorSize    | SIZE_8_BIT                |
| ComTxModeTimePeriodFactorSize    | SIZE_8_BIT                |
| ComTxlpduMDTFactorSize           | SIZE_0_BIT                |
| ComUpdateBitRxConfig             | UPDATE_BIT_ABSENT_FOR_ALL |
| ComUpdateBitTxConfig             | UPDATE_BIT_ABSENT_FOR_ALL |
| ComTmsEnable                     | false                     |
| ComFilterReceiverEnable          | false                     |
| ComTxDynLengthIPduEnable         | false                     |
| ComRxDynLengthIPduEnable         | false                     |
| ComFilterOneEveryNPeriodOffSMax  | SIZE_0_BIT                |
| ComFilterOneEveryNOccuranceMax   | SIZE_0_BIT                |
| ComTxModeDirectEnable            | true                      |
| ComTxModeNTimesEnable            | true                      |
| ComTxModePeriodicEnable          | true                      |
| ComTxModeMixedDirectEnable       | false                     |
| ComTxModeMixedNTimesEnable       | false                     |
| ComTxSigConfDeferredEnable       | false                     |
| ComTxSigConflmmediateEnable      | true                      |
| ComRxSigConfDeferredEnable       | false                     |
| ComRxSigConfImmediateEnable      | true                      |
| ComSignalGwEnable                | false                     |
| ComCheckValueSizeEnable          | false                     |
| ComConstCfgAddressEnable         | false                     |
| <u>ComConstCfgAddress</u>        | 0                         |
| ComRelocatableCfgEnable          | true                      |
| Com_TxF_MaskNewDiffersMaskOld_En | true                      |

# 5.2.2.4. ComRecConfigurationStandard

| Containers included |                      |
|---------------------|----------------------|
| Container name      | Container definition |



| Containers included |            |
|---------------------|------------|
| ComGeneral          | ComGeneral |

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |

#### 5.2.2.4.1. ComGeneral

| Containers included |                           |  |
|---------------------|---------------------------|--|
| Container name      | Container definition      |  |
| VendorSpecific      | ComGeneral VendorSpecific |  |

| Parameters included      |       |
|--------------------------|-------|
| Parameter name           | Value |
| ComConfigurationUseDet   | true  |
| <u>ComVersionInfoApi</u> | true  |

# 5.2.2.4.2. VendorSpecific

| Parameters included           |                               |
|-------------------------------|-------------------------------|
| Parameter name                | Value                         |
| ComDataMemSize                | (DISABLED)                    |
| ComRamSizeMax                 | INDEX_UINT16                  |
| ComCbkTxTOutArraySizeMax      | INDEX_UINT16                  |
| ComCbkRxTOutArraySizeMax      | INDEX_UINT16                  |
| ComCbkRxAckPtrArraySizeMax    | INDEX_UINT16                  |
| ComCbkTxAckPtrArraySizeMax    | INDEX_UINT16                  |
| ComCallOutFuncPtrArraySizeMax | INDEX_UINT16                  |
| ComTriggerTxCallOutEnable     | true                          |
| ComRxDataTimeoutAction        | RX_DATA_TIMEOUT_ACTION_CONFIG |
| ComRxTimeoutFactorSize        | SIZE_16_BIT                   |
| ComRxFirstTimeoutFactorSize   | SIZE_16_BIT                   |



| Parameters included                     |                       |
|---|-----------------------|
| <u>ComTxTimeoutFactorSize</u>           | SIZE_16_BIT           |
| <u>ComTxModeRepetitionPeriodFactorS</u> | SIZE_16_BIT           |
| <u>ComTxModeTimeOffsetFactorSize</u>    | SIZE_16_BIT           |
| ComTxModeTimePeriodFactorSize           | SIZE_16_BIT           |
| ComTxIpduMDTFactorSize                  | SIZE_16_BIT           |
| ComUpdateBitRxConfig                    | UPDATE_BIT_INDIVIDUAL |
| ComUpdateBitTxConfig                    | UPDATE_BIT_INDIVIDUAL |
| ComTmsEnable                            | true                  |
| ComFilterReceiverEnable                 | true                  |
| ComTxDynLengthlPduEnable                | true                  |
| ComRxDynLengthIPduEnable                | true                  |
| ComFilterOneEveryNPeriodOffSMax         | SIZE_16_BIT           |
| ComFilterOneEveryNOccuranceMax          | SIZE_16_BIT           |
| <u>ComTxModeDirectEnable</u>            | true                  |
| ComTxModeNTimesEnable                   | true                  |
| ComTxModePeriodicEnable                 | true                  |
| ComTxModeMixedDirectEnable              | true                  |
| ComTxModeMixedNTimesEnable              | true                  |
| ComTxSigConfDeferredEnable              | true                  |
| <u>ComTxSigConflmmediateEnable</u>      | true                  |
| ComRxSigConfDeferredEnable              | true                  |
| ComRxSigConflmmediateEnable             | true                  |
| ComSignalGwEnable                       | true                  |
| ComCheckValueSizeEnable                 | false                 |
| <u>ComConstCfgAddressEnable</u>         | false                 |
| <u>ComConstCfgAddress</u>               | 0                     |
| ComRelocatableCfgEnable                 | true                  |
| Com_TxF_MaskNewDiffersMaskOld_En        | true                  |

# 5.2.3. Application programming interface (API)



# 5.2.3.1. Type definitions

#### 5.2.3.1.1. Com\_lpduGroupIdType

| Purpose | definition of the Com_lpduGroupIdType |
|---------|---------------------------------------|
| Туре    | uint16                                |

### 5.2.3.1.2. Com\_lpduGroupVector

| Purpose | definition of the Com_IpduGroupVector  |
|---------|--|
| Туре    | uint8[COM_IPDU_GROUP_VECTOR_NUM_BYTES] |

#### 5.2.3.1.3. Com\_PduGroupIdType

| Purpose | definition of the Com_PduGroupIdType |
|---------|--------------------------------------|
| Туре    | uint8                                |

#### 5.2.3.1.4. Com\_RxCalloutType

| Purpose | Define Com_RxCalloutType.                              |
|---------|--|
| Туре    | boolean()(PduIdType ID, const PduInfoType *PduInfoPtr) |

#### 5.2.3.1.5. Com\_ServiceIdType

| Purpose | definition of the Com_ServiceIdType |
|---------|-------------------------------------|
| Туре    | uint8                               |

### 5.2.3.1.6. Com\_SignalGroupIdType

| Purpose definition of the Com_SignalGroupIdType |  |
|---|--|
|---|--|



| Туре | uint16 |
|------|--------|
|------|--------|

#### 5.2.3.1.7. Com\_SignalIdType

| Purpose | definition of the Com_SignalIdType |
|---------|------------------------------------|
| Туре    | uint16                             |

#### 5.2.3.1.8. Com\_StatusType

| Purpose   | definition of the Com_StatusType |
|-----------|----------------------------------|
| Туре      | enum                             |
| Constants | COM_UNINIT                       |
|           | COM_INIT                         |

### 5.2.3.1.9. Com\_TxCalloutType

| Purpose | Define Com_TxCalloutType.                        |
|---------|--|
| Туре    | boolean()(PduIdType ID, PduInfoType *PduInfoPtr) |

### 5.2.3.2. Macro constants

### 5.2.3.2.1. COMServiceId\_ClearlpduGroupVector

| Purpose     | Definition of constant COMServiceId_ClearIpduGroupVector. |
|-------------|---|
| Value       | 0x1CU   |
| Description | Define COMServiceId_ClearlpduGroupVector                  |

#### 5.2.3.2.2. COMServiceId\_CopyRxData

| Purpose | Definition of constant COMServiceId_CopyRxData. |  |
|---------|---|--|
|---------|---|--|



| Value       | 0x23                           |
|-------------|--------------------------------|
| Description | Define COMServiceId_CopyRxData |

### 5.2.3.2.3. COMServiceId\_CopyTxData

| Purpose     | Definition of constant COMServiceId_CopyRxData. |
|-------------|---|
| Value       | 0x24  |
| Description | Define COMServiceId_CopyTxData                  |

### 5.2.3.2.4. COMServiceId\_DeInit

| Purpose     | Definition of constant COMServiceId_DeInit. |
|-------------|---|
| Value       | 0x02U                                       |
| Description | Define COMServiceId_DeInit                  |

#### 5.2.3.2.5. COMServiceId\_GetConfigurationId

| Purpose     | Definition of constant COMServiceId_GetConfigurationId. |
|-------------|---|
| Value       | 0x08U   |
| Description | Define COMServiceId_GetConfigurationId                  |

#### 5.2.3.2.6. COMServiceId\_GetRxIPduBuffer

| Purpose     | Definition of constant COMServiceId_GetRxIPduBuffer. |
|-------------|--|
| Value       | 0xFEU  |
| Description | Define COMServiceId_GetRxIPduBuffer                  |

# 5.2.3.2.7. COMServiceId\_GetStatus

| Purpose Definition of constant COMServiceId_GetStatus. |  |
|--|--|
|--|--|



| Value       | 0x07U                         |
|-------------|-------------------------------|
| Description | Define COMServiceId_GetStatus |

### 5.2.3.2.8. COMServiceId\_GetVersionInfo

| Purpose     | Definition of constant COMServiceId_GetVersionInfo. |
|-------------|---|
| Value       | 0x09U   |
| Description | Define COMServiceId_GetVersionInfo                  |

### 5.2.3.2.9. COMServiceId\_Init

| Purpose     | Definition of constant COMServiceId_Init. |
|-------------|---|
| Value       | 0x01U                                     |
| Description | Define COMServiceId_Init                  |

#### 5.2.3.2.10. COMServiceId\_InternalAPI

| Purpose     | Definition of constant COMServiceId_InternalAPI. |
|-------------|--|
| Value       | 0xFFU  |
| Description | Define COMServiceId_InternalAPI                  |

#### 5.2.3.2.11. COMServiceId\_InvalidateShadowSignal

| Purpose     | Definition of constant COMServiceId_InvalidateShadowSignal. |
|-------------|---|
| Value       | 0x16U   |
| Description | Define COMServiceId_InvalidateShadowSignal                  |

### 5.2.3.2.12. COMServiceId\_InvalidateSignal

| Purpose | Definition of constant COMServiceId_InvalidateSignal. |
|---------|---|
|---------|---|



| Value       | 0x10U                                |
|-------------|--------------------------------------|
| Description | Define COMServiceId_InvalidateSignal |

### 5.2.3.2.13. COMServiceId\_InvalidateSignalGroup

| Purpose     | Definition of constant COMServiceId_InvalidateSignalGroup. |
|-------------|--|
| Value       | 0x1BU  |
| Description | Define COMServiceId_InvalidateSignalGroup                  |

#### 5.2.3.2.14. COMServiceId\_IpduGroupControl

| Purpose     | Definition of constant COMServiceId_IpduGroupControl. |
|-------------|---|
| Value       | 0x03U   |
| Description | Define COMServiceId_IpduGroupControl                  |

### 5.2.3.2.15. COMServiceId\_MainFunctionRouteSignals

| Purpose     | Definition of constant COMServiceId_MainFunctionRouteSignals. |
|-------------|---|
| Value       | 0x1AU   |
| Description | Define COMServiceId_MainFunctionRouteSignals                  |

#### 5.2.3.2.16. COMServiceId\_MainFunctionRx

| Purpose     | Definition of constant COMServiceId_MainFunctionRx. |
|-------------|---|
| Value       | 0x18U   |
| Description | Define COMServiceId_MainFunctionRx                  |

### 5.2.3.2.17. COMServiceId\_MainFunctionTx

| Purpose Definition of constant COMServiceId_MainFunctionTx. |  |
|---|--|
|---|--|



| Value       | 0x19U                              |
|-------------|------------------------------------|
| Description | Define COMServiceId_MainFunctionTx |

### 5.2.3.2.18. COMServiceId\_ReceiveDynSignal

| Purpose     | Definition of constant COMServiceId_ReceiveDynSignal. |
|-------------|---|
| Value       | 0x22  |
| Description | Define COMServiceId_ReceiveDynSignal                  |

#### 5.2.3.2.19. COMServiceId\_ReceiveShadowSignal

| Purpose     | Definition of constantDefinition of constant COMServiceId_ReceiveShadowSignal. |
|-------------|--|
| Value       | 0x0FU  |
| Description | Define COMServiceId_ReceiveShadowSignal  |

#### 5.2.3.2.20. COMServiceId\_ReceiveSignal

| Purpose     | Definition of constant COMServiceId_ReceiveSignal. |
|-------------|--|
| Value       | 0x0BU  |
| Description | Define COMServiceId_ReceiveSignal                  |

#### 5.2.3.2.21. COMServiceId\_ReceiveSignalGroup

| Purpose     | Definition of constant COMServiceId_ReceiveSignalGroup. |
|-------------|---|
| Value       | 0x0EU   |
| Description | Define COMServiceId_ReceiveSignalGroup                  |

### 5.2.3.2.22. COMServiceId\_ReceiveSignalGroupArray

| Purpose Definition of constant COMServiceId_ReceiveSignalGroupArra | y. |
|--|----|
|--|----|



| Value       | 0x44U                                       |
|-------------|---|
| Description | Define COMServiceId_ReceiveSignalGroupArray |

### ${\bf 5.2.3.2.23.} \ {\bf COMServiceId\_ReceptionDMControl}$

| Purpose     | Definition of constant COMServiceId_ReceptionDMControl. |
|-------------|---|
| Value       | 0x06U   |
| Description | Define COMServiceId_EnableReceptionDM                   |

### 5.2.3.2.24. COMServiceId\_RxIndication

| Purpose     | Definition of constant COMServiceId_RxIndication. |
|-------------|---|
| Value       | 0x42U   |
| Description | Define COMServiceId_RxIndication                  |

#### 5.2.3.2.25. COMServiceId\_SendDynSignal

| Purpose     | Definition of constant COMServiceId_SendDynSignal. |
|-------------|--|
| Value       | 0x21   |
| Description | Define COMServiceId_SendDynSignal                  |

### 5.2.3.2.26. COMServiceId\_SendSignal

| Purpose     | Definition of constant COMServiceId_SendSignal. |
|-------------|---|
| Value       | 0x0AU   |
| Description | Define COMServiceId_SendSignal                  |

# 5.2.3.2.27. COMServiceId\_SendSignalGroup

| Purpose | Definition of constant COMServiceId_SendSignalGroup. |
|---------|--|
|---------|--|



| Value       | 0x0DU                               |
|-------------|-------------------------------------|
| Description | Define COMServiceId_SendSignalGroup |

### ${\bf 5.2.3.2.28.}\ COMServiceld\_SendSignalGroupArray$

| Purpose     | Definition of constant COMServiceId_SendSignalGroupArray. |
|-------------|---|
| Value       | 0x43U   |
| Description | Define COMServiceId_SendSignalGroupArray                  |

#### 5.2.3.2.29. COMServiceId\_SetIpduGroup

| Purpose     | Definition of constant COMServiceId_SetIpduGroup. |
|-------------|---|
| Value       | 0x1DU   |
| Description | Define COMServiceId_SetIpduGroup                  |

#### 5.2.3.2.30. COMServiceId\_StartOfReception

| Purpose     | Definition of constant COMServiceId_StartOfReception. |
|-------------|---|
| Value       | 0x25  |
| Description | Define COMServiceId_StartOfReception                  |

#### 5.2.3.2.31. COMServiceId\_SwitchIpduTxMode

| Purpose     | Definition of constant COMServiceId_SwitchIpduTxMode. |
|-------------|---|
| Value       | 0x27U   |
| Description | Define COMServiceId_SwitchIpduTxMode                  |

# 5.2.3.2.32. COMServiceId\_TpRxIndication

| Purpose Definition of constant COMServiceId_TpRxIndication. |  |
|---|--|
|---|--|



| Value       | 0x1EU                              |
|-------------|------------------------------------|
| Description | Define COMServiceId_TpRxIndication |

### ${\bf 5.2.3.2.33.}\ {\bf COMServiceId\_TpTxConfirmation}$

| Purpose     | Definition of constant COMServiceId_TpTxConfirmation. |
|-------------|---|
| Value       | 0x26  |
| Description | Define COMServiceId_TpTxConfirmation                  |

#### 5.2.3.2.34. COMServiceId\_TriggerIPDUSend

| Purpose     | Definition of constant COMServiceId_TriggerIPDUSend. |
|-------------|--|
| Value       | 0x17U  |
| Description | Define COMServiceId_TriggerIPDUSend                  |

#### 5.2.3.2.35. COMServiceId\_TriggerTransmit

| Purpose     | Definition of constant COMServiceId_TriggerTransmit. |
|-------------|--|
| Value       | 0x41U  |
| Description | Define COMServiceId_TriggerTransmit                  |

#### 5.2.3.2.36. COMServiceId\_TxConfirmation

| Purpose     | Definition of constant COMServiceId_TxConfirmation. |
|-------------|---|
| Value       | 0x40U   |
| Description | Define COMServiceId_TxConfirmation                  |

### 5.2.3.2.37. COMServiceId\_UpdateShadowSignal

| Purpose | Definition of constant COMServiceId_UpdateShadowSignal. |
|---------|---|
|---------|---|



| Value       | 0x0CU                                  |
|-------------|--|
| Description | Define COMServiceId_UpdateShadowSignal |

### 5.2.3.2.38. COM\_E\_PARAM

| Purpose     | Definition of error code COM_E_PARAM. |
|-------------|---------------------------------------|
| Value       | 1U                                    |
| Description | Define COM_E_PARAM                    |

#### 5.2.3.2.39. COM\_E\_PARAM\_POINTER

| Purpose     | Definition of error code COM_E_PARAM_POINTER. |  |
|-------------|---|--|
| Value       | 3U  |  |
| Description | Define COM_E_PARAM_POINTER                    |  |

#### 5.2.3.2.40. COM\_E\_SIGNAL\_TOO\_WIDE

| Purpose | Define COM_E_SIGNAL_TOO_WIDE. |
|---------|-------------------------------|
| Value   | 0x21U                         |

### 5.2.3.2.41. COM\_E\_UNINIT

| Purpose     | Definition of error code COM_E_UNINIT. |
|-------------|--|
| Value       | 2U                                     |
| Description | Define COM_E_UNINIT                    |

#### **5.2.3.2.42. COM\_INSTANCE\_ID**

| Purpose | Com instance ID. |
|---------|------------------|
| Value   | 0U               |



### **5.2.3.3. Functions**

# 5.2.3.3.1. Com\_ClearlpduGroupVector

| Purpose         | Com_ClearlpduGroupVector - sets all bits of the given Com_lpduGroupVector to 0. |                                  |
|-----------------|---|----------------------------------|
| Synopsis        | <pre>void Com_ClearIpduGroupVector ( duGroupVector );</pre>                     | Com_IpduGroupVector ip-          |
| Service ID      | 0x1c  |                                  |
| Sync/Async      | Synchronous   |                                  |
| Reentrancy      | Reentrant   |                                  |
| Parameters (in) | ipduGroupVector   | I-PDU group vector to be cleared |

# 5.2.3.3.2. Com\_CopyRxData

| Purpose          | Com_CopyRxData Called once upon reception of each segment. Within this call, the received data is copied to the receive TP buffer. The function must only be called if the connection has been accepted by an initial call to Com_StartOfReception. Preconditions:  prior to this call, the COM module shall be initialized the Pdu must be started before. |   |
|------------------|---|---|
| Synopsis         | <pre>BufReq_ReturnType Com_CopyRxData ( PduIdType PduId , const PduInfoType * PduInfoPointer , PduLengthType * RxBufferSizePtr );</pre>   |   |
| Parameters (in)  | PduId   | - ID of Tp I-PDU to be transmitted  |
|                  | PduInfoPointer  | - Pointer to a PduInfoType, which indicates the number of bytes to be copied (SduLength) and the location of the source data (SduDataPtr). An SduLength of 0 is possible in order to poll the available receive buffer size. In this case no data are to be copied and PduInfoPtr might be invalid. |
| Parameters (out) | RxBufferSizePtr   | - Remaining receive buffer after successful completion of this call (Com_CopyRx-Data returns BUFREQ_OK otherwise out put parameter RxBufferSizePtr does not change).  |



| Return Value    | BUFREQ_OK                                   | - Data has been copied to the receive buffer completely as requested.     |
|-----------------|---|---|
|                 | BUFREQ_E_BUSY                               | - The receive buffer is actually not available (implementation specific). |
| BUFREQ_E_NOT_OK | - Data has not been copied. Request failed. |   |

# 5.2.3.3. Com\_CopyTxData

| Purpose          | Com_CopyTxData function which copy the requested transmit data of the large IPDU Preconditions:  prior to this call, the COM module shall be initialized the Pdu must be started before. |  |
|------------------|--|--|
| Synopsis         | BufReq_ReturnType Com_CopyTxData ( PduIdType PduId , PduIn-foType * PduInfoPtr , RetryInfoType * RetryInfoPtr , Pdu-LengthType * TxDataCntPtr );   |  |
| Parameters (in)  | PduId  | - ID of Tp I-PDU to be transmitted   |
|                  | PduInfoPtr   | - Pointer to a PduInfoType, which indicates the number of bytes to be copied (SduLength) and the location where the data have to be copied to (SduDataPtr). An SduLength of 0 is possible in order to poll the available transmit data count. In this case no data are to be copied and SduDataPtr might be invalid. |
|                  | RetryInfoPtr   | - The COM module ignores the value of<br>this pointer, since it always keeps the<br>complete buffer until the transmission of a<br>large I-PDU is either confirmed or aborted.   |
| Parameters (out) | TxDataCntPtr   | - Remaining Tx data after successful completion of this call (Com_CopyTxData returns BUFREQ_OK otherwise out put parameter TxDataCntPtr does not change).  |
| Return Value     | BUFREQ_OK  | - Data has been copied to the transmit buffer completely as requested.   |
|                  | BUFREQ_E_BUSY  | - The transmission buffer is actually not available (implementation specific).   |



| BUFREQ_E_NOT_OK | - Data has not been copied. Request     |  |
|-----------------|---|--|
|                 | failed, in case the corresponding I-PDU |  |
|                 | was stopped.                            |  |

# 5.2.3.3.4. Com\_Delnit

| Purpose     | Com_DeInit - sets COM to de-initialized state.            |  |
|-------------|---|--|
| Synopsis    | <pre>void Com_DeInit ( void );</pre>                      |  |
| Service ID  | 0x02  |  |
| Sync/Async  | Synchronous   |  |
| Reentrancy  | Non re-entrant  |  |
| Description | Simply sets the global variable Com_Status to COM_UNINIT. |  |

# 5.2.3.3.5. Com\_GetConfigurationId

| Purpose      | Com_GetConfiguratinoId - get post-build-time configuration ID. |  |
|--------------|--|--|
| Synopsis     | uint32 Com_GetConfigurationId ( void );                        |  |
| Service ID   | 0x08   |  |
| Sync/Async   | Synchronous  |  |
| Reentrancy   | Re-entrant   |  |
| Return Value | post-build-time configuration ID                               |  |

### 5.2.3.3.6. Com\_GetRxIPduBuffer

| Purpose          | Com_GetRxIPduBuffer - returns Rx IPdu buffer reference The service Com_GetRxIP-duBuffer returns the buffer object identified by ComRxPduId with the buffer referenced by the PduInfoPtr parameter. Preconditions: COM must be initialized. |                            |
|------------------|--|----------------------------|
| Synopsis         | <pre>uint8 Com_GetRxIPduBuffer ( PduIdType ComRxPduId , PduInfoType   * PduInfoPtr );</pre>  |                            |
| Parameters (in)  | ComRxPduId   | - ID of the Rx ComIPdu     |
| Parameters (out) | PduInfoPtr   | - Rx IPdu buffer reference |
| Return Value     | Function execution success status  |                            |



| E_OK     | - success                                 |
|----------|---|
| E_NOT_OK | - failure (Com not initialized or service |
|          | failed due to development error)          |

### 5.2.3.3.7. Com\_GetStatus

| Purpose      | returns status of Com                                   |                           |  |
|--------------|---|---------------------------|--|
| Synopsis     | Com_StatusType Com_GetStatus (                          | void );                   |  |
| Service ID   | 0x07  | 0x07                      |  |
| Sync/Async   | Synchronous   |                           |  |
| Reentrancy   | Re-entrant  |                           |  |
| Return Value | Result of init status                                   |                           |  |
|              | COM_INIT  | the module is initialized |  |
|              | COM_UNINIT the module is not initialized                |                           |  |
| Description  | This function returns whether the module is initialized |                           |  |

### 5.2.3.3.8. Com\_GetVersionInfo

| Purpose          | Returns the module version information.                        |   |
|------------------|--|---|
| Synopsis         | void Com_GetVersionInfo ( Std_VersionInfoType * versionInfoPtr |   |
| Service ID       | 0x09   |   |
| Sync/Async       | Synchronous  |   |
| Reentrancy       | Re-entrant   |   |
| Parameters (out) | versionInfoPtr   | Address the version information should be written to. |
| Description      | This service returns the version information of this module.   |   |

# 5.2.3.3.9. Com\_Init

| Purpose | Com_Init - Initializes the Com module. |
|---------|--|
|         |  |



| Synopsis        | void Com_Init ( const Com_Config   | gType * Com_ConfigPtr );  |
|-----------------|--|---|
| Service ID      | 0x01   |   |
| Sync/Async      | Synchronous  |   |
| Reentrancy      | Non re-entrant   |   |
| Parameters (in) | Com_ConfigPtr  | Pointer to configuration structure that holds the Com module post-build-time configuration data.  |
| Description     | Function to initialize the Com module. First ule calling the function Com_Init has to incl Com_Init function is without usage of Pbcfg uration>); or Com_Init(&Com_ConfigLayou Com_Init function for usage of PbcfgM Cor | ude Com_PBcfg.h. The invocation of the gM Com_Init(& <short com="" config-t.com_rootconfig);="" invocation="" name="" of="" th="" the="" the<=""></short> |

### 5.2.3.3.10. Com\_lpduGroupControl

| Purpose         | Com_lpduGroupControl - starts/stops I-PDU.   |  |
|-----------------|--|--|
| Synopsis        | <pre>void Com_IpduGroupControl ( Com , boolean Initialize );</pre>   | _IpduGroupVector ipduGroupVector   |
| Service ID      | 0x03   |  |
| Sync/Async      | Synchronous  |  |
| Reentrancy      | Non Reentrant  |  |
| Parameters (in) | ipduGroupVector  | I-PDU group vector containing the activation state (stopped = 0/ started = 1) for all IPdus. |
|                 | Initialize   | flag to request initialization of the I-PDUs which are newly started                         |
| Description     | Function to start/stop every Rx-Ipdu and Tx-Ipdu according to the passed states of the ComIpduGroups in the parameter ipduGroupVector. Preconditions:  COM must be initialized |  |

# 5.2.3.3.11. Com\_lsValidConfig

| Purpose | Com_lsValidConfig - Checks validity of the post-build configuration. |  |
|---------|--|--|
|---------|--|--|



| Synopsis        | Std_ReturnType Com_IsValidConfig ( const void * ConfigPtr );  |  |
|-----------------|---|--|
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Reentrant   |  |
| Parameters (in) | ConfigPtr   | Pointer to configuration structure that holds the Com module post-build-time configuration data. |
| Return Value    | Function execution success status   |  |
|                 | E_OK  | the provided module configuration is valid   |
|                 | E_NOT_OK  | the provided module configuration is invalid   |
| Description     | Checks if the post build configuration is valid. A configuration is invalid if  the platform signature does not match.  the published information signature does not match.  the link time signature does not match.  the compile time signature does not match.  the function is called with a null pointer. |  |

### 5.2.3.3.12. Com\_MainFunctionRouteSignals

| Purpose     | Com_MainFunctionRouteSignals - handle cyclic Signal Gateway tasks.   |
|-------------|--|
| Synopsis    | <pre>void Com_MainFunctionRouteSignals ( void );</pre>   |
| Service ID  | 0x1A   |
| Sync/Async  | Synchronous  |
| Reentrancy  | Non re-entrant   |
| Description | This function handles cyclic receiving and sending (group)signals(group) for the Signal Gateway functionality (SigGW). Preconditions:  COM must be initialized |

# 5.2.3.3.13. Com\_MainFunctionRx

| Purpose | Com_MainFunctionRx - handle cyclic receiving-related tasks. |  |
|---------|---|--|
|---------|---|--|



| Synopsis    | <pre>void Com_MainFunctionRx ( void );</pre>  |
|-------------|---|
| Service ID  | 0x18  |
| Sync/Async  | Synchronous   |
| Reentrancy  | Non re-entrant  |
| Description | This function handles cyclic receiving-related tasks like reception deadline monitoring.  Preconditions:  COM must be initialized |

# 5.2.3.3.14. Com\_MainFunctionTx

| Purpose     | Com_MainFunctionTx - handle cyclic sending-related tasks.   |
|-------------|---|
| Synopsis    | <pre>void Com_MainFunctionTx ( void );</pre>  |
| Service ID  | 0x19  |
| Sync/Async  | Synchronous   |
| Reentrancy  | Non re-entrant  |
| Description | This function handles cyclic sending-related tasks such as minimum delay time and cyclic sending. Preconditions:  COM must be initialized |

### 5.2.3.3.15. Com\_ReceiveDynSignal

| Purpose             | Com_ReceiveDynSignal - get a dynamic length signal's actual value from COM.                                      |  |
|---------------------|--|--|
| Synopsis            | <pre>uint8 Com_ReceiveDynSignal ( Com_SignalIdType SignalId , void * SignalDataPtr , uint16 * LengthPtr );</pre> |  |
| Service ID          | 0x22   |  |
| Sync/Async          | Synchronous  |  |
| Reentrancy          | Re-entrant for different values of Signalld only.  |  |
| Parameters (in)     | SignalId   | ID of signal to receive  |
|                     | SignalDataPtr  | piece of memory to copy data to  |
| Parameters (in,out) | LengthPtr  | in: maximum length that could be received out: length of the dynamic length signal |
| Return Value        | Result of operation  |  |



|             | E_OK   | success   |
|-------------|--|---|
|             | E_NOT_OK   | the Length (as in-parameter) is smaller than the received length of the dynamic length signal |
|             | COM_SERVICE_NOT_AVAILABLE  | corresponding I-PDU group was stopped (or service failed due to development error)            |
| Description | Com_ReceiveDynSignal copies the data of cation specified by SignalDataPtr and store the position given by the Length parameter Preconditions:  COM must be initialized | es the length of the dynamic length signal at   |

### 5.2.3.3.16. Com\_ReceiveShadowSignal

| Purpose         | Com_ReceiveShadowSignal - get a group signal's value from shadow buffer.   |                                  |
|-----------------|--|----------------------------------|
| Synopsis        | <pre>void Com_ReceiveShadowSignal ( 0 * SignalDataPtr );</pre>   | Com_SignalIdType SignalId , void |
| Service ID      | 0x0F   |                                  |
| Sync/Async      | Synchronous  |                                  |
| Reentrancy      | Re-entrant for different values of Signalld only.  |                                  |
| Parameters (in) | SignalId   | ID of group signal to receive    |
|                 | SignalDataPtr  | piece of memory to copy data to  |
| Description     | This function returns the value of a group signal from its shadow buffer of the signal group Preconditions:  COM must be initialized |                                  |

# 5.2.3.3.17. Com\_ReceiveSignal

| Purpose  | Com_ReceiveSignal - get a signal's actual value from COM.    |  |
|----------|--|--|
| Synopsis | uint8 Com_ReceiveSignal ( Com_SignalIdType SignalId , void * |  |
|          | SignalDataPtr );   |  |



| Service ID       | 0x0B  |  |
|------------------|---|--|
| Sync/Async       | Synchronous   |  |
| Reentrancy       | Re-entrant for different values of Signalld of  | only.  |
| Parameters (in)  | SignalId  | ID of signal to receive  |
| Parameters (out) | SignalDataPtr   | piece of memory to copy data to  |
| Return Value     | Result of operation   |  |
|                  | E_OK  | success  |
|                  | COM_SERVICE_NOT_AVAILABLE   | Com is disabled, no valid value passed   |
|                  |   | over   |
| Description      | This function returns the actual value of a solif the configuration parameter ComGeneration maps to the generic implementation of ter ComGeneratedRcvSigEnable is enable ReceiveSignalGeneric, this function maps tion. If the configuration parameter ComGe ComMapReceiveSignal == Com_ReceiveSignerated implementation of the function. | tedRcvSigEnable is disabled, this func-<br>the function. If the configuration parame-<br>d and ComMapReceiveSignal == Com<br>to the generic implementation of the func-<br>eneratedRcvSigEnable is enabled and<br>SignalGenerated, this function maps to the |

### 5.2.3.3.18. Com\_ReceiveSignalGeneric

| Purpose          | Com_ReceiveSignalGeneric - get a signal's actual value from COM This function returns the actual value of a signal. This function is only available if the configuration parameter ComGeneratedRcvSigEnable is enabled and ComMapReceiveSignal == Com_ReceiveSignalGenerated. If available, this function maps to the generic implementation of the function. Preconditions:  COM must be initialized. |   |
|------------------|--|---|
| Synopsis         | <pre>uint8 Com_ReceiveSignalGeneric ( Com_SignalIdType SignalId , void * SignalDataPtr );</pre>  |   |
| Parameters (in)  | SignalId   | ID of signal to receive                     |
| Parameters (out) | SignalDataPtr  | piece of memory to copy data to             |
| Return Value     | Result of operation  |   |
|                  | E_OK   | success                                     |
|                  | COM_SERVICE_NOT_AVAILABLE  | Com is disabled, no valid value passed over |



### 5.2.3.3.19. Com\_ReceiveSignalGroup

| Purpose         | Com_ReceiveSignalGroup - copies the actual value of a signal group into the shadow buffer.  |   |
|-----------------|---|---|
| Synopsis        | <pre>uint8 Com_ReceiveSignalGroup GroupId );</pre>  | ( Com_SignalGroupIdType Signal-             |
| Service ID      | 0x0E  |   |
| Sync/Async      | Synchronous   |   |
| Reentrancy      | Re-entrant for different values of SignalGroupId only.  |   |
| Parameters (in) | SignalGroupId   | ID of signal group                          |
| Return Value    | Result of operation   |   |
|                 | E_OK  | success                                     |
|                 | COM_SERVICE_NOT_AVAILABLE   | Com is disabled, no valid value passed over |
| Description     | This function copies the value of a Rx signal group from its Rx-IPdu into the its shadow buffer Preconditions:  COM must be initialized |   |

# 5.2.3.3.20. Com\_ReceiveSignalGroupArray

| Purpose          | Com_ReceiveSignalGroupArray - access signal group array.   |  |
|------------------|--|--|
| Synopsis         | <pre>uint8 Com_ReceiveSignalGroupArray ( Com_SignalGroupIdType Sig- nalGroupId , uint8 * SignalGroupArrayPtr , uint16 * Signal- GroupArrayLengthPtr );</pre> |  |
| Service ID       | 0x44   |  |
| Sync/Async       | Synchronous  |  |
| Reentrancy       | Re-entrant for different values of SignalGroupId only.   |  |
| Parameters (in)  | SignalGroupId  | ID of signal group to be received.   |
|                  | SignalGroupArrayLengthPtr  | reference to length of the signal group array  |
| Parameters (out) | SignalGroupArrayPtr  | reference to the location where the re-<br>ceived signal group array shall be stored |
| Return Value     | Result of operation  |  |
|                  | E_OK   | service has been accepted  |



|             | COM_SERVICE_NOT_AVAILABLE   | corresponding I-PDU group was stopped (or service failed due to development error) |
|-------------|---|--|
| Description | The service Com_ReceiveSignalGroupArrarepresentation from the I-PDU to the Signal COM must be initialized |  |

### 5.2.3.3.21. Com\_ReceptionDMControl

| Purpose         | Com_ReceptionDMControl - enables or disables Rx I-PDU Deadline Monitoring.   |   |
|-----------------|--|---|
| Synopsis        | void Com_ReceptionDMControl ( Com_IpduGroupVector ipduGroupVec-  |   |
|                 | tor);  |   |
| Service ID      | 0x06   |   |
| Sync/Async      | Synchronous  |   |
| Reentrancy      | Non Reentrant  |   |
| Parameters (in) | ipduGroupVector  | I-PDU group vector containing the activation of RxDM (disable = 0/ enable = 1) for all Rx-Pdus. |
| Description     | Function to enables/disables every RxDM of every Rx-IPdu according to the passed states of the ComlpduGroups in the parameter ipduGroupVector. Preconditions:  COM must be initialized |   |

# 5.2.3.3.22. Com\_RxIndication

| Purpose         | Com_RxIndication - Signal the COM a PDU   | J has arrived.   |
|-----------------|---|--|
| Synopsis        | <pre>void Com_RxIndication ( PduIdType ComRxPduId , PduInfoType * PduInfoPtr );</pre> |  |
| Service ID      | 0x42  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Re-entrant for different values of ComRxPduId only.                                   |  |
| Parameters (in) | ComRxPduId  | ID of the received I-PDU.  |
|                 | PduInfoPtr  | Contains the length (SduLength) of the received I-PDU and a pointer to a buffer (SduDataPtr) containing the I-PDU. |



| Description | This functions signals the COM that a PDU has arrived Preconditions: |  |
|-------------|--|--|
|             | COM should be initialized  |  |

# 5.2.3.3.23. Com\_SendDynSignal

| Purpose         | Com_SendDynSignal - send a dynamic length signal.   |   |
|-----------------|---|---|
| Synopsis        | <pre>uint8 Com_SendDynSignal ( Com_SignalIdType SignalId , const void * SignalDataPtr , uint16 Length );</pre>  |   |
| Service ID      | 0x21  |   |
| Sync/Async      | Asynchronous  |   |
| Reentrancy      | Re-entrant for different values of Signa  | lld only.   |
| Parameters (in) | SignalId  | ID of the signal to be sent   |
|                 | SignalDataPtr   | place in memory to copy the data from   |
|                 | Length  | Length of the dynamic length signal to be send  |
| Return Value    | Result of operation   |   |
|                 | E_OK  | success   |
|                 | E_NOT_OK  | in case the Length is greater than the configured ComSignalLength of this sent signal                           |
|                 | COM_SERVICE_NOT_AVAILABLE   | failure (Com not initialized, corresponding I-PDU group was stopped or service failed due to development error) |
|                 | COM_BUSY  | - The receive Tp buffer is actually not available   |
| Description     | The service Com_SendDynSignal updates the signal object identified by SignalId and from signal type UINT8_DYN with the value referenced by the SignalDataPtr parameter. Preconditions: COM must be initialized. |   |

# 5.2.3.3.24. Com\_SendSignal

| Purpose  | Com_SendSignal - send a signal see COM197.                      |  |
|----------|---|--|
| Synopsis | uint8 Com_SendSignal ( Com_SignalIdType SignalId , const void * |  |
|          | SignalDataPtr );  |  |



| Service ID      | 0x0A  |   |  |
|-----------------|---|---|--|
| Sync/Async      | Asynchronous  |   |  |
| Reentrancy      | Re-entrant for different values of Signall  | Re-entrant for different values of Signalld only.   |  |
| Parameters (in) | SignalId  | ID of the signal to be sent   |  |
|                 | SignalDataPtr   | place in memory to copy the data from   |  |
| Return Value    | Return Value Result of operation  |   |  |
|                 | E_OK  | success   |  |
|                 | COM_SERVICE_NOT_AVAILABLE   | failure (Com not initialized, corresponding I-PDU group was stopped or service failed due to development error) |  |
|                 | COM_BUSY  | - The receive Tp buffer is actually not available   |  |
| Description     | The service Com_SendSignal updates the signal object identified by SignalId with the value referenced by the SignalDataPtr parameter. Preconditions: COM must be initialized. |   |  |

# 5.2.3.3.25. Com\_SendSignalGroup

| Purpose                          | Com_SendSignalGroup - send a signal group.  |   |  |
|----------------------------------|---|---|--|
| Synopsis                         | <pre>uint8 Com_SendSignalGroup ( Com_SignalGroupIdType SignalGroupId );</pre>   |   |  |
| Service ID                       | 0x0D  | 0x0D  |  |
| Sync/Async                       | Asynchronous  | Asynchronous  |  |
| Reentrancy                       | Re-entrant for different values of SignalGroupId only.  |   |  |
| Parameters (in)                  | SignalGroupId ID of the signal group to be sent   |   |  |
| Return Value Result of operation |   |   |  |
|                                  | E_OK  | success   |  |
|                                  | COM_SERVICE_NOT_AVAILABLE   | failure (Com not initialized, corresponding I-PDU group was stopped or service failed due to development error) |  |
|                                  | COM_BUSY  | - The receive Tp buffer is actually not available   |  |
| Description                      | The service Com_SendSignalGroup updates the signal group object identified by SignalGroupId Preconditions: COM must be initialized. |   |  |



# 5.2.3.3.26. Com\_SendSignalGroupArray

| Purpose         | Com_SendSignalGroupArray - update and send a signal group.  |   |  |
|-----------------|---|---|--|
| Synopsis        | <pre>uint8 Com_SendSignalGroupArray ( Com_SignalGroupIdType Signal-<br/>GroupId , const uint8 * SignalGroupArrayPtr , uint16 Signal-<br/>GroupArrayLength );</pre>  |   |  |
| Service ID      | 0x43  |   |  |
| Sync/Async      | Asynchronous  | Asynchronous  |  |
| Reentrancy      | Re-entrant for different values of Signa  | Re-entrant for different values of SignalGroupId only.  |  |
| Parameters (in) | SignalGroupId   | ID of the signal group to be sent   |  |
|                 | SignalGroupArrayPtr   | Reference to the signal group array to be transmitted   |  |
|                 | SignalGroupArrayLength  | Length of the signal group array  |  |
| Return Value    | Result of operation   |   |  |
|                 | E_OK  | success   |  |
|                 | COM_SERVICE_NOT_AVAILABLE   | failure (Com not initialized, corresponding I-PDU group was stopped or service failed due to development error) |  |
|                 | COM_BUSY  | - The receive Tp buffer is actually not available   |  |
| Description     | The service Com_SendSignalGroupArray copies the content of the provided Signal-GroupArrayPtr to the associated I-PDU. The provided data shall correspond to the array representation of the signal group. Preconditions: COM must be initialized. |   |  |

# 5.2.3.3.27. Com\_SetIpduGroup

| Purpose         | Com_SetIpduGroup - sets the value of a bit in an I-PDU group vector.   |  |
|-----------------|--|--|
| Synopsis        | <pre>void Com_SetIpduGroup ( Com_IpduGroupVector ipduGroupVector , Com_IpduGroupIdType ipduGroupId , boolean bitval );</pre> |  |
| Service ID      | 0x1d   |  |
| Sync/Async      | Synchronous  |  |
| Reentrancy      | Reentrant  |  |
| Parameters (in) | ipduGroupVector  | I-PDU group vector to be modified                          |
|                 | ipduGroupId  | identifies the corresponding bit in the I-PDU group vector |



|             | bitval                  | new value of the corresponding bit |
|-------------|-------------------------|------------------------------------|
| Description | Preconditions:          |                                    |
|             | COM must be initialized |                                    |

### 5.2.3.3.28. Com\_StartOfReception

| Purpose          | Com_StartOfReception returns the pointer to the size of the AUTOSAR COM module's internal receive buffer for the I-PDU with ID ComRxPduId. Preconditions:  prior to this call, the COM module shall be initialized the Pdu must be started before. |  |
|------------------|--|--|
| Synopsis         | <pre>BufReq_ReturnType Com_StartOfReception ( PduIdType ComRxPduId , PduLengthType TpSduLength , PduLengthType * RxBufferSizePtr );</pre>  |  |
| Parameters (in)  | ComRxPduId   | - ID of Tp I-PDU to be received.   |
|                  | TpSduLength  | - complete length of the TP I-PDU to be received.  |
| Parameters (out) | RxBufferSizePtr  | - Pointer to the size of internal TP-receive buffer  |
| Return Value     | BUFREQ_OK  | - Connection has been accepted. RxBufferSizePtr indicates the available receive buffer.                  |
|                  | BUFREQ_E_NOT_OK  | - Connection has been rejected. RxBuffer-SizePtr remains unchanged.                                      |
|                  | BUFREQ_E_OVFL  | - In case the configured buffer size as specified via ComPduldRef.PduLength is smaller than TpSduLength. |
| BUFREQ_E_BUSY    | - In case the reception buffer is actually not available for a new reception (implementation specific).  |  |

# 5.2.3.3.29. Com\_SwitchlpduTxMode

| Purpose    | Switch to a Transmission Mode.   |  |
|------------|--|--|
| Synopsis   | <pre>void Com_SwitchIpduTxMode ( PduIdType PduId , boolean Mode );</pre> |  |
| Service ID | 0x27   |  |



| Sync/Async      | Synchronous  |   |
|-----------------|--|---|
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld   |   |
| Parameters (in) | PduId ID of the PDU to be sent   |   |
|                 | Mode   | the transmission mode that shall be set |
| Description     | The function sets the transmission mode of the I-PDU referenced by Pduld to Mode Preconditions:  The COM must be initialized Should not be mixed with signal based TMS |   |

### 5.2.3.3.30. Com\_TpRxIndication

| Purpose         | Com_TpRxIndication - indicating the correct, or incorrect, end of the reception process.   |   |
|-----------------|--|---|
| Synopsis        | <pre>void Com_TpRxIndication ( PduIdType PduId , NotifResultType Re-<br/>sult );</pre>   |   |
| Service ID      | 0x1E   |   |
| Sync/Async      | Synchronous  |   |
| Reentrancy      | Re-entrant for different values of ComRxPduld only.  |   |
| Parameters (in) | PduId  | - ID of the AUTOSAR COM module's I-<br>PDU that has been received. Identifies the<br>data that has been received.   |
|                 | Result   | - NTFRSLT_OK: the complete I-PDU has<br>been received and is stored in the receive<br>buffer. ANY OTHER VALUE: the I-PDU<br>has not been received; the receive buffer<br>can be unlocked by the AUTOSAR COM |
| Description     | This functions signals the COM the correct, or incorrect, end of the reception process.  Preconditions:  COM should be initialized |   |

### 5.2.3.3.31. Com\_TpTxConfirmation

| Purpose | TpTxConfirmation Function to signal the COM that an large IPDU has been transmit- |
|---------|---|
|         | ted Preconditions:  |



|                 | COM should be initialized.   |  |
|-----------------|--|--|
| Synopsis        | <pre>void Com_TpTxConfirmation ( PduIdType PduId , NotifResultType Result );</pre> |  |
| Parameters (in) | PduId  | - ID of the large PDU which was transmitted successfully |
|                 | Result   | - Result of the transmission of the I-PDU                |

#### 5.2.3.3.32. Com\_TriggerIPDUSend

| Purpose         | Send an IPDU.  |                          |  |
|-----------------|--|--------------------------|--|
| Synopsis        | <pre>void Com_TriggerIPDUSend ( PduIdType ComTxPduId );</pre>  |                          |  |
| Service ID      | 0x17   |                          |  |
| Sync/Async      | Synchronous  |                          |  |
| Reentrancy      | Non re-entrant   |                          |  |
| Parameters (in) | ComTxPduId   | ID of the PDU to be sent |  |
| Description     | The function triggers sending of an IPDU Preconditions:  The COM must be initialized  The function must only be called from callouts |                          |  |

# 5.2.3.3.33. Com\_TriggerTransmit

| Purpose         | Com_TriggerTransmit - copy data to PDU-router memory.  |   |  |
|-----------------|--|---|--|
| Synopsis        | <pre>Std_ReturnType Com_TriggerTransmit ( PduIdType ComTxPduId , PduInfoType * PduInfoPtr );</pre> |   |  |
| Service ID      | 0x41   |   |  |
| Sync/Async      | Synchronous  |   |  |
| Reentrancy      | Re-entrant for different values of ComTxPduId only.  |   |  |
| Parameters (in) | ComTxPduId   | ID of the PDU which's data shall be copied  |  |
|                 | PduInfoPtr   | Contains a pointer to a buffer (SduDataPtr) to where the SDU shall be copied to. On return, the service will indicate the |  |



|              |   | length of the copied SDU data in Sdu-<br>Length.  |
|--------------|---|---|
| Return Value | E_OK:   | SDU has been copied and SduLength indicates the number of copied bytes.   |
|              | E_NOT_OK:   | No SDU has been copied. PduInfoPtr must not be used since it may contain a NULL pointer or point to invalid data. |
| Description  | a function to be used to fetch data from the  COM should be initialized | COM immediately Preconditions:  |

# 5.2.3.3.34. Com\_TxConfirmation

| Purpose         | Com_TxConfirmation.  |  |
|-----------------|--|--|
| Synopsis        | <pre>void Com_TxConfirmation ( PduIdType ComTxPduId );</pre>   |  |
| Service ID      | 0x40   |  |
| Sync/Async      | Synchronous  |  |
| Reentrancy      | Re-entrant for different values of ComTxPduId only.  |  |
| Parameters (in) | ComTxPduId   | ID of the PDU which was transmitted successfully |
| Description     | Function to signal the COM that an IPDU has been transmitted Preconditions:  COM should be initialized |  |

## 5.2.3.3.5. Com\_UpdateShadowSignal

| Purpose         | Com_UpdateShadowSignal - updates the data in the signal group.          |                                       |
|-----------------|---|---------------------------------------|
| Synopsis        | <pre>void Com_UpdateShadowSignal ( Co<br/>void * SignalDataPtr );</pre> | om_SignalIdType SignalId , const      |
| Service ID      | 0x0C  |                                       |
| Sync/Async      | Synchronous   |                                       |
| Reentrancy      | Re-entrant for different values of Signalld only.                       |                                       |
| Parameters (in) | SignalId  | ID of the group signal to be updated  |
|                 | SignalDataPtr   | place in memory to copy the data from |



| Description | The service Com_UpdateShadowSignal updates the group signal object identified        |  |
|-------------|--|--|
|             | by Signalld with the value referenced by the SignalDataPtr parameter. Preconditions: |  |
|             | COM must be initialized.   |  |
|             |  |  |

# 5.2.4. Integration notes

#### 5.2.4.1. Exclusive areas

This section describes the exclusive areas used by the  ${\tt Com}\ module.$ 

#### 5.2.4.1.1. COM\_EXCLUSIVE\_AREA\_0

| Protected data structures     | All shared data that shall be protected from mutual access.                        |
|-------------------------------|--|
| Recommended locking mechanism | The locking mechanism for this exclusive area can be disabled if:                  |
|                               | all Tx-related functions do not interrupt each other, and                          |
|                               | all Rx-related functions do not interrupt each other, and                          |
|                               | if signal gateway is used: Tx and Rx related functions do not interrupt each other |
|                               | If the conditions listed above do not apply, the exclusive area                    |
|                               | shall be protected by a locking mechanism. The options for                         |
|                               | locking are described in the EB tresos AutoCore Generic                            |
|                               | documentation. Refer to the section Mapping exclusive                              |
|                               | areas in the basic software modules in the Inte-                                   |
|                               | gration notes section for details.   |

## 5.2.4.1.2. COM\_EXCLUSIVE\_AREA\_1

|                               | All shared data that shall be protected from mutual access when they are accessed via Com_RxIndication() or Com_Tx-Confirmation(). |
|-------------------------------|--|
| Recommended locking mechanism | The locking mechanism for this exclusive area can be disabled if:  |



- no Com module related function can interrupt Com\_-RxIndicaiton, and
- no Com module related function can interrupt Com\_Tx-Confirmation

If the conditions listed above do not apply, the exclusive area shall be protected by a locking mechanism. The options for locking are described in the EB tresos AutoCore Generic documentation. Refer to the section Mapping exclusive areas in the basic software modules in the Integration notes section for details.

#### 5.2.4.2. Production errors

Production errors are not reported by the Com module.

## 5.2.4.3. Memory mapping

General information about memory mapping is provided in the EB tresos AutoCore Generic documentation. Refer to the section Memory mapping and compiler abstraction in the Integration notes section for details.

The following table provides the list of sections that may be mapped for this module:

| Memory section          |
|-------------------------|
| CODE                    |
| APPL_CODE               |
| CONST_32                |
| CONST_UNSPECIFIED       |
| VAR_CLEARED_UNSPECIFIED |
| VAR_CLEARED_16BIT       |
| VAR_CLEARED_32BIT       |
| VAR_INIT_8BIT           |
| VAR_CLEARED_8BIT        |
| CONFIG_DATA_UNSPECIFIED |
| CODE_CC_BLOCK           |



#### 5.2.4.4. Integration requirements

#### WARNING

#### Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user's guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

#### 5.2.4.4.1. Com.EB.IntReq.Preemption01

| Description | The Com_lpduGroupControl() or Com_lnit() API shall not be interrupted or interrupt any function of the Com Module which accesses the RAM.  |
|-------------|--|
| Rationale   | Race conditions when Com_lpduGroupControl() or Com_lnit() is preempted or preempts other Com services. Com_lpduGroupControl() or Com_lnit() must not be interrupted or interrupt any function of the Com Module which accesses the RAM. Since these functions do not use protected memory access, the result might be undefined behavior of the Com module. For example, a mess-up of the number of transmission in case of n-time transmission. In order to prevent this race condition, all interrupts have to be disabled during the call to Com_lnit() and Com_lpduGroupControl(). |

#### 5.2.4.4.2. Com.EB.IntReq.Preemption02

#### Description

Restrictions to prevent race conditions in Com's Tx-path. The Com module exhibits several race conditions in its transmission path that can cause inconsistent and/or mutilated data to be transmitted. The transmission of an I-PDU can be triggered by a Tx-signal API if the I-PDU has a direct part (transmission mode is DIRECT or MIXED). The Tx-signal APIs are Com\_SendSignal(), Com\_SendDynSignal(), Com\_SendSignalGroup(), and Com\_SendSignalGroupArray(). The Tx-signal APIs have write access to the Com-internal I-PDU buffer. Note that (the internal implementations of) these APIs are also used in context of Com\_MainFunctionRouteSignals(). Additionally the transmission of an I-PDU can be triggered in context of Com MainFunction-Tx(), Com TriggerIPDUSend(), or Com IpduGroupControl(), or Com SwitchIpduTx-Mode. Triggering of a transmission in general requires the read access to the Cominternal I-PDU buffer by the Com lower layers. Depending on the implementation of a Tx-callout (ComIPduCallout and ComIPduTriggerTransmitCallout), it requires read and/or write access to the Com-internal I-PDU buffer. The callouts are invoked when a transmission is triggered. Depending on the underlying bus system, the API Com -TriggerTransmit() is invoked, which requires read access to the Com-internal I-PDU buffer. A race occurs when an ongoing transmission (access to the Com-internal I-PDU buffer by Com lower layer and Com callout) is interrupted by an invocation of a Tx-signal API. A race occurs when an ongoing transmission is interrupted by an API



which triggers another transmission for the same I-PDU and a configured Com callout changes data. This behavior leads to the following cases:

 An I-PDU has a direct part. It also has a call to a Tx-signal API to a signal/signal group, in which one of the following transfer properties is interrupted by another Tx-signal API call of a signal of the very same I-PDU: TRIGGERED,

TRIGGERED ON CHANGE,

TRIGGERED\_ON\_CHANGE\_WITHOUT\_REPETITION, or TRIGGERED WITHOUT REPETITION.

 A call to a Tx-signal API for a signal/signal group that belongs to the I-PDU interrupts a call to one of the following APIs of the very same I-PDU: Com\_TriggerIPDUSend(),

Com IpduGroupControl(),

Com SwitchlpduTxMode(), or

Com TriggerTransmit().

 A call to a Tx-signal API interrupts a call to Com MainFunctionTx().

 A callout uses the data of the I-PDU for a calculation (e.g. to calculate a CRC) and a call to Tx-signal API interrupts the sending of the I-PDU.

With a call to Com\_SendDynSignal() not only the content of an I-PDU may change, but also the length of the I-PDU. Work-around To prevent inconsistencies in the I-PDU, ensure the following:

- A call to a Tx-signal API that triggers a transmission does not interrupt a call to a Tx-signal API for signals which belong to the same I-PDU.
- A call to a Tx-signal API does not interrupt one of the following APIs: Com\_TriggerIPDUSend(),

Com\_SwitchIpduTxMode(), or

Com\_TriggerTransmit().

- A call to a Tx-signal API does not interrupt

Com\_MainFunctionTx().

- Additionally, if a callout is configured that modifies I-PDU data: Ensure that the APIs:

Com\_TriggerIPDUSend()and

Com\_SwitchIpduTxMode() and

Com TriggerTransmit() and

Com\_MainFunctionTx()



|           | do not interrupt each other for the very same I-PDU.                                     |
|-----------|--|
| Rationale | This issue could be avoided if you lock the PDU buffer or use expensive double           |
|           | buffers. However if you lock the PDU buffer while the callout function or the PduR       |
|           | ComTransmit function is called, it leads to an undefined locking time. It is not accept- |
|           | able to disable interrupts for too long. Therefore a usage restriction has been defined  |
|           | in the work-around section to avoid race conditions.                                     |

#### 5.2.4.4.3. Com.EB.IntReq.Preemption02.TP

#### Description

Restrictions to prevent race conditions and a undefined transmission behaviour in Com's Tx-path for large I-PDUs. The Com module exhibits several race conditions in its transmission path that can cause inconsistent and/or mutilated data to be transmitted as well as undefined transmission requests. The transmission of an large I-PDU can be initiated by a Tx-signal API (due to Com module Tp limitation only transmission mode DIRECT can be enabled) and is deferred to the next invocation of the Com -MainFunctionTx() (due to Com module Tp limitation all large Tx I-PDU transmission requests are deferred to the next execution of the Com transmission main function). The Tx-signal APIs are Com\_SendSignal(), Com\_SendDynSignal(), Com\_SendSignalGroup(), and Com SendSignalGroupArray(). The Tx-signal APIs have write access to the Com-internal I-PDU buffer. Additionally the transmission of an I-PDU can be initiated in context of Com\_TriggerIPDUSend(). Depending on the underlying bus system, the API Com\_TriggerTransmit() is invoked, which requires read access to the Com-internal I-PDU buffer. A race occurs when an ongoing transmission (access to the Com-internal I-PDU buffer by Com lower layer and Com callout) is interrupted by an invocation of a Tx-signal API. A undefined transmission behaviour occurs when an ongoing transmission (execution of the Com\_MainFunctionTx()) is interrupted by Com\_TriggerIPDUSend() which possible triggers a transmission during the current execution of the Com\_MainFunctionTx() and not the next invocation of the Com\_Main-FunctionTx(). This behaviour leads to the following cases:

- An large I-PDU has a direct part. It also has a call to a Tx-signal API to a signal/signal group, in which one of the following transfer properties is interrupted by another Tx-signal API call of a signal of the very same large I-PDU: TRIGGERED,
- TRIGGERED\_ON\_CHANGE,
- TRIGGERED\_ON\_CHANGE\_WITHOUT\_REPETITION, or TRIGGERED\_WITHOUT\_REPETITION.
- A call to a Tx-signal API interrupts a call to Com MainFunctionTx().
- A call to Com\_TriggerIPDUSend() interrupts a call to



Com MainFunctionTx().

 A callout uses the data of the large I-PDU for a calculation (e.g. to calculate a CRC) and a call to Tx-signal API interrupts the sending of the large I-PDU.

With a call to Com\_SendDynSignal() not only the content of an large I-PDU may change, but also the length of the large I-PDU. Work-around To prevent inconsistencies in the large I-PDU, ensure the following:

- A call to a Tx-signal API that initiates a transmission does not interrupt a call to a Tx-signal API for signals which belong to the same large I-PDU.
- A call to a Tx-signal API does not interrupt one of the following APIs: Com\_TriggerIPDUSend(), or Com\_TriggerTransmit().
- A call to a Tx-signal API does not interrupt Com\_MainFunctionTx().
- Additionally, if a callout is configured that modifies data of the large I-PDU: Ensure that the APIs:

Com\_TriggerIPDUSend()and Com\_TriggerTransmit() and

Com\_MainFunctionTx()

do not interrupt each other for the very same large I-PDU.

#### Rationale

This issue could be avoided if you lock the PDU buffer or use expensive double buffers. However if you lock the PDU buffer while the callout function or the PduR\_-ComTpTransmit function is called, it leads to an undefined locking time. It is not acceptable to disable interrupts for too long. Therefore a usage restriction has been defined in the work-around section to avoid race conditions.

#### 5.2.4.4.4. Com.EB.IntReq.Preemption03

# The access to the shadow buffer of a signal group is not protected. Therefore restrictions apply to the mutually possible preemptions. - On the Tx-side: A call to Com\_UpdateShadowSignal() shall not get interrupted by Com\_SendSignalGroup() for the signal group to which the group signal belongs to. - On the Rx side: A call to Com\_ReceiveShadowSignal() shall not get interrupted by Com\_ReceiveSignalGroup() for the signal group to which the group signal belongs to.



| Rationale | Restriction on allowed mutual preemptions Work-around:   |
|-----------|--|
|           | <ul> <li>Ensure that Com_SendSignalGroup() does not interrupt Com_UpdateShadowSignal() for the signal group to which the group signal belongs to.</li> <li>Ensure that Com_ReceiveSignalGroup() does not interrupt Com_ReceiveShadowSignal() for the signal group to which the group signal belongs to.</li> </ul> |

## 5.2.4.4.5. Com.EB.IntReq.MainRxSchedule04

| Description | The Com_MainFunctionRx() shall be scheduled even if no Rx-I-PDU is configured on a certain ECU.  |
|-------------|--|
| Rationale   | Scheduling the Com main functions is restricted You always need to schedule the Com_MainFunctionRx() even if no Rx-I-PDU is configured on a certain ECU. The Com_MainFunctionRx() maintains the internal timer of the Com module. The internal timer is used as a time base for reception deadline monitoring but also for features of the Tx-path like transmission deadline monitoring, minimum delay timer and sending of Tx-I-PDUs (cyclic and n-times). |

## 5.2.4.4.6. Com.EB.IntReq.UpdateBit05

| Description | Limitation on Com signals/signal groups with update-bits. AUTOSAR COM SWS specifies that signals/signal groups with update-bits which have not been updated shall be discarded. However, if after an update of an I-PDU the value of a signal changes from e.g. x to y without the update bit is set, a call to Com_ReceiveSignal()/Com_ReceiveSignalGroup()-Com_ReceiveGroupSignal() returns the changed value (i.e. y) and not the last received value (i.e. x). Note: It is very unlikely that the receiver receives an updated value without the update-bit set. Because at sender side, the sender always sets the update-bit in case a new value is transmitted. The value of a signal/signal group only changes when the Com_SendSignal()/Com_SendSignal-Group() is invoked which sets the update-bit. An impact may only occur if the value on the sender is changed while the update-bit is not set. If this conditions occur this has |
|-------------|---|
|             | the sender is changed while the update-bit is not set. If this conditions occur this has no impact on the following use-cases:  - For applications (SWCs), at least if the EB-optimization DirectReadFromCom in Rte is not used. Since the Rte reads the value from the Com module only if it is notified by the Com  |



|           | module. This does not happen when the update-bit is not set. Also it writes the received value into a buffer and reads requests from the application and uses the value of the buffer.  - For applications which only use Com APIs when ComNotification is received.   |
|-----------|--|
|           | However, this conditions may have an impact on the following use-case: Applications, which directly use the Com APIs, usually get the correct value, since the value of a signal usually does not change without setting the update-bit. If you use the Com APIs without ComNotification, changed values may be read that have no update-bit set. The following work-around is only applicable in this case. Work-around for signals of type U/SINT8/16/32 Configure a filter (ComFilterAlgorithm) NEW_IS_WITHIN, with the parameters [ComFilterMin, ComFilterMax] = maximum possible value range. |
| Rationale | This limitation allows a more efficient implementation and for the application usually the behavior does not change. Requirements: - COM324  |

## 5.2.4.4.7. Com.EB.IntReq.Preemption06

| Description | Regarding the multiple main function support with gateway use cases, the generated Com_MainFunctionRouteSignals_Src_ <mainfunctionname_src>() and ComMainFunctionRouteSignals_Src_<mainfunctionname_src>_Dest_<mainfunctionname_dest>() APIs for a related source main function shall be scheduled after (and thus non-concurrent to) the related source main function.</mainfunctionname_dest></mainfunctionname_src></mainfunctionname_src>  |
|-------------|--|
| Rationale   | Com_MainFunctionRouteSignals_Src_ <mainfunctionname_src>() and ComMainFunctionRouteSignals_Src_<mainfunctionname_src>_Dest_<mainfunction-name_dest>() APIs perform a read access to signal buffers (filter flags) and ComIP-du buffers (which are written by Com_RxIndication() and the related source main function). However, by scheduling the Com_MainFunctionRouteSignals_Src_<mainfunctionname_src>() and Com_MainFunctionRouteSignals_Src_<mainfunction-name_src>_Dest_<mainfunctionname_dest>() APIs after (and thus non-concurrent to) the related source main function, the concurrent access to data shared between the related source main function and the Com_MainFunctionRouteSignals_Src<mainfunctionname_src>() / Com_MainFunctionRouteSignals_Src_<mainfunction-name_src>_Dest_<mainfunctionname_dest>() APIs does not occur.</mainfunctionname_dest></mainfunction-name_src></mainfunctionname_src></mainfunctionname_dest></mainfunction-name_src></mainfunctionname_src></mainfunction-name_dest></mainfunctionname_src></mainfunctionname_src> |

## 5.2.4.4.8. Com.EB.IntReq.Preemption07

| Description | Regarding the multiple main function support with gateway use cases, the generat-  |
|-------------|--|
|             | ed Com_MainFunctionRouteSignals_Src_ <mainfunctionname_src>() and Com</mainfunctionname_src>                             |
|             | MainFunctionRouteSignals_Src_ <mainfunctionname_src>_Dest_<mainfunction-< th=""></mainfunction-<></mainfunctionname_src> |



|           | Name_Dest>() APIs for a related source main function shall not be interrupted by similar generated APIs from different source main functions. Furthermore, the ComMainFunctionRouteSignals_Src_ <mainfunctionname_src>() shall be called prior to every call to Com_MainFunctionRouteSignals_Src_<mainfunctionname_src>Dest_<mainfunctionname_dest>() of a source main function.</mainfunctionname_dest></mainfunctionname_src></mainfunctionname_src>  |
|-----------|---|
| Rationale | Com_MainFunctionRouteSignals_Src_ <mainfunctionname_src>() performs a write access to the Comlpdu buffers of the TX ComlPdus. Since Com_MainFunction-RouteSignals_Src_<mainfunctionname_src>_Dest_<mainfunctionname_dest>() (which triggers the TX ComlPdus) are potentially executed on different cores and thus theoretically multi-core capable mutual exclusion primitives are required. However, by scheduling the Com_MainFunctionRouteSignals_Src_<mainfunctionname_src>() calls prior to every call of Com_MainFunctionRouteSignals_Src_<mainfunction-name_src>_Dest_<mainfunctionname_dest>() and avoiding interruption by similar generated APIs for different source main functions, the concurrent write access to the Comlpdu buffers of the TX ComlPdus does not occur. Due to restricted scheduling concurrent write access is avoided because any send action initiated in Com_MainFunctionRouteSignals_Src_<mainfunctionname_src>() will be deferred till the execution of Com_MainFunctionRouteSignals_Src_<mainfunctionname_src>_Dest<mainfunctionname_dest>().</mainfunctionname_dest></mainfunctionname_src></mainfunctionname_src></mainfunctionname_dest></mainfunction-name_src></mainfunctionname_src></mainfunctionname_dest></mainfunctionname_src></mainfunctionname_src> |

# 5.3. IpduM

# 5.3.1. Configuration parameters

| Containers included              |              |  |
|----------------------------------|--------------|--|
| Container name                   | Multiplicity | Description  |
| CommonPublishedInformation       | 11           | Label: Common Published Information Common container, aggregated by all modules. It contains published information about vendor and versions.  |
| <u>IpduMDefensiveProgramming</u> | 11           | Label: Defensive Programming Options  Parameters for defensive programming   |
| IpduMConfig                      | 1n           | This container contains the sub containers of the IpduM module. The IpduMTxPathway sub container includes information about sent I-PDUs. The IpduMRxPathway includes information about received I-PDUs. This container is a Multi- |



| Containers included                   |    |  |
|---------------------------------------|----|--|
|                                       |    | pleConfigurationContainer, i.e. this container and its sub containers exist once per configuration set.  |
| <u>IpduMGeneral</u>                   | 11 | Contains the general configuration parameters of IpduM.  |
| <u>IpduMPublishedInformation</u>      | 11 | Additional published parameters not covered by. Common-<br>PublishedInformation container. Note that these parameters<br>do not have any configuration class setting, since they are<br>published information. |
| IpduMRequestMessageCon-<br>figuration | 01 | This is used to specify the configuration for multiplexed requesting messages.   |
| PublishedInformation                  | 11 | Label: EB Published Information Additional published parameters not covered by Common- PublishedInformation container.   |

| Parameters included           |              |  |
|-------------------------------|--------------|--|
| Parameter name                | Multiplicity |  |
| IMPLEMENTATION_CONFIG_VARIANT | 11           |  |

| Parameter Name | IMPLEMENTATION_CONFIG_VARIANT |
|----------------|-------------------------------|
| Label          | Config Variant                |
| Multiplicity   | 11                            |
| Туре           | ENUMERATION                   |
| Default value  | VariantPostBuild              |
| Range          | VariantPostBuild              |

## 5.3.1.1. CommonPublishedInformation

| Parameters included   |              |  |
|-----------------------|--------------|--|
| Parameter name        | Multiplicity |  |
| <u>ArMajorVersion</u> | 11           |  |
| <u>ArMinorVersion</u> | 11           |  |
| <u>ArPatchVersion</u> | 11           |  |
| <u>SwMajorVersion</u> | 11           |  |
| SwMinorVersion        | 11           |  |
| <u>SwPatchVersion</u> | 11           |  |



| Parameters included |    |  |
|---------------------|----|--|
| ModuleId            | 11 |  |
| Vendorld            | 11 |  |
| Release             | 11 |  |

| Parameter Name      | ArMajorVersion   |
|---------------------|--|
| Label               | AUTOSAR Major Version  |
| Description         | Major version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 2  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name      | ArMinorVersion   |  |
|---------------------|--|--|
| Label               | AUTOSAR Minor Version  |  |
| Description         | Minor version number of AUTOSAR specification on which the appropriate implementation is based on. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER_LABEL  |  |
| Default value       | 2  |  |
| Configuration class | PublishedInformation:  |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | ArPatchVersion   |
|---------------------|--|
| Label               | AUTOSAR Patch Version  |
| Description         | Patch level version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 0  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |



| Parameter Name      | SwMajorVersion  |
|---------------------|---|
| Label               | Software Major Version  |
| Description         | Major version number of the vendor specific implementation of the module. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 3   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | SwMinorVersion  |  |
|---------------------|---|--|
| Label               | Software Minor Version  |  |
| Description         | Minor version number of the vendor specific implementation of the module. The numbering is vendor specific. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER_LABEL   |  |
| Default value       | 3   |  |
| Configuration class | PublishedInformation:   |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name      | SwPatchVersion  |
|---------------------|---|
| Label               | Software Patch Version  |
| Description         | Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 40  |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name | Moduleld                                  |
|----------------|---|
| Label          | Numeric Module ID                         |
| Description    | Module ID of this module from Module List |
| Multiplicity   | 11  |
| Туре           | INTEGER_LABEL                             |



| Default value       | 52                         |
|---------------------|----------------------------|
| Configuration class | PublishedInformation:      |
| Origin              | Elektrobit Automotive GmbH |

| Parameter Name      | Vendorld  |
|---------------------|---|
| Label               | Vendor ID   |
| Description         | Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 1   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | Release                    |
|---------------------|----------------------------|
| Label               | Release Information        |
| Multiplicity        | 11                         |
| Туре                | STRING_LABEL               |
| Default value       |                            |
| Configuration class | PublishedInformation:      |
| Origin              | Elektrobit Automotive GmbH |

## 5.3.1.2. IpduMDefensiveProgramming

| Parameters included              |              |  |
|----------------------------------|--------------|--|
| Parameter name                   | Multiplicity |  |
| IpduMDefProgEnabled              | 11           |  |
| <u>IpduMPrecondAssertEnabled</u> | 11           |  |
| IpduMPostcondAssertEnabled       | 11           |  |
| IpduMStaticAssertEnabled         | 11           |  |
| IpduMUnreachAssertEnabled        | 11           |  |
| IpduMInvariantAssertEnabled      | 11           |  |

| Parameter Name | IpduMDefProgEnabled |
|----------------|---------------------|
|----------------|---------------------|



| Label               | Enable Defensive Programming  |                  |
|---------------------|---|------------------|
| Description         | Enables or disables the defensive programming feature for the module IpduM.   |                  |
|                     | Note: This feature is dependent on the use of the development error detection module. To use the defensive programming feature, proceed as follows: |                  |
|                     | Enable development error detection  |                  |
|                     | Enable defensive programming  |                  |
|                     | 3. Enable assertions as required  |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name      | IpduMPrecondAssertEnabled  |                  |
|---------------------|--|------------------|
| Label               | Enable Precondition Assertions   |                  |
| Description         | Enables handling of precondition assertion checks reported from the module Ip-duM. |                  |
|                     | Dependency on parameter(s):  |                  |
|                     | ► Enable Development Error Detection (IpduMDevErrorDetect): must be enabled        |                  |
|                     | ► Enable Defensive Programming (IpduMDefProgEnabled): must be enabled              |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | IpduMPostcondAssertEnabled   |
|----------------|--|
| Label          | Enable Postcondition Assertions  |
| Description    | Enables handling of postcondition assertion checks reported from the module Ip-duM.  Dependency on parameter(s): |



|                     | ► Enable Development Error Detection (IpduMDevErrorDetect): must be enabled |  |
|---------------------|---|--|
|                     | ► Enable Defensive Programming (Ip  | oduMDefProgEnabled <b>): must be en-</b> |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name      | IpduMStaticAssertEnabled  |   |  |
|---------------------|---|---|--|
| Label               | Enable Static Assertions  |   |  |
| Description         | Enables handling of static assertion che                                    | Enables handling of static assertion checks reported from the module IpduM. |  |
|                     | Dependency on parameter(s):   |   |  |
|                     | ► Enable Development Error Detection (IpduMDevErrorDetect): must be enabled |   |  |
|                     | ► Enable Defensive Programming (IpduMDefProgEnabled): must be enabled       |   |  |
| Multiplicity        | 11  |   |  |
| Туре                | BOOLEAN   |   |  |
| Default value       | false   |   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |   |  |
| Origin              | Elektrobit Automotive GmbH  |   |  |

| Parameter Name | IpduMUnreachAssertEnabled   |
|----------------|---|
| Label          | Enable Unreachable Code Assertions  |
| Description    | Enables handling of unreachable code assertion checks reported from the module lpduM. |
|                | Dependency on parameter(s):   |
|                | ► Enable Development Error Detection (IpduMDevErrorDetect): must be enabled           |
|                | ► Enable Defensive Programming (IpduMDefProgEnabled): must be enabled                 |
| Multiplicity   | 11  |



| Туре                | BOOLEAN                    |                  |
|---------------------|----------------------------|------------------|
| Default value       | false                      |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | IpduMInvariantAssertEnabled   |   |  |
|---------------------|---|---|--|
| Label               | Enable Invariant Assertions   | Enable Invariant Assertions   |  |
| Description         | Enables handling of invariant assertion module lpduM.                       | Enables handling of invariant assertion checks reported from functions of the module IpduM. |  |
|                     | Dependency on parameter(s):   |   |  |
|                     | ► Enable Development Error Detection (IpduMDevErrorDetect): must be enabled |   |  |
|                     | ► Enable Defensive Programming (IpduMDefProgEnabled): must be enabled       |   |  |
| Multiplicity        | 11  |   |  |
| Туре                | BOOLEAN   |   |  |
| Default value       | false   |   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |   |  |
| Origin              | Elektrobit Automotive GmbH  |   |  |

# 5.3.1.3. IpduMConfig

| Containers included        |              |   |
|----------------------------|--------------|---|
| Container name             | Multiplicity | Description   |
| <u>IpduMContainedRxPdu</u> | 0n           | Configuration of a received contained Pdu.  |
| <u>IpduMContainedTxPdu</u> | 0n           | Configuration of a sender ContainedPdu.   |
| <u>IpduMContainerRxPdu</u> | 0n           | EN: Configuration of a receiver ContainerPdu which may collect several ContainedPdus. |
| <u>IpduMContainerTxPdu</u> | 0n           | Configuration of a transmitted container Pdu.   |
| <u>IpduMRxPathway</u>      | 065535       | Contains the configuration parameters received I-PDUs by the IpduM module.            |
| <u>IpduMTxPathway</u>      | 065535       | Contains the configuration parameters transmitted I-PDUs by the IpduM module.         |



# 5.3.1.4. IpduMContainedRxPdu

| Parameters included               |    |
|-----------------------------------|----|
| Parameter name Multiplicity       |    |
| IpduMContainedPduHeaderId         | 11 |
| IpduMContainedPduOffset           | 01 |
| IpduMPduUpdateBitPosition         | 01 |
| IpduMContainedRxInContainerPduRef | 01 |
| IpduMContainedRxPduRef            | 11 |

| Parameter Name      | IpduMContainedPduHeaderId   |  |
|---------------------|---|--|
| Description         | Header Id which is part of the ContainerPdu when this ContainedPdu is inside. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER   |  |
| Configuration class | PostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | IpduMContainedPduOffset                       |  |
|---------------------|---|--|
| Description         | Static offset (in bytes) of the ContainedPdu. |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER                                       |  |
| Configuration class | PostBuild: VariantPostBuild                   |  |
| Origin              | AUTOSAR_ECUC                                  |  |

| Parameter Name      | IpduMPduUpdateBitPosition   |                  |
|---------------------|---|------------------|
| Description         | This value specifies where the PDU's Update-Bit is stored in the Container PDU (bit location of PDU's Update-Bit in the Container PDU). |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | IpduMContainedRxInContainerPduRef   |  |
|----------------|---|--|
| Description    | Optional reference to a container Pdu this contained Pdu may be transported in. |  |
| Multiplicity   | 01  |  |



| Туре                | REFERENCE                   |  |
|---------------------|-----------------------------|--|
| Configuration class | PostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                |  |

| Parameter Name      | IpduMContainedRxPduRef  |  |
|---------------------|---|--|
| Description         | Reference to the Pdu which represents this ContainedPdu and is used for reception indication. |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

# 5.3.1.5. IpduMContainedTxPdu

| Parameters included                    |              |  |
|--|--------------|--|
| Parameter name                         | Multiplicity |  |
| IpduMContainedPduHeaderId              | 11           |  |
| IpduMContainedTxPduPriority            | 01           |  |
| IpduMContainedPduOffset                | 01           |  |
| IpduMPduUpdateBitPosition              | 01           |  |
| IpduMContainedTxPduCollectionSemantics | 11           |  |
| IpduMContainedTxPduConfirmation        | 01           |  |
| IpduMContainedTxPduHandleId            | 11           |  |
| IpduMContainedTxPduSendTimeout         | 01           |  |
| IpduMContainedTxPduTrigger             | 11           |  |
| IpduMContainedTxInContainerPduRef      | 11           |  |
| IpduMContainedTxPduRef                 | 11           |  |

| Parameter Name | IpduMContainedPduHeaderId   |  |
|----------------|---|--|
| Description    | Header Id which is part of the ContainerPdu when this ContainedPdu is inside. |  |
| Multiplicity   | 11  |  |
| Туре           | INTEGER   |  |
| Range          | <=4294967295  |  |



|                     | >=1          |                  |
|---------------------|--------------|------------------|
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC |                  |

| Parameter Name      | IpduMContainedTxPduPriority  |  |
|---------------------|--|--|
| Description         | Defines a priority of a ContainedTxPdu. 255 represents the lowest priority and 0 represent the highest priority. |  |
| Multiplicity        | 01   |  |
| Туре                | INTEGER  |  |
| Default value       | 255  |  |
| Configuration class | PostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | IpduMContainedPduOffset                       |  |
|---------------------|---|--|
| Description         | Static offset (in bytes) of the ContainedPdu. |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER                                       |  |
| Range               | <=4294967295                                  |  |
|                     | >=0   |  |
| Configuration class | PostBuild: VariantPostBuild                   |  |
| Origin              | AUTOSAR_ECUC                                  |  |

| Parameter Name      | IpduMPduUpdateBitPosition   |                  |
|---------------------|---|------------------|
| Description         | This value specifies where the PDU's Update-Bit is stored in the Container PDU (bit location of PDU's Update-Bit in the Container PDU). |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | IpduMContainedTxPduCollectionSemantics  |  |
|----------------|---|--|
| •              | Defines whether this IpduMContainedTxPdu shall be collected using a last-is-best or queued semantics. |  |
| Multiplicity   | 11  |  |



| Туре                | ENUMERATION                |                  |
|---------------------|----------------------------|------------------|
| Range               | IPDUM_COLLECT_LAST_IS_BEST |                  |
|                     | IPDUM_COLLECT_QUEUED       |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | AUTOSAR_ECUC               |                  |

| Parameter Name      | IpduMContainedTxPduConf   | IpduMContainedTxPduConfirmation |  |
|---------------------|---|---------------------------------|--|
| Description         | This Parameter determines whether for this contained I-PDU a TxConfirmation shall be provided. If set to TRUE a TxConfirmation is issued. It is not used when an I-PDU is requested using the trigger transmit API. |                                 |  |
| Multiplicity        | 01  | 01                              |  |
| Туре                | BOOLEAN   |                                 |  |
| Default value       | false   |                                 |  |
| Configuration class | PostBuild:  | PostBuild: VariantPostBuild     |  |
| Origin              | AUTOSAR_ECUC  |                                 |  |

| Parameter Name      | IpduMContainedTxPduHandleId    |                  |
|---------------------|--------------------------------|------------------|
| Description         | Handle Id of the ContainedPdu. |                  |
| Multiplicity        | 11                             |                  |
| Туре                | INTEGER                        |                  |
| Range               | <=65535                        |                  |
|                     | >=0                            |                  |
| Configuration class | VariantPostBuild:              | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                   |                  |

| Parameter Name      | IpduMContainedTxPduSendTimeout  |                  |
|---------------------|---|------------------|
| Description         | Defines a ContainedPdu specific sender timeout which can reduce the ContainerPdu timer when this ContainedPdu is put inside the ContainerPdu. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FLOAT   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | IpduMContainedTxPduTrigger |
|----------------|----------------------------|
|----------------|----------------------------|



| Description         | Defines whether this Pdu triggers the sending of the ContainerPdu. |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | ENUMERATION  |  |
| Range               | IPDUM_TRIGGER_ALWAYS   |  |
|                     | IPDUM_TRIGGER_NEVER  |  |
| Configuration class | VariantPostBuild: VariantPostBuild                                 |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | IpduMContainedTxInContainerPduRef  |                  |
|---------------------|--|------------------|
| Description         | Reference to the container Pdu which this contained Pdu shall be collected in. |                  |
| Multiplicity        | 11   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | IpduMContainedTxPduRef  |                  |
|---------------------|---|------------------|
| Description         | Reference to the Pdu which represents this ContainedPdu and is used for transmission. |                  |
| Multiplicity        | 11  |                  |
| Туре                | REFERENCE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

# 5.3.1.6. IpduMContainerRxPdu

| Parameters included                |              |  |
|------------------------------------|--------------|--|
| Parameter name                     | Multiplicity |  |
| IpduMContainerHeaderSize           | 11           |  |
| IpduMContainerPduProcessing        | 11           |  |
| <u>IpduMContainerQueueSize</u>     | 01           |  |
| IpduMContainerRxAcceptContainedPdu | 11           |  |
| IpduMContainerRxHandleId           | 11           |  |
| <u>IpduMContainerRxPduRef</u>      | 11           |  |



| Parameter Name      | IpduMContainerHeaderSize   |                  |
|---------------------|--|------------------|
| Description         | Defines the layout of the header information (header id and length). |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Default value       | IPDUM_HEADERTYPE_SHORT   |                  |
| Range               | IPDUM_HEADERTYPE_LONG  |                  |
|                     | IPDUM_HEADERTYPE_SHORT   |                  |
|                     | IPDUM_HEADERTYPE_NONE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | IpduMContainerPduProcessing   |                  |
|---------------------|---|------------------|
| Description         | Defines whether the handling of this ContainerPdu shall be done in the context of the caller (IMMEDIATE) or in the next IpduM main function (DEFERRED). |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Default value       | IPDUM_PROCESSING_IMMEDIATE  |                  |
| Range               | IPDUM_PROCESSING_DEFERRED   |                  |
|                     | IPDUM_PROCESSING_IMMEDIATE  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | IpduMContainerQueueSize                                  |  |
|---------------------|--|--|
| Description         | Defines a local queue for handling of each ContainerPdu. |  |
| Multiplicity        | 01   |  |
| Туре                | INTEGER  |  |
| Default value       | 1  |  |
| Configuration class | PostBuild: VariantPostBuild                              |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name | IpduMContainerRxAcceptContainedPdu   |  |
|----------------|--|--|
| Description    | Defines for the received IpduMContainerRxPdu whether the list of referencing IpduMContainedRxPdus (via the reference IpduMContainedRxPduContainerRef) is a closed set. |  |



| Multiplicity        | 11                      |                  |
|---------------------|-------------------------|------------------|
| Туре                | ENUMERATION             |                  |
| Range               | IPDUM_ACCEPT_ALL        |                  |
|                     | IPDUM_ACCEPT_CONFIGURED |                  |
| Configuration class | VariantPostBuild:       | VariantPostBuild |
| Origin              | AUTOSAR_ECUC            |                  |

| Parameter Name      | IpduMContainerRxHandleId                         |                  |
|---------------------|--|------------------|
| Description         | EN: Handle Id used by the PduR for RxIndication. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=65535  |                  |
|                     | >=0  |                  |
| Configuration class | VariantPostBuild:                                | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                                     |                  |

| Parameter Name      | IpduMContainerRxPduRef   |                  |
|---------------------|--|------------------|
| Description         | Reference to the Pdu which represents the container and is used for reception. |                  |
| Multiplicity        | 11   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

# 5.3.1.7. IpduMContainerTxPdu

| Parameters included                      |              |  |
|--|--------------|--|
| Parameter name                           | Multiplicity |  |
| IpduMContainerHeaderSize                 | 11           |  |
| IpduMContainerQueueSize                  | 01           |  |
| IpduMContainerTxConfirmationTimeout      | 01           |  |
| IpduMContainerTxFirstContainedPduTrigger | 11           |  |
| IpduMContainerTxHandleId                 | 01           |  |
| <u>IpduMContainerTxSendTimeout</u>       | 01           |  |



| Parameters included           |    |  |
|-------------------------------|----|--|
| IpduMContainerTxSizeThreshold | 01 |  |
| IpduMContainerTxTriggerMode   | 11 |  |
| IpduMUnusedAreasDefault       | 01 |  |
| IpduMContainerTxPduRef        | 11 |  |

| Parameter Name      | IpduMContainerHeaderSize   |                  |
|---------------------|--|------------------|
| Description         | Defines the layout of the header information (header id and length). |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Range               | IPDUM_HEADERTYPE_LONG  |                  |
|                     | IPDUM_HEADERTYPE_SHORT   |                  |
|                     | IPDUM_HEADERTYPE_NONE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | IpduMContainerQueueSize                                  |                  |  |
|---------------------|--|------------------|--|
| Description         | Defines a local queue for handling of each ContainerPdu. |                  |  |
| Multiplicity        | 01   | 01               |  |
| Туре                | INTEGER  | INTEGER          |  |
| Default value       | 1  |                  |  |
| Range               | <=254  |                  |  |
|                     | >=1  |                  |  |
| Configuration class | PostBuild:   | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC   |                  |  |

| Parameter Name      | IpduMContainerTxConfirmationTimeout  |  |
|---------------------|--|--|
| Description         | This timeout (in seconds) defines the timeout period for monitoring the reception of the TxConfirmation. |  |
| Multiplicity        | 01   |  |
| Туре                | FLOAT  |  |
| Configuration class | PostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC   |  |



| Parameter Name      | IpduMContainerTxFirstContainedPduTrigger  |    |  |
|---------------------|---|----|--|
| Description         | Defines if the transmission of this IpduMContainerTxPdu shall be requested right after the first IpduMContainedTxPdu was put into it. |    |  |
| Multiplicity        | 11  | 11 |  |
| Туре                | BOOLEAN   |    |  |
| Default value       | false   |    |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |    |  |
| Origin              | AUTOSAR_ECUC  |    |  |

| Parameter Name      | IpduMContainerTxHandleId   |                  |
|---------------------|--|------------------|
| Description         | Handle Id used by the PduR for TxConfirmation and for TriggerTransmit of the ContainerPdu. |                  |
| Multiplicity        | 01   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=65535  |                  |
|                     | >=0  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | IpduMContainerTxSendTimeout   |                  |
|---------------------|---|------------------|
| Description         | When this timeout expires the ContainerPdu is triggered for sending. The respective timer is started when the first Pdu is put into the ContainerPdu. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FLOAT   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | IpduMContainerTxSizeThreshold   |
|----------------|---|
| Description    | Defines the size threshold in bytes which, when exceeded, triggers the sending of the ContainerPdu although the maxium Pdu size (PduLength parameter of Pdu object) has not been reached yet. |
| Multiplicity   | 01  |
| Туре           | INTEGER   |
| Range          | <=4294967295  |



|                     | >=0          |                  |
|---------------------|--------------|------------------|
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC |                  |

| Parameter Name      | IpduMContainerTxTriggerMode  |                  |
|---------------------|--|------------------|
| Description         | Defines whether this ContainerPdu is fetched via trigger transmit. |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Range               | IPDUM_DIRECT   |                  |
|                     | IPDUM_TRIGGERTRANSMIT  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | IpduMUnusedAreasDefault  |  |
|---------------------|--|--|
| Description         | IpduM fills not updated areas of the Container PDU with this byte-pattern. |  |
| Multiplicity        | 01   |  |
| Туре                | INTEGER  |  |
| Configuration class | PostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | IpduMContainerTxPduRef  |                  |
|---------------------|---|------------------|
| Description         | Reference to the Pdu which represents the container and is used for transmission. |                  |
| Multiplicity        | 11  |                  |
| Туре                | REFERENCE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

# 5.3.1.8. IpduMRxPathway

| Containers included      |              |   |
|--------------------------|--------------|---|
| Container name           | Multiplicity | Description   |
| <u>IpduMRxIndication</u> | 11           | Contains the configuration for incoming RxIndication calls. |



# 5.3.1.9. IpduMRxIndication

| Containers included               |              |  |
|-----------------------------------|--------------|--|
| Container name                    | Multiplicity | Description  |
| <u>IpduMRxDynamicPart</u>         | 1256         | This container contains the configuration for the dynamic part of incoming RxIndication calls. When an incoming received I-PDU's selector field matches the IpduM_Selector_Value, the new outgoing I-PDU for the dynamic part is constructed as defined by the segments of this container and sent out with the I-PDU ID referenced by IpduMOutgoingDynamicPduRef. |
| <u>IpduMRxStaticPart</u>          | 01           | This container contains the configuration for the static part of incoming RxIndication calls. On reception, the new outgoing I-PDU for the static part is constructed as defined by the segments of this container and sent out with the I-PDU ID referenced by IpduMOutgoingStaticPduRef.   |
| <u>IpduMSelectorFieldPosition</u> | 11           | This contains the location and the length of the selector field.   |

| Parameters included     |              |  |
|-------------------------|--------------|--|
| Parameter name          | Multiplicity |  |
| <u>IpduMByteOrder</u>   | 11           |  |
| IpduMRxHandleId         | 11           |  |
| IpduMRxIndicationPduRef | 11           |  |

| Parameter Name      | IpduMByteOrder  |                  |
|---------------------|---|------------------|
| Description         | This parameter defines the ByteOrder for all IpduMSegments (static and dynamic part) and for the selectorField within the MultiplexedPdu. The absolute position of a segment in the MultiplexedIPdu is determined by the definition of the ByteOrder parameter: If BIG_ENDIAN is specified, the SegmentPosition indicates the bit position of the most significant bit in an IPDU. If LITTLE_ENDIAN is specified, the SegmentPosition indicates the bit position of the least significant bit in an IPDU. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Default value       | LITTLE_ENDIAN   |                  |
| Range               | BIG_ENDIAN  |                  |
|                     | LITTLE_ENDIAN   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |



| Origin              | AUTOSAR_ECUC  |                  |
|---------------------|---|------------------|
| Parameter Name      | IpduMRxHandleId   |                  |
| Description         | This is the I-PDU ID of the incoming I-PDU. If an incoming RxIndication's I-PDU ID matches this value than it is unpacked according to the specification in this container. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=65535<br>>=0  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | IpduMRxIndicationPduRef  |                  |
|---------------------|--|------------------|
| Description         | Reference to the received PDU representation in the ECU Configuration Description exchange file. |                  |
| Multiplicity        | 11   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

## 5.3.1.10. IpduMRxDynamicPart

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| <u>IpduMSegment</u> | 1n           | This contains the location and the length of a segment. A segment must fit inside the I-PDU. The segment in the source I-PDU that is located at the IpduMSegmentPosition is copied to the same position in the destination I-PDU. |

| Parameters included           |              |  |
|-------------------------------|--------------|--|
| Parameter name                | Multiplicity |  |
| IpduMRxSelectorValue          | 11           |  |
| IpduMOutgoingDynamicPduRef 11 |              |  |

| Parameter Name |  |
|----------------|--|
|----------------|--|



| Description         | This is the selector value that this container refers to. |  |
|---------------------|---|--|
| Multiplicity        | 11  |  |
| Туре                | INTEGER   |  |
| Configuration class | VariantPostBuild: VariantPostBuild                        |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | IpduMOutgoingDynamicPduRef   |                  |
|---------------------|--|------------------|
| Description         | When the new I-PDU is sent out it is sent with this I-PDU ID. Reference to the sent PDU representation in the ECU Configuration Description exchange file. |                  |
| Multiplicity        | 11   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

## 5.3.1.11. IpduMSegment

| Parameters included  |              |  |
|----------------------|--------------|--|
| Parameter name       | Multiplicity |  |
| IpduMSegmentLength   | 11           |  |
| IpduMSegmentPosition | 11           |  |
| IpduMDestinationBit  | 01           |  |

| Parameter Name      | IpduMSegmentLength             |                  |
|---------------------|--------------------------------|------------------|
| Description         | Length of the segment in bits. |                  |
| Multiplicity        | 11                             |                  |
| Туре                | INTEGER                        |                  |
| Range               | <=2032                         |                  |
|                     | >=1                            |                  |
| Configuration class | VariantPostBuild:              | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                   |                  |

| Parameter Name | IpduMSegmentPosition                          |  |
|----------------|---|--|
| Description    | Segments bit position in the multiplexed PDU. |  |
| Multiplicity   | 11  |  |



| Туре                | INTEGER                            |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | IpduMDestinationBit   |                  |
|---------------------|---|------------------|
| Description         | Warning: this parameter is only available in this release for backward compatibility with IpduM ASR 3.x. For new configurations this parameter shall not be used any more. In ASR 4.x this parameter has been removed as IpduMSegmentPosition describes the position in both multiplexed and de-multiplexed Pdu.  Note: when importing a communication matrix, please select the option which |                  |
|                     | imports an ASR 4.x conform configuration.  Note: Changing the configuration to an ASR 4.x conform configuration requires also an update of the configuration of the Com module.  Bit position in an I-PDU of the start of the destination bit field for the copy. The   |                  |
|                     | resulting destination field must fit inside the I-PDU.  |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

## 5.3.1.12. IpduMRxStaticPart

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| <u>IpduMSegment</u> | 1n           | This contains the location and the length of a segment. A segment must fit inside the I-PDU. The segment in the source I-PDU that is located at the IpduMSegmentPosition is copied to the same position in the destination I-PDU. |

| Parameters included              |              |
|----------------------------------|--------------|
| Parameter name                   | Multiplicity |
| <u>IpduMOutgoingStaticPduRef</u> | 11           |

| Parameter Name | IpduMOutgoingStaticPduRef  |  |
|----------------|--|--|
| Description    | When the new I-PDU is sent out it is sent with this I-PDU ID. Reference to the |  |
|                | sent PDU representation in the ECU Configuration Description exchange file.    |  |



| Multiplicity        | 11                                 |  |
|---------------------|------------------------------------|--|
| Туре                | REFERENCE                          |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

# 5.3.1.13. IpduMSegment

| Parameters included         |    |  |
|-----------------------------|----|--|
| Parameter name Multiplicity |    |  |
| IpduMSegmentLength          | 11 |  |
| IpduMSegmentPosition        | 11 |  |
| IpduMDestinationBit         | 01 |  |

| Parameter Name      | IpduMSegmentLength                 |  |
|---------------------|------------------------------------|--|
| Description         | Length of the segment in bits.     |  |
| Multiplicity        | 11                                 |  |
| Туре                | INTEGER                            |  |
| Range               | <=2032                             |  |
|                     | >=1                                |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | IpduMSegmentPosition                          |  |
|---------------------|---|--|
| Description         | Segments bit position in the multiplexed PDU. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER                                       |  |
| Configuration class | VariantPostBuild: VariantPostBuild            |  |
| Origin              | AUTOSAR_ECUC                                  |  |

| Parameter Name | IpduMDestinationBit  |
|----------------|--|
| Description    | Warning: this parameter is only available in this release for backward compatibil- |
|                | ity with IpduM ASR 3.x. For new configurations this parameter shall not be used    |
|                | any more. In ASR 4.x this parameter has been removed as IpduMSegmentPosi-          |
|                | tion describes the position in both multiplexed and de-multiplexed Pdu.            |



|                     | Note: when importing a communication matrix, please select the option which imports an ASR 4.x conform configuration.                       |  |
|---------------------|---|--|
|                     | Note: Changing the configuration to an ASR 4.x conform configuration requires also an update of the configuration of the Com module.        |  |
|                     | Bit position in an I-PDU of the start of the destination bit field for the copy. The resulting destination field must fit inside the I-PDU. |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER   |  |
| Configuration class | PostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH  |  |

# 5.3.1.14. IpduMSelectorFieldPosition

| Parameters included        |              |  |
|----------------------------|--------------|--|
| Parameter name             | Multiplicity |  |
| IpduMSelectorFieldLength   | 11           |  |
| IpduMSelectorFieldPosition | 11           |  |

| Parameter Name      | IpduMSelectorFieldLength              |                                       |  |  |
|---------------------|---------------------------------------|---------------------------------------|--|--|
| Description         | Length of the selector field in bits. | Length of the selector field in bits. |  |  |
| Multiplicity        | 11                                    | 11                                    |  |  |
| Туре                | INTEGER                               |                                       |  |  |
| Range               | <=8                                   |                                       |  |  |
|                     | >=1                                   |                                       |  |  |
| Configuration class | VariantPostBuild:                     | VariantPostBuild                      |  |  |
| Origin              | AUTOSAR_ECUC                          |                                       |  |  |

| Parameter Name      | IpduMSelectorFieldPosition                          |  |
|---------------------|---|--|
| Description         | Selector field bit position in the multiplexed PDU. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER   |  |
| Configuration class | VariantPostBuild: VariantPostBuild                  |  |
| Origin              | AUTOSAR_ECUC  |  |



# 5.3.1.15. IpduMTxPathway

| Containers included   |              |  |
|-----------------------|--------------|--|
| Container name        | Multiplicity | Description  |
| <u>IpduMTxRequest</u> | 11           | This is used to specify the configuration for Transmit requests. There will one instance of this container for each I-PDU that can be requested for transmission (the outgoing I-PDUs) by the IpduM. |

## 5.3.1.16. IpduMTxRequest

| Containers included               |              |  |
|-----------------------------------|--------------|--|
| Container name                    | Multiplicity | Description  |
| <u>IpduMSelectorFieldPosition</u> | 11           | This contains the location and the length of the selector field.   |
| <u>IpduMTxDynamicPart</u>         | 1256         | Configuration parameters for an instance of a TxRequest call into the IpduM. When a Tx Request with the IpduMTx-DynamicHandleId is received by the IpduM, all segments as defined by this container are copied from the incoming I-PDU into the outgoing I-PDU buffer and then the send mode honoured. This container is used by the dynamic part of a TxRequest configuration. Therefore, for each outgoing I-PDU there will be one instance of this container for the dynamic part.            |
| <u>IpduMTxStaticPart</u>          | 01           | Configuration parameters for an instance of a Tx_Request call into the IpduM. When a Tx Request with the IpduMTxStaticHandleId is received by the IpduM, all segments as defined by this container are copied from the incoming I-PDU into the outgoing I-PDU buffer and then the send mode honoured. This container is used for the static part of a TxRequest configuration. Therefore, for each outgoing I-PDU there will be one instance of this container for the static part if it exists. |

| Parameters included             |              |  |
|---------------------------------|--------------|--|
| Parameter name                  | Multiplicity |  |
| <u>IpduMByteOrder</u>           | 11           |  |
| IpduMIPduUnusedAreasDefault     | 01           |  |
| <u>IpduMTxConfirmationPduId</u> | 11           |  |



| Parameters included               |    |  |
|-----------------------------------|----|--|
| <u>IpduMTxConfirmationTimeout</u> | 01 |  |
| IpduMTxTriggerMode                | 11 |  |
| IpduMInitialDynamicPart           | 11 |  |
| IpduMOutgoingPduRef               | 11 |  |
| <u>IpduMQueueSize</u>             | 11 |  |

| Parameter Name      | IpduMByteOrder  |                  |
|---------------------|---|------------------|
| Description         | This parameter defines the ByteOrder for all IpduMSegments (static and dynamic part) and for the selectorField within the MultiplexedPdu. The absolute position of a segment in the MultiplexedIPdu is determined by the definition of the ByteOrder parameter: If BIG_ENDIAN is specified, the SegmentPosition indicates the bit position of the most significant bit in an IPDU. If LITTLE_ENDIAN is specified, the SegmentPosition indicates the bit position of the least significant bit in an IPDU. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Default value       | LITTLE_ENDIAN   |                  |
| Range               | BIG_ENDIAN  |                  |
|                     | LITTLE_ENDIAN   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | IpduMIPduUnusedAreasDefault   |                  |
|---------------------|---|------------------|
| Description         | IpduM module fills not used areas of an I-PDU with this bit-pattern. If this attribute is omitted the IpduM module does not fill the I-PDU. |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=255   |                  |
|                     | >=0   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | IpduMTxConfirmationPduId |
|----------------|--------------------------|
|----------------|--------------------------|



| Description         | The handle Id to be used by the PduR to confirm the transmission of this PDU. The existence of this parameter is essential for the PduR generation tool to actually find a symbolicNameValue for the OutgoingPdu. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=65535   |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | IpduMTxConfirmationTimeout   |                  |
|---------------------|--|------------------|
| Description         | This timeout (in seconds) defines the timeout period for monitoring the reception of the TxConfirmation. It is not used when an I-PDU is requested using the trigger transmit API. |                  |
| Multiplicity        | 01   |                  |
| Туре                | FLOAT  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | lpduMTxTriggerMode   |                  |
|---------------------|--|------------------|
| Description         | Selects whether to send the multiplexed I-PDU immediately or at some later date. |                  |
| Multiplicity        | 11   |                  |
| Туре                | ENUMERATION  |                  |
| Range               | DYNAMIC_PART_TRIGGER   |                  |
|                     | NONE   |                  |
|                     | STATIC_OR_DYNAMIC_PART_TRIGGER   |                  |
|                     | STATIC_PART_TRIGGER  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name | IpduMInitialDynamicPart   |  |
|----------------|---|--|
| Description    | Reference to the dynamic part that shall be used to initialize this multiplexed TX-I-PDU. |  |
| Multiplicity   | 11  |  |



| Туре                | REFERENCE                          |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | IpduMOutgoingPduRef   |  |
|---------------------|---|--|
| Description         | Reference to the PDU defining the outgoing I-PDU. When the outgoing I-PDU is sent this is the I-PDU ID to give it. It is the IpduM I-PDU ID of the assembled I-PDU. |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | IpduMQueueSize   |  |
|---------------------|--|--|
| Description         | This value is specifies the queue size. A value of '0' means not using a queue at all. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Default value       | 0  |  |
| Configuration class | PostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH   |  |

# 5.3.1.17. IpduMSelectorFieldPosition

| Parameters included         |    |  |
|-----------------------------|----|--|
| Parameter name Multiplicity |    |  |
| IpduMSelectorFieldLength    | 11 |  |
| IpduMSelectorFieldPosition  | 11 |  |

| Parameter Name | IpduMSelectorFieldLength              |  |
|----------------|---------------------------------------|--|
| Description    | Length of the selector field in bits. |  |
| Multiplicity   | 11                                    |  |
| Туре           | INTEGER                               |  |
| Range          | <=8                                   |  |



|                     | >=1                                |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name      | IpduMSelectorFieldPosition                          |  |
|---------------------|---|--|
| Description         | Selector field bit position in the multiplexed PDU. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER   |  |
| Configuration class | VariantPostBuild: VariantPostBuild                  |  |
| Origin              | AUTOSAR_ECUC  |  |

# 5.3.1.18. IpduMTxDynamicPart

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| <u>IpduMSegment</u> | 1n           | This contains the location and the length of a segment. A segment must fit inside the I-PDU. The segment in the source I-PDU that is located at the IpduMSegmentPosition is copied to the same position in the destination I-PDU. |

| Parameters included        |              |  |
|----------------------------|--------------|--|
| Parameter name             | Multiplicity |  |
| IpduMJitUpdate             | 01           |  |
| IpduMTxDynamicConfirmation | 11           |  |
| IpduMTxDynamicHandleId     | 11           |  |
| IpduMTxDynamicPduRef       | 11           |  |
| IpduMTxDynamicPriority     | 11           |  |
| IpduMTxSelectorValue       | 11           |  |

| Parameter Name | IpduMJitUpdate  |
|----------------|---|
| Description    | If configured to true fetch the data of this part Just-In-Time via the triggerTransmit API of the PduR. |
| Multiplicity   | 01  |
| Туре           | BOOLEAN   |



| Default value       | false                       |  |
|---------------------|-----------------------------|--|
| Configuration class | PostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                |  |

| Parameter Name      | IpduMTxDynamicConfirmation  |                  |
|---------------------|---|------------------|
| Description         | A transmit request can be confirmed by the lower layer. If this parameter is set to true a confirmation of the I-PDU in COM representing the dynamic part is generated. |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | IpduMTxDynamicHandleId   |  |
|---------------------|--|--|
| Description         | This is an incoming handle id. When the handle of an incoming Tx Request matches this, the bits fields (see IPduMSegment) are copied and the IpduMTx-TriggerMode is honored. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Range               | <=65535  |  |
|                     | >=0  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | IpduMTxDynamicPduRef  |  |
|---------------------|---|--|
| Description         | Reference to the PDU representation in the ECU Configuration Description exchange file to be transmitted. |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name | IpduMTxDynamicPriority                                   |  |
|----------------|--|--|
| Description    | The priority of each Handleld. 0 is the highest priority |  |



| Multiplicity        | 11         |                  |
|---------------------|------------|------------------|
| Туре                | INTEGER    |                  |
| Default value       | 0          |                  |
| Range               | <=127      |                  |
|                     | >=0        |                  |
| Configuration class | PostBuild: | VariantPostBuild |

| Parameter Name      | IpduMTxSelectorValue   |                  |
|---------------------|--|------------------|
| Description         | If IpduMTxAutomaticSelector is enabled IpduMTxSelectorValue defines the selector value which is set for this transmit PDU. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |

## 5.3.1.19. IpduMSegment

| Parameters included       |              |  |
|---------------------------|--------------|--|
| Parameter name            | Multiplicity |  |
| <u>IpduMSegmentLength</u> | 11           |  |
| IpduMSegmentPosition      | 11           |  |
| IpduMDestinationBit       | 01           |  |

| Parameter Name      | IpduMSegmentLength                 |    |  |
|---------------------|------------------------------------|----|--|
| Description         | Length of the segment in bits.     |    |  |
| Multiplicity        | 11                                 | 11 |  |
| Туре                | INTEGER                            |    |  |
| Range               | <=2032                             |    |  |
|                     | >=1                                |    |  |
| Configuration class | VariantPostBuild: VariantPostBuild |    |  |
| Origin              | AUTOSAR_ECUC                       |    |  |

| Parameter Name | IpduMSegmentPosition                          |
|----------------|---|
| Description    | Segments bit position in the multiplexed PDU. |



| Multiplicity        | 11                |                  |  |
|---------------------|-------------------|------------------|--|
| Туре                | INTEGER           |                  |  |
| Configuration class | VariantPostBuild: | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC      |                  |  |

| Parameter Name      | IpduMDestinationBit  |  |
|---------------------|--|--|
| Description         | Warning: this parameter is only available in this release for backward compatibility with IpduM ASR 3.x. For new configurations this parameter shall not be used any more. In ASR 4.x this parameter has been removed as IpduMSegmentPosition describes the position in both multiplexed and de-multiplexed Pdu.  Note: when importing a communication matrix, please select the option which imports an ASR 4.x conform configuration.  Note: Changing the configuration to an ASR 4.x conform configuration requires also an update of the configuration of the Com module.  Bit position in an I-PDU of the start of the destination bit field for the copy. The resulting destination field must fit inside the I-PDU. |  |
| Multiplicity        | 01   |  |
| Туре                | INTEGER  |  |
| Configuration class | PostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH   |  |

### 5.3.1.20. IpduMTxStaticPart

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| <u>IpduMSegment</u> | 1n           | This contains the location and the length of a segment.  A segment must fit inside the I-PDU. The segment in the source I-PDU that is located at the IpduMSegmentPosition is copied to the same position in the destination I-PDU. |

| Parameters included       |              |  |
|---------------------------|--------------|--|
| Parameter name            | Multiplicity |  |
| IpduMJitUpdate            | 01           |  |
| IpduMTxStaticConfirmation | 11           |  |



| Parameters included   |    |
|-----------------------|----|
| IpduMTxStaticHandleId | 11 |
| IpduMTxStaticPduRef   | 11 |

| Parameter Name      | IpduMJitUpdate  |                  |
|---------------------|---|------------------|
| Description         | If configured to true fetch the data of this part Just-In-Time via the triggerTransmit API of the PduR. |                  |
| Multiplicity        | 01  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | IpduMTxStaticConfirmation  |                  |
|---------------------|--|------------------|
| Description         | A transmit request can be confirmed by the lower layer. If this parameter is set to true a confirmation of the I-PDU in COM representing the static part is generated. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | IpduMTxStaticHandleId  |                  |
|---------------------|--|------------------|
| Description         | This is an incoming handle id. When the handle of an incoming Tx Request matches this, the bits fields (see IPduMSegment) are copied and the IpduMTx-TriggerMode is honored. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=65535  |                  |
|                     | >=0  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name    | IpduMTxStaticPduRef    |
|-------------------|------------------------|
| i arameter ivanie | ipadim Actation duries |



| Description         | Reference to the PDU representation in the ECU Configuration Description exchange file to be transmitted. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | REFERENCE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

## 5.3.1.21. IpduMSegment

| Parameters included  |              |
|----------------------|--------------|
| Parameter name       | Multiplicity |
| IpduMSegmentLength   | 11           |
| IpduMSegmentPosition | 11           |
| IpduMDestinationBit  | 01           |

| Parameter Name      | IpduMSegmentLength             |                  |
|---------------------|--------------------------------|------------------|
| Description         | Length of the segment in bits. |                  |
| Multiplicity        | 11                             |                  |
| Туре                | INTEGER                        |                  |
| Range               | <=2032                         |                  |
|                     | >=1                            |                  |
| Configuration class | VariantPostBuild:              | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                   |                  |

| Parameter Name      | IpduMSegmentPosition                          |                  |
|---------------------|---|------------------|
| Description         | Segments bit position in the multiplexed PDU. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER                                       |                  |
| Configuration class | VariantPostBuild:                             | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                                  |                  |

| Parameter Name | IpduMDestinationBit  |  |
|----------------|--|--|
| Description    | Warning: this parameter is only available in this release for backward compatibil- |  |
|                | ity with IpduM ASR 3.x. For new configurations this parameter shall not be used    |  |



|                     | any more. In ASR 4.x this parameter has been removed as IpduMSegmentPosition describes the position in both multiplexed and de-multiplexed Pdu. |   |
|---------------------|---|---|
|                     | Note: when importing a communication matrix, please select the option which imports an ASR 4.x conform configuration.                           |   |
|                     | Note: Changing the configuration to an A also an update of the configuration of the   | ·                                       |
|                     | Bit position in an I-PDU of the start of the resulting destination field must fit inside  | • |
| Multiplicity        | 01  |   |
| Туре                | INTEGER   |   |
| Configuration class | PostBuild:  | VariantPostBuild                        |
| Origin              | Elektrobit Automotive GmbH  |   |

# 5.3.1.22. IpduMGeneral

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| IpduMRxProcessing   | 0n           | Configuration of a dedicated RX MainFunction. The name of the generated function uses the pattern Ip-duM_MainFunctionRx"Short-Name". |
| IpduMTxProcessing   | 0n           | Configuration of a dedicated TX MainFunction. The name of the generated function uses the pattern Ip-duM_MainFunctionTx"Short-Name". |

| Parameters included        |              |  |
|----------------------------|--------------|--|
| Parameter name             | Multiplicity |  |
| IpduMRxTimeBase            | 11           |  |
| IpduMTxTimeBase            | 11           |  |
| IpduMDevErrorDetect        | 11           |  |
| IpduMZeroCopy              | 11           |  |
| IpduMByteCopy              | 11           |  |
| IpduMDynamicPartQueue      | 11           |  |
| IpduMTxRequestMaxSduLength | 11           |  |
| IpduMTxAutomaticSelector   | 11           |  |



| Parameters included                        |    |  |
|--|----|--|
| <u>IpduMDataMemSize</u>                    | 01 |  |
| <u>IpduMInitializationBySignalValue</u>    | 11 |  |
| <u>IpduMEnableJitUpdate</u>                | 11 |  |
| <u>IpduMDedicatedIpduProcessingSupport</u> | 11 |  |
| <u>IpduMContainerPduHandlingEnable</u>     | 11 |  |
| <u>IpduMStaticContainerPduHandling</u>     | 11 |  |
| <u>IpduMContainerQueuingRx</u>             | 11 |  |
| <u>IpduMContainedCollectQueuedTx</u>       | 11 |  |
| <u>IpduMMaxContainerRxLength</u>           | 11 |  |
| <u>IpduMDequeueInTxConf</u>                | 11 |  |
| <u>IpduMRelocatablePbcfgEnable</u>         | 11 |  |
| IpduMRxContainerAcceptAllNoRefOnly         | 01 |  |
| <u>IpduMContainedTxPduPriorityHandling</u> | 11 |  |
| <u>IpduMHeaderByteOrder</u>                | 01 |  |
| <u>IpduMStaticPartExists</u>               | 11 |  |
| <u>IpduMVersionInfoApi</u>                 | 11 |  |

| Parameter Name      | IpduMRxTimeBase   |                  |
|---------------------|---|------------------|
| Description         | The period between successive calls to IpduM_MainFunctionRx in seconds. This parameter may be used by the IpduM generator to transform the values of the reception related timing configuration parameters of the IpduM module to internal implementation specific counter or tick values. The IpduM module's internal timing handling is implementation specific. The IpduM module (generator) may rely on the fact that IpduM_MainFunctionRx is scheduled according to the value configured here. |                  |
| Multiplicity        | 11  |                  |
| Туре                | FLOAT   |                  |
| Default value       | 0.005   |                  |
| Range               | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name IpduMTxTimeBase |
|--------------------------------|
|--------------------------------|



| Description         | The period between successive calls to IpduM_MainFunctionTx in seconds. This parameter may be used by the IpduM generator to transform the values of the reception related timing configuration parameters of the IpduM module to internal implementation specific counter or tick values. The IpduM module's internal timing handling is implementation specific. The IpduM module (generator) may rely on the fact that IpduM_MainFunctionTx is scheduled according to the value configured here. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | FLOAT   |                  |
| Default value       | 0.005   |                  |
| Range               | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name      | IpduMDevErrorDetect  |                  |  |
|---------------------|--|------------------|--|
| Description         | Active/Deactivate the detection of development errors, for production code this parameter has to be False. |                  |  |
|                     | True: error detection activated  |                  |  |
|                     | False: error detection deactivated   |                  |  |
|                     | Optimization Effect:   |                  |  |
|                     | ▶ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.           |                  |  |
|                     | Execution time reduction (code): Disabling this parameter reduces the execution time of the module code.   |                  |  |
| Multiplicity        | 11   |                  |  |
| Туре                | BOOLEAN  |                  |  |
| Default value       | true   |                  |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC   |                  |  |

| Parameter Name | IpduMZeroCopy   |
|----------------|---|
| Description    | Do not allocate memory for data in the IpduM. Only pointers for static and dynamic parts will be passed. Zero copy is only in some circumstances possible. Please refer the users guide.  Destination bits will be taken as zero, if this parameter is set. |



|                     | Optimization Effect:   |                  |
|---------------------|--|------------------|
|                     | <b>Execution time reduction (code):</b> Enabling this parameter reduces the execution time of the module code. |                  |
|                     | ▶ <b>ROM reduction (code):</b> Enabling this parameter reduces the ROM consumption of the module code.         |                  |
|                     | ➤ ROM reduction (config): Enabling this parameter reduces the ROM consumption of the module configuration.     |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name      | IpduMByteCopy   |                  |
|---------------------|---|------------------|
| Description         | Use byte-wise copy routines. Only possible if static and dynamic part is already byte-aligned.          |                  |
|                     | Optimization Effect:  |                  |
|                     | Execution time reduction (code): Enabling this parameter reduces the execution time of the module code. |                  |
|                     | ROM reduction (code): Enabling this parameter reduces the ROM con-                                      |                  |
|                     | sumption of the module code.  |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | IpduMDynamicPartQueue  |  |
|----------------|--|--|
| Description    | This specifies if queuing is enabled for dynamic PDUs.  Optimization Effect:                             |  |
|                |  |  |
|                | Execution time reduction (code): Disabling this parameter reduces the execution time of the module code. |  |
|                | <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code.    |  |



|                     | <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration. |                  |
|---------------------|--|------------------|
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name      | IpduMTxRequestMaxSduLength   |                  |
|---------------------|--|------------------|
| Description         | The value specified is used for allocating buffers for TxRequests. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Default value       | 32   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name      | IpduMTxAutomaticSelector   |  |
|---------------------|--|--|
| Description         | If enabled the selector values for the transmit PDUs are set by the IpduM. If disabled the selector value is not set by the IpduM. |  |
|                     | Optimization Effect:   |  |
|                     | Execution time reduction (code): Disabling this parameter reduces the execution time of the module code.                           |  |
|                     | ➤ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.                                   |  |
|                     | ➤ ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.                        |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name | IpduMDataMemSize  |  |
|----------------|---|--|
| Description    | Size of internal IpduM data in units of bytes (static memory allocation) - Memory |  |
|                | required by post-build config must be smaller than this constant                  |  |



|                     | Optimization Effect:  |   |
|---------------------|---|---|
|                     | RAM reduction (config): Decreasing sumption of the module configuration | ng this parameter reduces the RAM con-<br>on. |
| Multiplicity        | 01  |   |
| Туре                | INTEGER   |   |
| Configuration class | Link: VariantPostBuild  |   |
| Origin              | Elektrobit Automotive GmbH  |   |

| Parameter Name      | IpduMInitializationBySignalValue   |  |
|---------------------|--|--|
| Description         | If IpduMInitializationBySignalValue is enabled, the static and dynamic parts are initialized in retrieving signal values from the upper layer module by IpduM_Init. If IpduMInitializationBySignalValue is disabled the static and dynamic parts are only initialized by the unused area pattern configured. |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | lpduMEnableJitUpdate   |                  |
|---------------------|--|------------------|
| Description         | If IpduMEnableJitUpdate is enabled, the initial dynamic part is used for JIT update. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | true   |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | IpduMDedicatedIpduProcessingSupport  |  |
|----------------|--|--|
| Description    | Enable the mapping of Containers/TxPathways to specific MainFunctions.                                   |  |
|                | Optimization Effect:   |  |
|                | Execution time reduction (code): Disabling this parameter reduces the execution time of the module code. |  |
|                | ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.           |  |



| Multiplicity        | 11                         |                  |
|---------------------|----------------------------|------------------|
| Туре                | BOOLEAN                    |                  |
| Default value       | false                      |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | IpduMContainerPduHandlingEnable  |  |  |
|---------------------|--|--|--|
| Description         | Enables or disables the Multiple-PDU-to-Container handling.  |  |  |
|                     | ► True: Multiple-PDU-to-Container handling is enabled.   |  |  |
|                     | False: Multiple-PDU-to-Container handling is disabled.   |  |  |
|                     | Optimization Effect:   |  |  |
|                     | ▶ <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code.            |  |  |
|                     | <b>Execution time reduction (code):</b> Disabling this parameter reduces the execution time of the module code.    |  |  |
|                     | ▶ <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration. |  |  |
|                     | ▶ <b>RAM reduction (code):</b> Disabling this parameter reduces the RAM consumption of the module code.            |  |  |
| Multiplicity        | 11   |  |  |
| Туре                | BOOLEAN  |  |  |
| Default value       | node:exists(//IpduMConfig/*[1]/IpduMContainerTxPdu/*) or node:exists(//IpduMConfig/*[1]/IpduMContainerRxPdu/*)     |  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |  |
| Origin              | Elektrobit Automotive GmbH   |  |  |

| Parameter Name | IpduMStaticContainerPduHandling   |  |
|----------------|---|--|
| Description    | Enables or disables the use of static multiple-PDU-to-Container handling.                             |  |
|                | ➤ True: Static multiple-PDU-to-Container handling is enabled.   |  |
|                | False: Static multiple-PDU-to-Container handling is disabled.   |  |
|                | Optimization Effect:  |  |
|                | <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code. |  |



|                     |  | on time reduction (code):<br>on time of the module code. | Disabling this parameter reduces the |
|---------------------|--|--|--------------------------------------|
|                     | <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration. |  |                                      |
|                     |  | duction (code): Disabling to the module code.            | this parameter reduces the RAM con-  |
| Multiplicity        | 11   |  |                                      |
| Туре                | BOOLEAN  |  |                                      |
| Default value       | false  |  |                                      |
| Configuration class | PreCompile: VariantPostBuild   |  |                                      |
| Origin              | Elektrobit Automotive GmbH   |  |                                      |

| Parameter Name      | IpduMContainerQueuingRx  |                          |
|---------------------|--|--------------------------|
| Description         | Enables or disables the queuing of Multiple-PDU-to-Container PDUs during reception.                                |                          |
|                     | ► True: Multiple-PDU-to-Container qu   | ueuing is enabled (RX).  |
|                     | False: Multiple-PDU-to-Container   | queuing is enabled (RX). |
|                     | Optimization Effect:   |                          |
|                     | ▶ <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code.            |                          |
|                     | ► Execution time reduction (code): Disabling this parameter reduces the execution time of the module code.         |                          |
|                     | ▶ <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration. |                          |
|                     | ➤ RAM reduction (code): Disabling this parameter reduces the RAM consumption of the module code.                   |                          |
| Multiplicity        | 11   |                          |
| Туре                | BOOLEAN  |                          |
| Default value       | false  |                          |
| Configuration class | PreCompile: VariantPostBuild   |                          |
| Origin              | Elektrobit Automotive GmbH   |                          |

| Parameter Name | IpduMContainedCollectQueuedTx  |
|----------------|--|
| Description    | Enables or disables the handling of Contained PDUs with IpduMContainedTxP- |
|                | duCollectionSemantics set to IPDUM_COLLECT_QUEUED.                         |



| Origin              | Elektrobit Automotive GmbH   |    |  |
|---------------------|--|----|--|
| Configuration class | PreCompile: VariantPostBuild   |    |  |
| Default value       | false  |    |  |
| Туре                | BOOLEAN  |    |  |
| Multiplicity        | 11   | 11 |  |
|                     | ▶ RAM reduction (code): Disabling this parameter reduces the RAM consumption of the module code.                 |    |  |
|                     | <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration. |    |  |
|                     | Execution time reduction (code): Disabling this parameter reduces the execution time of the module code.         |    |  |
|                     | ▶ <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code.          |    |  |
|                     | Optimization Effect:   |    |  |
|                     | False: Only IPDUM_COLLECT_LAST_IS_BEST is supported.   |    |  |
|                     | ➤ True: IPDUM_COLLECT_QUEUED is supported.   |    |  |

| Parameter Name      | IpduMMaxContainerRxLength   |  |
|---------------------|---|--|
| Description         | This value specifies the length of the buffer allocated on the stack during the reception of Container PDUs. The value must be equal to the length of the largest referenced Pdu. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER   |  |
| Default value       | 64  |  |
| Range               | >=0   |  |
| Configuration class | PreCompile: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name | IpduMDequeueInTxConf  |
|----------------|---|
| Description    | Enables or disables dequeuing (transmission) in addition in the context of an IpduM_TxConfirmation() call.  |
|                | <b>NOTE:</b> The parameter applies only to Containers with IpduMContainerTxTriggerMode set to IPDUM_DIRECT. IPDUM_TRIGGERTRANSMIT ones are <b>al-ways</b> dequeued. |



|                     | Based on the value, transmission would occur:  |  |
|---------------------|--|--|
|                     | ► True: additionally in IpduM_TxConfirmation() |  |
|                     | False: only in IpduM_MainFunctionTx()          |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPostBuild: VariantPostBuild             |  |
| Origin              | Elektrobit Automotive GmbH                     |  |

| Parameter Name      | IpduMRelocatablePbcfgEnable                                      |  |
|---------------------|--|--|
| Description         | Enables/disable support for relocatable postbuild configuration. |  |
|                     | True: Postbuild configuration relocatable in memory.             |  |
|                     | False: Postbuild configuration not relocatable in memory.        |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild                               |  |
| Origin              | Elektrobit Automotive GmbH                                       |  |

| Parameter Name | IpduMRxContainerAcceptAllNoRefOnly   |  |
|----------------|--|--|
| Description    | Switches the behavior of IPDUM_ACCEPT_ALL.  True: IpduMContainedRxPdus which do not have IpduMContainedRxInCon-  |  |
|                | tainerPduRef configured are accepted, according to <b>ASR19-11 SWS_Ip-duM_00206</b> (IpduM.ASR19-11.SWS_IpduM_00206).  |  |
|                | False: All IpduMContainedRxPdus are accepted regardless of IpduMContainedRxInContainerPduRef, according to <b>ASR4.2.1 SWS_IpduM_00206</b> (IpduM.ASR42.SWS_IpduM_00206) |  |
|                | Optimization Effect:   |  |
|                | Execution time reduction (code): Enabling this parameter reduces the execution time of the module code.  |  |
|                | ▶ ROM reduction (code): Enabling this parameter reduces the ROM consumption of the module code.  |  |
| Multiplicity   | 01   |  |



| Туре                | BOOLEAN                    |                  |
|---------------------|----------------------------|------------------|
| Configuration class | PreCompile:                | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | IpduMContainedTxPduPriorityHandling   |                  |
|---------------------|---|------------------|
| Description         | This parameter enables/disables handling of priority for IpduMContainedTxPdus with IpduMContainedTxPduCollectionSemantics IPDUM_LAST_IS_BEST. |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | IpduMHeaderByteOrder  |                  |
|---------------------|---|------------------|
| Description         | This parameter defines the ByteOrder of the headers inside a Container I-PDU. |                  |
| Multiplicity        | 01  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | IPDUM_BIG_ENDIAN  |                  |
|                     | IPDUM_LITTLE_ENDIAN   |                  |
| Configuration class | PreCompile:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | IpduMStaticPartExists   |  |
|----------------|---|--|
| Description    | This is to allow optimizations in the case the IpduM will never be used with a static part.   |  |
|                | Note that this is a pre-compile option. If this is set to False then it will not be possible to add static parts after compilation. |  |
|                | ▶ True: A static part may exist.  |  |
|                | False: A static part will never exist.  |  |
|                | Optimization Effect:  |  |
|                | Execution time reduction (code): Disabling this parameter reduces the execution time of the module code.                            |  |
|                | ▶ <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code.                             |  |



|                     | <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration. |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | IpduMVersionInfoApi  |                  |
|---------------------|--|------------------|
| Description         | Active/Deactivate the version information API.   |                  |
|                     | true: version information activated  |                  |
|                     | ▶ false: version information deactive  | ated             |
|                     | Optimization Effect:   |                  |
|                     | ▶ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

### 5.3.1.23. IpduMRxProcessing

| Parameters included         |    |
|-----------------------------|----|
| Parameter name Multiplicity |    |
| IpduMTimeBase               | 11 |
| IpduMPartitionRef           | 11 |
| <u>IpduMRxPduRef</u>        | 1n |

| Parameter Name | IpduMTimeBase   |  |
|----------------|---|--|
| Description    | TimeBase for this specific MainFunction in seconds (similar to IpduMRxTime-Base). |  |
| Multiplicity   | 11  |  |



| Туре                | FLOAT                              |  |
|---------------------|------------------------------------|--|
| Range               | >=0                                |  |
|                     | <=3600                             |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH         |  |

| Parameter Name      | IpduMPartitionRef   |                  |
|---------------------|---|------------------|
| Description         | Reference to EcucPartition to allow for grouping of MainFunction according to EcucPartition elements. |                  |
| Multiplicity        | 11  |                  |
| Туре                | REFERENCE   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name      | IpduMRxPduRef  |                  |
|---------------------|--|------------------|
| Description         | Reference to IpduMContainerRxPdu which is assigned to this MainFunction. |                  |
| Multiplicity        | 1n   |                  |
| Туре                | REFERENCE  |                  |
| Configuration class | PostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

## 5.3.1.24. IpduMTxProcessing

| Parameters included         |    |
|-----------------------------|----|
| Parameter name Multiplicity |    |
| IpduMTimeBase               | 11 |
| IpduMPartitionRef           | 11 |
| IpduMTxPduRef               | 1n |

| Parameter Name | IpduMTimeBase   |  |
|----------------|---|--|
| Description    | TimeBase for this specific MainFunction in seconds (similar to IpduMTxTime-Base). |  |
| Multiplicity   | 11  |  |



| Туре                | FLOAT                      |                  |
|---------------------|----------------------------|------------------|
| Range               | >=0                        |                  |
|                     | <=3600                     |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | IpduMPartitionRef   |  |
|---------------------|---|--|
| Description         | Reference to EcucPartition to allow for grouping of MainFunction according to EcucPartition elements. |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name      | IpduMTxPduRef   |                  |
|---------------------|---|------------------|
| Description         | Reference to IpduMContainerTxPdu/IpduMTxPathway which is assigned to this MainFunction. |                  |
| Multiplicity        | 1n  |                  |
| Туре                | CHOICE-REFERENCE  |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

# 5.3.1.25. IpduMPublishedInformation

| Parameters included               |              |
|-----------------------------------|--------------|
| Parameter name                    | Multiplicity |
| <u>IpduMRxDirectComInvocation</u> | 11           |

| Parameter Name | IpduMRxDirectComInvocation   |
|----------------|--|
| Description    | If set to TRUE the COM invocation optimization as defined in. IPDUM140 is implemented. |
| Multiplicity   | 11   |
| Туре           | BOOLEAN  |



| Default value       | false                              |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

### 5.3.1.26. IpduMRequestMessageConfiguration

| Containers included             |              |  |
|---------------------------------|--------------|--|
| Container name                  | Multiplicity | Description                                      |
| IpduMRequestMes-<br>sageMapInfo | 1n           | This is used to specify the mapping information. |

| Parameters included          |    |
|------------------------------|----|
| Parameter name Multiplicity  |    |
| IpduMRequestMessageIdLength  | 11 |
| IpduMRequestMessageIdBytePos | 11 |

| Parameter Name      | IpduMRequestMessageIdLength   |   |
|---------------------|---|---|
| Description         | Defines the length of the data field (number of bytes) in the received message from which the requested message ID is to be extracted starting from IP-DUM_REQUEST_MESSAGE_ID_BYTEPOS.  Optimization Effect:  Execution time reduction (code): Decreasing this parameter reduces the execution time of the module code. |   |
| Multiplicity        | ▶ ROM reduction (code): Decreasin sumption of the module code.  | g this parameter reduces the ROM cong this parameter reduces the RAM con- |
| Multiplicity        | 1   |   |
| Туре                | INTEGER   |   |
| Range               | <=4<br>>=1  |   |
| Configuration class | VariantPostBuild:   | VariantPostBuild  |
| Origin              | Elektrobit Automotive GmbH  |   |



| Parameter Name      | IpduMRequestMessageIdBytePos  |                  |
|---------------------|---|------------------|
| Description         | Defines the Byte position of the data field in the received message from which the requested message ID is to be extracted. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Range               | <=7   |                  |
|                     | >=0   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

## ${\bf 5.3.1.27.}\ IpduMR equest Message Map Info$

| Parameters included         |    |
|-----------------------------|----|
| Parameter name Multiplicity |    |
| IpduMRequestedMessageId     | 11 |
| IpduMRequestedMessagePduRef | 11 |

| Parameter Name      | IpduMRequestedMessageId  |                  |
|---------------------|--|------------------|
| Description         | Defines the requested message ID, which is sent from the requestor. This requested message ID is matched with the requested message ID extracted from the data field in the received message. This will be later mapped to IPDUM_RE-QUESTED_MESSAGE_PDU_REF. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=4294967295   |                  |
|                     | >=0  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | IpduMRequestedMessagePduRef   |  |
|----------------|---|--|
| Description    | Reference to the global EcuC Pdu (defined in EcuC's PduCollection) that corresponds to the Com I-Pdu that shall be triggered. |  |
| Multiplicity   | 11  |  |



| Туре                | REFERENCE                          |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH         |  |

#### 5.3.1.28. PublishedInformation

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| PbcfgMSupport       | 11           |

| Parameter Name      | PbcfgMSupport  |
|---------------------|--|
| Label               | PbcfgM support   |
| Description         | Specifies whether or not the IpduM can use the PbcfgM module for post-build support. |
| Multiplicity        | 11   |
| Туре                | BOOLEAN  |
| Default value       | true   |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

# 5.3.2. Application programming interface (API)

#### 5.3.2.1. Macro constants

#### 5.3.2.1.1. IPDUM\_E\_GLOBAL\_ECUID

| Purpose     | Development Error Code.      |
|-------------|------------------------------|
| Value       | 0x80                         |
| Description | Global EcuID unknown to ECU. |



### ${\bf 5.3.2.1.2.\ IPDUM\_SID\_PROCESS\_REQUEST\_PDU}$

| Purpose     | Service Message API service ID.                       |  |
|-------------|---|--|
| Value       | 0x20  |  |
| Description | Definition of service ID for IpduM_ProcessRequestPdu. |  |

#### **5.3.2.2. Functions**

#### 5.3.2.2.1. IpduM\_GetVersionInfo

| Purpose          | Return module version information.  |  |
|------------------|---|--|
| Synopsis         | <pre>void IpduM_GetVersionInfo ( Std_VersionInfoType *const version-</pre>  |  |
|                  | info );   |  |
| Service ID       | 0x01  |  |
| Sync/Async       | Synchronous   |  |
| Reentrancy       | Non-Reentrant   |  |
| Parameters (out) | versioninfo Version information   |  |
| Description      | This function returns the IpduM version information in the memory area versioninfo references.  Preconditions:  The parameter versioninfo may not be a NULL pointer |  |

#### 5.3.2.2.2 IpduM\_Init

| Purpose         | Initializes all module-related global variables.                |  |
|-----------------|---|--|
| Synopsis        | <pre>void IpduM_Init ( const IpduM_ConfigType * Config );</pre> |  |
| Service ID      | 0x00  |  |
| Sync/Async      | synchronous   |  |
| Reentrancy      | non reentrant   |  |
| Parameters (in) | Config  | Pointer to post build configuration of the lpduM |



| Description | Initializes all module-related global variables including default values, default selector |  |
|-------------|--|--|
|             | field and state of timeout monitors.   |  |
|             |  |  |

#### 5.3.2.2.3. IpduM\_MainFunctionRx

| Purpose     | IpduM RX main function.  |  |
|-------------|--|--|
| Synopsis    | <pre>void IpduM_MainFunctionRx ( void );</pre>   |  |
| Service ID  | 0x11   |  |
| Sync/Async  | Synchronous  |  |
| Reentrancy  | Non-Reentrant  |  |
| Description | Processes DEFERRED ContainerRxPdus  This function has to be called periodically by a task controlled by the BSW scheduler. |  |

### 5.3.2.2.4. IpduM\_MainFunctionTx

| Purpose     | IpduM TX main function.   |  |
|-------------|---|--|
| Synopsis    | <pre>void IpduM_MainFunctionTx ( void );</pre>  |  |
| Service ID  | 0x12  |  |
| Sync/Async  | Synchronous   |  |
| Reentrancy  | Non-Reentrant   |  |
| Description | Performs the processes of the activities that are not directly initiated by the calls from PDU-R. This includes at least the TxConfirmation time observation.  This function has to be called periodically by a task controlled by the BSW scheduler. |  |

#### 5.3.2.2.5. IpduM\_ProcessRequestPdu

| Purpose    | Process a request PDU.  |  |
|------------|---|--|
| Synopsis   | <pre>boolean IpduM_ProcessRequestPdu ( PduIdType PdumRxPduId , const PduInfoType * RxRequestPduInfoPtr );</pre> |  |
| Service ID | 0x20  |  |
| Sync/Async | Synchronous   |  |



| Reentrancy      | Non-Reentrant   |  |
|-----------------|---|--|
| Parameters (in) | PdumRxPduId   | Unused parameter                                   |
|                 | RxRequestPduInfoPtr   | The PDU data which contains the service message ID |
| Return Value    | Returns always FALSE to avoid further processing by Com   |  |
| Description     | Returns always FALSE to avoid further processing by Com  This function has to be called as a Com call out function for a Com Rx-PDU that is a requesting message. The function extracts the requested service message ID from the data of the PDU and triggers the sending of the appropriate Com PDU via ComTriggerIPDUSend().  Preconditions:  The parameter SduDataPtr may not be a NULL pointer |  |

#### 5.3.2.2.6. IpduM\_RxIndication

| Purpose         | Receive indication callback function.   |                                     |
|-----------------|---|-------------------------------------|
| Synopsis        | <pre>void IpduM_RxIndication ( PduIdType RxPduId , PduInfoType * PduInfoPtr );</pre>  |                                     |
| Service ID      | 0x42  |                                     |
| Sync/Async      | synchronous   |                                     |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld  |                                     |
| Parameters (in) | RxPduId   | ID of I-PDU that has been received. |
|                 | PduInfoPtr  Contains the length (SduLength) of the received I-PDU and a pointer to a buffer (SduDataPtr) containing the I-PDU.                                  |                                     |
| Description     | This is the receive indication callback function. It de-multiplex the incoming PDU and calls the corresponding upper layer receive indication callback function |                                     |

#### 5.3.2.2.7. IpduM\_Transmit

| Purpose    | Transmit an I-PDU.  |
|------------|---|
| Synopsis   | Std_ReturnType IpduM_Transmit ( PduIdType TxPduId , const PduInfoType * PduInfoPtr ); |
| Service ID | 0x03  |



| Sync/Async      | synchronous   |   |
|-----------------|---|---|
| Reentrancy      | Non Reentrant for the same PDU-ID. Reentrant for different PDU-ID                             |   |
| Parameters (in) | TxPduId   | ID of I-PDU to be transmitted.  |
|                 | PduInfoPtr  | A pointer to a structure with I-PDU related data that shall be transmitted: data length and pointer to I-SDU buffer |
| Return Value    | Standard Return Code  |   |
|                 | E_OK  | The request was accepted by IpduM.  |
|                 | E_NOT_OK  | The request was not accepted by IpduM, a detailed error condition was sent to DET.                                  |
| Description     | This function transmits the data given through PduInfoPtr through the I-PDU given by TxPduId. |   |

### 5.3.2.2.8. IpduM\_TriggerTransmit

| Purpose         | Copy data to PDU-router memory.   |   |  |
|-----------------|---|---|--|
| Synopsis        | <pre>Std_ReturnType IpduM_TriggerTransmit ( PduIdType TxPduId , PduInfoType * PduInfoPtr );</pre>                 |   |  |
| Service ID      | 0x41  | 0x41  |  |
| Sync/Async      | synchronous   | synchronous   |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld  |   |  |
| Parameters (in) | TxPduId   | ID of IpduM I-PDU that is requested to be transmitted by IpduM  |  |
|                 | PduInfoPtr  | Contains a pointer to a buffer (SduDat-<br>aPtr) to where the SDU shall be copied<br>to. On return, the service will indicate the<br>length of the copied SDU data in Sdu-<br>Length. |  |
| Return Value    | E_OK  | SDU has been copied and SduLength indicates the number of copied bytes.   |  |
| E_NOT_OK        | No SDU has been copied. PduInfoPtr must not be used since it may contain a NULL pointer or point to invalid data. |   |  |
| Description     | The lower layer communication module requests the buffer of the SDU for transmission from the upper layer module. |   |  |



#### 5.3.2.2.9. IpduM\_TxConfirmation

| Purpose         | Transmit confirmation callback function.   |  |
|-----------------|--|--|
| Synopsis        | void IpduM_TxConfirmation ( PduIdType TxPduId );   |  |
| Service ID      | 0x40   |  |
| Sync/Async      | synchronous  |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld   |  |
| Parameters (in) | TxPduId  | ID of multiplexed I-PDU that has been transmitted. |
| Description     | This is the transmit confirmation callback function. It gets the PDU handle for the transmitted I-PDU, translates it for the upper layer and then calls the upper layer callback functions configured for this handle. |  |

# 5.3.3. Integration notes

#### 5.3.3.1. Exclusive areas

This section describes the exclusive areas used by the  ${\tt IpduM}$  module.

#### 5.3.3.1.1. SCHM\_IPDUM\_EXCLUSIVE\_AREA\_0

| Protected data structures     | All shared data that shall be protected from mutual access.        |
|-------------------------------|--|
| Recommended locking mechanism | This exclusive area must always be protected by a locking          |
|                               | mechanism. The options for locking are described in the ${\tt EB}$ |
|                               | tresos AutoCore Generic documentation. Refer to                    |
|                               | the section Mapping exclusive areas in the basic                   |
|                               | software modules in the Integration notes section                  |
|                               | for details.   |

#### 5.3.3.2. Production errors

Production errors are not reported by the  ${\tt IpduM}$  module.



#### 5.3.3. Memory mapping

General information about memory mapping is provided in the EB tresos AutoCore Generic documentation. Refer to the section Memory mapping and compiler abstraction in the Integration notes section for details.

The following table provides the list of sections that may be mapped for this module:

| Memory section          |
|-------------------------|
| CODE                    |
| CONST_32                |
| CONST_UNSPECIFIED       |
| VAR_CLEARED_UNSPECIFIED |
| VAR_INIT_8              |
| VAR_INIT_UNSPECIFIED    |
| CONFIG_DATA_UNSPECIFIED |

#### 5.3.3.4. Integration requirements

#### **WARNING**

#### Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user's guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

#### 5.3.3.4.1. lim.lpduM.EB\_INTREQ\_lpduM\_0001

| Description | Ensuring that the configured data retrieval mechanisms (the configuration parameters IpduMContainerTxTriggerMode and IpduMContainedTxPduCollectionSemantics) are compatible with the associated modules is the responsibility of the integrator. |
|-------------|--|
| Rationale   | For example by choosing IPDUM_COLLECT_LAST_IS_BEST as IpduMContainedTx-PduCollectionSemantics it is expected that the module initiating the transmission exposes the interface <module>_TriggerTransmit().</module>                              |

#### 5.3.3.4.2. lim.lpduM.EB\_INTREQ\_lpduM\_0002

| Description | An IpduMContainerTxPdu container with IpduMContainerQueueSize not configured        |  |
|-------------|---|--|
|             | will have no queue buffer. The effect is that IpduM_Transmit() will return E_NOT_OK |  |



|           | for a contained IPDU within a container for which IpduM_TxConfirmation() is awaited from an ongoing transmission.  |
|-----------|--|
| Rationale | Previously, an IpduMContainerTxPdu container with IpduMContainerQueueSize not configured would have had the same behavior as if IpduMContainerQueueSize was configured to 1. The change is meant to bring a clear distinction between the above two configurations and brings the expectation of the user from the IpduM configuration into actual sequence of events. |

#### 5.3.3.4.3. lim.lpduM.EB\_INTREQ\_lpduM\_0003

| Description | API IpduM_Transmit() is not reentrant for contained IPDUs belonging to the same IpduMContainerTxPdu container.                       |
|-------------|--|
| Rationale   | The measure is necessary to assure the order and consistency of contained IPDUs and their data within an instance of a TX container. |

# 5.4. LdCom

# 5.4.1. Configuration parameters

| Containers included        |              |   |
|----------------------------|--------------|---|
| Container name             | Multiplicity | Description   |
| CommonPublishedInformation | 11           | Label: Common Published Information Common container, aggregated by all modules. It contains published information about vendor and versions. |
| LdComConfig                | 11           | EN: This container contains the configuration parameters and sub containers of the AUTOSAR LdCom module.                                      |
| LdComGeneral               | 11           | EN: Contains the general configuration parameters of the Ld-Com module.   |
| PublishedInformation       | 11           | Label: EB Published Information Additional published parameters not covered by Common- PublishedInformation container.                        |
| <u>VendorSpecific</u>      | 11           |   |



| Parameters included           |              |
|-------------------------------|--------------|
| Parameter name                | Multiplicity |
| IMPLEMENTATION_CONFIG_VARIANT | 11           |

| Parameter Name | IMPLEMENTATION_CONFIG_VARIANT |
|----------------|-------------------------------|
| Label          | Configuration Variant         |
| Multiplicity   | 11                            |
| Туре           | ENUMERATION                   |
| Default value  | VariantPostBuild              |
| Range          | VariantPostBuild              |

### 5.4.1.1. CommonPublishedInformation

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| ArMajorVersion      | 11           |  |
| ArMinorVersion      | 11           |  |
| ArPatchVersion      | 11           |  |
| SwMajorVersion      | 11           |  |
| SwMinorVersion      | 11           |  |
| SwPatchVersion      | 11           |  |
| ModuleId            | 11           |  |
| Vendorld            | 11           |  |
| Release             | 11           |  |

| Parameter Name      | ArMajorVersion   |
|---------------------|--|
| Label               | AUTOSAR Major Version  |
| Description         | Major version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 4  |
| Configuration class | PublishedInformation:  |



| Origin | Elektrobit Automotive GmbH |
|--------|----------------------------|
|--------|----------------------------|

| Parameter Name      | ArMinorVersion   |
|---------------------|--|
| Label               | AUTOSAR Minor Version  |
| Description         | Minor version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 2  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name      | ArPatchVersion   |  |  |
|---------------------|--|--|--|
| Label               | AUTOSAR Patch Version  |  |  |
| Description         | Patch level version number of AUTOSAR specification on which the appropriate implementation is based on. |  |  |
| Multiplicity        | 11   |  |  |
| Туре                | INTEGER_LABEL  |  |  |
| Default value       | 1  |  |  |
| Configuration class | PublishedInformation:  |  |  |
| Origin              | Elektrobit Automotive GmbH   |  |  |

| Parameter Name      | SwMajorVersion  |  |  |
|---------------------|---|--|--|
| Label               | Software Major Version  |  |  |
| Description         | Major version number of the vendor specific implementation of the module. |  |  |
| Multiplicity        | 11  |  |  |
| Туре                | INTEGER_LABEL   |  |  |
| Default value       | 1   |  |  |
| Configuration class | PublishedInformation:   |  |  |
| Origin              | Elektrobit Automotive GmbH  |  |  |

| Parameter Name | SwMinorVersion  |  |
|----------------|---|--|
| Label          | Software Minor Version  |  |
| •              | Minor version number of the vendor specific implementation of the module. The numbering is vendor specific. |  |



| Multiplicity        | 11                         |
|---------------------|----------------------------|
| Туре                | INTEGER_LABEL              |
| Default value       | 0                          |
| Configuration class | PublishedInformation:      |
| Origin              | Elektrobit Automotive GmbH |

| Parameter Name      | SwPatchVersion  |  |  |
|---------------------|---|--|--|
| Label               | Software Patch Version  |  |  |
| Description         | Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific. |  |  |
| Multiplicity        | 11  |  |  |
| Туре                | INTEGER_LABEL   |  |  |
| Default value       | 26  |  |  |
| Configuration class | PublishedInformation:   |  |  |
| Origin              | Elektrobit Automotive GmbH  |  |  |

| Parameter Name      | Moduleld                                  |  |  |  |
|---------------------|---|--|--|--|
| Label               | Numeric Module ID                         |  |  |  |
| Description         | Module ID of this module from Module List |  |  |  |
| Multiplicity        | 11  |  |  |  |
| Туре                | INTEGER_LABEL                             |  |  |  |
| Default value       | 49  |  |  |  |
| Configuration class | PublishedInformation:                     |  |  |  |
| Origin              | Elektrobit Automotive GmbH                |  |  |  |

| Parameter Name      | Vendorld  |  |  |  |
|---------------------|---|--|--|--|
| Label               | Vendor ID   |  |  |  |
| Description         | Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list |  |  |  |
| Multiplicity        | 11  |  |  |  |
| Туре                | INTEGER_LABEL   |  |  |  |
| Default value       | 1   |  |  |  |
| Configuration class | PublishedInformation:   |  |  |  |



| Origin         | Elektrobit Automotive GmbH |  |  |
|----------------|----------------------------|--|--|
| Parameter Name | Release                    |  |  |
| Label          | Release Information        |  |  |
| Multiplicity   | 11                         |  |  |

Type STRING\_LABEL

Default value

Configuration class PublishedInformation:

Origin Elektrobit Automotive GmbH

### 5.4.1.2. LdComConfig

| Containers included |              |  |  |
|---------------------|--------------|--|--|
| Container name      | Multiplicity | Description  |  |
| <u>LdComIPdu</u>    | 0n           | Contains the configuration parameters of the IPdu inside Ld-Com. |  |

#### 5.4.1.3. LdComlPdu

| Parameters included                 |              |  |
|-------------------------------------|--------------|--|
| Parameter name                      | Multiplicity |  |
| LdComApiType                        | 11           |  |
| LdComHandleId                       | 11           |  |
| LdComlPduDirection                  | 11           |  |
| LdComRxCopyRxData                   | 01           |  |
| LdComRxIndication                   | 01           |  |
| LdComRxStartOfReception             | 01           |  |
| LdComTpRxIndication                 | 01           |  |
| LdComTpTxConfirmation               | 01           |  |
| LdComTxConfirmation                 | 01           |  |
| LdComTxCopyTxData                   | 01           |  |
| LdComTxTriggerTransmit              | 01           |  |
| <u>LdComSystemTemplateSignalRef</u> | 01           |  |



| Parameters included |    |
|---------------------|----|
| LdComPduRef         | 11 |

| Parameter Name      | LdComApiType  |                  |
|---------------------|---|------------------|
| Description         | Defines if this I-PDU is a normal I-PDU that shall be sent unfragmented or if this is a large I-PDU that shall be sent via the Transport Protocol of the underlying bus.  This setting is used by RTE to invoke the proper API. |                  |
| Multiplicity        | 11  |                  |
| Туре                | ENUMERATION   |                  |
| Range               | LDCOM_IF LDCOM_TP   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | LdComHandleld  |                  |
|---------------------|--|------------------|
| Description         | This is the ID used by RTE to invoke LdCom.                                    |                  |
|                     | A corresponding shortName is created, which is used for the invocations of the |                  |
|                     | RTE. The same ID is used for invocation  | ns by PduR.      |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Range               | <=65535  |                  |
|                     | >=0  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name | LdComlPduDirection  |
|----------------|---|
| Description    | The direction defines if this IPdu, and therefore the contributing signal, shall be sent or received. |
| Multiplicity   | 11  |
| Туре           | ENUMERATION   |
| Range          | LDCOM_RECEIVE   |
|                | LDCOM_SEND  |



| Configuration class | VariantPostBuild: | VariantPostBuild |
|---------------------|-------------------|------------------|
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | LdComRxCopyRxData   |                  |
|---------------------|---|------------------|
| Description         | Only on receiver side: Name of Rte_LdComCbkCopyRxData callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Default value       | LdCom_DummyCbkCopyRxData  |                  |
| Configuration class | Link:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | LdComRxIndication   |                  |
|---------------------|---|------------------|
| Description         | Only on receiver side: Name of Rte_LdComCbkRxIndication callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Default value       | LdCom_DummyCbkRxIndication  |                  |
| Configuration class | Link:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | LdComRxStartOfReception   |                  |
|---------------------|---|------------------|
| Description         | Only on receiver side: Name of Rte_LdComCbkStartOfReception callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Default value       | LdCom_DummyCbkStartOfReception  |                  |
| Configuration class | Link:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | LdComTpRxIndication   |
|----------------|---|
| Description    | Only on receiver side: Name of Rte_LdComCbkTpRxIndication callback function to be called. |
| Multiplicity   | 01  |
| Туре           | FUNCTION-NAME   |



| Default value       | LdCom_DummyCbkTpRxIndication |  |
|---------------------|------------------------------|--|
| Configuration class | Link: VariantPostBuild       |  |
| Origin              | AUTOSAR_ECUC                 |  |

| Parameter Name      | LdComTpTxConfirmation   |                  |
|---------------------|---|------------------|
| Description         | Only on sender side: Name of Rte_LdComCbkCopyTpTxConfirmation callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Default value       | LdCom_DummyCbkTpTxConfirmation  |                  |
| Configuration class | Link:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | LdComTxConfirmation   |                  |
|---------------------|---|------------------|
| Description         | Only on sender side: Name of Rte_LdComCbkTxConfirmation callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Default value       | LdCom_DummyCbkTxConfirmation  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | LdComTxCopyTxData   |                  |
|---------------------|---|------------------|
| Description         | Only on sender side: Name of Rte_LdComCbkCopyTxData callback function to be called. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FUNCTION-NAME   |                  |
| Default value       | LdCom_DummyCbkCopyTxData  |                  |
| Configuration class | Link:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | LdComTxTriggerTransmit   |  |
|----------------|--|--|
| Description    | Only on sender side: Name of Rte_LdComCbkTriggerTransmit callback function to be called. |  |
| Multiplicity   | 01   |  |



| Туре                | FUNCTION-NAME                 |                  |
|---------------------|-------------------------------|------------------|
| Default value       | LdCom_DummyCbkTriggerTransmit |                  |
| Configuration class | VariantPostBuild:             | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                  |                  |

| Parameter Name      | LdComSystemTemplateSignalRef   |                  |
|---------------------|--|------------------|
| Description         | Reference to the ISignalToIPduMapping that contains a reference to the ISignal (System Template) which this LdCom signal represents. |                  |
| Multiplicity        | 01   |                  |
| Туре                | FOREIGN-REFERENCE  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | LdComPduRef                  |                  |
|---------------------|------------------------------|------------------|
| Description         | Reference to the global Pdu. |                  |
| Multiplicity        | 11                           |                  |
| Туре                | REFERENCE                    |                  |
| Configuration class | VariantPostBuild:            | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                 |                  |

### 5.4.1.4. LdComGeneral

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| LdComDevErrorDetect | 11           |
| LdComVersionInfoApi | 11           |

| Parameter Name      | LdComDevErrorDetect  |  |
|---------------------|--|--|
| Description         | EN: Switches the Development Error Detection and Notification ON or OFF. |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild                                       |  |



| Origin | AUTOSAR_ECUC |
|--------|--------------|
|--------|--------------|

| Parameter Name      | LdComVersionInfoApi  |                  |
|---------------------|--|------------------|
| Description         | Activate/Deactivates the version information API (LdCom_GetVersionInfo). |                  |
|                     | true: version information API activated                                  |                  |
|                     | false: version information API deactivated                               |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

### 5.4.1.5. PublishedInformation

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| PbcfgMSupport       | 11           |

| Parameter Name      | PbcfgMSupport  |
|---------------------|--|
| Label               | PbcfgM support   |
| Description         | Specifies whether or not the LdCom can use the PbcfgM module for post-build support. |
| Multiplicity        | 11   |
| Туре                | BOOLEAN  |
| Default value       | true   |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

# 5.4.1.6. VendorSpecific

| Parameters included         |              |
|-----------------------------|--------------|
| Parameter name              | Multiplicity |
| LdComRelocatablePbcfgEnable | 11           |



| Parameters included              |    |
|----------------------------------|----|
| <u>LdComUpperLayerHeaderFile</u> | 0n |

| Parameter Name      | LdComRelocatablePbcfgEnable  | LdComRelocatablePbcfgEnable |  |
|---------------------|--|-----------------------------|--|
| Description         | Enables or disables the post-build-time configuration data to be used either by relative offsets to the configuration start address (relocatable) or by absolute pointers (not relocatable).  TRUE: Relocateable configuration is in use (switched on).  FALSE: Relocateable configuration is not in use (switched off). |                             |  |
|                     | Note: If PbcfgMBswModuleRef contains a reference to this module, then this feature is managed by the parameter PbcfgMRelocatableCfgEnable of the PbcfgM.   |                             |  |
|                     | <ul> <li>Optimization Effect:</li> <li>ROM reduction (config): Enabling this parameter reduces the ROM consumption of the module configuration.</li> <li>Execution time reduction (code): Disabling this parameter reduces the execution time of the module code.</li> </ul>   |                             |  |
| Multiplicity        | 11   |                             |  |
| Туре                | BOOLEAN  |                             |  |
| Default value       | true   |                             |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild            |  |
| Origin              | Elektrobit Automotive GmbH   |                             |  |

| Parameter Name      | LdComUpperLayerHeaderFile  |                  |
|---------------------|--|------------------|
| Description         | Defines header file for callback functions of the upper layer. If no header file is configured, Rte_Cbk.h is included automatically. |                  |
| Multiplicity        | 0n   |                  |
| Туре                | STRING   |                  |
| Configuration class | PreCompile:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

# 5.4.2. Application programming interface (API)



### 5.4.2.1. Type definitions

### 5.4.2.1.1. LdCom\_ApilfRxType

| Purpose |  |
|---------|--|
| Туре    | struct                                 |
| Members | LdCom_RteCbkRxIndicationFpType RxIndFp |

### 5.4.2.1.2. LdCom\_ApilfTxType

| Purpose |  |
|---------|--|
| Туре    | struct                                       |
| Members | LdCom_RteCbkTriggerTransmitFp- Type TrigTxFp |
|         | LdCom_RteCbkTxConfirmationFp- Type TxConfFp  |

### 5.4.2.1.3. LdCom\_ApiTpRxType

| Purpose |   |
|---------|---|
| Туре    | struct  |
| Members | LdCom_RteCbkStartOfReceptionFp- Type StartOfRecFp |
|         | LdCom_RteCbkCopyRxDataFpType<br>CopyRxDataFp      |
|         | LdCom_RteCbkTpRxIndicationFp- Type TpRxIndFp      |

### 5.4.2.1.4. LdCom\_ApiTpTxType

| Purpose |        |
|---------|--------|
| Туре    | struct |



| Members | LdCom_RteCbkCopyTxDataFpType<br>CopyTxDataFp       |  |
|---------|--|--|
|         | LdCom_RteCbkTpTxConfirmationFp-<br>Type TpTxConfFp |  |

### 5.4.2.1.5. LdCom\_RteCbkCopyRxDataFpType

| Purpose |  |
|---------|--|
| Туре    | BufReq_ReturnType(*)(const PduInfoType *SduInfoPtr, Pdu- |
|         | LengthType *RxBufferSizePtr)                             |

### 5.4.2.1.6. LdCom\_RteCbkCopyTxDataFpType

| Purpose |   |
|---------|---|
| Туре    | BufReq_ReturnType(*)(PduInfoType *SduInfoPtr, RetryInfoType |
|         | *RetryInfoPtr, PduLengthType *TxDataCntPtr)                 |

### 5.4.2.1.7. LdCom\_RteCbkRxIndicationFpType

| Purpose |  |
|---------|--|
| Туре    | void(*)(const PduInfoType *PduInfoPtr) |

### 5.4.2.1.8. LdCom\_RteCbkStartOfReceptionFpType

| Purpose |   |
|---------|---|
| Туре    | BufReq_ReturnType(*)(PduLengthType SduLength, PduLengthType *RxBufferSizePtr) |

### 5.4.2.1.9. LdCom\_RteCbkTpRxIndicationFpType

| Purpose |                                 |
|---------|---------------------------------|
| Туре    | void(*)(NotifResultType Result) |



### 5.4.2.1.10. LdCom\_RteCbkTpTxConfirmationFpType

| Purpose |                                 |
|---------|---------------------------------|
| Туре    | void(*)(NotifResultType Result) |

### 5.4.2.1.11. LdCom\_RteCbkTriggerTransmitFpType

| Purpose |  |
|---------|--|
| Туре    | Std_ReturnType(*)(PduInfoType *PduInfoPtr) |

### 5.4.2.1.12. LdCom\_RteCbkTxConfirmationFpType

| Purpose |               |
|---------|---------------|
| Туре    | void(*)(void) |

### 5.4.2.2. Macro constants

### 5.4.2.2.1. LDCOM\_E\_INIT\_FAILED

| Purpose | Invalid configuration set selection. |
|---------|--------------------------------------|
| Value   | 0x06U                                |

### 5.4.2.2.2. LDCOM\_E\_INVALID\_PDU\_SDU\_ID

| Purpose | API service called with wrong PDU-ID. |
|---------|---------------------------------------|
| Value   | 0x04U                                 |

### 5.4.2.2.3. LDCOM\_E\_INVALID\_SIGNAL\_ID

| Purpose | API service called with wrong Signal-ID. |
|---------|--|
| Value   | 0x05U                                    |



### 5.4.2.2.4. LDCOM\_E\_PARAM\_POINTER

| Purpose | API service called with a NULL pointer. In case of this error, the API service shall return immediately without any further action, except for reporting this development error. |
|---------|--|
| Value   | 0x03U  |

### **5.4.2.2.5. LDCOM\_E\_UNINIT**

| •     | Error code if any other API service, except LdCom_GetVersionInfo is called before the AUTOSAR LdCom module was initialized with LdCom_Init or after a call to LdCom_Deinit. |
|-------|---|
| Value | 0x02U   |

### 5.4.2.2.6. LDCOM\_INSTANCE\_ID

| Purpose |       |
|---------|-------|
| Value   | 0x00U |

### **5.4.2.2.7. LDCOM\_ONLINE**

| Purpose |    |
|---------|----|
| Value   | 1U |

### 5.4.2.2.8. LDCOM\_SID\_COPYRXDATA

| Purpose | API Service ID for LdCom_CopyRxData(). |
|---------|--|
| Value   | 0x44U                                  |

### 5.4.2.2.9. LDCOM\_SID\_COPYTXDATA

| Purpose | API Service ID for <u>LdCom_CopyTxData()</u> . |
|---------|--|
|---------|--|



|--|

### 5.4.2.2.10. LDCOM\_SID\_DEINIT

| Purpose | API Service ID for <u>LdCom_Delnit()</u> . |
|---------|--|
| Value   | 0x02U                                      |

### 5.4.2.2.11. LDCOM\_SID\_GETVERSIONINFO

| Purpose | API Service ID for LdCom_GetVersioninfo(). |
|---------|--|
| Value   | 0x03U                                      |

### 5.4.2.2.12. LDCOM\_SID\_IFTRANSMIT

| Purpose | API Service ID for <u>LdCom_IfTransmit()</u> . |
|---------|--|
| Value   | 0x05U  |

### 5.4.2.2.13. LDCOM\_SID\_INIT

| Purpose | API Service ID for LdCom_Init(). |
|---------|----------------------------------|
| Value   | 0x01U                            |

### 5.4.2.2.14. LDCOM\_SID\_RXINDICATION

| Purpose | API Service ID for <u>LdCom_RxIndication()</u> . |
|---------|--|
| Value   | 0x42U  |

### 5.4.2.2.15. LDCOM\_SID\_STARTOFRECEPTION

| Purpose | API Service ID for LdCom_StartOfReception(). |
|---------|--|
|---------|--|



|--|

### 5.4.2.2.16. LDCOM\_SID\_TPRXINDICATION

| Purpose | API Service ID for LdCom_TpRxIndication(). |
|---------|--|
| Value   | 0x45U                                      |

### 5.4.2.2.17. LDCOM\_SID\_TPTRANSMIT

| Purpose | API Service ID for LDCOM_TpTransmit(). |
|---------|--|
| Value   | 0x04U                                  |

### 5.4.2.2.18. LDCOM\_SID\_TPTXCONFIRMATION

| Purpose | API Service ID for LdCom_TpTxConfirmation(). |
|---------|--|
| Value   | 0x48U  |

### 5.4.2.2.19. LDCOM\_SID\_TRIGGERTRANSMIT

| Purpose | API Service ID for <u>LdCom_TriggerTransmit()</u> . |
|---------|---|
| Value   | 0x41U   |

### 5.4.2.2.20. LDCOM\_SID\_TXCONFIRMATION

| Purpose | API Service ID for <u>LdCom_TxConfirmation()</u> . |
|---------|--|
| Value   | 0x40U  |

### 5.4.2.2.21. LDCOM\_UNINIT



|--|

### 5.4.2.2.22. LdCom\_Transmit

| Purpose |                                     |
|---------|-------------------------------------|
| Value   | LdCom_lfTransmit((ld),(PduInfoPtr)) |

### **5.4.2.3. Functions**

### 5.4.2.3.1. LdCom\_CopyRxData

| Purpose          | This function is called to provide the received data of an I-PDU segment (N-PDU) to the upper layer.   |   |
|------------------|--|---|
| Synopsis         | <pre>BufReq_ReturnType LdCom_CopyRxData ( PduIdType Id , const PduInfoType * Info , PduLengthType * BufferSizePtr );</pre>   |   |
| Service ID       | 0x44   |   |
| Sync/Async       | Synchronous  |   |
| Reentrancy       | Reentrant for different Pdulds. Non reentrant for the same Pduld.  |   |
| Parameters (in)  | ers (in) Id Identification of the receive  |   |
|                  | Info   | Provides the source buffer (SduDataPtr) and the number of bytes to be copied (SduLength). An SduLength of 0 can be used to query the current amount of available buffer in the upper layer module. In this case, the SduDataPtr may be a NULLPTR. |
| Parameters (out) | BufferSizePtr  | Available receive buffer after data has been copied.  |
| Return Value     | Result of buffer request   |   |
|                  | BUFREQ_OK  | Data copied successfully.   |
|                  | BUFREQ_E_NOT_OK  | Data was not copied because an error occurred.  |
| Description      | This function is called when a transport protocol module has data to copy for the receiving module. Several calls may be made during one transportation of an I-PDU. |   |



The service shall provide the currently available buffer size when invoked with Info.SduLength equal to 0.

### 5.4.2.3.2. LdCom\_CopyTxData

| Purpose          | This function is called to acquire the transmit data of an I-PDU segment (N-PDU).   |   |
|------------------|---|---|
| Synopsis         | <pre>BufReq_ReturnType LdCom_CopyTxData ( PduIdType Id , PduInfoType * Info , RetryInfoType * Retry , PduLengthType * AvailableDat- aPtr );</pre> |   |
| Service ID       | 0x43  |   |
| Sync/Async       | Synchronous   |   |
| Reentrancy       | Reentrant for different Pdulds. Non r   | reentrant for the same Pduld.   |
| Parameters (in)  | Id  | Identification of the transmitted I-PDU.  |
|                  | Retry   | This parameter is used to acknowledge transmitted data or to retransmit data after transmission problems. If the Retry parameter is a NULL_PTR, it indicates that the transmit data can be removed from the buffer immediately after it has been copied. Otherwise, the Retry parameter must point to a valid RetryInfo-Type element. If TpDataState indicates TP_CONFPENDING, the previously copied data must remain in the TP buffer to be available for error recovery. TPDATACONF indicates that all data that has been copied before this call is confirmed and can be removed from the TP buffer. Data copied by this API call is excluded and will be confirmed later. TPDATARETRY indicates that this API call shall copy previously copied data in order to recover from an error. In this case TxTpDataCnt specifies the offset in bytes from the current data copy position. |
| Parameters (out) | Info  | Provides the destination buffer (Sdu-<br>DataPtr) and the number of bytes to be<br>copied (SduLength). If not enough trans-<br>mit data is available, no data is copied by  |



|              |   | the upper layer module and BUFREQ_EBUSY is returned. The lower layer module may Retry the call. An SduLength of 0 can be used to indicate state changes in the Retry parameter or to query the current amount of available data in the upper layer module. In this case, the SduDataPtr may be a NULL_PTR. |
|--------------|---|--|
|              | AvailableDataPtr  | Indicates the remaining number of bytes that are available in the upper layer module's Tx buffer. AvailableDataPtr can be used by TP modules that support dynamic payload lengths (e.g. FrIsoTp) to determine the size of the following CFs.   |
| Return Value | Result of buffer request  |  |
|              | BUFREQ_OK   | Data has been copied to the transmit buffer completely as requested.   |
|              | BUFREQ_E_BUSY   | Request could not be fulfilled, because the required amount of Tx data is not available. The lower layer module may retry this call later on. No data has been copied.   |
|              | BUFREQ_E_NOT_OK   | Data has not been copied. Request failed.  |
| Description  | Each call to this function provides the next part of the I-PDU data unless Retry->Tp-DataState is TP_DATARETRY. In this case the function restarts to copy the data beginning at the offset from the current position indicated by Retry->TxTpDataCnt. The size of the remaining data is written to the position indicated by AvailableDataPtr. |  |

### 5.4.2.3.3. LdCom\_DeInit

| Purpose     | Deinitialize the LdCom module.   |
|-------------|--|
| Synopsis    | <pre>void LdCom_DeInit ( void );</pre>   |
| Service ID  | 0x02   |
| Sync/Async  | Synchronous  |
| Reentrancy  | Non-Reentrant  |
| Description | With a call to LdCom_Delnit the AUTOSAR LdCom module is put into a de-initialized state. |



### 5.4.2.3.4. LdCom\_GetVersionInfo

| Purpose          | Get version information of the LdCom module.  |   |
|------------------|---|---|
| Synopsis         | <pre>void LdCom_GetVersionInfo ( Std_VersionInfoType * versioninfo );</pre>   |   |
| Service ID       | 0x03  |   |
| Sync/Async       | Synchronous   |   |
| Reentrancy       | Non-Reentrant   |   |
| Parameters (out) | versioninfo   | Pointer to where to store the version information of this module. |
| Description      | This service returns the version information of this module. The version information includes:  Module Id  Vendor Id  Vendor specific version numbers |   |

### 5.4.2.3.5. LdCom\_lfTransmit

| Purpose         | Initiate a transmission of a signal to communication interface modules.   |   |  |
|-----------------|---|---|--|
| Synopsis        | <pre>Std_ReturnType LdCom_IfTransmit ( PduIdType Id , const PduInfo-<br/>Type * PduInfoPtr );</pre>   |   |  |
| Service ID      | 0x05  | 0x05  |  |
| Sync/Async      | Synchronous   |   |  |
| Parameters (in) | Id  | ID of the signal to be sent.  |  |
|                 | PduInfoPtr  | Length and pointer to the buffer of the Signal.                             |  |
| Return Value    | Standard Return Code  |   |  |
|                 | E_OK  | Request is accepted by the destination module; transmission is continued.   |  |
|                 | E_NOT_OK  | Request is not accepted by the destination module; transmission is aborted. |  |
| Description     | This function transmits the signal data given by Id and PduInfoPtr by replacing the Signal ID by the according PDU ID and invoking of PduR_LdComTransmit. |   |  |



{Non Reentrant for the same Handleld, otherwise Reentrant}

### 5.4.2.3.6. LdCom\_Init

| Purpose         | Initialize the LdCom module.  |  |
|-----------------|---|--|
| Synopsis        | <pre>void LdCom_Init ( const LdCom_ConfigType * config );</pre>   |  |
| Service ID      | 0x01  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Non-Reentrant   |  |
| Parameters (in) | config Points to the implementation specific structure  |  |
| Description     | This service initializes internal and external interfaces and variables of the AUTOSAR LdCom module for further processing. |  |

### 5.4.2.3.7. LdCom\_lsValidConfig

| Purpose         | Validate configuration.  |  |  |
|-----------------|--|--|--|
| Synopsis        | <pre>Std_ReturnType LdCom_IsValidConfig ( const void * ConfigPtr );</pre>  |  |  |
| Sync/Async      | Synchronous  | Synchronous                                  |  |
| Reentrancy      | Reentrant  | Reentrant                                    |  |
| Parameters (in) | Pointer to configuration structure that holds the LdCom module post-build-time configuration data.   |  |  |
| Return Value    | Function execution success status  |  |  |
|                 | E_OK   | the provided module configuration is valid   |  |
|                 | E_NOT_OK   | the provided module configuration is invalid |  |
| Description     | Checks if the post build configuration is valid. A configuration is invalid if  the platform signature does not match.  the published information signature does not match.  the link time signature does not match.  the compile time signature does not match. |  |  |



| the function is called with a null pointer. |
|---|
|   |

### 5.4.2.3.8. LdCom\_RxIndication

| Purpose         | This function indicates a received I-PDU from a lower layer communication interface module. |  |  |
|-----------------|---|--|--|
| Synopsis        | <pre>void LdCom_RxIndication ( PduIdType RxPduId , PduInfoType * PduInfoPtr );</pre>        |  |  |
| Service ID      | 0x42  |  |  |
| Sync/Async      | Synchronous   |  |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentra   | Reentrant for different Pdulds. Non reentrant for the same Pduld.  |  |
| Parameters (in) | RxPduId ID of the received I-PDU.   |  |  |
|                 | PduInfoPtr  | Contains the length (SduLength) of the received I-PDU and a pointer to a buffer (SduDataPtr) containing the I-PDU. |  |

### 5.4.2.3.9. LdCom\_StartOfReception

| Purpose          | This function is called at the start of receiving an I-PDU.   |   |
|------------------|---|---|
| Synopsis         | <pre>BufReq_ReturnType LdCom_StartOfReception ( PduIdType Id , Pdu-<br/>LengthType TpSduLength , PduLengthType * BufferSizePtr );</pre> |   |
| Service ID       | 0x46  |   |
| Sync/Async       | Synchronous   |   |
| Reentrancy       | Reentrant for different Pdulds. Non reentrant for the same Pduld.   |   |
| Parameters (in)  | Id  | Identification of the received I-PDU.   |
|                  | TpSduLength   | Total length of the PDU to be received.   |
| Parameters (out) | BufferSizePtr   | Available receive buffer in the receiving module. This parameter will be used to compute the Block Size (BS) in the transport protocol module.                      |
| Return Value     | Result of buffer request  |   |
|                  | BUFREQ_OK   | Connection has been accepted. Buffer-SizePtr indicates the available receive buffer. Reception is continued. If no buffer of the requested size is available, a re- |



|             |   | ceive buffer size of 0 shall be indicated by BufferSizePtr.   |
|-------------|---|---|
|             | BUFREQ_E_OVFL   | No Buffer of the required length can be provided. Reception is aborted. Buffer-SizePtr remains unchanged. |
|             | BUFREQ_E_NOT_OK   | Connection has been rejected. Reception is aborted. BufferSizePtr remains unchanged.                      |
| Description | This function will be called by the transport protocol module at the start of receiving an I-PDU. The I-PDU might be fragmented into multiple N-PDUs (FF with one or more following CFs) or might consist of a single N-PDU (SF). The service shall provide the currently available maximum buffer size when invoked with TpSduLength equal to 0. |   |

### 5.4.2.3.10. LdCom\_TpRxIndication

| Purpose   | This function is called after an I-PDU has been received via the TP API.  |                                       |
|---|---|---------------------------------------|
| Synopsis  | <pre>void LdCom_TpRxIndication ( PduIdType Id , NotifResultType Re-<br/>sult );</pre>   |                                       |
| Service ID  | 0x45  |                                       |
| Sync/Async  | Synchronous   |                                       |
| Reentrancy  | Reentrant for different Pdulds. Non reentrant for the same Pduld.   |                                       |
| Parameters (in) Id Identification of the received |   | Identification of the received I-PDU. |
|   | Result  | Result of the reception.              |
| Description                                       | This service is called by the transport protocol module after an I-PDU has been received successfully or when an error occurred. It is also used to confirm cancellation of an I-PDU. |                                       |

### 5.4.2.3.11. LdCom\_TpTransmit

| Purpose    | Initiate a transmission of a signal to transport protocol modules.                                  |  |
|------------|---|--|
| Synopsis   | <pre>Std_ReturnType LdCom_TpTransmit ( PduIdType Id , const PduInfo-<br/>Type * PduInfoPtr );</pre> |  |
| Service ID | 0x05  |  |
| Sync/Async | Asynchronous  |  |



| Parameters (in) | Id  | ID of the signal to be sent.  |
|-----------------|---|---|
|                 | PduInfoPtr  | Length and pointer to the buffer of the Signal.                             |
| Return Value    | Standard Return Code  |   |
|                 | E_OK  | Request is accepted by the destination module; transmission is continued.   |
|                 | E_NOT_OK  | Request is not accepted by the destination module; transmission is aborted. |
| Description     | This function transmits the signal data given by Id and PduInfoPtr by replacing the Signal ID by the according PDU ID and invoking of PduR_LdComTpTransmit.  {Non Reentrant for the same HandleId, otherwise Reentrant} |   |

### 5.4.2.3.12. LdCom\_TpTxConfirmation

| Purpose         | This function is called after the I-PDU has been transmitted on its network.  |  |
|-----------------|---|--|
| Synopsis        | <pre>void LdCom_TpTxConfirmation ( PduIdType Id , NotifResultType Result );</pre>   |  |
| Service ID      | 0x48  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.   |  |
| Parameters (in) | Id  | Identification of the transmitted I-PDU. |
|                 | Result  | Result of the transmission of the I-PDU. |
| Description     | This service is called by a transport protocol module after the I-PDU has been transmitted on its network, the result indicates whether the transmission was successful or not. |  |

### 5.4.2.3.13. LdCom\_TriggerTransmit

| Purpose    | This function requests the buffer of the SDU for transmission from the upper layer module.        |  |
|------------|---|--|
| Synopsis   | <pre>Std_ReturnType LdCom_TriggerTransmit ( PduIdType TxPduId , PduInfoType * PduInfoPtr );</pre> |  |
| Service ID | 0x41  |  |
| Sync/Async | Synchronous   |  |



| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.  |   |
|-----------------|--|---|
| Parameters (in) | TxPduId  | ID of the SDU that is requested to be transmitted.  |
|                 | PduInfoPtr   | Contains a pointer to a buffer (SduDataPtr) to where the SDU data shall be copied. On return, the service will indicate the length of the copied SDU data in SduLength. |
| Return Value    | Function execution success status  |   |
|                 | E_OK   | SDU has been copied and SduLength indicates the number of copied bytes.   |
|                 | E_NOT_OK   | No SDU has been copied. PduInfoPtr<br>must not be used since it may contain a<br>NULL pointer or point to invalid data.   |
| Description     | Within this API, the upper layer module (called module) shall copy its data into the buffer provided by PduInfoPtr->SduDataPtr and update the length of the actual copied data in PduInfoPtr->SduLength. |   |

### 5.4.2.3.14. LdCom\_TxConfirmation

| Purpose         | The lower layer communication interface module confirms the transmission of an I-PDU. |  |
|-----------------|---|--|
| Synopsis        | <pre>void LdCom_TxConfirmation ( PduIdType TxPduId );</pre>                           |  |
| Service ID      | 0x40  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.                     |  |
| Parameters (in) | TxPduId   | ID of the I-PDU that has been transmitted. |

# 5.4.3. Integration notes

### 5.4.3.1. Exclusive areas

Exclusive areas are not used by the LdCom module.



#### 5.4.3.2. Production errors

Production errors are not reported by the LdCom module.

### 5.4.3.3. Memory mapping

General information about memory mapping is provided in the EB tresos AutoCore Generic documentation. Refer to the section Memory mapping and compiler abstraction in the Integration notes section for details.

The following table provides the list of sections that may be mapped for this module:

| Memory section          |
|-------------------------|
| CODE                    |
| APPL_CODE               |
| CONST_32                |
| CONST_UNSPECIFIED       |
| VAR_CLEARED_UNSPECIFIED |
| VAR_INIT_UNSPECIFIED    |
| VAR_INIT_8              |
| CONFIG_DATA_UNSPECIFIED |

### 5.4.3.4. Integration requirements

#### **WARNING**

#### Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

Integration requirements are not listed for the LdCom module.

# 5.5. Mirror

# 5.5.1. Configuration parameters



| Containers included             |              |   |
|---------------------------------|--------------|---|
| Container name                  | Multiplicity | Description   |
| CommonPublishedInforma-<br>tion | 11           | Label: Common Published Information Common container, aggregated by all modules. It contains published information about vendor and versions. |
| MirrorDefensiveProgramming      | 11           | Label: Defensive Programming Options  Parameters for defensive programming  |
| <u>MirrorConfigSet</u>          | 11           | Contains the configuration parameters and sub containers of the Bus Mirroring module.   |
| MirrorGeneral                   | 11           | Contains the general configuration parameters of the module.  |
| PublishedInformation            | 11           | Label: EB Published Information Additional published parameters not covered by Common- PublishedInformation container.                        |

| Parameters included              |  |
|----------------------------------|--|
| Parameter name Multiplicity      |  |
| IMPLEMENTATION_CONFIG_VARIANT 11 |  |

| Parameter Name      | IMPLEMENTATION_CONFIG_VARIANT        |                |  |
|---------------------|--------------------------------------|----------------|--|
| Label               | Config Variant                       | Config Variant |  |
| Multiplicity        | 11                                   | 11             |  |
| Туре                | ENUMERATION                          |                |  |
| Default value       | VariantPreCompile                    |                |  |
| Range               | VariantPreCompile                    |                |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |                |  |
|                     | VariantPostBuild: VariantPostBuild   |                |  |
|                     | VariantPreCompile: VariantPreCompile |                |  |

### 5.5.1.1. CommonPublishedInformation

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| ArMajorVersion      | 11           |



| Parameters included   |    |
|-----------------------|----|
| ArMinorVersion        | 11 |
| ArPatchVersion        | 11 |
| <u>SwMajorVersion</u> | 11 |
| SwMinorVersion        | 11 |
| SwPatchVersion        | 11 |
| ModuleId              | 11 |
| Vendorld              | 11 |
| Release               | 11 |

| Parameter Name      | ArMajorVersion   |
|---------------------|--|
| Label               | AUTOSAR Major Version  |
| Description         | Major version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 4  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name      | ArMinorVersion   |
|---------------------|--|
| Label               | AUTOSAR Minor Version  |
| Description         | Minor version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 3  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name | ArPatchVersion   |
|----------------|--|
| Label          | AUTOSAR Patch Version  |
| Description    | Patch level version number of AUTOSAR specification on which the appropriate implementation is based on. |



| Multiplicity        | 11                         |
|---------------------|----------------------------|
| Туре                | INTEGER_LABEL              |
| Default value       | 1                          |
| Configuration class | PublishedInformation:      |
| Origin              | Elektrobit Automotive GmbH |

| Parameter Name      | SwMajorVersion  |
|---------------------|---|
| Label               | Software Major Version  |
| Description         | Major version number of the vendor specific implementation of the module. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 1   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | SwMinorVersion  |
|---------------------|---|
| Label               | Software Minor Version  |
| Description         | Minor version number of the vendor specific implementation of the module. The numbering is vendor specific. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 0   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | SwPatchVersion  |
|---------------------|---|
| Label               | Software Patch Version  |
| Description         | Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 17  |
| Configuration class | PublishedInformation:   |



| Origin              | Elektrobit Automotive GmbH                |
|---------------------|---|
| Parameter Name      | Moduleld                                  |
| Label               | Numeric Module ID                         |
| Description         | Module ID of this module from Module List |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL                             |
| Default value       | 48  |
| Configuration class | PublishedInformation:                     |
| Origin              | Elektrobit Automotive GmbH                |

| Parameter Name      | Vendorld  |
|---------------------|---|
| Label               | Vendor ID   |
| Description         | Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 1   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | Release                    |
|---------------------|----------------------------|
| Label               | Release Information        |
| Multiplicity        | 11                         |
| Туре                | STRING_LABEL               |
| Default value       |                            |
| Configuration class | PublishedInformation:      |
| Origin              | Elektrobit Automotive GmbH |

# 5.5.1.2. MirrorDefensiveProgramming

| Parameters included  |              |
|----------------------|--------------|
| Parameter name       | Multiplicity |
| MirrorDefProgEnabled | 11           |



| Parameters included          |    |
|------------------------------|----|
| MirrorPrecondAssertEnabled   | 11 |
| MirrorPostcondAssertEnabled  | 11 |
| MirrorStaticAssertEnabled    | 11 |
| MirrorUnreachAssertEnabled   | 11 |
| MirrorInvariantAssertEnabled | 11 |

| Parameter Name      | MirrorDefProgEnabled  |  |
|---------------------|---|--|
| Label               | Enable Defensive Programming  |  |
| Description         | Enables or disables the defensive programming feature for the module Mirror.  Note: This feature is dependent on the use of the development error detection module. To use the defensive programming feature, proceed as follows:  1. Enable development error detection  2. Enable defensive programming  3. Enable assertions as required |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPreCompile: VariantPreCompile  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name | MirrorPrecondAssertEnabled   |  |  |
|----------------|--|--|--|
| Label          | Enable Precondition Assertions   |  |  |
| Description    | Enables handling of precondition assertion checks reported from the module Mirror. |  |  |
|                | Dependency on parameter(s):  |  |  |
|                | ► Enable Development Error Detection (MirrorDevErrorDetect): must be enabled       |  |  |
|                | ► Enable Defensive Programming (MirrorDefProgEnabled): must be enabled             |  |  |
| Multiplicity   | 11   |  |  |
| Туре           | BOOLEAN  |  |  |
| Default value  | false  |  |  |



| Configuration class | VariantPreCompile:         | VariantPreCompile |
|---------------------|----------------------------|-------------------|
| Origin              | Elektrobit Automotive GmbH |                   |

| Parameter Name      | MirrorPostcondAssertEnabled   |  |
|---------------------|---|--|
| Label               | Enable Postcondition Assertions   |  |
| Description         | Enables handling of postcondition assertion checks reported from the module Mirror.   |  |
|                     | <ul> <li>Dependency on parameter(s):</li> <li>■ Enable Development Error Detection (MirrorDevErrorDetect): must be enabled</li> <li>■ Enable Defensive Programming (MirrorDefProgEnabled): must be enabled</li> </ul> |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPreCompile: VariantPreCompile  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name      | MirrorStaticAssertEnabled  |                                      |
|---------------------|--|--------------------------------------|
| Label               | Enable Static Assertions   |                                      |
| Description         | Enables handling of static assertion ched                                    | cks reported from the module Mirror. |
|                     | Dependency on parameter(s):  |                                      |
|                     | ► Enable Development Error Detection (MirrorDevErrorDetect): must be enabled |                                      |
|                     | ► Enable Defensive Programming (MirrorDefProgEnabled): must be enabled       |                                      |
| Multiplicity        | 11   |                                      |
| Туре                | BOOLEAN  |                                      |
| Default value       | false  |                                      |
| Configuration class | VariantPreCompile: VariantPreCompile   |                                      |
| Origin              | Elektrobit Automotive GmbH   |                                      |

| Parameter Name Mirror | rUnreachAssertEnabled |
|-----------------------|-----------------------|
|-----------------------|-----------------------|



| Label               | Enable Unreachable Code Assertions   |  |
|---------------------|--|--|
| Description         | Enables handling of unreachable code assertion checks reported from the module Mirror. |  |
|                     | Dependency on parameter(s):  |  |
|                     | ► Enable Development Error Detection (MirrorDevErrorDetect): must be enabled           |  |
|                     | ► Enable Defensive Programming (MirrorDefProgEnabled): must be enabled                 |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPreCompile: VariantPreCompile   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

| Parameter Name      | MirrorInvariantAssertEnabled   |  |
|---------------------|--|--|
| Label               | Enable Invariant Assertions  |  |
| Description         | Enables handling of invariant assertion checks reported from functions of the module Mirror. |  |
|                     | Dependency on parameter(s):  |  |
|                     | ► Enable Development Error Detection (MirrorDevErrorDetect): must be enabled                 |  |
|                     | ► Enable Defensive Programming (MirrorDefProgEnabled): must be enabled                       |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPreCompile: VariantPreCompile   |  |
| Origin              | Elektrobit Automotive GmbH   |  |

# 5.5.1.3. MirrorConfigSet

| Containers included |              |             |
|---------------------|--------------|-------------|
| Container name      | Multiplicity | Description |



| Containers included        |    |  |
|----------------------------|----|--|
| <u>MirrorDestNetwork</u>   | 1n | Destination bus to which frames are sent by the Bus Mirroring module.  |
| <u>MirrorSourceNetwork</u> | 1n | Source bus from which frames are received by the Bus Mirroring module. |

| Parameters included         |              |
|-----------------------------|--------------|
| Parameter name              | Multiplicity |
| MirrorInitialDestNetworkRef | 11           |

| Parameter Name      | MirrorInitialDestNetworkRef   |                   |
|---------------------|---|-------------------|
| Description         | Reference to the destination bus that is selected after initialization of the Bus Mirroring module. |                   |
| Multiplicity        | 11  |                   |
| Туре                | REFERENCE   |                   |
| Configuration class | VariantLinkTime: VariantLinkTime  |                   |
|                     | VariantPostBuild:   | VariantPostBuild  |
|                     | VariantPreCompile:  | VariantPreCompile |
| Origin              | AUTOSAR_ECUC  |                   |

### 5.5.1.4. MirrorDestNetwork

| Containers included             |              |  |
|---------------------------------|--------------|--|
| Container name                  | Multiplicity | Description  |
| MirrorDestNetworklp             | 11           | Destination bus representing an IP network.          |
| <u>MirrorDestNetworkFlexRay</u> | 11           | Destination bus representing a FlexRay network.      |
| <u>MirrorDestNetworkCan</u>     | 11           | Destination bus representing a CAN network.          |
| <u>MirrorDestNetworkCdd</u>     | 11           | Destination bus representing a user defined network. |

### 5.5.1.5. MirrorDestNetworklp

| Containers included |              |             |
|---------------------|--------------|-------------|
| Container name      | Multiplicity | Description |



| Containers included |    |   |
|---------------------|----|---|
| MirrorDestPdu       | 11 | I-PDU used for transmission of the mirrored frames on the |
|                     |    | destination bus.  |

| Parameters included            |    |  |
|--------------------------------|----|--|
| Parameter name Multiplicity    |    |  |
| MirrorDestQueueSize            | 11 |  |
| MirrorDestTransmissionDeadline | 01 |  |
| MirrorNetworkId                | 11 |  |
| MirrorComMNetworkHandleRef     | 11 |  |
| MirrorTxConfirmationTimeout    | 11 |  |

| Parameter Name      | MirrorDestQueueSize          |   |  |
|---------------------|------------------------------|---|--|
| Description         | Number of frames that can be | stored in the output queue for the destination bus. |  |
| Multiplicity        | 11                           | 11  |  |
| Туре                | INTEGER                      | INTEGER   |  |
| Default value       | 20                           | 20  |  |
| Range               | <=65535                      |   |  |
|                     | >=1                          |   |  |
| Configuration class | VariantLinkTime:             | VariantLinkTime                                     |  |
|                     | VariantPostBuild:            | VariantPostBuild                                    |  |
|                     | VariantPreCompile:           | VariantPreCompile                                   |  |
| Origin              | AUTOSAR_ECUC                 |   |  |

| Parameter Name      | MirrorDestTransmissionDeadline  |                  |
|---------------------|---|------------------|
| Description         | Time in seconds after which the collection of source frames into the destination frame stopped and the frame is sent at the latest. |                  |
| Multiplicity        | 01  |                  |
| Туре                | FLOAT   |                  |
| Default value       | 0.1   |                  |
| Range               | <=0.655   |                  |
|                     | >=0.001   |                  |
| Configuration class | VariantLinkTime: VariantLinkTime  |                  |
|                     | VariantPostBuild:   | VariantPostBuild |



|        | VariantPreCompile: | VariantPreCompile |
|--------|--------------------|-------------------|
| Origin | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorNetworkId                  |                   |  |
|---------------------|----------------------------------|-------------------|--|
| Description         | Network ID of the bus.           |                   |  |
| Multiplicity        | 11                               |                   |  |
| Туре                | INTEGER                          | INTEGER           |  |
| Range               | <=255                            |                   |  |
|                     | >=0                              |                   |  |
| Configuration class | VariantLinkTime: VariantLinkTime |                   |  |
|                     | VariantPostBuild:                | VariantPostBuild  |  |
|                     | VariantPreCompile:               | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC                     |                   |  |

| Parameter Name      | MirrorComMNetworkHandleRef |   |  |
|---------------------|----------------------------|---|--|
| Description         | Reference to the ComMChann | Reference to the ComMChannel that represents the bus. |  |
| Multiplicity        | 11                         | 11  |  |
| Туре                | REFERENCE                  | REFERENCE   |  |
| Configuration class | VariantLinkTime:           | VariantLinkTime: VariantLinkTime                      |  |
|                     | VariantPostBuild:          | VariantPostBuild                                      |  |
|                     | VariantPreCompile:         | VariantPreCompile                                     |  |
| Origin              | AUTOSAR_ECUC               |   |  |

| Parameter Name      | MirrorTxConfirmationTimeout  |  |
|---------------------|--|--|
| Description         | Timeout in seconds for the Mirror Tx confirmation. After this time the Mirror assumes that the destination I-PDU could not be transmitted. |  |
| Multiplicity        | 11   |  |
| Туре                | FLOAT  |  |
| Default value       | 0.3  |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |  |
|                     | VariantPostBuild: VariantPostBuild   |  |
|                     | VariantPreCompile: VariantPreCompile   |  |
| Origin              | AUTOSAR_ECUC   |  |



### 5.5.1.6. MirrorDestPdu

| Parameters included              |    |  |
|----------------------------------|----|--|
| Parameter name Multiplicity      |    |  |
| MirrorDestPduld                  | 11 |  |
| MirrorDestPduUsesTriggerTransmit | 11 |  |
| MirrorDestPduRef                 | 11 |  |

| Parameter Name      | MirrorDestPduld                              |   |  |
|---------------------|--|---|--|
| Description         | I-PDU identifier used for TxCor              | I-PDU identifier used for TxConfirmation from PduR. |  |
| Multiplicity        | 11   | 11  |  |
| Туре                | INTEGER                                      |   |  |
| Configuration class | VariantLinkTime: VariantLinkTime             |   |  |
|                     | VariantPostBuild: VariantPostBuild           |   |  |
|                     | VariantPreCompile:         VariantPreCompile |   |  |
| Origin              | AUTOSAR_ECUC                                 |   |  |

| Parameter Name      | MirrorDestPduUsesTriggerTransmit           |  |
|---------------------|--|--|
| Description         | Switches transmission via TriggerTransmit. |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN                                    |  |
| Configuration class | VariantLinkTime: VariantLinkTime           |  |
|                     | VariantPostBuild: VariantPostBuild         |  |
|                     | VariantPreCompile: VariantPreCompile       |  |
| Origin              | AUTOSAR_ECUC                               |  |

| Parameter Name      | MirrorDestPduRef                                    |  |
|---------------------|---|--|
| Description         | Reference to the Pdu object representing the I-PDU. |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantLinkTime: VariantLinkTime                    |  |
|                     | VariantPostBuild: VariantPostBuild                  |  |
|                     | VariantPreCompile: VariantPreCompile                |  |
| Origin              | AUTOSAR_ECUC  |  |



# 5.5.1.7. MirrorDestNetworkFlexRay

| Containers included  |              |  |
|----------------------|--------------|--|
| Container name       | Multiplicity | Description  |
| <u>MirrorDestPdu</u> | 1n           | I-PDU used for transmission of the mirrored frames on the destination bus. |

| Parameters included               |              |  |
|-----------------------------------|--------------|--|
| Parameter name                    | Multiplicity |  |
| MirrorDestQueueSize               | 11           |  |
| MirrorDestTransmissionDeadline    | 01           |  |
| MirrorNetworkId                   | 11           |  |
| <u>MirrorComMNetworkHandleRef</u> | 11           |  |

| Parameter Name      | MirrorDestQueueSize  |         |  |
|---------------------|--|---------|--|
| Description         | Number of frames that can be stored in the output queue for the destination bus. |         |  |
| Multiplicity        | 11   |         |  |
| Туре                | INTEGER  | INTEGER |  |
| Default value       | 20   |         |  |
| Range               | <=65535  |         |  |
|                     | >=1  |         |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |         |  |
|                     | VariantPostBuild: VariantPostBuild   |         |  |
|                     | VariantPreCompile: VariantPreCompile   |         |  |
| Origin              | AUTOSAR_ECUC   |         |  |

| Parameter Name | MirrorDestTransmissionDeadline  |
|----------------|---|
| Description    | Time in seconds after which the collection of source frames into the destination frame stopped and the frame is sent at the latest. |
| Multiplicity   | 01  |
| Туре           | FLOAT   |
| Default value  | 0.1   |
| Range          | <=0.655   |
|                | >=0.001   |



| Configuration class | VariantLinkTime:   | VariantLinkTime   |
|---------------------|--------------------|-------------------|
|                     | VariantPostBuild:  | VariantPostBuild  |
|                     | VariantPreCompile: | VariantPreCompile |
| Origin              | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorNetworkId                      |         |  |
|---------------------|--------------------------------------|---------|--|
| Description         | Network ID of the bus.               |         |  |
| Multiplicity        | 11                                   |         |  |
| Туре                | INTEGER                              | INTEGER |  |
| Range               | <=255                                |         |  |
|                     | >=0                                  |         |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |         |  |
|                     | VariantPostBuild: VariantPostBuild   |         |  |
|                     | VariantPreCompile: VariantPreCompile |         |  |
| Origin              | AUTOSAR_ECUC                         |         |  |

| Parameter Name      | MirrorComMNetworkHandleRef                            |    |  |
|---------------------|---|----|--|
| Description         | Reference to the ComMChannel that represents the bus. |    |  |
| Multiplicity        | 11  | 11 |  |
| Туре                | REFERENCE   |    |  |
| Configuration class | VariantLinkTime: VariantLinkTime                      |    |  |
|                     | VariantPostBuild: VariantPostBuild                    |    |  |
|                     | VariantPreCompile: VariantPreCompile                  |    |  |
| Origin              | AUTOSAR_ECUC  |    |  |

### 5.5.1.8. MirrorDestPdu

| Parameters included              |    |
|----------------------------------|----|
| Parameter name Multiplicity      |    |
| MirrorDestPduld                  | 11 |
| MirrorDestPduUsesTriggerTransmit | 11 |
| <u>MirrorDestPduRef</u>          | 11 |



| Parameter Name      | MirrorDestPduld                                     |                   |
|---------------------|---|-------------------|
| Description         | I-PDU identifier used for TxConfirmation from PduR. |                   |
| Multiplicity        | 11  |                   |
| Туре                | INTEGER   |                   |
| Range               | <=65535   |                   |
|                     | >=0   |                   |
| Configuration class | VariantLinkTime: VariantLinkTime                    |                   |
|                     | VariantPostBuild:                                   | VariantPostBuild  |
|                     | VariantPreCompile:                                  | VariantPreCompile |
| Origin              | AUTOSAR_ECUC  |                   |

| Parameter Name      | MirrorDestPduUsesTriggerTransmit           |                   |
|---------------------|--|-------------------|
| Description         | Switches transmission via TriggerTransmit. |                   |
| Multiplicity        | 11   |                   |
| Туре                | BOOLEAN                                    |                   |
| Configuration class | VariantLinkTime:                           | VariantLinkTime   |
|                     | VariantPostBuild:                          | VariantPostBuild  |
|                     | VariantPreCompile:                         | VariantPreCompile |
| Origin              | AUTOSAR_ECUC                               |                   |

| Parameter Name      | MirrorDestPduRef                                    |                   |
|---------------------|---|-------------------|
| Description         | Reference to the Pdu object representing the I-PDU. |                   |
| Multiplicity        | 11  |                   |
| Туре                | REFERENCE   |                   |
| Configuration class | VariantLinkTime:                                    | VariantLinkTime   |
|                     | VariantPostBuild:                                   | VariantPostBuild  |
|                     | VariantPreCompile:                                  | VariantPreCompile |
| Origin              | AUTOSAR_ECUC  |                   |

### 5.5.1.9. MirrorDestNetworkCan

| Containers included |              |             |
|---------------------|--------------|-------------|
| Container name      | Multiplicity | Description |



| Containers included  |    |   |
|----------------------|----|---|
| <u>MirrorDestPdu</u> | 1n | I-PDU used for transmission of the mirrored frames on the |
|                      |    | destination bus.  |

| Parameters included        |              |  |
|----------------------------|--------------|--|
| Parameter name             | Multiplicity |  |
| MirrorDestQueueSize        | 11           |  |
| MirrorNetworkId            | 11           |  |
| MirrorStatusCanId          | 01           |  |
| MirrorComMNetworkHandleRef | 11           |  |

| Parameter Name      | MirrorDestQueueSize              |  |  |
|---------------------|----------------------------------|--|--|
| Description         | Number of frames that can be s   | Number of frames that can be stored in the output queue for the destination bus. |  |
| Multiplicity        | 11                               | 11   |  |
| Туре                | INTEGER                          | INTEGER  |  |
| Default value       | 20                               |  |  |
| Range               | <=65535                          |  |  |
|                     | >=1                              |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime |  |  |
|                     | VariantPostBuild:                | VariantPostBuild   |  |
|                     | VariantPreCompile:               | VariantPreCompile  |  |
| Origin              | AUTOSAR_ECUC                     |  |  |

| Parameter Name      | MirrorNetworkId                  |                        |  |
|---------------------|----------------------------------|------------------------|--|
| Description         | Network ID of the bus.           | Network ID of the bus. |  |
| Multiplicity        | 11                               | 11                     |  |
| Туре                | INTEGER                          |                        |  |
| Range               | <=255<br>>=0                     |                        |  |
|                     |                                  |                        |  |
| Configuration class | VariantLinkTime: VariantLinkTime |                        |  |
|                     | VariantPostBuild:                | VariantPostBuild       |  |
|                     | VariantPreCompile:               | VariantPreCompile      |  |
| Origin              | AUTOSAR_ECUC                     |                        |  |



| Parameter Name      | MirrorStatusCanId                    |                                 |  |
|---------------------|--------------------------------------|---------------------------------|--|
| Description         | CAN ID of the CAN status frame.      | CAN ID of the CAN status frame. |  |
| Multiplicity        | 01                                   | 01                              |  |
| Туре                | INTEGER                              |                                 |  |
| Range               | <=4294967295                         |                                 |  |
|                     | >=0                                  |                                 |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |                                 |  |
|                     | VariantPostBuild: VariantPostBuild   |                                 |  |
|                     | VariantPreCompile: VariantPreCompile |                                 |  |
| Origin              | AUTOSAR_ECUC                         |                                 |  |

| Parameter Name      | MirrorComMNetworkHandleRef   |  |
|---------------------|--|--|
| Description         | Reference to the ComMChannel that represents the bus.  |  |
| Multiplicity        | 11   |  |
| Туре                | REFERENCE  |  |
| Configuration class | VariantLinkTime:         VariantLinkTime           VariantPostBuild:         VariantPostBuild           VariantPreCompile:         VariantPreCompile |  |
|                     |  |  |
|                     |  |  |
| Origin              | AUTOSAR_ECUC   |  |

## 5.5.1.10. MirrorDestPdu

| Parameters included              |    |  |
|----------------------------------|----|--|
| Parameter name Multiplicity      |    |  |
| MirrorDestPduld                  | 11 |  |
| MirrorDestPduUsesTriggerTransmit | 11 |  |
| <u>MirrorDestPduRef</u>          | 11 |  |

| Parameter Name | MirrorDestPduId                                     |
|----------------|---|
| Description    | I-PDU identifier used for TxConfirmation from PduR. |
| Multiplicity   | 11  |
| Туре           | INTEGER   |
| Range          | <=65535   |



|                     | >=0   |                   |
|---------------------|---|-------------------|
| Configuration class | VariantLinkTime:     VariantLinkTime       VariantPostBuild:     VariantPostBuild |                   |
|                     |   |                   |
|                     | VariantPreCompile:  | VariantPreCompile |
| Origin              | AUTOSAR_ECUC  |                   |

| Parameter Name      | MirrorDestPduUsesTriggerTransmit           |  |
|---------------------|--|--|
| Description         | Switches transmission via TriggerTransmit. |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN                                    |  |
| Configuration class | VariantLinkTime: VariantLinkTime           |  |
|                     | VariantPostBuild: VariantPostBuild         |  |
|                     | VariantPreCompile: VariantPreCompile       |  |
| Origin              | AUTOSAR_ECUC                               |  |

| Parameter Name      | MirrorDestPduRef  |  |
|---------------------|---|--|
| Description         | Reference to the Pdu object representing the I-PDU.                               |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantLinkTime:     VariantLinkTime       VariantPostBuild:     VariantPostBuild |  |
|                     |   |  |
|                     | VariantPreCompile: VariantPreCompile  |  |
| Origin              | AUTOSAR_ECUC  |  |

## 5.5.1.11. MirrorDestNetworkCdd

| Containers included |              |  |
|---------------------|--------------|--|
| Container name      | Multiplicity | Description  |
| MirrorDestPdu       | 1n           | I-PDU used for transmission of the mirrored frames on the destination bus. |

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |



| Parameters included            |    |  |
|--------------------------------|----|--|
| MirrorDestQueueSize            | 11 |  |
| MirrorDestTransmissionDeadline | 01 |  |
| MirrorNetworkId                | 11 |  |
| MirrorComMNetworkHandleRef     | 11 |  |

| Parameter Name      | MirrorDestQueueSize                |  |  |
|---------------------|------------------------------------|--|--|
| Description         | Number of frames that can be s     | Number of frames that can be stored in the output queue for the destination bus. |  |
| Multiplicity        | 11                                 | 11   |  |
| Туре                | INTEGER                            | INTEGER  |  |
| Default value       | 20                                 |  |  |
| Range               | <=65535                            |  |  |
|                     | >=1                                |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |  |  |
|                     | VariantPostBuild: VariantPostBuild |  |  |
|                     | VariantPreCompile:                 | VariantPreCompile  |  |
| Origin              | AUTOSAR_ECUC                       |  |  |

| Parameter Name      | MirrorDestTransmissionDeadline  |  |
|---------------------|---|--|
| Description         | Time in seconds after which the collection of source frames into the destination frame stopped and the frame is sent at the latest. |  |
| Multiplicity        | 01  |  |
| Туре                | FLOAT   |  |
| Default value       | 0.1   |  |
| Range               | <=0.655   |  |
|                     | >=0.001   |  |
| Configuration class | VariantLinkTime: VariantLinkTime  |  |
|                     | VariantPostBuild: VariantPostBuild  |  |
|                     | VariantPreCompile: VariantPreCompile  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name | MirrorNetworkId        |  |
|----------------|------------------------|--|
| Description    | Network ID of the bus. |  |
| Multiplicity   | 11                     |  |



| Туре                | INTEGER                          |                   |  |
|---------------------|----------------------------------|-------------------|--|
| Range               | <=255                            |                   |  |
|                     | >=0                              |                   |  |
| Configuration class | VariantLinkTime: VariantLinkTime |                   |  |
|                     | VariantPostBuild:                | VariantPostBuild  |  |
|                     | VariantPreCompile:               | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC                     |                   |  |

| Parameter Name      | MirrorComMNetworkHandleRef                            |                   |  |
|---------------------|---|-------------------|--|
| Description         | Reference to the ComMChannel that represents the bus. |                   |  |
| Multiplicity        | 11  |                   |  |
| Туре                | REFERENCE   |                   |  |
| Configuration class | VariantLinkTime: VariantLinkTime                      |                   |  |
|                     | VariantPostBuild:                                     | VariantPostBuild  |  |
|                     | VariantPreCompile:                                    | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC  |                   |  |

## 5.5.1.12. MirrorDestPdu

| Parameters included              |              |  |  |
|----------------------------------|--------------|--|--|
| Parameter name                   | Multiplicity |  |  |
| MirrorDestPduld                  | 11           |  |  |
| MirrorDestPduUsesTriggerTransmit | 11           |  |  |
| MirrorDestPduRef                 | 11           |  |  |

| Parameter Name      | MirrorDestPduId                                     |                  |  |
|---------------------|---|------------------|--|
| Description         | I-PDU identifier used for TxConfirmation from PduR. |                  |  |
| Multiplicity        | 11  |                  |  |
| Туре                | INTEGER   |                  |  |
| Range               | <=65535   |                  |  |
|                     | >=0   |                  |  |
| Configuration class | VariantLinkTime:                                    | VariantLinkTime  |  |
|                     | VariantPostBuild:                                   | VariantPostBuild |  |



|        | VariantPreCompile: | VariantPreCompile |  |
|--------|--------------------|-------------------|--|
| Origin | AUTOSAR_ECUC       |                   |  |

| Parameter Name      | MirrorDestPduUsesTriggerTransmit           |                   |  |
|---------------------|--|-------------------|--|
| Description         | Switches transmission via TriggerTransmit. |                   |  |
| Multiplicity        | 11   |                   |  |
| Туре                | BOOLEAN                                    |                   |  |
| Configuration class | VariantLinkTime: VariantLinkTime           |                   |  |
|                     | VariantPostBuild:                          | VariantPostBuild  |  |
|                     | VariantPreCompile:                         | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC                               |                   |  |

| Parameter Name      | MirrorDestPduRef                                    |                   |  |
|---------------------|---|-------------------|--|
| Description         | Reference to the Pdu object representing the I-PDU. |                   |  |
| Multiplicity        | 11  |                   |  |
| Туре                | REFERENCE   |                   |  |
| Configuration class | VariantLinkTime: VariantLinkTime                    |                   |  |
|                     | VariantPostBuild:                                   | VariantPostBuild  |  |
|                     | VariantPreCompile:                                  | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC  |                   |  |

## 5.5.1.13. MirrorSourceNetwork

| Containers included           |              |  |  |
|-------------------------------|--------------|--|--|
| Container name                | Multiplicity | Description                                |  |
| <u>MirrorSourceNetworkCan</u> | 11           | Source bus representing a CAN network.     |  |
| <u>MirrorSourceNetworkLin</u> | 11           | Source bus representing a LIN network.     |  |
| MirrorSourceNetworkFlexRay    | 11           | Source bus representing a FlexRay network. |  |

## 5.5.1.14. MirrorSourceNetworkCan

| Containers included |              |             |
|---------------------|--------------|-------------|
| Container name      | Multiplicity | Description |



| Containers included                    |      |                                       |
|--|------|---------------------------------------|
| <u>MirrorSourceCanFilter</u>           | 0255 | Pre-configured filter for CAN frames. |
| MirrorSourceCan-<br>MaskBasedIdMapping | 0n   | Rule for remapping a set of CAN IDs.  |
| MirrorSourceCanSin-<br>gleIdMapping    | 0n   | Rule for remapping a single CAN ID.   |

| Parameters included           |              |  |  |
|-------------------------------|--------------|--|--|
| Parameter name                | Multiplicity |  |  |
| MirrorNetworkId               | 11           |  |  |
| MirrorSourceMaxDynamicFilters | 11           |  |  |
| MirrorComMNetworkHandleRef    | 11           |  |  |

| Parameter Name      | MirrorNetworkId                    |                        |  |  |
|---------------------|------------------------------------|------------------------|--|--|
| Description         | Network ID of the bus.             | Network ID of the bus. |  |  |
| Multiplicity        | 11                                 | 11                     |  |  |
| Туре                | INTEGER                            |                        |  |  |
| Range               | <=255                              |                        |  |  |
|                     | >=0                                |                        |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |                        |  |  |
|                     | VariantPostBuild: VariantPostBuild |                        |  |  |
|                     | VariantPreCompile:                 | VariantPreCompile      |  |  |
| Origin              | AUTOSAR_ECUC                       |                        |  |  |

| Parameter Name      | MirrorSourceMaxDynamicFilters  |  |
|---------------------|--|--|
| Description         | Maximum number of filters that can be dynamically added using Mirror_AddXxxFilter(). |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Default value       | 5  |  |
| Range               | <=255  |  |
|                     | >=0  |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |  |
|                     | VariantPostBuild: VariantPostBuild   |  |



|        | VariantPreCompile: | VariantPreCompile |
|--------|--------------------|-------------------|
| Origin | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorComMNetworkHandleRef                            |                  |
|---------------------|---|------------------|
| Description         | Reference to the ComMChannel that represents the bus. |                  |
| Multiplicity        | 11  |                  |
| Туре                | REFERENCE   |                  |
| Configuration class | VariantLinkTime: VariantLinkTime                      |                  |
|                     | VariantPostBuild:                                     | VariantPostBuild |
|                     | VariantPreCompile: VariantPreCompile                  |                  |
| Origin              | AUTOSAR_ECUC  |                  |

## 5.5.1.15. MirrorSourceCanFilter

| Containers included              |              |  |
|----------------------------------|--------------|--|
| Container name                   | Multiplicity | Description                                      |
| <u>MirrorSourceCanFilterMask</u> | 11           | Pre-configured mask based filter for CAN frames. |
| MirrorSourceCanFilterRange       | 11           | Pre-configured range filter for CAN frames.      |

## 5.5.1.16. MirrorSourceCanFilterMask

| Parameters included            |              |  |
|--------------------------------|--------------|--|
| Parameter name                 | Multiplicity |  |
| MirrorSourceCanFilterCanIdCode | 11           |  |
| MirrorSourceCanFilterCanIdMask | 11           |  |
| MirrorSourceCanFilterId        | 11           |  |

| Parameter Name | MirrorSourceCanFilterCanIdCode |  |
|----------------|--------------------------------|--|
| Description    | Value to match masked CAN IDs. |  |
| Multiplicity   | 11                             |  |
| Туре           | INTEGER                        |  |
| Range          | <=4294967295                   |  |
|                | >=0                            |  |



| Configuration class | VariantLinkTime:   | VariantLinkTime   |
|---------------------|--------------------|-------------------|
|                     | VariantPostBuild:  | VariantPostBuild  |
|                     | VariantPreCompile: | VariantPreCompile |
| Origin              | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorSourceCanFilterCanldMask       |  |  |
|---------------------|--------------------------------------|--|--|
| Description         | Mask applied to CAN IDs befor        | Mask applied to CAN IDs before comparison. |  |
| Multiplicity        | 11                                   | 11   |  |
| Туре                | INTEGER                              | INTEGER                                    |  |
| Range               | <=4294967295                         |  |  |
|                     | >=0                                  |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |  |  |
|                     | VariantPostBuild: VariantPostBuild   |  |  |
|                     | VariantPreCompile: VariantPreCompile |  |  |
| Origin              | AUTOSAR_ECUC                         |  |  |

| Parameter Name      | MirrorSourceCanFilterId                             |  |  |
|---------------------|---|--|--|
| Description         | Unique identifier of the pre-configured CAN filter. |  |  |
| Multiplicity        | 11  |  |  |
| Туре                | INTEGER   |  |  |
| Range               | <=255   |  |  |
|                     | >=0   |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime                    |  |  |
|                     | VariantPostBuild: VariantPostBuild                  |  |  |
|                     | VariantPreCompile: VariantPreCompile                |  |  |
| Origin              | AUTOSAR_ECUC  |  |  |

# 5.5.1.17. MirrorSourceCanFilterRange

| Parameters included         |    |  |
|-----------------------------|----|--|
| Parameter name Multiplicity |    |  |
| MirrorSourceCanFilterId     | 11 |  |



| Parameters included               |    |  |
|-----------------------------------|----|--|
| <u>MirrorSourceCanFilterLower</u> | 11 |  |
| <u>MirrorSourceCanFilterUpper</u> | 11 |  |

| Parameter Name      | MirrorSourceCanFilterId          | MirrorSourceCanFilterId                             |  |
|---------------------|----------------------------------|---|--|
| Description         | Unique identifier of the pre-con | Unique identifier of the pre-configured CAN filter. |  |
| Multiplicity        | 11                               | 11  |  |
| Туре                | INTEGER                          | INTEGER   |  |
| Range               | <=255                            |   |  |
|                     | >=0                              |   |  |
| Configuration class | VariantLinkTime:                 | VariantLinkTime                                     |  |
|                     | VariantPostBuild:                | VariantPostBuild                                    |  |
|                     | VariantPreCompile:               | VariantPreCompile                                   |  |
| Origin              | AUTOSAR_ECUC                     |   |  |

| Parameter Name      | MirrorSourceCanFilterLower       |   |  |
|---------------------|----------------------------------|---|--|
| Description         | Lowest CAN ID that is accepted   | Lowest CAN ID that is accepted by the filter. |  |
| Multiplicity        | 11                               | 11  |  |
| Туре                | INTEGER                          | INTEGER                                       |  |
| Range               | <=4294967295<br>>=0              |   |  |
|                     |                                  |   |  |
| Configuration class | VariantLinkTime: VariantLinkTime |   |  |
|                     | VariantPostBuild:                | VariantPostBuild                              |  |
|                     | VariantPreCompile:               | VariantPreCompile                             |  |
| Origin              | AUTOSAR_ECUC                     |   |  |

| Parameter Name      | MirrorSourceCanFilterUpper                     |                 |
|---------------------|--|-----------------|
| Description         | Highest CAN ID that is accepted by the filter. |                 |
| Multiplicity        | 11   |                 |
| Туре                | INTEGER  |                 |
| Range               | <=4294967295                                   |                 |
|                     | >=0  |                 |
| Configuration class | VariantLinkTime:                               | VariantLinkTime |



|        | VariantPostBuild:  | VariantPostBuild  |
|--------|--------------------|-------------------|
|        | VariantPreCompile: | VariantPreCompile |
| Origin | AUTOSAR_ECUC       |                   |

# 5.5.1.18. MirrorSourceCanMaskBasedIdMapping

| Parameters included                              |              |
|--|--------------|
| Parameter name                                   | Multiplicity |
| MirrorSourceCanMaskBasedIdMappingDestBaseId      | 11           |
| MirrorSourceCanMaskBasedIdMappingSourceCanIdCode | 11           |
| MirrorSourceCanMaskBasedIdMappingSourceCanIdMask | 11           |

| Parameter Name      | MirrorSourceCanMaskBasedIdMappingDestBaseId  |                   |
|---------------------|--|-------------------|
| Description         | Base ID merged with the masked parts of the original CAN ID to form the mapped CAN ID. |                   |
| Multiplicity        | 11   |                   |
| Туре                | INTEGER  |                   |
| Range               | <=4294967295<br>>=0  |                   |
|                     |  |                   |
| Configuration class | VariantLinkTime: VariantLinkTime   |                   |
|                     | VariantPostBuild:  | VariantPostBuild  |
|                     | VariantPreCompile:   | VariantPreCompile |
| Origin              | AUTOSAR_ECUC   |                   |

| Parameter Name      | MirrorSourceCanMaskBasedIdMappingSourceCanIdCode |   |  |
|---------------------|--|---|--|
| Description         | Value to match masked original                   | Value to match masked original CAN IDs. |  |
| Multiplicity        | 11   |   |  |
| Туре                | INTEGER  |   |  |
| Range               | <=4294967295                                     |   |  |
|                     | >=0  |   |  |
| Configuration class | VariantLinkTime:                                 | VariantLinkTime                         |  |
|                     | VariantPostBuild:                                | VariantPostBuild                        |  |
|                     | VariantPreCompile:                               | VariantPreCompile                       |  |



| <b>Origin</b> AUTO | OSAR_ECUC |
|--------------------|-----------|
|--------------------|-----------|

| Parameter Name      | MirrorSourceCanMaskBasedIdMappingSourceCanIdMask |   |  |
|---------------------|--|---|--|
| Description         | Mask applied to original CAN I                   | Mask applied to original CAN IDs before comparison. |  |
| Multiplicity        | 11   | 11  |  |
| Туре                | INTEGER  |   |  |
| Range               | <=4294967295<br>>=0                              |   |  |
|                     |  |   |  |
| Configuration class | VariantLinkTime: VariantLinkTime                 |   |  |
|                     | VariantPostBuild:                                | VariantPostBuild                                    |  |
|                     | VariantPreCompile:                               | VariantPreCompile                                   |  |
| Origin              | AUTOSAR_ECUC                                     |   |  |

# 5.5.1.19. MirrorSourceCanSingleIdMapping

| Parameters included                       |              |
|---|--------------|
| Parameter name                            | Multiplicity |
| MirrorSourceCanSingleIdMappingDestCanId   | 11           |
| MirrorSourceCanSingleIdMappingSourceCanId | 11           |

| Parameter Name      | MirrorSourceCanSingleIdMappingDestCanId |                   |  |
|---------------------|---|-------------------|--|
| Description         | Mapped CAN ID.                          | Mapped CAN ID.    |  |
| Multiplicity        | 11                                      | 11                |  |
| Туре                | INTEGER                                 |                   |  |
| Range               | <=4294967295                            |                   |  |
|                     | >=0                                     |                   |  |
| Configuration class | VariantLinkTime: VariantLinkTime        |                   |  |
|                     | VariantPostBuild:                       | VariantPostBuild  |  |
|                     | VariantPreCompile:                      | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC                            |                   |  |

| Parameter Name | MirrorSourceCanSingleIdMappingSourceCanId |  |
|----------------|---|--|
| Description    | Original CAN ID.                          |  |



| Multiplicity        | 11                                   |  |
|---------------------|--------------------------------------|--|
| Туре                | INTEGER                              |  |
| Range               | <=4294967295                         |  |
|                     | >=0                                  |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |  |
|                     | VariantPostBuild: VariantPostBuild   |  |
|                     | VariantPreCompile: VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC                         |  |

## 5.5.1.20. MirrorSourceNetworkLin

| Containers included        |              |  |
|----------------------------|--------------|--|
| Container name             | Multiplicity | Description  |
| MirrorSourceLinFilter      | 0255         | Pre-configured filter for LIN frames.                |
| MirrorSourceLinToCanldMap- | 0n           | Rule for mapping a LIN frame ID to a special CAN ID. |
| ping                       |              |  |

| Parameters included           |              |  |
|-------------------------------|--------------|--|
| Parameter name                | Multiplicity |  |
| MirrorNetworkId               | 11           |  |
| MirrorComMNetworkHandleRef    | 11           |  |
| MirrorSourceLinToCanBaseId    | 11           |  |
| MirrorSourceMaxDynamicFilters | 11           |  |

| Parameter Name      | MirrorNetworkId                      |  |  |
|---------------------|--------------------------------------|--|--|
| Description         | Network ID of the bus.               |  |  |
| Multiplicity        | 11                                   |  |  |
| Туре                | INTEGER                              |  |  |
| Range               | <=255                                |  |  |
|                     | >=0                                  |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |  |  |
|                     | VariantPostBuild: VariantPostBuild   |  |  |
|                     | VariantPreCompile: VariantPreCompile |  |  |



| Origin | AUTOSAR_ECUC |
|--------|--------------|
|--------|--------------|

| Parameter Name      | MirrorComMNetworkHandleRef                            |  |
|---------------------|---|--|
| Description         | Reference to the ComMChannel that represents the bus. |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantLinkTime: VariantLinkTime                      |  |
|                     | VariantPostBuild: VariantPostBuild                    |  |
|                     | VariantPreCompile: VariantPreCompile                  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | MirrorSourceLinToCanBaseId           |  |  |
|---------------------|--------------------------------------|--|--|
| Description         | Base ID merged with the LIN fra      | Base ID merged with the LIN frame ID to form the CAN ID. |  |
| Multiplicity        | 11                                   |  |  |
| Туре                | INTEGER                              | INTEGER  |  |
| Range               | <=4294967295                         |  |  |
|                     | >=0                                  |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |  |  |
|                     | VariantPostBuild: VariantPostBuild   |  |  |
|                     | VariantPreCompile: VariantPreCompile |  |  |
| Origin              | AUTOSAR_ECUC                         |  |  |

| Parameter Name      | MirrorSourceMaxDynamicFilters                |   |  |
|---------------------|--|---|--|
| Description         | Maximum number of filters that dXxxFilter(). | Maximum number of filters that can be dynamically added using Mirror_Ad-dXxxFilter(). |  |
| Multiplicity        | 11   |   |  |
| Туре                | INTEGER                                      | INTEGER   |  |
| Default value       | 5  | 5   |  |
| Range               | <=255  | <=255   |  |
|                     | >=0  |   |  |
| Configuration class | VariantLinkTime:                             | VariantLinkTime: VariantLinkTime  |  |
|                     | VariantPostBuild: VariantPostBuild           |   |  |
|                     | VariantPreCompile: VariantPreCompile         |   |  |



| Origin | AUTOSAR_ECUC |
|--------|--------------|
|--------|--------------|

## 5.5.1.21. MirrorSourceLinFilter

| Containers included               |              |  |
|-----------------------------------|--------------|--|
| Container name                    | Multiplicity | Description                                      |
| <u>MirrorSourceLinFilterMask</u>  | 11           | Pre-configured mask based filter for LIN frames. |
| <u>MirrorSourceLinFilterRange</u> | 11           | Pre-configured range filter for LIN frames.      |

## 5.5.1.22. MirrorSourceLinFilterMask

| Parameters included            |    |  |
|--------------------------------|----|--|
| Parameter name Multiplicity    |    |  |
| MirrorSourceLinFilterId        | 11 |  |
| MirrorSourceLinFilterLinIdCode | 11 |  |
| MirrorSourceLinFilterLinIdMask | 11 |  |

| Parameter Name      | MirrorSourceLinFilterId              |   |  |
|---------------------|--------------------------------------|---|--|
| Description         | Unique identifier of the pre-cor     | Unique identifier of the pre-configured LIN filter. |  |
| Multiplicity        | 11                                   |   |  |
| Туре                | INTEGER                              | INTEGER   |  |
| Range               | <=255                                |   |  |
|                     | >=0                                  | >=0   |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |   |  |
|                     | VariantPostBuild: VariantPostBuild   |   |  |
|                     | VariantPreCompile: VariantPreCompile |   |  |
| Origin              | AUTOSAR_ECUC                         |   |  |

| Parameter Name | MirrorSourceLinFilterLinIdCode   |  |
|----------------|----------------------------------|--|
| Description    | Value to match masked frame IDs. |  |
| Multiplicity   | 11                               |  |
| Туре           | INTEGER                          |  |
| Range          | <=63                             |  |



|                     | >=0                              |                   |
|---------------------|----------------------------------|-------------------|
| Configuration class | VariantLinkTime: VariantLinkTime |                   |
|                     | VariantPostBuild:                | VariantPostBuild  |
|                     | VariantPreCompile:               | VariantPreCompile |
| Origin              | AUTOSAR_ECUC                     |                   |

| Parameter Name      | MirrorSourceLinFilterLinIdMask               |  |
|---------------------|--|--|
| Description         | Mask applied to frame IDs before comparison. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER                                      |  |
| Range               | <=63   |  |
|                     | >=0  |  |
| Configuration class | VariantLinkTime: VariantLinkTime             |  |
|                     | VariantPostBuild: VariantPostBuild           |  |
|                     | VariantPreCompile: VariantPreCompile         |  |
| Origin              | AUTOSAR_ECUC                                 |  |

# 5.5.1.23. MirrorSourceLinFilterRange

| Parameters included         |    |  |
|-----------------------------|----|--|
| Parameter name Multiplicity |    |  |
| MirrorSourceLinFilterId     | 11 |  |
| MirrorSourceLinFilterLower  | 11 |  |
| MirrorSourceLinFilterUpper  | 11 |  |

| Parameter Name      | MirrorSourceLinFilterId                   |   |  |
|---------------------|---|---|--|
| Description         | Unique identifier of the pre-configured L | Unique identifier of the pre-configured LIN filter. |  |
| Multiplicity        | 11  | 11  |  |
| Туре                | INTEGER                                   |   |  |
| Range               | <=255<br>>=0                              |   |  |
| Configuration class | VariantLinkTime:                          | VariantLinkTime                                     |  |



|        | VariantPostBuild:  | VariantPostBuild  |
|--------|--------------------|-------------------|
|        | VariantPreCompile: | VariantPreCompile |
| Origin | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorSourceLinFilterLower     |   |  |
|---------------------|--------------------------------|---|--|
| Description         | Lowest frame ID that is accept | Lowest frame ID that is accepted by the filter. |  |
| Multiplicity        | 11                             | 11  |  |
| Туре                | INTEGER                        | INTEGER   |  |
| Range               | <=63<br>>=0                    |   |  |
|                     |                                |   |  |
| Configuration class | VariantLinkTime:               | VariantLinkTime: VariantLinkTime                |  |
|                     | VariantPostBuild:              | VariantPostBuild                                |  |
|                     | VariantPreCompile:             | VariantPreCompile                               |  |
| Origin              | AUTOSAR_ECUC                   |   |  |

| Parameter Name      | MirrorSourceLinFilterUpper       |  |  |
|---------------------|----------------------------------|--|--|
| Description         | Highest frame ID that is accept  | Highest frame ID that is accepted by the filter. |  |
| Multiplicity        | 11                               | 11   |  |
| Туре                | INTEGER                          |  |  |
| Range               | <=63<br>>=0                      |  |  |
|                     |                                  |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime |  |  |
|                     | VariantPostBuild:                | VariantPostBuild                                 |  |
|                     | VariantPreCompile:               | VariantPreCompile                                |  |
| Origin              | AUTOSAR_ECUC                     |  |  |

# 5.5.1.24. MirrorSourceLinToCanldMapping

| Parameters included                   |              |  |
|---------------------------------------|--------------|--|
| Parameter name                        | Multiplicity |  |
| MirrorSourceLinToCanldMappingCanld 11 |              |  |
| MirrorSourceLinToCanIdMappingLinId    | 11           |  |



| Parameter Name      | MirrorSourceLinToCanldMappingCanld   |   |  |
|---------------------|--------------------------------------|---|--|
| Description         | CAN ID which lies outside of the     | CAN ID which lies outside of the range mapping. |  |
| Multiplicity        | 11                                   | 11  |  |
| Туре                | INTEGER                              | INTEGER   |  |
| Range               | <=4294967295<br>>=0                  |   |  |
|                     |                                      |   |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |   |  |
|                     | VariantPostBuild: VariantPostBuild   |   |  |
|                     | VariantPreCompile: VariantPreCompile |   |  |
| Origin              | AUTOSAR_ECUC                         |   |  |

| Parameter Name      | MirrorSourceLinToCanldMappingLinId                 |  |
|---------------------|--|--|
| Description         | Frame ID which is excluded from the range mapping. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Range               | <=63   |  |
|                     | >=0  |  |
| Configuration class | VariantLinkTime: VariantLinkTime                   |  |
|                     | VariantPostBuild: VariantPostBuild                 |  |
|                     | VariantPreCompile: VariantPreCompile               |  |
| Origin              | AUTOSAR_ECUC                                       |  |

## 5.5.1.25. MirrorSourceNetworkFlexRay

| Containers included              |              |   |
|----------------------------------|--------------|---|
| Container name                   | Multiplicity | Description                               |
| <u>MirrorSourceFlexRayFilter</u> | 0255         | Pre-configured filter for FlexRay frames. |

| Parameters included         |    |  |
|-----------------------------|----|--|
| Parameter name Multiplicity |    |  |
| MirrorNetworkId             | 11 |  |
| MirrorComMNetworkHandleRef  | 11 |  |



| Parameters included                  |    |
|--------------------------------------|----|
| <u>MirrorSourceMaxDynamicFilters</u> | 11 |

| Parameter Name      | MirrorNetworkId                  |                        |  |
|---------------------|----------------------------------|------------------------|--|
| Description         | Network ID of the bus.           | Network ID of the bus. |  |
| Multiplicity        | 11                               |                        |  |
| Туре                | INTEGER                          | INTEGER                |  |
| Range               | <=255                            |                        |  |
|                     | >=0                              |                        |  |
| Configuration class | VariantLinkTime: VariantLinkTime |                        |  |
|                     | VariantPostBuild:                | VariantPostBuild       |  |
|                     | VariantPreCompile:               | VariantPreCompile      |  |
| Origin              | AUTOSAR_ECUC                     |                        |  |

| Parameter Name      | MirrorComMNetworkHandleRef                            |                   |
|---------------------|---|-------------------|
| Description         | Reference to the ComMChannel that represents the bus. |                   |
| Multiplicity        | 11  |                   |
| Туре                | REFERENCE   |                   |
| Configuration class | VariantLinkTime: VariantLinkTime                      |                   |
|                     | VariantPostBuild:                                     | VariantPostBuild  |
|                     | VariantPreCompile:                                    | VariantPreCompile |
| Origin              | AUTOSAR_ECUC  |                   |

| Parameter Name      | MirrorSourceMaxDynamicFilters  |                  |  |
|---------------------|--|------------------|--|
| Description         | Maximum number of filters that can be dynamically added using Mirror_AddXxxFilter(). |                  |  |
| Multiplicity        | 11   |                  |  |
| Туре                | INTEGER  | INTEGER          |  |
| Default value       | 5  |                  |  |
| Range               | <=255  |                  |  |
|                     | >=0  |                  |  |
| Configuration class | VariantLinkTime:   | VariantLinkTime  |  |
|                     | VariantPostBuild:  | VariantPostBuild |  |



|        | VariantPreCompile: | VariantPreCompile |
|--------|--------------------|-------------------|
| Origin | AUTOSAR_ECUC       |                   |

# 5.5.1.26. MirrorSourceFlexRayFilter

| Parameters included                        |              |  |
|--|--------------|--|
| Parameter name                             | Multiplicity |  |
| MirrorSourceFlexRayFilterChannelAssignment | 11           |  |
| MirrorSourceFlexRayFilterCycleRepetition   | 11           |  |
| MirrorSourceFlexRayFilterId                | 11           |  |
| MirrorSourceFlexRayFilterLowerBaseCycle    | 11           |  |
| MirrorSourceFlexRayFilterLowerSlot         | 11           |  |
| MirrorSourceFlexRayFilterUpperBaseCycle    | 11           |  |
| MirrorSourceFlexRayFilterUpperSlot         | 11           |  |

| Parameter Name      | MirrorSourceFlexRayFilterChannelAssignment |                   |
|---------------------|--|-------------------|
| Description         | FlexRay channels accepted by the filter.   |                   |
| Multiplicity        | 11   |                   |
| Туре                | ENUMERATION                                |                   |
| Range               | MIRROR_FR_CHANNEL_A                        |                   |
|                     | MIRROR_FR_CHANNEL_AB                       |                   |
|                     | MIRROR_FR_CHANNEL_B                        |                   |
| Configuration class | VariantLinkTime: VariantLinkTime           |                   |
|                     | VariantPostBuild:                          | VariantPostBuild  |
|                     | VariantPreCompile:                         | VariantPreCompile |
| Origin              | AUTOSAR_ECUC                               |                   |

| Parameter Name | MirrorSourceFlexRayFilterCycleRepetition |  |
|----------------|--|--|
| Description    | Cycle repetition of accepted cycles.     |  |
| Multiplicity   | 11                                       |  |
| Туре           | INTEGER                                  |  |
| Range          | <=64                                     |  |
|                | >=1                                      |  |



| Configuration class | VariantLinkTime:   | VariantLinkTime   |
|---------------------|--------------------|-------------------|
|                     | VariantPostBuild:  | VariantPostBuild  |
|                     | VariantPreCompile: | VariantPreCompile |
| Origin              | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorSourceFlexRayFilterId        |   |  |
|---------------------|------------------------------------|---|--|
| Description         | Unique identifier of the pre-con   | Unique identifier of the pre-configured FlexRay filter. |  |
| Multiplicity        | 11                                 | 11  |  |
| Туре                | INTEGER                            | INTEGER   |  |
| Range               | <=255                              |   |  |
|                     | >=0                                |   |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |   |  |
|                     | VariantPostBuild: VariantPostBuild |   |  |
|                     | VariantPreCompile:                 | VariantPreCompile                                       |  |
| Origin              | AUTOSAR_ECUC                       |   |  |

| Parameter Name      | MirrorSourceFlexRayFilterLowerBaseCycle |  |  |
|---------------------|---|--|--|
| Description         | Lowest base cycle number that           | Lowest base cycle number that is accepted by the filter. |  |
| Multiplicity        | 11                                      | 11   |  |
| Туре                | INTEGER                                 |  |  |
| Range               | <=63                                    |  |  |
|                     | >=0                                     |  |  |
| Configuration class | VariantLinkTime: VariantLinkTime        |  |  |
|                     | VariantPostBuild:                       | VariantPostBuild   |  |
|                     | VariantPreCompile:                      | VariantPreCompile  |  |
| Origin              | AUTOSAR_ECUC                            |  |  |

| Parameter Name | MirrorSourceFlexRayFilterLowerSlot             |  |
|----------------|--|--|
| Description    | Lowest slot ID that is accepted by the filter. |  |
| Multiplicity   | 11   |  |
| Туре           | INTEGER  |  |
| Range          | <=2047   |  |
|                | >=1  |  |



| Configuration class | VariantLinkTime:   | VariantLinkTime   |
|---------------------|--------------------|-------------------|
|                     | VariantPostBuild:  | VariantPostBuild  |
|                     | VariantPreCompile: | VariantPreCompile |
| Origin              | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorSourceFlexRayFilterUpperBaseCycle                   |  |
|---------------------|---|--|
| Description         | Highest base cycle number that is accepted by the filter. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER   |  |
| Range               | <=63  |  |
|                     | >=0   |  |
| Configuration class | VariantLinkTime: VariantLinkTime                          |  |
|                     | VariantPostBuild: VariantPostBuild                        |  |
|                     | VariantPreCompile: VariantPreCompile                      |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | MirrorSourceFlexRayFilterUpperSlot              |                   |
|---------------------|---|-------------------|
| Description         | Highest slot ID that is accepted by the filter. |                   |
| Multiplicity        | 11  |                   |
| Туре                | INTEGER   |                   |
| Range               | <=2047  |                   |
|                     | >=1   |                   |
| Configuration class | VariantLinkTime: VariantLinkTime                |                   |
|                     | VariantPostBuild: VariantPostBuild              |                   |
|                     | VariantPreCompile:                              | VariantPreCompile |
| Origin              | AUTOSAR_ECUC                                    |                   |

## 5.5.1.27. MirrorGeneral

| Parameters included  |              |
|----------------------|--------------|
| Parameter name       | Multiplicity |
| MirrorDevErrorDetect | 11           |



| Parameters included               |    |  |
|-----------------------------------|----|--|
| <u>MirrorMainFunctionPeriod</u>   | 11 |  |
| MirrorVersionInfoApi              | 11 |  |
| MirrorStbRef                      | 01 |  |
| MirrorUseCustomTimeStamp          | 11 |  |
| MirrorCustomTimeFileName          | 11 |  |
| MirrorCustomGetTimeFuncName       | 11 |  |
| MirrorUseCanIfIPC                 | 11 |  |
| MirrorUseLinIfIPC                 | 11 |  |
| MirrorUseFrlfIPC                  | 11 |  |
| MirrorLinFramesPerSecond          | 11 |  |
| MirrorLinLostFrameCallBack        | 01 |  |
| MirrorCanFramesPerSecond          | 11 |  |
| <u>MirrorCanLostFrameCallBack</u> | 01 |  |
| MirrorCanFDFramesPerSecond        | 01 |  |
| MirrorCanFDLostFrameCallBack      | 01 |  |
| MirrorFrFramesPerSecond           | 11 |  |
| MirrorFrLostFrameCallBack         | 01 |  |
| <u>MirrorLinMaxFrameSize</u>      | 01 |  |
| MirrorCanMaxFrameSize             | 01 |  |
| MirrorCanFDMaxFrameSize           | 01 |  |
| MirrorFrMaxFrameSize              | 01 |  |
| <u>MirrorHeaderFileInclusion</u>  | 0n |  |

| Parameter Name      | MirrorDevErrorDetect  |  |
|---------------------|---|--|
| Description         | Switches the development error detection and notification on or off.                        |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantLinkTime: VariantLinkTime  |  |
|                     | VariantPostBuild:       VariantPostBuild         VariantPreCompile:       VariantPreCompile |  |
|                     |   |  |
| Origin              | AUTOSAR_ECUC  |  |



| Parameter Name      | MirrorMainFunctionPeriod                             |  |
|---------------------|--|--|
| Description         | Execution cycle of Mirror_MainFunction() in seconds. |  |
| Multiplicity        | 11   |  |
| Туре                | FLOAT  |  |
| Default value       | 0.05   |  |
| Range               | <infinity< th=""></infinity<>                        |  |
|                     | >0.0   |  |
| Configuration class | VariantLinkTime: VariantLinkTime                     |  |
|                     | VariantPostBuild: VariantPostBuild                   |  |
|                     | VariantPreCompile: VariantPreCompile                 |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | MirrorVersionInfoApi                 |   |  |
|---------------------|--------------------------------------|---|--|
| Description         | Pre-processor switch for enabli      | Pre-processor switch for enabling version info API support. |  |
| Multiplicity        | 11                                   | 11  |  |
| Туре                | BOOLEAN                              | BOOLEAN   |  |
| Default value       | false                                | false   |  |
| Configuration class | VariantLinkTime: VariantLinkTime     |   |  |
|                     | VariantPostBuild:                    | VariantPostBuild  |  |
|                     | VariantPreCompile: VariantPreCompile |   |  |
| Origin              | AUTOSAR_ECUC                         |   |  |

| Parameter Name      | MirrorStbRef   |           |  |
|---------------------|--|-----------|--|
| Description         | Reference to the StbM time base to use for acquiring the time stamps used in the mirroring protocol.                             |           |  |
| Multiplicity        | 01   | 01        |  |
| Туре                | REFERENCE  | REFERENCE |  |
| Configuration class | VariantLinkTime:     VariantLinkTime       VariantPostBuild:     VariantPostBuild       VariantPreCompile:     VariantPreCompile |           |  |
|                     |  |           |  |
|                     |  |           |  |
| Origin              | AUTOSAR_ECUC   |           |  |

| Parameter Name | MirrorUseCustomTimeStamp  |  |
|----------------|---|--|
| Description    | Pre-processor check if a custom function to get the time stamp is used. |  |



| Multiplicity        | 11                                   |                  |
|---------------------|--------------------------------------|------------------|
| Туре                | BOOLEAN                              |                  |
| Default value       | false                                |                  |
| Configuration class | VariantPreCompile: VariantPreCompile |                  |
|                     | VariantPostBuild:                    | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                         |                  |

| Parameter Name      | MirrorCustomTimeFileName   |                  |
|---------------------|--|------------------|
| Description         | The file name which has the implementation of the custom function to get the time stamp and the definition of the Mirror_TimeStampType . |                  |
| Multiplicity        | 11   |                  |
| Туре                | STRING   |                  |
| Configuration class | VariantPreCompile: VariantPreCompile   |                  |
|                     | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | MirrorCustomGetTimeFuncName                                      |                  |
|---------------------|--|------------------|
| Description         | The header of the custom function to get the current time stamp. |                  |
| Multiplicity        | 11   |                  |
| Туре                | STRING   |                  |
| Configuration class | VariantPreCompile: VariantPreCompile                             |                  |
|                     | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | MirrorUseCanIfIPC   |                  |
|---------------------|---|------------------|
| Description         | Pre-processor check if the Mirror will call the Canlf APIs using IPC channel or a direct call, If enabled then the SchM must be configured to support this feature. |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPreCompile: VariantPreCompile  |                  |
|                     | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name MirrorUseLinIfIPC |  |
|----------------------------------|--|
|----------------------------------|--|



| Description         | Pre-processor check if the Mirror will call the LinIf APIs using IPC channel or a direct call, If enabled then the SchM must be configured to support this feature. |                  |  |
|---------------------|---|------------------|--|
| Multiplicity        | 11  | 11               |  |
| Туре                | BOOLEAN   |                  |  |
| Default value       | false   |                  |  |
| Configuration class | VariantPreCompile: VariantPreCompile  |                  |  |
|                     | VariantPostBuild:   | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC  |                  |  |

| Parameter Name      | MirrorUseFrlfIPC   |                  |
|---------------------|--|------------------|
| Description         | Pre-processor check if the Mirror will call the FrIf APIs using IPC channel or a direct call, If enabled then the SchM must be configured to support this feature. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPreCompile: VariantPreCompile   |                  |
|                     | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | MirrorLinFramesPerSecond                       |                   |
|---------------------|--|-------------------|
| Description         | Expected LIN frames to be Mirrored per second. |                   |
| Multiplicity        | 11   |                   |
| Туре                | INTEGER  |                   |
| Range               | <4294967296                                    |                   |
|                     | >0   |                   |
| Configuration class | VariantLinkTime: VariantLinkTime               |                   |
|                     | VariantPostBuild:                              | VariantPostBuild  |
|                     | VariantPreCompile:                             | VariantPreCompile |
| Origin              | AUTOSAR_ECUC                                   |                   |

| Parameter Name | MirrorLinLostFrameCallBack  |  |
|----------------|---|--|
| Description    | The name of the C call back function in case a Lin frame could not be stored in |  |
|                | the intermediate buffer.  |  |
|                | To enable usage of this C callback function, proceed as follows:                |  |



|                     | Configure at least one source network of the LinSourceNetwork type.                                 |                            |  |
|---------------------|---|----------------------------|--|
|                     | 2. Activate this parameter  | 2. Activate this parameter |  |
|                     | 3. Configure the related C function name, e.g. Cdd_EbTest_DemRead-DataElement_0                     |                            |  |
|                     | 4. Configure the related C header file inclusion using the parameter Mirror-<br>HeaderFileInclusion |                            |  |
| Multiplicity        | 01  |                            |  |
| Туре                | STRING  |                            |  |
| Configuration class | VariantPreCompile:  | VariantPreCompile          |  |
|                     | VariantPostBuild:   | VariantPostBuild           |  |
| Origin              | AUTOSAR_ECUC  |                            |  |

| Parameter Name      | MirrorCanFramesPerSecond                       |                   |
|---------------------|--|-------------------|
| Description         | Expected CAN frames to be Mirrored per second. |                   |
| Multiplicity        | 11   |                   |
| Туре                | INTEGER  |                   |
| Range               | <4294967296                                    |                   |
|                     | >0   |                   |
| Configuration class | VariantLinkTime: VariantLinkTime               |                   |
|                     | VariantPostBuild:                              | VariantPostBuild  |
|                     | VariantPreCompile:                             | VariantPreCompile |
| Origin              | AUTOSAR_ECUC                                   |                   |

| Parameter Name | MirrorCanLostFrameCallBack   |  |
|----------------|--|--|
| Description    | The name of the C call back function in case a Can frame could not be stored in the intermediate buffer. |  |
|                | To enable usage of this C callback function, proceed as follows:   |  |
|                | Configure at least one source network of the CanSourceNetwork type.                                      |  |
|                | 2. Activate this parameter   |  |
|                | 3. Configure the related C function name, e.g. Cdd_EbTest_DemRead-DataElement_0                          |  |
|                | 4. Configure the related C header file inclusion using the parameter Mirror-HeaderFileInclusion          |  |
| Multiplicity   | 01   |  |



| Туре                | STRING                               |                  |
|---------------------|--------------------------------------|------------------|
| Configuration class | VariantPreCompile: VariantPreCompile |                  |
|                     | VariantPostBuild:                    | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                         |                  |

| Parameter Name      | MirrorCanFDFramesPerSecond   |                   |  |
|---------------------|--|-------------------|--|
| Description         | Expected CANFD frames to be Mirrored per second. Note: If disabled no CANFD frames are expected. |                   |  |
| Multiplicity        | 01   | 01                |  |
| Туре                | INTEGER  | INTEGER           |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |                   |  |
|                     | VariantPostBuild:  | VariantPostBuild  |  |
|                     | VariantPreCompile:   | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC   |                   |  |

| Parameter Name      | MirrorCanFDLostFrameCallBack   |                  |
|---------------------|--|------------------|
| Description         | The name of the C call back function in case a CanFD frame could not be stored in the intermediate buffer. |                  |
|                     | To enable usage of this C callback function, proceed as follows:   |                  |
|                     | enable the MirrorCanFDFramesPers   | Second.          |
|                     | 2. Activate this parameter   |                  |
|                     | 3. Configure the related C function name, e.g. Cdd_EbTest_DemRead-DataElement_0                            |                  |
|                     | 4. Configure the related C header file inclusion using the parameter Mirror-<br>HeaderFileInclusion        |                  |
| Multiplicity        | 01   |                  |
| Туре                | STRING   |                  |
| Configuration class | VariantPreCompile: VariantPreCompile   |                  |
|                     | VariantPostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name | MirrorFrFramesPerSecond                            |  |
|----------------|--|--|
| Description    | Expected FlexRay frames to be Mirrored per second. |  |
| Multiplicity   | 11   |  |



| Туре                | INTEGER   |                   |
|---------------------|---|-------------------|
| Range               | <4294967296   |                   |
|                     | >0  |                   |
| Configuration class | VariantLinkTime:     VariantLinkTime       VariantPostBuild:     VariantPostBuild |                   |
|                     |   |                   |
|                     | VariantPreCompile:  | VariantPreCompile |
| Origin              | AUTOSAR_ECUC  |                   |

| Parameter Name      | MirrorFrLostFrameCallBack  |                                  |
|---------------------|--|----------------------------------|
| Description         | The name of the C call back function in case a FlexRay frame could not be stored in the intermediate buffer. |                                  |
|                     | To enable usage of this C callback funct   | ion, proceed as follows:         |
|                     | Configure at least one source network  | ork of the FrSourceNetwork type. |
|                     | 2. Activate this parameter   |                                  |
|                     | 3. Configure the related C function name, e.g. Cdd_EbTest_DemRead-   |                                  |
|                     | DataElement_0  |                                  |
|                     | 4. Configure the related C header file inclusion using the parameter Mirror-HeaderFileInclusion              |                                  |
| Multiplicity        | 01   |                                  |
| Туре                | STRING   |                                  |
| Configuration class | VariantPreCompile: VariantPreCompile   |                                  |
|                     | VariantPostBuild: VariantPostBuild   |                                  |
| Origin              | AUTOSAR_ECUC   |                                  |

| Parameter Name      | MirrorLinMaxFrameSize   |                 |
|---------------------|---|-----------------|
| Description         | Max size of the LIN frame. Note: no LIN frame size should exceed this value even if added in the post build configurations. |                 |
| Multiplicity        | 01  |                 |
| Туре                | INTEGER   |                 |
| Default value       | 8   |                 |
| Range               | <9<br>>0  |                 |
| Configuration class | VariantLinkTime:  | VariantLinkTime |



|        | VariantPostBuild:  | VariantPostBuild  |
|--------|--------------------|-------------------|
|        | VariantPreCompile: | VariantPreCompile |
| Origin | AUTOSAR_ECUC       |                   |

| Parameter Name      | MirrorCanMaxFrameSize   | MirrorCanMaxFrameSize |  |
|---------------------|---|-----------------------|--|
| Description         | Max size of the Can frame. Note: no CAN frame size should exceed this value even if added in the post build configurations. |                       |  |
| Multiplicity        | 01  | 01                    |  |
| Туре                | INTEGER   | INTEGER               |  |
| Default value       | 8   |                       |  |
| Range               | <9  |                       |  |
|                     | >0  | >0                    |  |
| Configuration class | VariantLinkTime: VariantLinkTime  |                       |  |
|                     | VariantPostBuild: VariantPostBuild  |                       |  |
|                     | VariantPreCompile:  | VariantPreCompile     |  |
| Origin              | AUTOSAR_ECUC  |                       |  |

| Parameter Name      | MirrorCanFDMaxFrameSize   | MirrorCanFDMaxFrameSize |  |
|---------------------|---|-------------------------|--|
| Description         | Max size of the CanFD frame. Note: no CANFD frame size should exceed this value even if added in the post build configurations. |                         |  |
| Multiplicity        | 01  | 01                      |  |
| Туре                | INTEGER   | INTEGER                 |  |
| Default value       | 64  |                         |  |
| Range               | <65   |                         |  |
|                     | >0  | >0                      |  |
| Configuration class | VariantLinkTime: VariantLinkTime  |                         |  |
|                     | VariantPostBuild:   | VariantPostBuild        |  |
|                     | VariantPreCompile:  | VariantPreCompile       |  |
| Origin              | AUTOSAR_ECUC  |                         |  |

| Parameter Name | MirrorFrMaxFrameSize  |  |
|----------------|---|--|
| Description    | Max size of the FlexRay frame. Note: no FlexRay frame size should exceed this value even if added in the post build configurations. |  |
| Multiplicity   | 01  |  |



| Туре                | INTEGER                            |                   |  |
|---------------------|------------------------------------|-------------------|--|
| Default value       | 254                                | 254               |  |
| Range               | <255                               | <255              |  |
|                     | >0                                 |                   |  |
| Configuration class | VariantLinkTime: VariantLinkTime   |                   |  |
|                     | VariantPostBuild: VariantPostBuild |                   |  |
|                     | VariantPreCompile:                 | VariantPreCompile |  |
| Origin              | AUTOSAR_ECUC                       |                   |  |

| Parameter Name      | MirrorHeaderFileInclusion   |                   |
|---------------------|---|-------------------|
| Description         | Name of the header file(s) to be included by the Mirror module containing the used C-callback declarations. |                   |
| Multiplicity        | 0n  |                   |
| Туре                | STRING  |                   |
| Default value       | Module_Cbk.h  |                   |
| Configuration class | PreCompile:   | VariantPreCompile |
| Origin              | AUTOSAR_ECUC  |                   |

## 5.5.1.28. PublishedInformation

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| PbcfgMSupport       | 11           |

| Parameter Name      | PbcfgMSupport   |
|---------------------|---|
| Label               | PbcfgM support  |
| Description         | Specifies whether or not the Mirror can use the PbcfgM module for post-build support. |
| Multiplicity        | 11  |
| Туре                | BOOLEAN   |
| Default value       | false   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |



# 5.5.2. Application programming interface (API)

## 5.5.2.1. Macro constants

## 5.5.2.1.1. MIRROR\_DET\_REPORT\_ERROR

| Purpose |  |
|---------|--|
| Value   | (void) Det_ReportError(MIRROR_MODULE_ID, MIRROR_INSTANCE_ID, (Apild), (Errorld)) |

## 5.5.2.1.2. MIRROR\_E\_INIT\_FAILED

| Purpose | Definition of DET error code MIRROR_E_INIT_FAILED. |
|---------|--|
| Value   | 0x03U  |

## 5.5.2.1.3. MIRROR\_E\_INTERMEDIATE\_BUFFER\_OVERRUN

| Purpose | Definition of DET error code MIRROR_E_INTERMEDIATE_BUFFER_OVERRUN. |
|---------|--|
| Value   | 0x42U  |

## 5.5.2.1.4. MIRROR\_E\_INVALID\_CALL

| Purpose | Definition of DET error code MIRROR_E_INVALID_CALL. |
|---------|---|
| Value   | 0x13  |

## 5.5.2.1.5. MIRROR\_E\_INVALID\_CHANNEL

| Purpose | Definition of DET error code MIRROR_E_INVALID_CHANNEL. |
|---------|--|
| Value   | 0x18U  |



## 5.5.2.1.6. MIRROR\_E\_INVALID\_CLUSTER\_ID

| Purpose | Definition of DET error code MIRROR_E_INVALID_CLUSTER_ID. |
|---------|---|
| Value   | 0x17  |

## 5.5.2.1.7. MIRROR\_E\_INVALID\_CONTROLLER\_ID

| Purpose | Definition of DET error code MIRROR_E_INVALID_CONTROLLER_ID. |
|---------|--|
| Value   | 0x16   |

## 5.5.2.1.8. MIRROR\_E\_INVALID\_NETWORK\_ID

| Purpose | Definition of DET error code MIRROR_E_INVALID_NETWORK_ID. |
|---------|---|
| Value   | 0x12  |

## 5.5.2.1.9. MIRROR\_E\_INVALID\_PARAM

| Purpose | Definition of DET error code MIRROR_E_INVALID_PARAM. |
|---------|--|
| Value   | 0x14   |

## 5.5.2.1.10. MIRROR\_E\_INVALID\_PDU\_SDU\_ID

| Purpose | Definition of DET error code MIRROR_E_INVALID_PDU_SDU_ID. |
|---------|---|
| Value   | 0x11  |

## 5.5.2.1.11. MIRROR\_E\_INVALID\_STATUS

| Purpose | Definition of DET error code MIRROR_E_INVALID_STATUS. |
|---------|---|
| Value   | 0x15  |

## 5.5.2.1.12. MIRROR\_E\_NESTED\_REPORT\_FRAMES

| Purpose Definition of DET error code MIRROR_E_NEST | ED_REPORT_FRAMES. |
|--|-------------------|
|--|-------------------|



| Value |
|-------|
|-------|

## 5.5.2.1.13. MIRROR\_E\_PARAM\_POINTER

| Purpose | Definition of DET error code MIRROR_E_PARAM_POINTER. |
|---------|--|
| Value   | 0x10   |

## 5.5.2.1.14. MIRROR\_E\_QUEUE\_OVERRUN

| Purpose | Definition of DET error code MIRROR_E_QUEUE_OVERRUN. |
|---------|--|
| Value   | 0x40U  |

## 5.5.2.1.15. MIRROR\_E\_REINIT

| Purpose | Definition of DET error code MIRROR_E_REINIT. |
|---------|---|
| Value   | 0x02U   |

## 5.5.2.1.16. MIRROR\_E\_TRANSMIT\_FAILED

| Purpose | Definition of DET error code MIRROR_E_TRANSMIT_FAILED. |
|---------|--|
| Value   | 0x41U  |

## 5.5.2.1.17. MIRROR\_E\_UNINIT

| Purpose | Definition of DET error code MIRROR_E_UNINIT. |
|---------|---|
| Value   | 0x01U   |

## 5.5.2.1.18. MIRROR\_INSTANCE\_ID

| Purpose | Module instance ID. |
|---------|---------------------|
| Value   | 0U                  |



| Description | Defines the instance number of this module. Since multiple instances are not support- |
|-------------|---|
|             | ed this ID is always zero.  |

## 5.5.2.1.19. MIRROR\_SID\_DEINIT

| Purpose | Defines API id of function Mirror_Delnit(). |
|---------|---|
| Value   | 0x02U                                       |

## 5.5.2.1.20. MIRROR\_SID\_GETDESTINATIONNETWORK

| Purpose | Defines API id of function Mirror_GetDestNetwork(). |
|---------|---|
| Value   | 0x21U   |

## 5.5.2.1.21. MIRROR\_SID\_GETNETWORKHANDLE

| Purpose | Defines API id of function Mirror_GetNetworkHandle(). |
|---------|---|
| Value   | 0x26U   |

## 5.5.2.1.22. MIRROR\_SID\_GETNETWORKID

| Purpose | Defines API id of function Mirror_GetNetworkId(). |
|---------|---|
| Value   | 0x25U   |

## 5.5.2.1.23. MIRROR\_SID\_GETNETWORKTYPE

| Purpose | Defines API id of function Mirror_GetNetworkType(). |
|---------|---|
| Value   | 0x24U   |

## 5.5.2.1.24. MIRROR\_SID\_GETVERSIONINFO

| Purpose | Defines API id of function Mirror_GetVersionInfo(). |
|---------|---|
|---------|---|



| Value |
|-------|
|-------|

## 5.5.2.1.25. MIRROR\_SID\_INIT

| Purpose | Defines API id of function Mirror_Init(). |
|---------|---|
| Value   | 0x01U                                     |

## 5.5.2.1.26. MIRROR\_SID\_ISMIRRORACTIVE

| Purpose | Defines API id of function Mirror_IsMirrorActive(). |
|---------|---|
| Value   | 0x20U   |

## ${\bf 5.5.2.1.27.\ MIRROR\_SID\_ISSOURCENETWORKSTARTED}$

| Purpose | Defines API id of function Mirror_IsSourceNetworkStarted(). |
|---------|---|
| Value   | 0x22U   |

## 5.5.2.1.28. MIRROR\_SID\_MAINFUNCTION

| Purpose | Defines API id of function Mirror_MainFunction(). |
|---------|---|
| Value   | 0x04U   |

## 5.5.2.1.29. MIRROR\_SID\_OFFLINE

| Purpose | Defines API id of function Mirror_Offline(). |
|---------|--|
| Value   | 0x13U  |

## 5.5.2.1.30. MIRROR\_SID\_PDURIFRXINDICATION

| Purpose |       |
|---------|-------|
| Value   | 0x41U |



## 5.5.2.1.31. MIRROR\_SID\_REPORTCANFRAME

| Purpose | Defines API id of function Mirror_ReportCanFrame(). |
|---------|---|
| Value   | 0x50U   |

## 5.5.2.1.32. MIRROR\_SID\_REPORTFLEXRAYCHANNELSTATUS

| Purpose | Defines API id of function Mirror_ReportFlexRayChannelStatus(). |
|---------|---|
| Value   | 0x53U   |

## 5.5.2.1.33. MIRROR\_SID\_REPORTFLEXRAYFRAME

| Purpose | Defines API id of function Mirror_ReportFlexRayFrame(). |
|---------|---|
| Value   | 0x52U   |

## 5.5.2.1.34. MIRROR\_SID\_REPORTLINFRAME

| Purpose | Defines API id of function Mirror_ReportLinFrame(). |
|---------|---|
| Value   | 0x51U   |

## 5.5.2.1.35. MIRROR\_SID\_STARTALLSOURCENETWORKS

| Purpose | Defines API id of function Mirror_StartAllSourceNetworks(). |
|---------|---|
| Value   | 0x08U   |

## 5.5.2.1.36. MIRROR\_SID\_STARTSOURCENETWORK

| Purpose | Defines API id of function Mirror_StartSourceNetwork(). |
|---------|---|
| Value   | 0x10U   |

## 5.5.2.1.37. MIRROR\_SID\_STOPALLSOURCENETWORKS

| Purpose | Defines API id of function Mirror_StopAllSourceNetworks(). |
|---------|--|
|---------|--|



| Value |
|-------|
|-------|

#### 5.5.2.1.38. MIRROR\_SID\_STOPSOURCENETWORK

| Purpose | Defines API id of function Mirror_StopSourceNetwork(). |  |
|---------|--|--|
| Value   | 0x11U  |  |

# 5.5.2.1.39. MIRROR\_SID\_TXCONFIRMATION

| Purpose | Defines API id of function Mirror_TxConfirmation(). |
|---------|---|
| Value   | 0x40U   |

#### **5.5.2.2. Functions**

#### 5.5.2.2.1. Mirror\_Delnit

| Purpose     | Deinitializes the Mirror module.   |
|-------------|--|
| Synopsis    | <pre>void Mirror_DeInit ( void );</pre>  |
| Service ID  | 0x02   |
| Sync/Async  | Synchronous  |
| Reentrancy  | Non Reentrant  |
| Description | This function resets the Bus Mirroring module to the uninitialized state. It could be called after the intiallization of the module. |

#### 5.5.2.2.2. Mirror\_GetDestNetwork

| Purpose      | Returns the currently selected destination bus.   |  |
|--------------|---|--|
| Synopsis     | NetworkHandleType Mirror_GetDestNetwork ( void ); |  |
| Service ID   | 0x21  |  |
| Sync/Async   | Synchronous                                       |  |
| Reentrancy   | Reentrant   |  |
| Return Value |   |  |



| NetworkHandle- | The currently selected destination bus.       |                    |
|----------------|---|--------------------|
| Type:          |   |                    |
| Description    | This service returns the currently active des | stination network. |

#### 5.5.2.2.3. Mirror\_GetNetworkHandle

| Purpose         | Returns the network type of the given network.   |  |
|-----------------|--|--|
| Synopsis        | <pre>NetworkHandleType Mirror_GetNetworkHandle ( Mirror_NetworkType networkType , uint8 networkId );</pre> |  |
| Service ID      | 0x26   |  |
| Sync/Async      | Synchronous  |  |
| Reentrancy      | Reentrant  |  |
| Parameters (in) | networkType  | - The type of the Mirror network.                              |
|                 | networkId  | - ComM channel Mirror network ID                               |
| Return Value    | MIRROR_INVALID_NETWORK:  | if no configured network corresponds to the given combination. |
| NetworkHandle-  | The ComM handle ID if the network corre-   |  |
| Type:           | sponds to the given combination.   |  |
| Description     | This service returns the ComM network Id of the given Mirror network ID and the Mirror_NetworkType.        |  |

# 5.5.2.2.4. Mirror\_GetNetworkId

| Purpose         | Returns the Mirror network ID of the given network.      |  |
|-----------------|--|--|
| Synopsis        | uint8 Mirror_GetNetworkId ( NetworkHandleType network ); |  |
| Service ID      | 0x25   |  |
| Sync/Async      | Synchronous  |  |
| Reentrancy      | Reentrant  |  |
| Parameters (in) | network  | - The ComM channel Id of source or destination network.          |
| Return Value    | The  | Mirror network ID corresponding to the entered ComM network ID . |
| 0xff:           | if the ComM network ID is invalid.                       |  |



| Description | This service returns the Mirror network ID of the given network and if the network en- |   |
|-------------|--|---|
|             | tered isn't valid it returns 0xFF  | ĺ |
|             |  |   |

# 5.5.2.2.5. Mirror\_GetNetworkType

| Purpose                  | Returns the network type of the given network.   |   |
|--------------------------|--|---|
| Synopsis                 | <pre>Mirror_NetworkType Mirror_GetNetworkType ( NetworkHandleType network );</pre>                     |   |
| Service ID               | 0x24   |   |
| Sync/Async               | Synchronous  |   |
| Reentrancy               | Reentrant  |   |
| Parameters (in)          | network  | - The ComM channel ld of source or destination network. |
| Return Value             | MIRROR_NT_INVALID  | if the bus is not configured.                           |
|                          | MIRROR_NT_CAN:   | if the network is CAN type.                             |
|                          | MIRROR_NT_LIN:   | if the network is LIN type.                             |
| MIRROR_NT_ETH-<br>ERNET: | if the network is Ethernet type.   |   |
| Description              | This service returns the network type of the given network and it would be LIN, CAN or IP network type |   |

# 5.5.2.2.6. Mirror\_GetVersionInfo

| Purpose          | API to get the version information of Mirror module.                         |   |
|------------------|--|---|
| Synopsis         | <pre>void Mirror_GetVersionInfo ( Std_VersionInfoType * VersionInfo );</pre> |   |
| Service ID       | 0x03   |   |
| Sync/Async       | Synchronous  |   |
| Reentrancy       | Reentrant  |   |
| Parameters (out) | VersionInfo  | - Pointer to where to store the version information of this module. |
| Description      | This service returns the version information of this module.                 |   |



#### 5.5.2.2.7. Mirror\_Init

| Purpose         | Initializes the Mirror module.   |   |
|-----------------|--|---|
| Synopsis        | <pre>void Mirror_Init ( const Mirror_ConfigType * config );</pre>                                      |   |
| Service ID      | 0x01   |   |
| Sync/Async      | Synchronous  |   |
| Reentrancy      | Non Reentrant  |   |
| Parameters (in) | config   | - Base pointer to the configuration structure of the Mirror module. |
| Description     | This service initializes the Mirror module. It shall be the first function of the module to be called. |   |

#### 5.5.2.2.8. Mirror\_IsMirrorActive

| Purpose      | Returns the global mirroring state.  |  |
|--------------|--|--|
| Synopsis     | boolean Mirror_IsMirrorActive ( void );  |  |
| Service ID   | 0x20   |  |
| Sync/Async   | Synchronous  |  |
| Reentrancy   | Reentrant  |  |
| Return Value | TRUE: Mirror is active.  |  |
| FALSE:       | Mirror is inactive.  |  |
| Description  | This service returns true if the Mirror is active and false if the Mirror is inactive. |  |

#### 5.5.2.2.9. Mirror\_IsSourceNetworkStarted

| Purpose         | Returns the state of a source bus.  |  |
|-----------------|---|--|
| Synopsis        | <pre>boolean Mirror_IsSourceNetworkStarted ( NetworkHandleType net- work );</pre> |  |
| Service ID      | 0x22  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Reentrant   |  |
| Parameters (in) | network   | - The ComM channel ld of the source network. |



| Return Value | TRUE:  | Source bus is active.               |
|--------------|--|-------------------------------------|
| FALSE:       | Source bus is inactive.                        |                                     |
| Description  | This service returns true if the source bus is | s started and false if not started. |

# 5.5.2.2.10. Mirror\_MainFunction

| Purpose     | Mirror module main function.   |  |
|-------------|--|--|
| Synopsis    | <pre>void Mirror_MainFunction ( void );</pre>  |  |
| Service ID  | 0x04   |  |
| Sync/Async  | Synchronous  |  |
| Reentrancy  | Non Reentrant  |  |
| Description | This function performs the processing of the AUTOSAR MIRROR module's destination network activities. |  |

# 5.5.2.2.11. Mirror\_Offline

| Purpose     | Completely disables any mirroring activities.  |
|-------------|--|
| Synopsis    | <pre>void Mirror_Offline ( void );</pre>   |
| Service ID  | 0x13   |
| Sync/Async  | Synchronous  |
| Reentrancy  | Non Reentrant  |
| Description | This service resets source buses are to disabled, queued messages are purged, and the destination bus is reset to the default destination. |

#### 5.5.2.2.12. Mirror\_PduRlfRxIndication

| Purpose    | Mirror module Reception indication callback function.   |  |
|------------|---|--|
| Synopsis   | <pre>void Mirror_PduRIfRxIndication ( PduIdType MirrorRxPduId , PduInfoType * PduInfoPtr );</pre> |  |
| Service ID | 0x41  |  |
| Sync/Async | Synchronous   |  |



| Reentrancy      | Reentrant for different Pdulds Non Reentrant for the same Pduld  |  |
|-----------------|--|--|
| Parameters (in) | MirrorRxPduId  | - ID of the PDU that has been received.        |
|                 | PduInfoPtr   | - Pointer to the data which has been received. |
| Description     | This callback function is called by the lower interface module to confirm the reception of a PDU. "This is a dummy function that should never be called and if it's called a DET error is reported". |  |

# 5.5.2.2.13. Mirror\_ReportCanFrame

| Purpose         | Mirror module Report Can frame callback function.                                   |  |
|-----------------|---|--|
| Synopsis        | void Mirror_ReportCanFrame ( uint8 controllerId , Can_IdType                        |  |
|                 | canId , uint8 length , const uint8 * payload );                                     |  |
| Service ID      | 0x50  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Non reentrant   |  |
| Parameters (in) | controllerId  | - ID of the CAN controller that received or transmitted the frame. |
|                 | canId   | - CAN ID of the CAN frame.   |
|                 | length  | - length Length of the CAN frame.                                  |
|                 | payload   | - Content of the CAN frame.  |
| Description     | This callback is called by the lower layer of the Canlf to Report an incoming frame |  |

# ${\bf 5.5.2.2.14.\ Mirror\_ReportFlexRayChannelStatus}$

| Purpose         | Mirror module Report FlexRay channel status callback function.   |  |
|-----------------|--|--|
| Synopsis        | <pre>void Mirror_ReportFlexRayChannelStatus ( uint8 clusterId , uint16 channelAStatus , uint16 channelBStatus );</pre> |  |
| Service ID      | 0x53   |  |
| Sync/Async      | Non Synchronous  |  |
| Reentrancy      | Reentrant for different clusterIds. Non reentrant for the same clusterId   |  |
| Parameters (in) | uint8  | clusterId, - FlexRay cluster for which the status is reported. |



|             | channelAStatus                                | - Status of FlexRay channel A.       |
|-------------|---|--------------------------------------|
|             | channelBStatus                                | - Status of FlexRay channel B.       |
| Description | This callback is called by the lower layer of | the FrIf to Report an incoming frame |

#### 5.5.2.2.15. Mirror\_ReportFlexRayFrame

| Purpose         | Mirror module Report FlexRay frame callback function.   |   |  |
|-----------------|---|---|--|
| Synopsis        | <pre>void Mirror_ReportFlexRayFrame ( uint8 controllerId , uint16 slotId , uint8 cycle , Fr_ChannelType frChannel , const PduIn- foType * frame , boolean txConflict );</pre> |   |  |
| Service ID      | 0x52  | 0x52  |  |
| Sync/Async      | Non Synchronous   | Non Synchronous   |  |
| Reentrancy      | Non reentrant   |   |  |
| Parameters (in) | controllerId  | - FlexRay controller that received/transmitted the frame.             |  |
|                 | slotId  | - ID of the slot in which the received/transmitted frame is located.  |  |
|                 | cycle   | - Cycle in which the reception/transmission takes place.              |  |
|                 | frChannel   | - FlexRay channel(s) on which the reception/transmission takes place. |  |
|                 | frame   | - Content of the FlexRay frame, or NULL when a txConflict is reported |  |
|                 | txConflict  | - TRUE in case a txConflict has been detected, FALSE otherwise.       |  |
| Description     | This callback is called by the lower layer of the Frlf to Report an incoming frame  |   |  |

#### 5.5.2.2.16. Mirror\_ReportLinFrame

| Purpose    | Mirror module Report Lin frame callback function.   |  |
|------------|---|--|
| Synopsis   | <pre>void Mirror_ReportLinFrame ( NetworkHandleType network , Lin FramePidType pid , const PduInfoType * pdu , Lin_StatusType status );</pre> |  |
| Service ID | 0x51  |  |



| Sync/Async      | Synchronous   |  |
|-----------------|---|--|
| Reentrancy      | Non reentrant   |  |
| Parameters (in) | network   | - ComM channel associated with the LIN channel on which the frame was received or transmitted. |
|                 | pid   | - Protected ID of the LIN frame.   |
|                 | pdu   | - Content of the LIN frame.  |
|                 | status  | - Rx/Tx status of the frame access through the LIN driver.                                     |
| Description     | This callback is called by the lower layer of the Linlf to Report an incoming frame |  |

# 5.5.2.2.17. Mirror\_StartAllSourceNetworks

| Purpose      | Activates all source bus.                              |  |
|--------------|--|--|
| Synopsis     | Std_ReturnType Mirror_StartAllSourceNetworks ( void ); |  |
| Service ID   | 0x08   |  |
| Sync/Async   | Asynchronous   |  |
| Reentrancy   | Reentrant  |  |
| Return Value |  |  |

#### 5.5.2.2.18. Mirror\_StartSourceNetwork

| Purpose         | Activates a source bus.  |   |  |
|-----------------|--|---|--|
| Synopsis        | <pre>Std_ReturnType Mirror_StartSourceNetwork ( NetworkHandleType network );</pre> |   |  |
| Service ID      | 0x10   |   |  |
| Sync/Async      | Asynchronous   |   |  |
| Reentrancy      | Reentrant  |   |  |
| Parameters (in) | network  | - The ComM channel Id of the destination network. |  |
| Return Value    | E_OK:  | Source bus was activated.                         |  |
| E_NOT_OK:       | Function was called with invalid parameters.                                       |   |  |



| Description | This service return E_OK if the activation of the source bus is successful and E |  |
|-------------|--|--|
|             | NOT_OK if the activation failed.   |  |
|             |  |  |

#### 5.5.2.2.19. Mirror\_StopAllSourceNetworks

| Purpose      | Dectivates all source bus.                            |
|--------------|---|
| Synopsis     | Std_ReturnType Mirror_StopAllSourceNetworks ( void ); |
| Service ID   | 0x09  |
| Sync/Async   | Asynchronous  |
| Reentrancy   | Reentrant   |
| Return Value |   |

# 5.5.2.2.20. Mirror\_StopSourceNetwork

| Purpose         | Deactivates a source bus.  |   |
|-----------------|--|---|
| Synopsis        | <pre>Std_ReturnType Mirror_StopSourceNetwork ( NetworkHandleType network );</pre>                                    |   |
| Service ID      | 0x11   |   |
| Sync/Async      | Asynchronous   |   |
| Reentrancy      | Reentrant  |   |
| Parameters (in) | network  | - The ComM channel Id of the destination network. |
| Return Value    | E_OK:  | Source bus was deactivated.                       |
| E_NOT_OK:       | Function was called with invalid parameters.   |   |
| Description     | This service return E_OK if the deactivation of the source bus is successful and ENOT_OK if the deactivation failed. |   |

# 5.5.2.2.21. Mirror\_TxConfirmation

| Purpose  | Mirror module Transmission confirmation callback function.   |  |
|----------|--|--|
| Synopsis | <pre>void Mirror_TxConfirmation ( PduIdType TxPduId );</pre> |  |



| Service ID      | 0x40   |  |
|-----------------|--|--|
| Sync/Async      | Synchronous  |  |
| Reentrancy      | Reentrant for different Pdulds Non Reentrant for the same Pduld                                      |  |
| Parameters (in) | TxPduId  | - ID of the PDU that has been transmitted. |
| Description     | This callback function is called by the lower interface module to confirm the transmission of a PDU. |  |

# 5.5.3. Integration notes

#### 5.5.3.1. Exclusive areas

Exclusive areas information is not available for this module.

#### 5.5.3.2. Production errors

Production errors are not reported by the Mirror module.

#### 5.5.3.3. Memory mapping

General information about memory mapping is provided in the EB tresos AutoCore Generic documentation. Refer to the section Memory mapping and compiler abstraction in the Integration notes section for details.

The following table provides the list of sections that may be mapped for this module:

| Memory section          |
|-------------------------|
| CONFIG_DATA_UNSPECIFIED |
| CONFIG_DATA_8           |
| CONST_UNSPECIFIED       |
| VAR_CLEARED_GLOBAL_64   |
| VAR_CLEARED_GLOBAL_32   |
| VAR_CLEARED_GLOBAL_16   |
| VAR_INIT_GLOBAL_8       |



| VAR_CLEARED_LOCAL_UNSPECIFIED      |
|------------------------------------|
| LIN_VAR_CLEARED_GLOBAL_UNSPECIFIED |
| CAN_VAR_CLEARED_GLOBAL_UNSPECIFIED |
| FR_VAR_CLEARED_GLOBAL_UNSPECIFIED  |
| VAR_CLEARED_LOCAL_8                |
| VAR_CLEARED_LOCAL_16               |
| VAR_CLEARED_LOCAL_32               |
| CODE                               |
| CAN_CODE                           |
| FLEXRAY_CODE                       |
| LIN_CODE                           |

#### 5.5.3.4. Integration requirements

#### **WARNING**

#### Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

Integration requirements are not listed for the Mirror module.

# 5.6. PduR

# 5.6.1. Configuration parameters

| Containers included        |              |   |
|----------------------------|--------------|---|
| Container name             | Multiplicity | Description   |
| CommonPublishedInformation | 11           | Label: Common Published Information Common container, aggregated by all modules. It contains published information about vendor and versions. |
| PublishedInformation       | 11           | Label: EB Published Information   |



| Containers included |    |   |
|---------------------|----|---|
|                     |    | Additional published parameters not covered by Common-PublishedInformation container.   |
| PduRBswModules      | 0n | Each container describes a specific BSW module (upper/CDD/lower/lpduM) that the PDU Router shall interface to. The reason to have it as own configuration container instead of implication of the routing path is to be able to configure CDD:s properly and to force module's to be used in a post-build situation even though no routing is made to/from this module (future configurations may include these modules).  Note: The short name of the container PduRBswModules provides the Module Short Name MSN. |
| PduRGeneral         | 11 | This container is a subcontainer of PduR and specifies the general configuration parameters of the PDU Router.  |
| PduRRoutingTables   | 1n | Represents one table of routing paths. This routing table allows multiple configurations that can be used to create several routing tables in the same configuration. This is mainly used for post-build (e.g. post-build selectable) but can be used by pre-compile and link-time for variant handling.  |

| Parameters included           |              |
|-------------------------------|--------------|
| Parameter name                | Multiplicity |
| IMPLEMENTATION_CONFIG_VARIANT | 11           |

| Parameter Name | IMPLEMENTATION_CONFIG_VARIANT |
|----------------|-------------------------------|
| Label          | Configuration Variant         |
| Multiplicity   | 11                            |
| Туре           | ENUMERATION                   |
| Default value  | VariantPostBuild              |
| Range          | VariantPostBuild              |

# 5.6.1.1. CommonPublishedInformation

| Parameters included   |              |
|-----------------------|--------------|
| Parameter name        | Multiplicity |
| <u>ArMajorVersion</u> | 11           |



| Parameters included |    |
|---------------------|----|
| ArMinorVersion      | 11 |
| ArPatchVersion      | 11 |
| SwMajorVersion      | 11 |
| SwMinorVersion      | 11 |
| SwPatchVersion      | 11 |
| ModuleId            | 11 |
| Vendorld            | 11 |
| Release             | 11 |

| Parameter Name      | ArMajorVersion   |
|---------------------|--|
| Label               | AUTOSAR Major Version  |
| Description         | Major version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 3  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name      | ArMinorVersion   |
|---------------------|--|
| Label               | AUTOSAR Minor Version  |
| Description         | Minor version number of AUTOSAR specification on which the appropriate implementation is based on. |
| Multiplicity        | 11   |
| Туре                | INTEGER_LABEL  |
| Default value       | 2  |
| Configuration class | PublishedInformation:  |
| Origin              | Elektrobit Automotive GmbH   |

| Parameter Name | ArPatchVersion   |
|----------------|--|
| Label          | AUTOSAR Patch Version  |
| Description    | Patch level version number of AUTOSAR specification on which the appropriate implementation is based on. |



| Multiplicity        | 11                         |
|---------------------|----------------------------|
| Туре                | INTEGER_LABEL              |
| Default value       | 0                          |
| Configuration class | PublishedInformation:      |
| Origin              | Elektrobit Automotive GmbH |

| Parameter Name      | SwMajorVersion  |
|---------------------|---|
| Label               | Software Major Version  |
| Description         | Major version number of the vendor specific implementation of the module. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 5   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | SwMinorVersion  |
|---------------------|---|
| Label               | Software Minor Version  |
| Description         | Minor version number of the vendor specific implementation of the module. The numbering is vendor specific. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 3   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | SwPatchVersion  |
|---------------------|---|
| Label               | Software Patch Version  |
| Description         | Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific. |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 46  |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |



| Parameter Name      | Moduleld                                  |
|---------------------|---|
| Label               | Numeric Module ID                         |
| Description         | Module ID of this module from Module List |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL                             |
| Default value       | 51  |
| Configuration class | PublishedInformation:                     |
| Origin              | Elektrobit Automotive GmbH                |

| Parameter Name      | Vendorld  |
|---------------------|---|
| Label               | Vendor ID   |
| Description         | Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list |
| Multiplicity        | 11  |
| Туре                | INTEGER_LABEL   |
| Default value       | 1   |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

| Parameter Name      | Release                    |
|---------------------|----------------------------|
| Label               | Release Information        |
| Multiplicity        | 11                         |
| Туре                | STRING_LABEL               |
| Default value       |                            |
| Configuration class | PublishedInformation:      |
| Origin              | Elektrobit Automotive GmbH |

# 5.6.1.2. PublishedInformation

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| PbcfgMSupport       | 11           |  |

| Parameter Name | PbcfgMSupport |
|----------------|---------------|
|                |               |



| Label               | PbcfgM support  |
|---------------------|---|
| Description         | Specifies whether or not the PduR can use the PbcfgM module for post-build support. |
| Multiplicity        | 11  |
| Туре                | BOOLEAN   |
| Default value       | true  |
| Configuration class | PublishedInformation:   |
| Origin              | Elektrobit Automotive GmbH  |

# 5.6.1.3. PduRBswModules

| Parameters included           |              |  |
|-------------------------------|--------------|--|
| Parameter name                | Multiplicity |  |
| PduRCancelReceive             | 11           |  |
| PduRCancelTransmit            | 11           |  |
| PduRChangeParameterRequestApi | 11           |  |
| PduRCommunicationInterface    | 11           |  |
| PduRLowerModule               | 11           |  |
| PduRRetransmission            | 11           |  |
| PduRTransportProtocol         | 11           |  |
| PduRTriggertransmit           | 11           |  |
| PduRTxConfirmation            | 11           |  |
| PduRUpperModule               | 11           |  |
| PduRUseTag                    | 11           |  |
| PduRBswModuleRef              | 11           |  |
| PduRBswModuleIsEnabled        | 11           |  |
| PduRStaticPduLengthSupport    | 11           |  |
| PduRBswModuleApiDefinition    | 11           |  |
| PduRCalculateHandleId         | 11           |  |
| PduRMaxRxPduld                | 11           |  |
| PduRMaxTxPduId                | 11           |  |

| Parameter Name | PduRCancelReceive |
|----------------|-------------------|
|                |                   |



| Description         | Specifies if the Transport protocol module supports the CancelReceive API or not.  TRUE: Cancel Receive Functionality is enabled (switched on).   |                  |  |
|---------------------|---|------------------|--|
|                     | FALSE: Cancel Receive Functionality is disabled (switched off).   |                  |  |
|                     | Optimization Effect:  |                  |  |
|                     | <ul> <li>ROM reduction (config): Disabling all of the parameters</li> <li><parameter>PduRCancelReceive</parameter> reduces the ROM consumption of the module configuration.</li> <li>ROM reduction (code): Disabling this parameter reduces the ROM con-</li> </ul> |                  |  |
|                     | sumption of the module code.  |                  |  |
| Multiplicity        | 11  |                  |  |
| Туре                | BOOLEAN   |                  |  |
| Default value       | false   |                  |  |
| Configuration class | PreCompile:   | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC  |                  |  |

| Parameter Name      | PduRCancelTransmit   |                  |  |
|---------------------|--|------------------|--|
| Description         | Specifies if the BSW module supports the CancelTransmit API or not.  |                  |  |
|                     | TRUE: Cancel transmit functionality is enabled (switched on).  |                  |  |
|                     | FALSE: Cancel transmit functionality is disabled (switched off).   |                  |  |
|                     | Optimization Effect:   |                  |  |
|                     | ▶ ROM reduction (config): Disabling all of the parameters <parameter>PduRCancelTransmit</parameter> reduces the ROM consumption of the module configuration. |                  |  |
|                     | ▶ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.   |                  |  |
| Multiplicity        | 11   |                  |  |
| Туре                | BOOLEAN  |                  |  |
| Default value       | false  |                  |  |
| Configuration class | PreCompile:  | VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC   |                  |  |

| Parameter Name | PduRChangeParameterRequestApi |
|----------------|-------------------------------|
|----------------|-------------------------------|



| Description         | Specifies if the BSW module supports the ChangeParameter API or not.   |                  |
|---------------------|--|------------------|
|                     | ► TRUE: Change parameter functionality is enabled (switched on).   |                  |
|                     | FALSE: Change parameter functionality is disabled (switched off).  |                  |
|                     | Optimization Effect:   |                  |
|                     | <ul> <li>ROM reduction (config): Disabling all of the parameters     <pre><parameter>PduRChangeParameterRequestApi</parameter></pre>/parameter&gt; reduces the     ROM consumption of the module configuration.</li> <li>ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.</li> </ul> |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | PreCompile:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | PduRCommunicationInterface  |                  |
|---------------------|---|------------------|
| Description         | Specifies if the BSW module supports the Communication Interface APIs or not. Value true the APIs are supported. A module can have both Communication Interface APIs and Transport Protocol APIs (e.g. the COM module). |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | PduRLowerModule   |
|----------------|---|
| Description    | The PduRLowerModule will decide who will call the APIs and who will implement the APIs. For example, if the CanIf module is referenced then the PDU Router module will implement the PduR_CanIfRxIndication API. And the PDUR module will call the CanIf_Transmit API. Other APIs are of course also covered. An upper module can also be a lower module (e.g. the IpduM module). |
| Multiplicity   | 11  |
| Туре           | BOOLEAN   |
| Default value  | false   |



| Configuration class | VariantPostBuild: | VariantPostBuild |
|---------------------|-------------------|------------------|
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | PduRRetransmission  |                  |
|---------------------|---|------------------|
| Description         | The functionality related to this parameter is not supported by the current implementation.  If set to true this means that the destination transport protocol module will use the retransmission feature. This parameter might be set to false if the retransmission feature is not used, even though the destination transport protocol is supporting it. This parameter is only valid for transport protocol modules and gateway operations. If transmission from a local upper layer module this module will handle the retransmission. |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name      | PduRTransportProtocol  |  |
|---------------------|--|--|
| Description         | The PDU Router module shall use the API parameters specified for transport protocol interface. |  |
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | false  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name | PduRTriggertransmit   |
|----------------|---|
| Description    | Specifies if the BSW module supports the TriggerTransmit API or not. Value true means that the BSW module supports the TriggerTransmit interface which a lower layer module can call and also that it can call the TriggerTransmit interface of an upper layer module. Value false means that the BSW module does not support the TriggerTransmit interface which a lower layer module can call and also that it shall not call the TriggerTransmit interface of an upper layer module. |
| Multiplicity   | 11  |
| Туре           | BOOLEAN   |



| Default value       | false                        |  |
|---------------------|------------------------------|--|
| Configuration class | PreCompile: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                 |  |

| Parameter Name      | PduRTxConfirmation   |                  |
|---------------------|--|------------------|
| Description         | Specifies if the BSW module supports the TxConfirmation API or not. Value true the API is supported. |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | PreCompile:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC   |                  |

| Parameter Name      | PduRUpperModule   |                  |
|---------------------|---|------------------|
| Description         | The PduRUpperModule will decide who will call the APIs and who will implement the APIs. For example, if the COM module is referenced then the PDU Router module will implement the PduR_Transmit API. And the PDUR module will call the Com_RxIndication API. Other APIs are of course also covered. An upper module can also be an lower module (e.g. the IpduM module). |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | PduRUseTag   |
|----------------|--|
| Description    | The functionality related to this parameter is not supported by the current implementation.  This parameter, if set to true, enables the usage of the tag ( <up>) in the following API calls: * PduR_<up>CancelReceive * PduR_<up>CancelTransmit * PduR_<up>ChangeParameter Example: If used by COM and the parameter is enabled the PduR_ComCancelTransmit is used. The background is that upper layer modules differ in usage of this tag (e.g. COM is using the tag, DCM is not).</up></up></up></up> |
| Multiplicity   | 11   |
| Туре           | BOOLEAN  |
| Default value  | true   |



| Configuration class | VariantPostBuild: | VariantPostBuild |
|---------------------|-------------------|------------------|
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | PduRBswModuleRef  |  |
|---------------------|---|--|
| Description         | The functionality related to this parameter is not supported by the current implementation.  To identify the adjacent module by the properties, the PduRBswModules container name shall be equal to the module name. This is a reference to one BSW module's configuration (i.e. not the ECUC parameter definition template). Example, there could be several configurations of Linlf and this reference selects one of them. |  |
| Multiplicity        | 11  |  |
| Туре                | FOREIGN-REFERENCE   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | PduRBswModuleIsEnabled  |  |  |
|---------------------|---|--|--|
| Description         | Specifies if the Bsw Module is available.   |  |  |
|                     | TRUE: The Bsw Module is available   | (switched on).   |  |
|                     | FALSE: The Bsw Module is not avai   | FALSE: The Bsw Module is not available (switched off). |  |
|                     | Optimization Effect:  |  |  |
|                     | <b>ROM reduction (config):</b> Disabling the parameter reduces the ROM consumption of the module configuration. |  |  |
|                     | ▶ <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code.         |  |  |
| Multiplicity        | 11  |  |  |
| Туре                | BOOLEAN   |  |  |
| Default value       | true  |  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild                                       |  |

| Parameter Name | PduRStaticPduLengthSupport  |  |
|----------------|---|--|
| Description    | Solely I-PDUs with fixed payload are gatewayed by the module.                               |  |
|                | TRUE: Only static communication interface I-PDUs are received for gatewaying (switched on). |  |



|                     | FALSE: Also communication interface I-PDUs variable in length might be received for gatewaying (switched off).  Note: The lower layer must always provide a buffer which is not smaller than the length specified in EcuC. Rationale: If the actual length of the receive buffer provided by the lower layer is smaller than the length used by the upper layer, the |                  |  |
|---------------------|--|------------------|--|
|                     | <ul> <li>upper layer will read more bytes than available in the provided buffer.</li> <li>Optimization Effect:</li> <li>ROM reduction (config): Enabling this parameter reduces the ROM consumption of the module configuration.</li> <li>RAM reduction (config): Enabling this parameter reduces the RAM con-</li> </ul>  |                  |  |
| Multiplicity        | sumption of the module configuration.  11  |                  |  |
| Туре                | BOOLEAN  |                  |  |
| Default value       | false  |                  |  |
| Configuration class | PreCompile:  | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH   |                  |  |

| Parameter Name      | PduRBswModuleApiDefinition  |                    |
|---------------------|---|--------------------|
| Description         | The functionality related to this parameter is not supported by the current implementation. |                    |
|                     | Selects the way the APIs of the module  | are to be defined: |
|                     | FUNCTION: Module APIs are define  | d as functions.    |
|                     | MACRO: Module APIs are defined as macros.   |                    |
| Multiplicity        | 11  |                    |
| Туре                | ENUMERATION   |                    |
| Default value       | FUNCTION  |                    |
| Range               | FUNCTION  |                    |
|                     | MACRO   |                    |
| Configuration class | VariantPostBuild:   | VariantPostBuild   |
| Origin              | Elektrobit Automotive GmbH  |                    |

| Parameter Name | PduRCalculateHandleId                                |  |
|----------------|--|--|
| Description    | Specifies if the Handle IDs shall be calculated.     |  |
|                | ► TRUE: The Handle IDs are calculated (switched on). |  |



|                     | FALSE: The Handle IDs are not calculated (switched off). |  |
|---------------------|--|--|
| Multiplicity        | 11   |  |
| Туре                | BOOLEAN  |  |
| Default value       | true   |  |
| Configuration class | VariantPostBuild: VariantPostBuild                       |  |
| Origin              | Elektrobit Automotive GmbH                               |  |

| Parameter Name      | PduRMaxRxPduld   |                  |
|---------------------|--|------------------|
| Description         | Specifies the maximum RxPduId that might be provided by the AUTOSAR 3.2 upper layer module.  Note: The RxPduIds of the upper layer module with TP interface shall be zero-based and dense.  Optimization Effect:  RAM reduction (config): Decreasing this parameter reduces the RAM consumption of the module configuration. |                  |
| Multiplicity        | 11   |                  |
| Туре                | INTEGER  |                  |
| Default value       | 0  |                  |
| Range               | >=0<br><=255   |                  |
| Configuration class | PreCompile:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | PduRMaxTxPduld   |  |
|----------------|--|--|
| Description    | Specifies the maximum TxPduId that might be provided by the AUTOSAR 3.2 upper layer module.  Note: The TxPduIds of the upper layer module with TP interface shall be zero-based and dense.  Optimization Effect:  RAM reduction (config): Decreasing this parameter reduces the RAM con- |  |
|                | sumption of the module configuration.  |  |
| Multiplicity   | 11   |  |
| Туре           | INTEGER  |  |
| Default value  | 0  |  |



| Range               | >=0                          |  |
|---------------------|------------------------------|--|
|                     | <=255                        |  |
| Configuration class | PreCompile: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH   |  |

#### 5.6.1.4. PduRGeneral

| Parameters included                         |              |
|---|--------------|
| Parameter name                              | Multiplicity |
| PduRDevErrorDetect                          | 11           |
| PduRVersionInfoApi                          | 11           |
| PduRZeroCostOperation PduRZeroCostOperation | 11           |
| PduRASR32RevisionCompatibility              | 11           |
| PduRMultiCoreSupport                        | 11           |
| PduRPartitionCount                          | 11           |
| PduRMultiTpTxRPathsMax                      | 11           |
| PduRRotfBufferAssignmentStrategy            | 11           |
| PduRlfGatewaySupport                        | 11           |
| PduRTpGatewaySupport                        | 11           |
| PduRTpGwQueueEnable                         | 11           |
| PduRRelocatableCfgEnable                    | 11           |
| PduRSbTxBufferSupport                       | 11           |
| PduRFifoTxBufferSupport                     | 11           |
| PduRNto1RoutingSupport                      | 11           |
| PduRMemorySize                              | 01           |
| PduRMemorySizeExtension                     | 11           |
| PduRMulticastTxConfirmation                 | 11           |
| PduRMulticastFromIfSupport                  | 11           |
| PduRMulticastTolfSupport                    | 11           |
| PduRMulticastLoTpToUpSupport                | 11           |
| PduRMulticastUpToLoTpSupport                | 11           |
| PduRRoutingPathGroupSupport                 | 11           |



| Parameters included                |    |
|------------------------------------|----|
| PduRMulticastTpHighestWinsStrategy | 11 |

| Parameter Name      | PduRDevErrorDetect  |  |
|---------------------|---|--|
| Label               | Enable Development Error Detection  |  |
| Description         | Enables the error-reporting to the Development Error Tracer (DET).  |  |
|                     | TRUE: Development Error Detection mechanism is enabled (switched on).   |  |
|                     | FALSE: Development Error Detection  | on mechanism is disabled (switched off). |
|                     | Optimization Effect:  |  |
|                     | <ul> <li>ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.</li> <li>Execution time reduction (code): Disabling this parameter reduces the</li> </ul> |  |
|                     | execution time of the module code.  |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | true  |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | PduRVersionInfoApi   |                                      |  |
|---------------------|--|--------------------------------------|--|
| Label               | Enable Version Info API  |                                      |  |
| Description         | Enables the PduR_GetVersionInfo API.   | Enables the PduR_GetVersionInfo API. |  |
|                     | <ul> <li>TRUE: PduR_GetVersionInfo API is available (switched on).</li> <li>FALSE: PduR_GetVersionInfo API is available (switched off).</li> </ul> |                                      |  |
|                     | Optimization Effect:   |                                      |  |
|                     | ▶ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.   |                                      |  |
| Multiplicity        | 11   |                                      |  |
| Туре                | BOOLEAN  |                                      |  |
| Default value       | false  |                                      |  |
| Configuration class | VariantPostBuild:  | VariantPostBuild                     |  |
| Origin              | AUTOSAR_ECUC   |                                      |  |



| Parameter Name      | PduRZeroCostOperation   |  |
|---------------------|---|--|
| Description         | If set the PduR configuration generator will report an error if zero-cost-operation cannot be fulfilled. This parameter shall be seen as an input requirement to the configuration generator. |  |
|                     | Optimization Effect:  |  |
|                     | ▶ ROM reduction (config): Enabling this parameter reduces the ROM consumption of the module configuration.  |  |
|                     | ▶ <b>ROM reduction (code):</b> Enabling this parameter reduces the ROM consumption of the module code.  |  |
|                     | Execution time reduction (code): Enabling this parameter reduces the execution time of the module code.   |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | PduRASR32RevisionCompatibility  |                  |
|---------------------|---|------------------|
| Description         | Enables/Disables the passing of return values of AUTOSAR 3.2 upper layer modules for dedicated AUTOSAR 3.2 revisions on Rx side.  TRUE: Return values are passed according to revision 1 and 2 (BUFREQE BUSY is available). |                  |
|                     | FALSE: Return values are passed according to revision 3 (BUFREQ_EBUSY is NOT available, i.e. mapped to BUFREQ_E_OVFL).  |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | PduRMultiCoreSupport   |  |
|----------------|--|--|
| Description    | Enables/Disables the decoupling functionality for gateway and multicast operations. DecouplingImprovement: more detailed description |  |
|                | ➤ TRUE: Decoupling functionality is enabled (switched on).   |  |



|                     | FALSE: Decoupling functionality is disabled (switched off).  |  |  |
|---------------------|--|--|--|
|                     | Optimization Effect:   |  |  |
|                     | ▶ <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration. |  |  |
|                     |  | <b>RAM reduction (config):</b> Disabling this parameter reduces the RAM consumption of the module configuration. |  |
|                     |  | <b>ROM reduction (code):</b> Disabling this parameter reduces the ROM consumption of the module code.            |  |
|                     |  | <b>RAM reduction (code):</b> Disabling this parameter reduces the RAM consumption of the module code.            |  |
|                     |  | <b>Execution time reduction (code):</b> Disabling this parameter reduces the execution time of the module code.  |  |
| Multiplicity        | 11   |  |  |
| Туре                | BOOLEAN  |  |  |
| Default value       | false  |  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |  |
| Origin              | Elektrobit Automotive GmbH   |  |  |

| Parameter Name | PduRPartitionCount  |  |
|----------------|---|--|
| Description    | Specifies the number of partitions the PduR module is distributed at. Parameter is enabled when PduRMultiCoreSupport is enabled and has to be at least 2.  Optimization Effect: |  |
|                |   |  |
|                | ▶ ROM reduction (config): Decreasing this parameter reduces the ROM consumption of the module configuration.  |  |
|                | ▶ RAM reduction (config): Decreasing this parameter reduces the RAM consumption of the module configuration.  |  |
|                | ▶ ROM reduction (code): Decreasing this parameter reduces the ROM consumption of the module code.   |  |
|                | ▶ RAM reduction (code): Decreasing this parameter reduces the RAM consumption of the module code.   |  |
|                | Execution time reduction (code): Decreasing this parameter reduces the execution time of the module code.   |  |
| Multiplicity   | 11  |  |
| Туре           | INTEGER   |  |



| Range               | >1                         |                  |
|---------------------|----------------------------|------------------|
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | PduRMultiTpTxRPathsMax   | PduRMultiTpTxRPathsMax       |  |
|---------------------|--|------------------------------|--|
| Description         | Maximum number of simultaneously handled routing paths that route an I-PDU from an upper layer module to multiple lower layer TP modules.  Note 1: If value 0 is chosen, the value is internally set to the number of routing paths configured that support routing of an I-PDU from an upper layer module to multiple lower layer TP modules.  Note 2: If value 0 is chosen, the value is internally set at least to one.  Optimization Effect:  RAM reduction (config): Decreasing this parameter reduces the RAM consumption of the module configuration. |                              |  |
| Multiplicity        | 11   |                              |  |
| Туре                | INTEGER  |                              |  |
| Default value       | 0  |                              |  |
| Range               | >=0  | >=0                          |  |
|                     | <=255  |                              |  |
| Configuration class | PreCompile:  | PreCompile: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH   |                              |  |

| Parameter Name | PduRRotfBufferAssignmentStrategy  |  |
|----------------|---|--|
| Description    | This parameter defines the strategy a TP buffer is assigned from the pool of Tp buffers for routing on-the-fly.  NEXT_TO_TPTHRESHOLD: The available TP buffer next in size greater or equal than PduRTpThreshold is selected, the classic Autosar approach for TpSduLength greater or equal PduRTpThreshold.      |  |
|                | NEXT_TO_SDULENGTH: The available TP buffer next in size smaller or equal than TpSduLength of StartOfReception is selected for TpSdu-Length greater or equal PduRTpThreshold. If no Tp buffer in the range of PduRTpThreshold and TpSduLength is available, the next in size greater than TpSduLength is selected. |  |
| Multiplicity   | 11  |  |
| Туре           | ENUMERATION   |  |



| Default value       | NEXT_TO_TPTHRESHOLD        |                  |
|---------------------|----------------------------|------------------|
| Range               | NEXT_TO_TPTHRESHOLD        |                  |
|                     | NEXT_TO_SDULENGTH          |                  |
| Configuration class | PreCompile:                | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | PduRlfGatewaySupport   |                                |
|---------------------|--|--------------------------------|
| Description         | Configuration parameter to enable or disable the PDU Router gateway operation between lower layer Interface modules. |                                |
|                     | ■ TRUE: non-TP PDU gateway routing   | g is enabled (switched on).    |
|                     | FALSE: non-TP PDU gateway routing  | ng is disabled (switched off). |
|                     | Optimization Effect:   |                                |
|                     | ▶ ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.          |                                |
|                     | ➤ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.                     |                                |
| Multiplicity        | 11   |                                |
| Туре                | BOOLEAN  |                                |
| Default value       | false  |                                |
| Configuration class | VariantPostBuild:  | VariantPostBuild               |
| Origin              | Elektrobit Automotive GmbH   |                                |

| Parameter Name | PduRTpGatewaySupport  |
|----------------|---|
| Description    | Configuration parameter to enable or disable the PDU Router gateway operation from a lower layer transport protocol module to one or more lower layer transport protocol module(s). |
|                | <ul> <li>TRUE: TP PDU gateway routing is enabled (switched on).</li> <li>FALSE: TP PDU gateway routing is disabled (switched off).</li> </ul>                                       |
|                | Optimization Effect:  |
|                | ▶ ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.   |
|                | ▶ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.  |



| Multiplicity        | 11                         |                  |
|---------------------|----------------------------|------------------|
| Туре                | BOOLEAN                    |                  |
| Default value       | false                      |                  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH |                  |

| Parameter Name      | PduRTpGwQueueEnable   |   |
|---------------------|---|---|
| Description         | <ul> <li>RAM reduction (config): Disabling sumption of the module configuration</li> <li>ROM reduction (code): Disabling to sumption of the module code.</li> </ul> | The queued requests are processed cool of TP buffers. Enabling this feature suffers for incoming TP bursts.  Us is enabled (switched on).  OUS is disabled (switched off).  If this parameter reduces the ROM content.  If this parameter reduces the RAM contents is the parameter reduces the RAM contents. |
| Multiplicity        | 11  |   |
| Туре                | BOOLEAN   |   |
| Default value       | false   |   |
| Configuration class | PreCompile:   | VariantPostBuild  |
| Origin              | Elektrobit Automotive GmbH  |   |

| Parameter Name | PduRRelocatableCfgEnable   |
|----------------|--|
| Description    | Enables or disables the post-build-time configuration data to be used either by relative offsets to the configuration start address (relocatable) or by absolute pointers (not relocatable). |
|                | TRUE: Relocateable configuration is in use (switched on).  |



|                     | FALSE: Relocateable configuration   | is not in use (switched off).        |  |
|---------------------|---|--------------------------------------|--|
|                     | <b>Note:</b> If PbcfgMBswModuleRef contains a reference to this module, then this feature is managed by the parameter PbcfgMRelocatableCfgEnable of the PbcfgM. |                                      |  |
|                     | Optimization Effect:  | Optimization Effect:                 |  |
|                     | ▶ ROM reduction (config): Enabling this parameter reduces the ROM consumption of the module configuration.  |                                      |  |
|                     | Execution time reduction (code): execution time of the module code.   | Disabling this parameter reduces the |  |
| Multiplicity        | 11  |                                      |  |
| Туре                | BOOLEAN   |                                      |  |
| Default value       | false   |                                      |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild                     |  |
| Origin              | Elektrobit Automotive GmbH  |                                      |  |

| Parameter Name      | PduRSbTxBufferSupport   |  |
|---------------------|---|--|
| Description         | Configuration parameter to enable or disable PDU Router support for single buffers used by non-TP-PDU gateway operations. |  |
|                     | Optimization Effect:  |  |
|                     | ▶ <b>ROM reduction (config):</b> Disabling this parameter reduces the ROM consumption of the module configuration.        |  |
|                     | ➤ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.                          |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name | PduRFifoTxBufferSupport   |
|----------------|---|
| Description    | Configuration parameter to enable or disable PDU Router support for FIFO buffers used by non-TP-PDU gateway operations. |
|                | Optimization Effect:  |



|                     | sumption of the module configura   | ng this parameter reduces the ROM contion.  g this parameter reduces the ROM con- |
|---------------------|------------------------------------|---|
| Multiplicity        | 11                                 |   |
| Туре                | BOOLEAN                            |   |
| Default value       | false                              |   |
| Configuration class | VariantPostBuild: VariantPostBuild |   |
| Origin              | Elektrobit Automotive GmbH         |   |

| Parameter Name      | PduRNto1RoutingSupport  |  |  |
|---------------------|---|--|--|
| Description         | Configuration parameter to enable or d  | Configuration parameter to enable or disable the N:1 gatewaying of I-PDUs. |  |
|                     | <ul> <li>▶ TRUE: N:1 gatewaying of I-PDUs is enabled (switched on).</li> <li>▶ FALSE: N:1 gatewaying of I-PDUs is disabled (switched off).</li> <li>Note: The destination PDUs have to be configured completely identical!</li> </ul> |  |  |
| Multiplicity        | , ,   |  |  |
| Multiplicity        | 11  |  |  |
| Туре                | BOOLEAN   |  |  |
| Default value       | false   |  |  |
| Configuration class | VariantPostBuild:   | VariantPostBuild   |  |
| Origin              | Elektrobit Automotive GmbH  |  |  |

| Parameter Name      | PduRMemorySize   |                  |
|---------------------|--|------------------|
| Description         | Memory size reserved for the PDU Router. Only required for gateway operation. If the parameter is disabled, then the size is calculated for the current configuration by the module configuration generator. |                  |
| Multiplicity        | 01   |                  |
| Туре                | INTEGER  |                  |
| Default value       | 0  |                  |
| Configuration class | PreCompile:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | PduRMemorySizeExtension  |
|----------------|--|
| Description    | Configuration parameter to allow RAM size usage of more than 64 KiB. |
|                | ▶ TRUE: RAM size NOT limited by 64 KiB at maximum (switched on).     |



|                     | FALSE: RAM size limited by 64 KiB                                      | at maximum (switched off).           |
|---------------------|--|--------------------------------------|
|                     | Optimization Effect:   |                                      |
|                     | ROM reduction (config): Disabling sumption of the module configuration | this parameter reduces the ROM conn. |
| Multiplicity        | 11   |                                      |
| Туре                | BOOLEAN  |                                      |
| Default value       | false  |                                      |
| Configuration class | VariantPostBuild: VariantPostBuild                                     |                                      |
| Origin              | Elektrobit Automotive GmbH   |                                      |

| Parameter Name      | PduRMulticastTxConfirmation  | PduRMulticastTxConfirmation |  |
|---------------------|--|-----------------------------|--|
| Description         | Configuration parameter to enable multicast transmission confirmation. This allows to call Up_TxConfirmation with the last PduR_LoTxConfirmation received for a transmission to multiple communication interface modules. Receiving PduR_LoTxConfirmation for dedicated destination PDUs is enabled by parameter PduRTransmissionConfirmation.  TRUE: Allows calling Up_TxConfirmation for multicast transmission.  FALSE: Disallows calling Up_TxConfirmation for multicast transmission.  Optimization Effect:  ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.  RAM reduction (config): Disabling this parameter reduces the RAM consumption of the module configuration. |                             |  |
| Multiplicity        | 11   |                             |  |
| Туре                | BOOLEAN  |                             |  |
| Default value       | false  |                             |  |
| Configuration class | PreCompile: VariantPostBuild   |                             |  |
| Origin              | Elektrobit Automotive GmbH   |                             |  |

| Parameter Name | PduRMulticastFromIfSupport   |
|----------------|--|
| Description    | Configuration parameter to enable or disable PDU Router support for multicast from a lower layer interface module to upper layer modules or lower layer interface modules.  Optimization Effect: |



|                     | <ul> <li>ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.</li> <li>ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.</li> </ul> |  |
|---------------------|---|--|
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | Elektrobit Automotive GmbH  |  |

| Parameter Name      | PduRMulticastTolfSupport   |                  |
|---------------------|--|------------------|
| Description         | Configuration parameter to enable or disable PDU Router support for multicast from an upper layer module to lower layer interface modules. |                  |
|                     | Optimization Effect:   |                  |
|                     | ▶ ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.                                |                  |
|                     | ➤ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.   |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | VariantPostBuild:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

| Parameter Name | PduRMulticastLoTpToUpSupport  |  |
|----------------|---|--|
| Description    | onfiguration parameter to enable or disable PDU Router support for multicast om a lower layer TP module to an upper layer module and one or more lower yer TP modules. Note: Enabling this switch is only necessary if an upper layer ansport protocol module is involved. Otherwise enabling configuration parameter PduRTpGatewaySupport is sufficient. |  |
|                | <ul> <li>ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.</li> <li>ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.</li> </ul>   |  |



| Multiplicity        | 11                                 |  |
|---------------------|------------------------------------|--|
| Туре                | BOOLEAN                            |  |
| Default value       | false                              |  |
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH         |  |

| Parameter Name      | PduRMulticastUpToLoTpSupport  |                  |
|---------------------|---|------------------|
| Description         | Configuration parameter to enable or disable PDU Router support for multicast from an upper layer module to lower layer TP modules. |                  |
|                     | Optimization Effect:  ROM reduction (config): Disabling this parameter reduces the ROM consumption of the module configuration.     |                  |
|                     | ▶ ROM reduction (code): Disabling this parameter reduces the ROM consumption of the module code.                                    |                  |
| Multiplicity        | 11  |                  |
| Туре                | BOOLEAN   |                  |
| Default value       | false   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH  |                  |

| Parameter Name | PduRRoutingPathGroupSupport  |  |
|----------------|--|--|
| Description    | Configuration parameter to enable or disable PDU Router support for Routing Path Groups.                   |  |
|                | ► TRUE: Routing path groups functionality is enabled (switched on).  |  |
|                | FALSE: Routing path groups functionality is disabled (switched off).                                       |  |
|                | Optimization Effect:   |  |
|                | ➤ ROM reduction (config): Disabling the parameter reduces the ROM consumption of the module configuration. |  |
|                | ➤ RAM reduction (code): Disabling this parameter reduces the RAM consumption of the module code.           |  |
|                | Execution time reduction (code): Disabling this parameter reduces the execution time of the module code.   |  |
| Multiplicity   | 11   |  |



| Туре                | BOOLEAN                    |                  |  |
|---------------------|----------------------------|------------------|--|
| Default value       | false                      |                  |  |
| Configuration class | VariantPostBuild:          | VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH |                  |  |

| Parameter Name      | PduRMulticastTpHighestWinsStrategy   |                  |
|---------------------|--|------------------|
| Description         | Configuration parameter to enable or disable PDU Router support of highest wins strategy for multicast gateway transmissions and pure multicast transmissions on transport protocol modules. Highest Wins strategy means, that for a single LoTp_Transmit returning E_OK, the complete multicast transmission is considered as successful. It continues with other LoTp_Transmit calls even if a return value is not E_OK. The same applies to PduR_LoTpTxConfirmation calls for parameter Result obtained with NTFRSLT_OK.  TRUE: Highest Wins strategy is enabled (switched on).  FALSE: Highest Wins strategy is disabled (switched off, lowest wins strategy applies). |                  |
| Multiplicity        | 11   |                  |
| Туре                | BOOLEAN  |                  |
| Default value       | false  |                  |
| Configuration class | PreCompile:  | VariantPostBuild |
| Origin              | Elektrobit Automotive GmbH   |                  |

# 5.6.1.5. PduRRoutingTables

| Containers included  |              |   |
|----------------------|--------------|---|
| Container name       | Multiplicity | Description   |
| PduRRoutingPathGroup | 0n           | This container groups routing path destinations. Destinations are used instead of routing paths since a routing path can be 1:n. It is desirable to be able to enable/disable a specific bus (i.e. a destination) rather than a routing path. Of course it is possible to create groups that covers specific routing paths as well.  Note: Enabling and disabling of routing path groups are made using the PduR API. |
| PduRRoutingTable     | 0n           | Represents one container of routing paths. Each container is either minimum routing or not.   |



| Containers included |    |   |
|---------------------|----|---|
| PduRTpBufferTable   | 01 | This container will specify the needed buffers for gatewaying using TP. It is not connected to the specific routing path destination to allow a more efficient buffer handling. |
| PduRTxBufferTable   | 01 | This container will specify the needed buffers for gatewaying using communication interface. It is not defined per routing path to allow reuse of buffers.                      |

| Parameters included |              |  |
|---------------------|--------------|--|
| Parameter name      | Multiplicity |  |
| PduRConfigurationId | 11           |  |

| Parameter Name      | PduRConfigurationId   |                  |
|---------------------|---|------------------|
| Description         | Identification of the configuration of the PduR configuration. This identification can be read using the PduR API. <i>Note: The value 65535 is used as an invalid configuration ID.</i> |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Default value       | 0   |                  |
| Range               | <=65534<br>>=0  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

# 5.6.1.6. PduRRoutingPathGroup

| Parameters included    |              |  |
|------------------------|--------------|--|
| Parameter name         | Multiplicity |  |
| PduRIsEnabledAtInit    | 11           |  |
| PduRRoutingPathGroupId | 11           |  |
| PduRDestPduRef         | 1n           |  |

| Parameter Name | PduRlsEnabledAtInit   |  |
|----------------|---|--|
| •              | If set to true this routing path group will be enabled after initializing the PDU Router module (i.e. enabled in the PduR_Init function). |  |
| Multiplicity   | 11  |  |



| Туре                | BOOLEAN                            |  |
|---------------------|------------------------------------|--|
| Configuration class | VariantPostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                       |  |

| Parameter Name       | PduRRoutingPathGroupId   |  |
|----------------------|--|--|
| Description          | Identification of the routing group.  Note: The identification will be used by the disable/enable API in the PDU  Router module API. |  |
| Multiplicity         | 11   |  |
| Туре                 | INTEGER  |  |
| Range                | <65535<br>>=0  |  |
| O anti-montion along |  |  |
| Configuration class  | VariantPostBuild: VariantPostBuild   |  |
| Origin               | AUTOSAR_ECUC   |  |

| Parameter Name      | PduRDestPduRef  |  |
|---------------------|---|--|
| Description         | This reference selects one destination of the routing path. |  |
| Multiplicity        | 1n  |  |
| Туре                | REFERENCE   |  |
| Configuration class | PostBuild: VariantPostBuild                                 |  |
| Origin              | AUTOSAR_ECUC  |  |

# 5.6.1.7. PduRRoutingTable

| Containers included |              |  |  |
|---------------------|--------------|--|--|
| Container name      | Multiplicity | Description  |  |
| PduRRoutingPath     | 0n           | This container specifies the routing path of a PDU.  Optimization Effect:                                  |  |
|                     |              | ▶ ROM reduction (config): Removing a Routing Path reduces the ROM consumption of the module configuration. |  |

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |



| Parameters included  |    |
|----------------------|----|
| PduRIsMinimumRouting | 11 |

| Parameter Name      | PduRIsMinimumRouting  |  |
|---------------------|---|--|
| Description         | The functionality related to this parameter is not supported by the current implementation.  Specifies if the container contains routing paths that are of the type minimum routing or not. |  |
| Multiplicity        | 11  |  |
| Туре                | BOOLEAN   |  |
| Default value       | false   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

# 5.6.1.8. PduRRoutingPath

| Containers included |              |   |
|---------------------|--------------|---|
| Container name      | Multiplicity | Description   |
| <u>PduRDestPdu</u>  | 1n           | This container is a subcontainer of PduRRoutingPath and specifies one destination for the PDU to be routed. |
| <u>PduRSrcPdu</u>   | 11           | This container is a subcontainer of PduRRoutingPath and specifies the source of the PDU to be routed.       |

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| PduRTpGwQueueDepth  | 01           |

| Parameter Name | PduRTpGwQueueDepth  |  |
|----------------|---|--|
| Description    | This parameter defines the queue depth for this routing path. It represents the maximum number of ongoing TP gateway receptions that can be handled for considered source PDU in case of enabled TP gateway queueing. The value corresponds to the maximum number of TP buffers that can be assigned to route and queue incoming PDUs, i.e. including the Tp buffer in use. |  |
|                | Optimization Effect:  |  |
|                | ▶ RAM reduction (config): Disabling this parameter reduces the RAM consumption of the module configuration.   |  |



| Multiplicity        | 01                          |  |
|---------------------|-----------------------------|--|
| Туре                | INTEGER                     |  |
| Default value       | 1                           |  |
| Configuration class | PostBuild: VariantPostBuild |  |
| Origin              | Elektrobit Automotive GmbH  |  |

# 5.6.1.9. PduRDestPdu

| Containers included     |              |   |
|-------------------------|--------------|---|
| Container name          | Multiplicity | Description   |
| <u>PduRDefaultValue</u> | 01           | Specifies the default value of the I-PDU. Only required for gateway operation and if at least one PDU specified by PduRDestPdu uses TriggerTransmit Data provision. Represented as an array of IntegerParamDef. |

| Parameters included          |              |  |
|------------------------------|--------------|--|
| Parameter name               | Multiplicity |  |
| PduRDestPduDataProvision     | 01           |  |
| PduRDestPduHandleId          | 01           |  |
| PduRTpThreshold              | 01           |  |
| PduRTransmissionConfirmation | 01           |  |
| PduRDestPduRef               | 11           |  |
| PduRDestTxBufferRef          | 01           |  |

| Parameter Name | PduRDestPduDataProvision  |  |
|----------------|---|--|
| Description    | Specifies how data are provided:                                |  |
|                | ➤ PDUR_DIRECT: direct (as part of the Transmit call)            |  |
|                | PDUR_TRIGGERTRANSMIT: via the TriggerTransmit callback function |  |
|                | Only required for non-TP gatewayed I-PDUs.                      |  |
| Multiplicity   | 01  |  |
| Туре           | ENUMERATION   |  |
| Default value  | PDUR_DIRECT   |  |
| Range          | PDUR_DIRECT   |  |



|                     | PDUR_TRIGGERTRANSMIT        |  |
|---------------------|-----------------------------|--|
| Configuration class | PostBuild: VariantPostBuild |  |
| Origin              | AUTOSAR_ECUC                |  |

| Parameter Name      | PduRDestPduHandleld   |  |
|---------------------|---|--|
| Description         | PDU identifier assigned by PDU Router. Used by communication interface and transport protocol modules for confirmation. |  |
| Multiplicity        | 01  |  |
| Туре                | INTEGER   |  |
| Range               | <=65535   |  |
|                     | >=0   |  |
| Configuration class | PostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | PduRTpThreshold   |                  |
|---------------------|---|------------------|
| Description         | Defines the number of bytes which shall be received before transmission on the destination bus may start. Only required for routing-on-the-fly TP gateway PDUs. The threshold shall not be larger than the length of the related TP buffer. |                  |
| Multiplicity        | 01  |                  |
| Туре                | INTEGER   |                  |
| Default value       | 1   |                  |
| Configuration class | PostBuild:  | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

| Parameter Name | PduRTransmissionConfirmation   |
|----------------|--|
| Description    | This parameter is only for communication interfaces. Transport protocol modules will always call the TxConfirmation function. If set the destination communication interface module will call the TxConfirmation. However the TxConfirmation may be not called due to error. So the PduR shall not block until the TxConfirmation is called. One background for this parameter is for the PduR to know when all modules have confirmed a multicast operation. The support of this functionality is generally switched on/off by parameter PduRMulticastTxConfirmation. |
| Multiplicity   | 01   |
| Туре           | BOOLEAN  |
| Default value  | FALSE  |



| Configuration class | PostBuild:   | VariantPostBuild |
|---------------------|--------------|------------------|
| Origin              | AUTOSAR_ECUC |                  |

| Parameter Name      | PduRDestPduRef  |  |
|---------------------|---|--|
| Description         | Destination PDU reference; reference to unique PDU identifier which shall be used by the PDU Router instead of the source PDU ID when calling the related function of the destination module. |  |
| Multiplicity        | 11  |  |
| Туре                | REFERENCE   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

| Parameter Name      | PduRDestTxBufferRef   |  |
|---------------------|---|--|
| Description         | Reference to a buffer that is allocated in the PduRTxBuffer. Having a global (for PduR) list of buffers allows reuse and hence less memory consumption. |  |
| Multiplicity        | 01  |  |
| Туре                | REFERENCE   |  |
| Configuration class | PostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC  |  |

## 5.6.1.10. PduRDefaultValue

| Containers included     |              |  |
|-------------------------|--------------|--|
| Container name          | Multiplicity | Description  |
| PduRDefaultValueElement | 0n           | Each value element is represented by the element and the position in an array. |

# 5.6.1.11. PduRDefaultValueElement

| Parameters included                 |    |  |
|-------------------------------------|----|--|
| Parameter name Multiplicity         |    |  |
| PduRDefaultValueElement             | 11 |  |
| PduRDefaultValueElementBytePosition | 11 |  |



| Parameter Name      | PduRDefaultValueElement  |  |
|---------------------|--|--|
| Description         | The default value consists of a number of elements. Each element is one byte long and the number of elements is specified by PduLength. The position of this parameter in the container is specified by the PduRElementBytePosition parameter. |  |
| Multiplicity        | 11   |  |
| Туре                | INTEGER  |  |
| Default value       | 0  |  |
| Range               | <=255  |  |
|                     | >=0  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

| Parameter Name      | PduRDefaultValueElementBytePosition   |  |
|---------------------|---|--|
| Description         | This parameter specifies the byte position of the element within the default value. |  |
| Multiplicity        | 11  |  |
| Туре                | INTEGER   |  |
| Default value       | 0   |  |
| Range               | <=255   |  |
|                     | >=0   |  |
| Configuration class | VariantPostBuild: VariantPostBuild  |  |
| Origin              | AUTOSAR_ECUC  |  |

# 5.6.1.12. PduRSrcPdu

| Parameters included         |    |  |
|-----------------------------|----|--|
| Parameter name Multiplicity |    |  |
| PduRSourcePduHandleId       | 11 |  |
| PduRSrcPduRef               | 11 |  |

| Parameter Name | PduRSourcePduHandleld                  |  |
|----------------|--|--|
| Description    | PDU identifier assigned by PDU Router. |  |
| Multiplicity   | 11                                     |  |



| Туре                | INTEGER           |                  |
|---------------------|-------------------|------------------|
| Range               | <=65535           |                  |
|                     | >=0               |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

| Parameter Name      | PduRSrcPduRef  |  |
|---------------------|--|--|
| Description         | Source PDU reference; reference to unique PDU identifier which shall be used for the requested PDU Router operation. |  |
| Multiplicity        | 11   |  |
| Туре                | REFERENCE  |  |
| Configuration class | VariantPostBuild: VariantPostBuild   |  |
| Origin              | AUTOSAR_ECUC   |  |

# 5.6.1.13. PduRTpBufferTable

| Containers included |              |   |  |
|---------------------|--------------|---|--|
| Container name      | Multiplicity | Description   |  |
| PduRTpBuffer        | 0n           | This container specifies a buffer for a TP gateway operation.  Note: A circular TP buffer implementation is applied for routing on the fly. |  |
|                     |              | Optimization Effect:  |  |
|                     |              | ▶ RAM reduction (config): Removing a TP buffer reduces the RAM consumption of the module configuration.                                     |  |

| Parameters included         |    |  |
|-----------------------------|----|--|
| Parameter name Multiplicity |    |  |
| PduRMaxTpBufferNumber       | 11 |  |

| Parameter Name | PduRMaxTpBufferNumber  |  |
|----------------|--|--|
| Description    | The functionality related to this parameter is not supported by the current implementation.  Maximum number of TP buffers used for TP gateway operation. |  |
| Multiplicity   | 11   |  |



| Туре                | INTEGER           |                  |
|---------------------|-------------------|------------------|
| Default value       | 0                 |                  |
| Range               | <=65535           |                  |
|                     | >=0               |                  |
| Configuration class | VariantPostBuild: | VariantPostBuild |
| Origin              | AUTOSAR_ECUC      |                  |

# 5.6.1.14. PduRTpBuffer

| Parameters included |              |
|---------------------|--------------|
| Parameter name      | Multiplicity |
| PduRTpBufferLength  | 11           |

| Parameter Name      | PduRTpBufferLength                          |                  |
|---------------------|---|------------------|
| Description         | Length of the TP buffer in number of bytes. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER                                     |                  |
| Default value       | 8   |                  |
| Range               | <=65535                                     |                  |
|                     | >=1   |                  |
| Configuration class | VariantPostBuild:                           | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                                |                  |

# 5.6.1.15. PduRTxBufferTable

| Containers included |              |   |  |
|---------------------|--------------|---|--|
| Container name      | Multiplicity | Description   |  |
| PduRTxBuffer        | 0n           | This container specifies a Transmit Buffer for a non-TP PDU.  Optimization Effect:                                    |  |
|                     |              | ▶ RAM reduction (config): Removing a Transmit Buffer<br>reduces the RAM consumption of the module configura-<br>tion. |  |



| Parameters included   |              |  |
|-----------------------|--------------|--|
| Parameter name        | Multiplicity |  |
| PduRMaxTxBufferNumber | 11           |  |

| Parameter Name      | PduRMaxTxBufferNumber   |                  |
|---------------------|---|------------------|
| Description         | The functionality related to this parameter is not supported by the current implementation.  Maximum number of transmit buffers used for non-TP gateway operations. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Default value       | 0   |                  |
| Range               | <=65535<br>>=0  |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

## 5.6.1.16. PduRTxBuffer

| Parameters included                 |              |  |
|-------------------------------------|--------------|--|
| Parameter name                      | Multiplicity |  |
| PduRPduMaxLength                    | 11           |  |
| PduRTxBufferDepth PduRTxBufferDepth | 11           |  |

| Parameter Name      | PduRPduMaxLength                            |                  |
|---------------------|---|------------------|
| Description         | Length of the Tx buffer in number of bytes. |                  |
| Multiplicity        | 11  |                  |
| Туре                | INTEGER                                     |                  |
| Default value       | 8   |                  |
| Range               | <=255                                       |                  |
|                     | >=1   |                  |
| Configuration class | VariantPostBuild:                           | VariantPostBuild |
| Origin              | AUTOSAR_ECUC                                |                  |

| Parameter Name | PduRTxBufferDepth |
|----------------|-------------------|
|----------------|-------------------|



| Description         | Number of Pdus that can be stored in the buffer. If value is 1 then the buffer semantic is "last is best". If the value is greater then 1 then the buffer semantic is a FiFo. |                  |
|---------------------|---|------------------|
| Multiplicity        | 11  |                  |
| Туре                | INTEGER   |                  |
| Default value       | 1   |                  |
| Range               | <=255   |                  |
|                     | >=1   |                  |
| Configuration class | VariantPostBuild:   | VariantPostBuild |
| Origin              | AUTOSAR_ECUC  |                  |

# 5.6.2. Recommended configurations

# 5.6.2.1. PduRRecConfigurationCanEcu

| Containers included                 |                               |  |
|-------------------------------------|-------------------------------|--|
| Container name Container definition |                               |  |
| Com                                 | PduRBswModules PduRBswModules |  |
| Dcm                                 | PduRBswModules                |  |
| CanIf                               | PduRBswModules                |  |
| CanTp                               | PduRBswModules PduRBswModules |  |
| IpduM                               | PduRBswModules                |  |

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |

### 5.6.2.1.1. Com

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |



| Parameters included           |          |
|-------------------------------|----------|
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | false    |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

### 5.6.2.1.2. Dcm

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | true  |
| PduRCancelTransmit            | true  |
| PduRChangeParameterRequestApi | false |
| PduRCommunicationInterface    | true  |
| PduRLowerModule               | false |
| PduRRetransmission            | true  |
| PduRTransportProtocol         | true  |
| PduRTriggertransmit           | false |
| PduRTxConfirmation            | true  |
| PduRUpperModule               | true  |
| PduRUseTag                    | true  |
| PduRBswModuleIsEnabled        | true  |
| PduRStaticPduLengthSupport    | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRBswModuleApiDefinition | FUNCTION |

### 5.6.2.1.3. CanIf

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

# 5.6.2.1.4. CanTp

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | true  |
| PduRCancelTransmit            | true  |
| PduRChangeParameterRequestApi | true  |
| PduRCommunicationInterface    | false |
| PduRLowerModule               | true  |
| PduRRetransmission            | false |
| PduRTransportProtocol         | true  |



| Parameters included        |          |
|----------------------------|----------|
| PduRTriggertransmit        | false    |
| PduRTxConfirmation         | false    |
| PduRUpperModule            | false    |
| PduRUseTag                 | true     |
| PduRBswModuleIsEnabled     | true     |
| PduRStaticPduLengthSupport | false    |
| PduRBswModuleApiDefinition | FUNCTION |

### 5.6.2.1.5. lpduM

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

# 5.6.2.2. PduRRecConfigurationEthernetEcu

| Containers included |                      |
|---------------------|----------------------|
| Container name      | Container definition |



| Containers included |                |
|---------------------|----------------|
| Com                 | PduRBswModules |
| Dcm                 | PduRBswModules |
| SoAd                | PduRBswModules |
| DolP                | PduRBswModules |
| IpduM               | PduRBswModules |

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |

## 5.6.2.2.1. Com

| Parameters included                   |          |
|---------------------------------------|----------|
| Parameter name                        | Value    |
| PduRCancelReceive                     | false    |
| PduRCancelTransmit                    | false    |
| PduRChangeParameterRequestApi         | false    |
| PduRCommunicationInterface            | true     |
| PduRLowerModule                       | false    |
| PduRRetransmission PduRRetransmission | false    |
| PduRTransportProtocol                 | false    |
| PduRTriggertransmit                   | true     |
| PduRTxConfirmation                    | true     |
| PduRUpperModule                       | true     |
| PduRUseTag                            | true     |
| PduRBswModuleIsEnabled                | true     |
| PduRStaticPduLengthSupport            | false    |
| PduRBswModuleApiDefinition            | FUNCTION |

### 5.6.2.2.2. Dcm

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |



| Parameters included           |          |
|-------------------------------|----------|
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | false    |
| PduRRetransmission            | true     |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

### 5.6.2.2.3. SoAd

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | true  |
| PduRCancelTransmit            | false |
| PduRChangeParameterRequestApi | false |
| PduRCommunicationInterface    | true  |
| PduRLowerModule               | true  |
| PduRRetransmission            | false |
| PduRTransportProtocol         | true  |
| PduRTriggertransmit           | true  |
| PduRTxConfirmation            | true  |
| PduRUpperModule               | false |
| PduRUseTag                    | true  |
| PduRBswModuleIsEnabled        | true  |
| PduRStaticPduLengthSupport    | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRBswModuleApiDefinition | FUNCTION |

### 5.6.2.2.4. DoIP

| Parameters included                 |          |
|-------------------------------------|----------|
| Parameter name                      | Value    |
| PduRCancelReceive PduRCancelReceive | false    |
| PduRCancelTransmit                  | false    |
| PduRChangeParameterRequestApi       | false    |
| PduRCommunicationInterface          | true     |
| PduRLowerModule PduRLowerModule     | true     |
| PduRRetransmission                  | false    |
| PduRTransportProtocol               | true     |
| PduRTriggertransmit                 | false    |
| PduRTxConfirmation                  | false    |
| PduRUpperModule                     | false    |
| PduRUseTag                          | true     |
| PduRBswModuleIsEnabled              | true     |
| PduRStaticPduLengthSupport          | false    |
| PduRBswModuleApiDefinition          | FUNCTION |

## 5.6.2.2.5. lpduM

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | false |
| PduRCancelTransmit            | false |
| PduRChangeParameterRequestApi | false |
| PduRCommunicationInterface    | true  |
| PduRLowerModule               | true  |
| PduRRetransmission            | false |
| PduRTransportProtocol         | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRTriggertransmit        | true     |
| PduRTxConfirmation         | true     |
| PduRUpperModule            | true     |
| PduRUseTag                 | true     |
| PduRBswModuleIsEnabled     | true     |
| PduRStaticPduLengthSupport | false    |
| PduRBswModuleApiDefinition | FUNCTION |

# 5.6.2.3. PduRRecConfigurationFrEcu

| Containers included |                      |
|---------------------|----------------------|
| Container name      | Container definition |
| Com                 | PduRBswModules       |
| Dcm                 | PduRBswModules       |
| Frlf                | PduRBswModules       |
| FrTp                | PduRBswModules       |
| <u>IpduM</u>        | PduRBswModules       |

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |

### 5.6.2.3.1. Com

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | false |
| PduRCancelTransmit            | false |
| PduRChangeParameterRequestApi | false |
| PduRCommunicationInterface    | true  |
| PduRLowerModule               | false |
| PduRRetransmission            | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRTransportProtocol      | false    |
| PduRTriggertransmit        | true     |
| PduRTxConfirmation         | true     |
| PduRUpperModule            | true     |
| PduRUseTag                 | true     |
| PduRBswModuleIsEnabled     | true     |
| PduRStaticPduLengthSupport | false    |
| PduRBswModuleApiDefinition | FUNCTION |

### 5.6.2.3.2. Dcm

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | false    |
| PduRRetransmission            | true     |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

### 5.6.2.3.3. Frlf

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |



| Parameters included           |          |
|-------------------------------|----------|
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

# 5.6.2.3.4. FrTp

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | true  |
| PduRCancelTransmit            | true  |
| PduRChangeParameterRequestApi | true  |
| PduRCommunicationInterface    | false |
| PduRLowerModule               | true  |
| PduRRetransmission            | true  |
| PduRTransportProtocol         | true  |
| PduRTriggertransmit           | false |
| PduRTxConfirmation            | false |
| PduRUpperModule               | false |
| PduRUseTag                    | true  |
| PduRBswModuleIsEnabled        | true  |
| PduRStaticPduLengthSupport    | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRBswModuleApiDefinition | FUNCTION |

### 5.6.2.3.5. IpduM

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

# 5.6.2.4. PduRRecConfigurationGatewayEcu

| Containers included |                               |
|---------------------|-------------------------------|
| Container name      | Container definition          |
| Com                 | PduRBswModules PduRBswModules |
| <u>Dcm</u>          | PduRBswModules PduRBswModules |
| Canlf               | PduRBswModules PduRBswModules |
| Linlf               | PduRBswModules PduRBswModules |
| <u>Frlf</u>         | PduRBswModules PduRBswModules |
| CanTp               | <u>PduRBswModules</u>         |



| Containers included |                               |
|---------------------|-------------------------------|
| LinTp               | PduRBswModules                |
| FrTp                | PduRBswModules PduRBswModules |
| SoAd                | PduRBswModules PduRBswModules |
| DoIP                | PduRBswModules PduRBswModules |
| IpduM               | PduRBswModules                |
| PduRGeneral         | PduRGeneral                   |

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |

### 5.6.2.4.1. Com

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | false    |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

#### 5.6.2.4.2. Dcm

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |



| Parameters included           |          |
|-------------------------------|----------|
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | false    |
| PduRRetransmission            | true     |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

### 5.6.2.4.3. CanIf

| Parameters included             |       |
|---------------------------------|-------|
| Parameter name                  | Value |
| PduRCancelReceive               | false |
| PduRCancelTransmit              | false |
| PduRChangeParameterRequestApi   | false |
| PduRCommunicationInterface      | true  |
| PduRLowerModule PduRLowerModule | true  |
| PduRRetransmission              | false |
| PduRTransportProtocol           | false |
| PduRTriggertransmit             | false |
| PduRTxConfirmation              | true  |
| PduRUpperModule                 | false |
| PduRUseTag                      | true  |
| PduRBswModuleIsEnabled          | true  |
| PduRStaticPduLengthSupport      | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRBswModuleApiDefinition | FUNCTION |

## 5.6.2.4.4. LinIf

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

## 5.6.2.4.5. FrIf

| Parameters included             |       |
|---------------------------------|-------|
| Parameter name                  | Value |
| PduRCancelReceive               | false |
| PduRCancelTransmit              | false |
| PduRChangeParameterRequestApi   | false |
| PduRCommunicationInterface      | true  |
| PduRLowerModule PduRLowerModule | true  |
| PduRRetransmission              | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRTransportProtocol      | false    |
| PduRTriggertransmit        | true     |
| PduRTxConfirmation         | true     |
| PduRUpperModule            | false    |
| PduRUseTag                 | true     |
| PduRBswModuleIsEnabled     | true     |
| PduRStaticPduLengthSupport | false    |
| PduRBswModuleApiDefinition | FUNCTION |

## 5.6.2.4.6. CanTp

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | true     |
| PduRCommunicationInterface    | false    |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | false    |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

# 5.6.2.4.7. LinTp

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |



| Parameters included           |          |
|-------------------------------|----------|
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | true     |
| PduRCommunicationInterface    | false    |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | false    |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

# 5.6.2.4.8. FrTp

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | true  |
| PduRCancelTransmit            | true  |
| PduRChangeParameterRequestApi | true  |
| PduRCommunicationInterface    | false |
| PduRLowerModule               | true  |
| PduRRetransmission            | true  |
| PduRTransportProtocol         | true  |
| PduRTriggertransmit           | false |
| PduRTxConfirmation            | false |
| PduRUpperModule               | false |
| PduRUseTag                    | true  |
| PduRBswModuleIsEnabled        | true  |
| PduRStaticPduLengthSupport    | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRBswModuleApiDefinition | FUNCTION |

### 5.6.2.4.9. SoAd

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

### 5.6.2.4.10. DoIP

| Parameters included             |       |
|---------------------------------|-------|
| Parameter name                  | Value |
| PduRCancelReceive               | false |
| PduRCancelTransmit              | false |
| PduRChangeParameterRequestApi   | false |
| PduRCommunicationInterface      | true  |
| PduRLowerModule PduRLowerModule | true  |
| PduRRetransmission              | false |
| PduRTransportProtocol           | true  |



| Parameters included        |          |
|----------------------------|----------|
| PduRTriggertransmit        | false    |
| PduRTxConfirmation         | false    |
| PduRUpperModule            | false    |
| PduRUseTag                 | true     |
| PduRBswModuleIsEnabled     | true     |
| PduRStaticPduLengthSupport | false    |
| PduRBswModuleApiDefinition | FUNCTION |

## 5.6.2.4.11. lpduM

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | false    |
| PduRCancelTransmit            | false    |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

## 5.6.2.4.12. PduRGeneral

| Parameters included  |       |
|----------------------|-------|
| Parameter name       | Value |
| PduRlfGatewaySupport | true  |



| Parameters included          |      |
|------------------------------|------|
| PduRTpGatewaySupport         | true |
| PduRSbTxBufferSupport        | true |
| PduRFifoTxBufferSupport      | true |
| PduRMulticastFromlfSupport   | true |
| PduRMulticastToIfSupport     | true |
| PduRMulticastLoTpToUpSupport | true |
| PduRMulticastUpToLoTpSupport | true |

# 5.6.2.5. PduRRecConfigurationLinEcu

| Containers included |                       |  |
|---------------------|-----------------------|--|
| Container name      | Container definition  |  |
| Com                 | <u>PduRBswModules</u> |  |
| <u>Dcm</u>          | <u>PduRBswModules</u> |  |
| <u>Linlf</u>        | <u>PduRBswModules</u> |  |
| <u>LinTp</u>        | <u>PduRBswModules</u> |  |
| <u>IpduM</u>        | <u>PduRBswModules</u> |  |

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |

### 5.6.2.5.1. Com

| Parameters included           |       |
|-------------------------------|-------|
| Parameter name                | Value |
| PduRCancelReceive             | false |
| PduRCancelTransmit            | false |
| PduRChangeParameterRequestApi | false |
| PduRCommunicationInterface    | true  |
| PduRLowerModule               | false |
| PduRRetransmission            | false |
| PduRTransportProtocol         | false |



| Parameters included        |          |
|----------------------------|----------|
| PduRTriggertransmit        | true     |
| PduRTxConfirmation         | true     |
| PduRUpperModule            | true     |
| PduRUseTag                 | true     |
| PduRBswModuleIsEnabled     | true     |
| PduRStaticPduLengthSupport | false    |
| PduRBswModuleApiDefinition | FUNCTION |

### 5.6.2.5.2. Dcm

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | false    |
| PduRRetransmission            | true     |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | true     |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

## 5.6.2.5.3. LinIf

| Parameters included |       |
|---------------------|-------|
| Parameter name      | Value |
| PduRCancelReceive   | false |



| Parameters included           |          |
|-------------------------------|----------|
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | false    |
| PduRCommunicationInterface    | true     |
| PduRLowerModule               | true     |
| PduRRetransmission            | false    |
| PduRTransportProtocol         | false    |
| PduRTriggertransmit           | true     |
| PduRTxConfirmation            | true     |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |

# 5.6.2.5.4. LinTp

| Parameters included           |          |
|-------------------------------|----------|
| Parameter name                | Value    |
| PduRCancelReceive             | true     |
| PduRCancelTransmit            | true     |
| PduRChangeParameterRequestApi | true     |
| PduRCommunicationInterface    | false    |
| PduRLowerModule               | true     |
| PduRRetransmission            | true     |
| PduRTransportProtocol         | true     |
| PduRTriggertransmit           | false    |
| PduRTxConfirmation            | false    |
| PduRUpperModule               | false    |
| PduRUseTag                    | true     |
| PduRBswModuleIsEnabled        | true     |
| PduRStaticPduLengthSupport    | false    |
| PduRBswModuleApiDefinition    | FUNCTION |



### 5.6.2.5.5. IpduM

| Parameters included                 |          |
|-------------------------------------|----------|
| Parameter name                      | Value    |
| PduRCancelReceive PduRCancelReceive | false    |
| PduRCancelTransmit                  | false    |
| PduRChangeParameterRequestApi       | false    |
| PduRCommunicationInterface          | true     |
| PduRLowerModule                     | true     |
| PduRRetransmission                  | false    |
| PduRTransportProtocol               | false    |
| PduRTriggertransmit                 | true     |
| PduRTxConfirmation                  | true     |
| PduRUpperModule                     | true     |
| <u>PduRUseTag</u>                   | true     |
| PduRBswModuleIsEnabled              | true     |
| PduRStaticPduLengthSupport          | false    |
| PduRBswModuleApiDefinition          | FUNCTION |

# 5.6.3. Application programming interface (API)

#### 5.6.3.1. Macro constants

### 5.6.3.1.1. PDUR\_E\_CONFIG\_PTR\_INVALID

| Purpose | Error code for invalid configuration pointer. |
|---------|---|
| Value   | 0x00U   |

### 5.6.3.1.2. PDUR\_E\_INVALID\_REQUEST

| Purpose | Error code if API service used without module initialization or PduR_Init called in any |
|---------|---|
|         | state other than PDUR_UNINIT.   |



| Value |
|-------|
|-------|

### 5.6.3.1.3. PDUR\_E\_NULL\_POINTER

| Purpose | Pointer parameter is null. Note that specific API calls may disable this error. |
|---------|---|
| Value   | 0x09U   |

# 5.6.3.1.4. PDUR\_E\_PDU\_ID\_INVALID

| Purpose | Error code if invalid PDU identifier has been passed to a public API function. |
|---------|--|
| Value   | 0x02U  |

### 5.6.3.1.5. PDUR\_E\_PDU\_INSTANCES\_LOST

| Purpose | Loss of a PDU instance (FIFO flushed because of an overrun). |
|---------|--|
| Value   | 0x0AU  |

# $5.6.3.1.6.\ PDUR\_E\_ROUTING\_PATH\_GROUP\_ID\_INVALID$

| Purpose | Error code if invalid Routing Path Group identifier is passed to PduR_DisableRouting() and PduR EnableRouting() functions. |
|---------|--|
|         |  |
| Value   | 0x08U  |

### 5.6.3.1.7. PDUR\_E\_TP\_TX\_REQ\_REJECTED

| Purpose | Error code if TP module rejects a transmit request for a valid PDU identifier. |
|---------|--|
| Value   | 0x03U  |

## 5.6.3.1.8. PDUR\_INSTANCE\_ID

| Purpose | Id of instance of PDU Router provided to Det_ReportError(). |
|---------|---|
| Value   | 0x00U   |



### 5.6.3.1.9. PDUR\_INVALID\_CONFIGURATION\_ID

| •     | Macro definition for the invalid configuration Id returned by PduR_GetConfigurationId if the PduR is not initialized. |
|-------|---|
| Value | 0xFFFFU   |

### 5.6.3.1.10. PDUR\_SID\_DISABLE\_ROUTING

| Purpose | Definition of service ID for PduR_DisableRouting. |
|---------|---|
| Value   | 0x51U   |

### 5.6.3.1.11. PDUR\_SID\_ENABLE\_ROUTING

| Purpose | Definition of service ID for PduR_EnableRouting. |
|---------|--|
| Value   | 0x50U  |

### 5.6.3.1.12. PDUR\_SID\_GET\_CONF\_ID

| Purpose | Definition of service ID for PduR_GetConfigurationId. |
|---------|---|
| Value   | 0x10U   |

## 5.6.3.1.13. PDUR\_SID\_GET\_VER\_INF

| Purpose | Definition of service ID for PduR_GetVersionInfo. |
|---------|---|
| Value   | 0x02U   |

## 5.6.3.1.14. PDUR\_SID\_IFGW\_RXIND\_DF

| Purpose | Definition of service ID for internal handler function PduR GateIfRxIndicationDf(DynPyld). |
|---------|--|
| Value   | 0x55U  |

### 5.6.3.1.15. PDUR\_SID\_IFGW\_RXIND\_SB

| Purpose | Definition of service ID for internal handler function PduR |
|---------|---|
|         | GateIfRxIndicationSb(DynPyld).                              |



|--|

## 5.6.3.1.16. PDUR\_SID\_IFGW\_RXIND\_TF

| Purpose | Definition of service ID for internal handler function PduR GateIfRxIndicationTf(DynPyld). |
|---------|--|
| Value   | 0x56U  |

## 5.6.3.1.17. PDUR\_SID\_IFGW\_TRIGTX\_SB

| Purpose | Definition of service ID for internal handler function PduR GateIfTriggerTransmitSb(DynPyld). |
|---------|---|
| Value   | 0x59U   |

## 5.6.3.1.18. PDUR\_SID\_IFGW\_TRIGTX\_TF

| •     | Definition of service ID for internal handler function PduR GateIfTriggerTransmitTf(DynPyld). |
|-------|---|
| Value | 0x58U   |

## 5.6.3.1.19. PDUR\_SID\_INIT

| Purpose | Definition of service ID for PduR_Init. |
|---------|---|
| Value   | 0x01U                                   |

# ${\bf 5.6.3.1.20.\ PDUR\_SID\_LOTP\_COPY\_RX\_DATA}$

| Purpose | Definition of service ID for PduR_LoTpCopyRxData. |
|---------|---|
| Value   | 0x32U   |

# ${\bf 5.6.3.1.21.\ PDUR\_SID\_LOTP\_COPY\_TX\_DATA}$

| Purpose | Definition of service ID for PduR_LoTpCopyTxData. |
|---------|---|
| Value   | 0x36U   |



## 5.6.3.1.22. PDUR\_SID\_LOTP\_RXIND

| Purpose | Definition of service ID for PduR_LoTpRxIndication. |
|---------|---|
| Value   | 0x33U   |

### 5.6.3.1.23. PDUR\_SID\_LOTP\_STRT\_OF\_RCPTN

| Purpose | Definition of service ID for PduR_LoTpStartOfReception. |
|---------|---|
| Value   | 0x34U   |

## 5.6.3.1.24. PDUR\_SID\_LOTP\_TX\_CONF

| Purpose | Definition of service ID for PduR_LoTpTxConfirmation. |
|---------|---|
| Value   | 0x37U   |

### 5.6.3.1.25. PDUR\_SID\_LO\_RXIND

| Purpose | Definition of service ID for PduR_LoRxIndication. |
|---------|---|
| Value   | 0x42U   |

### 5.6.3.1.26. PDUR\_SID\_LO\_TRIGTX

| Purpose | Definition of service ID for PduR_LoTriggerTransmit. |
|---------|--|
| Value   | 0x41U  |

### 5.6.3.1.27. PDUR\_SID\_LO\_TXCONF

| Purpose | Definition of service ID for PduR_LoTxConfirmation. |
|---------|---|
| Value   | 0x40U   |

## 5.6.3.1.28. PDUR\_SID\_UP\_CANCELRXREQ

| Purpose | Definition of service ID for PduR_UpCancelReceive. |
|---------|--|
| Value   | 0x21U  |



# 5.6.3.1.29. PDUR\_SID\_UP\_CANCELTXREQ

| Purpose | Definition of service ID for PduR_UpCancelTransmit. |
|---------|---|
| Value   | 0x1CU   |

## 5.6.3.1.30. PDUR\_SID\_UP\_CHANGEPARAREQ

| Purpose | Definition of service ID for PduR_UpChangeParameter. |
|---------|--|
| Value   | 0x1DU  |

## 5.6.3.1.31. PDUR\_SID\_UP\_TX

| Purpose | Definition of service ID for PduR_UpTransmit. |
|---------|---|
| Value   | 0x14U   |

## 5.6.3.1.32. PduR\_GetVersionInfo

| Purpose     | Get version information.   |
|-------------|--|
| Value       | do \ { \ /* get version info of PduR module */ \ (versionInfo)->vendorID = PDUR_VEN-DOR_ID; \ (versionInfo)->moduleID = PDUR_MODULE_ID; \ (versionInfo)->sw_ma-jor_version = PDUR_SW_MAJOR_VERSION; \ (versionInfo)->sw_minor_version = PDUR_SW_MINOR_VERSION; \ (versionInfo)->sw_patch_version = PDUR_SWPATCH_VERSION; \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ |
| Description | This service returns the version information of this module.   |

# 5.6.3.1.33. SchM\_Enter\_PduR\_SCHM\_PDUR\_EXCLUSIVE\_AREA\_1

| Purpose |  |
|---------|--|
| Value   | SchM_Enter_PduR_SCHM_PDUR_EXCLUSIVE_AREA_0() |

# 5.6.3.1.34. SchM\_Enter\_PduR\_SCHM\_PDUR\_EXCLUSIVE\_AREA\_2

| Purpose |  |
|---------|--|
| Value   | SchM_Enter_PduR_SCHM_PDUR_EXCLUSIVE_AREA_0() |



# $5.6.3.1.35. \ SchM\_Exit\_PduR\_SCHM\_PDUR\_EXCLUSIVE\_AREA\_1$

| Purpose |   |
|---------|---|
| Value   | SchM_Exit_PduR_SCHM_PDUR_EXCLUSIVE_AREA_0() |

# 5.6.3.1.36. SchM\_Exit\_PduR\_SCHM\_PDUR\_EXCLUSIVE\_AREA\_2

| Purpose |   |
|---------|---|
| Value   | SchM_Exit_PduR_SCHM_PDUR_EXCLUSIVE_AREA_0() |

# 5.6.3.2. Objects

## 5.6.3.2.1. PduR\_GConfigPtr

| Purpose | PduR_GConfigPtr global variable for the pointer to the config of PduR. |
|---------|--|
| Туре    | const PduR_PBConfigType *  |

#### 5.6.3.2.2. PduR\_State

| Purpose | Variable holding the State of the PDU Router. |
|---------|---|
| Туре    | PduR_StateType                                |

# 5.6.3.3. Functions

# 5.6.3.3.1. PduR\_GetConfigurationId

| Purpose      | Get configuration ID.  |
|--------------|--|
| Synopsis     | PduR_PBConfigIdType PduR_GetConfigurationId ( void );  |
| Service ID   | 0x10   |
| Sync/Async   | Synchronous  |
| Reentrancy   | Reentrant  |
| Return Value | Identifier of the post-build time configuration. For enabled DET the invalid configuration Id 'PDUR_INVALID_CONFIGURATION_ID' is returned. |



| Description | Returns the unique identifier of the post-build time configuration of the PDU Router. |  |
|-------------|---|--|
|             |   |  |

# 5.6.3.3.2. PduR\_Init

| Purpose         | PduR_Init - Initializes the PDU Router. Function to initialize the PduR module.  First function to be called of PduR. The module calling the function PduR_Init has to include PduR_PBcfg.h. The invocation of the PduR_Init function is PduRInit(&(PDUR_CONFIG_NAME.PduR_RootConfig));. |                                      |
|-----------------|--|--------------------------------------|
| Synopsis        | <pre>void PduR_Init ( const PduR_PBConfigType * ConfigPtr );</pre>   |                                      |
| Service ID      | 0x01   |                                      |
| Sync/Async      | Synchronous  |                                      |
| Reentrancy      | Non Reentrant  |                                      |
| Parameters (in) | ConfigPtr  | Pointer to post build configuration. |

# 5.6.3.3.3. PduR\_lsValidConfig

| Purpose         | Validate configuration.   |  |  |
|-----------------|---|--|--|
| Synopsis        | Std_ReturnType PduR_IsValidConfig ( const void * ConfigPtr );   |  |  |
| Sync/Async      | Synchronous   |  |  |
| Reentrancy      | Reentrant   | Reentrant                                    |  |
| Parameters (in) | ConfigPtr  Pointer to configuration structure that holds the PduR module post-build-time configuration data.  |  |  |
| Return Value    | Function execution success status   |  |  |
|                 | E_OK  | the provided module configuration is valid   |  |
|                 | E_NOT_OK  | the provided module configuration is invalid |  |
| Description     | Checks if the post build configuration is valid. A configuration is invalid if  the platform signature does not match.  the published information signature does not match.  the link time signature does not match.  the compile time signature does not match.  the function is called with a null pointer. |  |  |



# 5.6.3.3.4. PduR\_LoRxIndication

| Purpose         | This service is called by the <lo> module to indicate a received I-PDU.</lo>          |  |
|-----------------|---|--|
| Synopsis        | <pre>void PduR_LoRxIndication ( PduIdType RxPduId , PduInfoType * PduInfoPtr );</pre> |  |
| Service ID      | 0x42  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.                     |  |
| Parameters (in) | RxPduId ID of the received I-PDU.   |  |
|                 | PduInfoPtr  | Contains the length (SduLength) of the received I-PDU and a pointer to a buffer (SduDataPtr) containing the I-PDU. |

# 5.6.3.3.5. PduR\_LoTpCopyRxData

| Purpose          | CopyRxData function.   |  |
|------------------|--|--|
| Synopsis         | <pre>BufReq_ReturnType PduR_LoTpCopyRxData ( PduIdType RxPduId , const PduInfoType * PduInfoPtr , PduLengthType * BufferSizePtr );</pre>                             |  |
| Service ID       | 0x32   |  |
| Sync/Async       | Synchronous  |  |
| Reentrancy       | Reentrant for different Pdulds. Non reentrant for the same Pduld.  |  |
| Parameters (in)  | RxPduId  | Identification of the received I-PDU.  |
|                  | PduInfoPtr   | Pointer to the buffer (SduDataPtr) and its length (SduLength) containing the data to be copied by PDU Router module in case of gateway or upper layer module in case of reception. |
| Parameters (out) | BufferSizePtr  | Available receive buffer after data has been copied.   |
| Return Value     | Result of buffer request   |  |
|                  | BUFREQ_OK  | Data copied successfully.  |
|                  | BUFREQ_E_NOT_OK  | Data was not copied because an error occurred.   |
| Description      | This function is called when a transport protocol module has data to copy for the receiving module. Several calls may be made during one transportation of an I-PDU. |  |



The service shall provide the currently available buffer size when invoked with info.Sd-uLength equal to 0.

# 5.6.3.3.6. PduR\_LoTpCopyTxData

| Purpose         | CopyTxData function.   |   |  |
|-----------------|--|---|--|
| Synopsis        | BufReq_ReturnType PduR_LoTpCopyTxData ( PduIdType TxPduId , PduInfoType * PduInfoPtr , RetryInfoType * RetryInfoPtr , Pdu-LengthType * AvailableDataPtr ); |   |  |
| Service ID      | 0x36   | 0x36  |  |
| Sync/Async      | Synchronous  |   |  |
| Reentrancy      | Reentrant for different Pdulds. Non ree  | entrant for the same Pduld.   |  |
| Parameters (in) | TxPduId  | Identification of the transmitted I-PDU.  |  |
|                 | RetryInfoPtr   | This parameter is used to retransmit data because problems during the last service call. If the I-PDU is transmitted from a local module (e.g. DCM) the PDU router module will just forward the parameter value without check. If the I-PDU is gatewayed from another bus, the PDU Router module will make the following interpretation: If the transmitted TP I-PDU does not support the retry feature a NULL_PTR is provided. It indicates that the copied transmit data can be removed from the buffer after it has been copied. If the retry feature is used by the Tx I-PDU, RetryInfoPtr must point to a valid RetryInfoType element. If TpDataState indicates TPCONFPENDING, the previously copied data must remain in the TP buffer to be available for error recovery. TP_DATA-CONF indicates that all data that have been copied so far are confirmed and can be removed from the TP buffer. Data copied by this API call are excluded and will be confirmed later. TP_DATARETRY indicates that this API call shall copy already copied data in order to recover from |  |



|                  |   | an error. In this case AvailableDataPtr specifies the offset of the first byte to be copied by the API call.   |
|------------------|---|--|
| Parameters (out) | PduInfoPtr  | Provides destination buffer and the number of bytes to copy. In case of gateway the PDU Router module will copy, otherwise the source upper layer module will copy the data. If not enough transmit data is available, no data is copied. The transport protocol module will retry. A copy size of 0 can be used to indicate state changes in the retry parameter. |
|                  | AvailableDataPtr  | Indicates the remaining number of bytes that are available in the PduR Tx buffer. AvailableDataPtr can be used by TP modules that support dynamic payload lengths (e.g. FlexRay ISO Transport Layer) to determine the size of the following CFs.   |
| Return Value     | Result of buffer request  |  |
|                  | BUFREQ_OK   | Data has been copied to the transmit buffer completely as requested.   |
|                  | BUFREQ_E_BUSY   | Request could not be fulfilled, because the required amount of Tx data is not available. TP layer might retry later on. No data has been copied.   |
|                  | BUFREQ_E_NOT_OK   | Data has not been copied. Request failed.  |
| Description      | This function is called by the transport protocol module to query the transmit data of an I-PDU segment. Each call to this function copies the next part of the transmit data until TpDataState indicates TP_DATARETRY. In this case the API restarts to copy the data beginning at the location indicated by AvailableDataPtr. The service shall provide the size of the remaining data when invoked with info.SduLength equal to 0. |  |

# 5.6.3.3.7. PduR\_LoTpRxIndication

| Purpose    | TpRxIndication function.  |
|------------|---|
| Synopsis   | <pre>void PduR_LoTpRxIndication ( PduIdType RxPduId , NotifResult-<br/>Type Result );</pre> |
| Service ID | 0x33  |



| Sync/Async      | Synchronous   |                          |
|-----------------|---|--------------------------|
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.   |                          |
| Parameters (in) | RxPduId Identification of the received I-PDU.   |                          |
|                 | Result  | Result of the reception. |
| Description     | This service is called by the transport protocol module after an I-PDU has been received successfully or when an error occurred. It is also used to confirm cancellation of an I-PDU. |                          |

# ${\bf 5.6.3.3.8.}\ {\bf PduR\_LoTpStartOfReception}$

| Purpose                    | StartOfReception function.  |  |  |
|----------------------------|---|--|--|
| Synopsis                   | <pre>BufReq_ReturnType PduR_LoTpStartOfReception ( PduIdType RxPduId , PduLengthType TpSduLength , PduLengthType * BufferSizePtr );</pre>   |  |  |
| Service ID                 | 0x34  |  |  |
| Sync/Async                 | Synchronous   | Synchronous  |  |
| Reentrancy                 | Reentrant for different Pdulds. Non ree   | ntrant for the same Pduld.   |  |
| Parameters (in)            | RxPduId   | Identification of the received I-PDU.  |  |
|                            | TpSduLength   | Total length of the PDU to be received.  |  |
| Parameters (out)           | BufferSizePtr   | Available receive buffer in the receiving module. This parameter will be used to compute the Block Size (BS) in the transport protocol module. |  |
| Return Value               | Result of buffer request  |  |  |
|                            | BUFREQ_OK   | Connection has been accepted. Buffer-<br>SizePtr indicates the available receive<br>buffer. Reception is continued.                            |  |
| provided. Reception is abo |   | No Buffer of the required length can be provided. Reception is aborted. Buffer-SizePtr remains unchanged.                                      |  |
|                            | BUFREQ_E_NOT_OK   | Connection has been rejected. Reception is aborted. BufferSizePtr remains unchanged.   |  |
| Description                | This function will be called by the transport protocol module at the start of receiving an I-PDU. The I-PDU might be fragmented into multiple N-PDUs (FF with one or more following CFs) or might consist of a single N-PDU (SF). The service shall provide the currently available maximum buffer size when invoked with TpSduLength equal to 0. |  |  |



# 5.6.3.3.9. PduR\_LoTpTxConfirmation

| Purpose         | TpTxConfirmation function.   |  |
|-----------------|--|--|
| Synopsis        | void PduR_LoTpTxConfirmation (   | PduIdType TxPduId , NotifResult-         |
|                 | Type Result );   |  |
| Service ID      | 0x37   |  |
| Sync/Async      | Synchronous  |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.  |  |
| Parameters (in) | TxPduId Identification of the transmitted I-PDU.   |  |
|                 | Result   | Result of the transmission of the I-PDU. |
| Description     | This service is called by a transport protocol module after the I-PDU has been transmitted on its network, the result will reveal if the transmission was successful or not. |  |

# 5.6.3.3.10. PduR\_LoTriggerTransmit

| Purpose         | The lower layer communication module requests the buffer of the SDU for transmission from the upper layer module. |  |
|-----------------|---|--|
| Synopsis        | <pre>Std_ReturnType PduR_LoTriggerTransmit ( PduIdType TxPduId , PduInfoType * PduInfoPtr );</pre>                |  |
| Service ID      | 0x41  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.   |  |
| Parameters (in) | TxPduId   | ID of the SDU that is requested to be transmitted.   |
|                 | PduInfoPtr  | Contains the length (SduLength) of the received I-PDU and a pointer to a buffer (SduDataPtr) containing the I-PDU. |
| Return Value    | Function execution success status   |  |
|                 | E_OK  | SDU has been copied and SduLength indicates the number of copied bytes.  |
|                 | E_NOT_OK  | No SDU has been copied. PduInfoPtr must not be used since it may contain a NULL pointer or point to invalid data.  |



# 5.6.3.3.11. PduR\_LoTxConfirmation

| Purpose         | This service is called by the <lo> module to confirm the transmission of an I-PDU.</lo> |  |
|-----------------|---|--|
| Synopsis        | void PduR_LoTxConfirmation ( PduIdType TxPduId );                                       |  |
| Service ID      | 0x40  |  |
| Sync/Async      | Synchronous   |  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.                       |  |
| Parameters (in) | TxPduId   | ID of the I-PDU that has been transmitted. |

# 5.6.3.3.12. PduR\_UpCancelReceive

| Purpose         | This service is called by the <up> module to request cancellation from an upper layer module of an I-PDU in a lower layer transport protocol module.</up> |   |
|-----------------|---|---|
| Synopsis        | Std_ReturnType PduR_UpCancelReceive ( PduIdType RxPduId );  |   |
| Service ID      | 0x21  |   |
| Sync/Async      | Synchronous   |   |
| Reentrancy      | Non Reentrant   |   |
| Parameters (in) | RxPduId   | Identification of the Rx I-PDU.                       |
| Return Value    | Function execution success status   |   |
|                 | E_OK  | Request accepted (but not yet performed).             |
|                 | E_NOT_OK  | Request not accepted (e.g. cancellation not possible) |

# 5.6.3.3.13. PduR\_UpCancelTransmit

| Purpose         | This service is called by the <up> module for cancellation of an ongoing transmission of an transport protocol module I-PDU.</up> |   |
|-----------------|---|---|
| Synopsis        | Std_ReturnType PduR_UpCancelTransmit ( PduIdType TxPduId );   |   |
| Service ID      | 0x1C  |   |
| Sync/Async      | Synchronous   |   |
| Reentrancy      | Non Reentrant   |   |
| Parameters (in) | TxPduId   | Identification of the Tx-PDU ID to be canceled. |
| Return Value    | Function execution success status   |   |



| E_OK | Request is accepted by the destination module.     |
|------|--|
|      | Request is not accepted by the destination module. |

# 5.6.3.3.14. PduR\_UpChangeParameter

| Purpose         | This service is called by the <up> module to request to change a specific transport protocol parameter (e.g. block-size). The affected transport protocol module is selected using the Rx I-PDU ID.</up> |   |  |
|-----------------|--|---|--|
| Synopsis        | Std_ReturnType PduR_UpChangeParameter ( PduIdType RxPduId , TP-ParameterType TPParameter , uint16 TPParameterValue );  |   |  |
| Service ID      | 0x1D   |   |  |
| Sync/Async      | Synchronous  |   |  |
| Reentrancy      | Non Reentrant  |   |  |
| Parameters (in) | RxPduId  | Identification of the Rx I-PDU to which the parameter the request shall affect. |  |
|                 | TPParameter  | The selected parameter that the request shall changed.                          |  |
|                 | TPParameterValue   | The value that the request shall change to.                                     |  |
| Return Value    | Function execution success status  | nction execution success status   |  |
|                 | E_OK   | Request is accepted.  |  |
|                 | E_NOT_OK   | Request is not accepted.  |  |

# 5.6.3.3.15. PduR\_UpTransmit

| Purpose         | This function is called by <up> module to request transmission of an I-PDU.</up> |                                  |
|-----------------|--|----------------------------------|
| Synopsis        | <pre>Std_ReturnType PduR_UpTransmit ( PduInfoType * PduInfoPtr );</pre>          | PduIdType TxPduId , const        |
| Service ID      | 0x14   |                                  |
| Sync/Async      | Synchronous  |                                  |
| Reentrancy      | Reentrant for different Pdulds. Non reentrant for the same Pduld.                |                                  |
| Parameters (in) | TxPduId  | Identification of the Tx-PDU ID. |



|              | PduInfoPtr                        | Length and pointer to the buffer of the I-PDU      |
|--------------|-----------------------------------|--|
| Return Value | Function execution success status |  |
|              | E_OK                              | Request is accepted by the destination module.     |
|              | E_NOT_OK                          | Request is not accepted by the destination module. |

# 5.6.4. Integration notes

#### 5.6.4.1. Exclusive areas

This section describes the exclusive areas used by the PduR module.

#### 5.6.4.1.1. SCHM\_PDUR\_EXCLUSIVE\_AREA\_0

| Protected data structures     | All shared data that shall be protected from mutual access.   |
|-------------------------------|---|
| Recommended locking mechanism | This exclusive area must always be protected by a locking mechanism. The options for locking are described in the EB tresos AutoCore Generic documentation. Refer to the section Mapping exclusive areas in the basic |
|                               | software modules in the Integration notes section for details.  |

# 5.6.4.2. Production errors

Production errors are not reported by the PduR module.

# 5.6.4.3. Memory mapping

General information about memory mapping is provided in the EB tresos AutoCore Generic documentation. Refer to the section Memory mapping and compiler abstraction in the Integration notes section for details.



The following table provides the list of sections that may be mapped for this module:

| Memory section          |
|-------------------------|
| VAR_CLEARED_UNSPECIFIED |
| VAR_INIT_UNSPECIFIED    |
| CODE                    |
| CONFIG_DATA_UNSPECIFIED |
| CONST_8                 |
| CONST_16                |
| CONST_32                |
| CONST_UNSPECIFIED       |
| CODE_CC_BLOCK           |

# 5.6.4.4. Integration requirements

#### WARNING

## Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user's guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

## 5.6.4.4.1. PduR.EB.IntReq.RestrictTpGwToSF

| Description | Restriction of TP gateway to single frames. TP gateway (1:n, n>1) of an I-PDU from a source transport protocol module to multiple destination transport protocol modules is restricted to single frames (SF) on the Tx-side. This implies that the completely stored I-PDU is fetched with a single call by PduR_ <lotp>CopyTxData. Calling the function PduR_<lotp>CopyTxData with a size PduInfoPtr-&gt;SduLength different to the complete I-PDU results in return value BUFREQ_E_BUSY. Calling the function PduR<lotp>CopyTxData after requesting the available size of data with PduInfoPtr-&gt;SduLength = 0 by PduR_<lotp>CopyTxData returns an AvailableDataSize of the completely stored I-PDU except the last one which returns 0.</lotp></lotp></lotp></lotp> |
|-------------|--|
| Rationale   | On a transport protocol module, an I-PDU can be transported in multiple N-PDUs (FF and CFs) or in a single N-PDU (SF). The typical case is that an I-PDU transported in multiple N-PDUs does not multicast I-PDUs (i.e. physical addressing) and in a single N-PDU may be multicast I-PDUs (i.e. functional addressing). Furthermore, the consumption of hardware resources (RAM, run time) is reduced.  |



## $5.6.4.4.2.\ PduR.EB.Int Req. Block LoTp Copy Tx Data For Tp Multicast$

|           | Blocked PduR_LoTpCopyTxData unless all LoTp_Transmit are called for TP multicast transmission. PduR_LoTpCopyTxData() is blocked for TP multicast transmission (1:n, n>1) unless all calls of LoTp_Transmit() are executed within PduR_UpTransmit(). |
|-----------|---|
| Rationale | This reduces the number of possible race conditions.  |

# 5.6.4.4.3. PduR.EB.IntReq.BlockLoTpCopyTxDataForDirectTpGw

| Description | Blocked PduR_LoTpCopyTxData, unless all LoTp_Transmit are called for a direct TP gateway. PduR_LoTpCopyTxData() is blocked for a direct TP gateway, unless all calls of LoTp_Transmit() are executed within PduR_LoTpRxIndication(). |
|-------------|--|
| Rationale   | This reduces the number of possible race conditions.   |

# $5.6.4.4.4.\ PduR. EB. Int Req. Block LoTpTx Confirmation For Direct TpGw$

| Description | Blocked PduR_LoTpTxConfirmation, unless all LoTp_Transmit are called for a direct TP gateway. PduR_LoTpTxConfirmation() is blocked for a direct TP gateway, unless all calls of LoTp_Transmit() are executed within PduR_LoTpRxIndication(). |
|-------------|--|
| Rationale   | This ensures that no race condition occurs regarding the state handling of LoTp Transmit within PduR_LoTpRxIndication to PduR_LoTpTxConfirmation. LoTp_Transmit are called for all enabled destinations prior to PduR_LoTpTxConfirmation.    |

# $5.6.4.4.5.\ PduR. EB. Int Req. Block LoTpTx Confirmation For TpMulticast$

| Description | Blocked PduR_LoTpTxConfirmation, unless all LoTp_Transmit are called for a TP multicast transmission. PduR_LoTpTxConfirmation() is blocked for a multicast TP transmission, unless all calls of LoTp_Transmit() are executed within PduR_UpTp-Transmit(). |
|-------------|---|
| Rationale   | This ensures that no race condition occurs regarding the state handling of LoTp Transmit within PduR_UpTpTransmit to PduR_LoTpTxConfirmation. LoTp_Transmit are called for all enabled destinations prior to PduR_LoTpTxConfirmation.                     |

## $5.6.4.4.6.\ PduR.EB.IntReq.RestrictNto1 toSingleActivatedRPath$

| Description | For N:1 PDU routing, there shall be at most one activated source PDU of the gateway |  |
|-------------|---|--|
|             | routing path.   |  |



| Rationale | As stated in RfC #71728, comment #3, it will be ensured that at run-time at most one of these N sources will be active. Note that this has been refined in RfC #67569, comment #84. 'Active' means, that concurrent calls are not possible, e.g. a CopyRxData from CAN1 can not be interrupted by a StartOfReception from CAN2. I.e. a tester is either used on CAN1 or CAN2, not to both. |
|-----------|--|
| Comment   | This requirement covers the TP gatewaying part of SWS_PDUR_00827 from AUTOSAR 4.4.0 release.   |

## 5.6.4.4.7. PduR.EB.IntReq.QualityMultiCore

| Description | In general, the usage of PduR with distributed communication stack is not ready for   |
|-------------|---|
|             | mass production. For details how to use it please refer to the important notes of the |
|             | release.  |

# 5.6.4.4.8. PduR.EB.IntReq.PartitionIndicesInClientServerEntities

| Description | Names of client-server entities shall include partition indices to distinguish different connections between multiple partitions in a unique way. The meaning of them is defined as follows: For distributed modules which are upper and lower layer module of the PduR at the same time (e.g. lpduM), source as well as destination partition indices are to be used, e.g.: lpduM_lfLLClient <srcldx>_<destidx>, where <srcldx> is the index of the source partition and <destidx> is the index of the destination partition. For non-distributed modules, only the source partition index <srcldx> is required, e.g.: Canlf_lfLLClient<srcldx>.</srcldx></srcldx></destidx></srcldx></destidx></srcldx> |
|-------------|---|
| Rationale   | Restrictions the Rte is imposed require to do so.   |

## 5.6.4.4.9. PduR.EB.IntReq.ProtectionMechanismMulticore

| Description | This protection mechnism constraints apply to PduR module with enabled multi-          |
|-------------|--|
|             | core feature. Critical sections PDUR_EXCLUSIVE_AREA_0 have to be protect-              |
|             | ed with intercore locks (Os spinlocks). This is the default critical sections for most |
|             | cases. For special cases no expensive intercore lock is necessary. However, fol-       |
|             | lowing constraints have to be considered: PDUR_EXCLUSIVE_AREA_1 is as-                 |
|             | signed to protect APIs for gateway use-case for communication interface mod-           |
|             | ules for direct data provision with single buffer and dynamic payload, i.e. PduR       |
|             | GateIfRxIndicationSbMCoreDynPyld and PduR_GateIfRxIndicationMcUpSbDyn-                 |
|             | Pyld. For PDUR_EXCLUSIVE_AREA_1 no protection is necessary if it is ensured that       |
|             | PduR_GateIfRxIndicationSbMCoreDynPyld or PduR_GateIfRxIndicationMcUpSb-                |



DynPyld is not called again before IfTransmit or UplfRxIndication calls have completed. E.g. IfTransmit and UplfRxIndication APIs represented with synchronous intercore calls (i.e. blocking) or scheduling of integrator ensures this otherwise. PDUR\_-EXCLUSIVE\_AREA\_2 is assigned to protect API for multicast transmit use-case for communication interface modules, i.e. PduR\_MultiUpMCorelfTransmit. For PDUR\_-EXCLUSIVE\_AREA\_2 no protection is necessary if it is ensured that PduR\_Multi-UpMCorelfTransmit is not called again before IfTransmit calls have completed. E.g. If-Transmit APIs represented with synchronous intercore calls (i.e. blocking) or scheduling of integrator ensures this otherwise.

#### 5.6.4.4.10. PduR.EB.IntReq.TriggerTransmitWithMultiCore

| Description | Ensure that PDUs which are transmitted on a network using trigger transmit data pro- |
|-------------|--|
|             | vision are assigned throughout the complete communication stack to the very same     |
|             | core / partition dedicated to the respective network.                                |



# 6. Bibliography

# **Bibliography**

- [1] Road Vehicles Diagnostic Systems Keyword Protocol 2000 Part 3: Application Layer,
  - 1, rue de Varembe, Case postale 56
  - 1211 Geneva 20, Switzerland, Publish date: 1999, Issue Version ISO/DIS 14230-3, Publisher: ISO (International Organization for Standardization)
- [2] Road Vehicles Unified Diagnostic Services (UDS) Part 1: Specification and Requirements,
  - 1, rue de Varembe, Case postale 56
  - 1211 Geneva 20, Switzerland, Publish date: 2013, Issue Version ISO/DIS 14229-1, Publisher: ISO (International Organization for Standardization)
- [3] Road vehicles Communication between vehicle and external equipment for emissions-related diagnostics Part 5: Emissions-related diagnostic services,
  - 1, rue de Varembe, Case postale 56
  - 1211 Geneva 20, Switzerland , Publish date: 2011, Issue Version ISO/DIS 15031-5, Publisher: ISO (International Organization for Standardization)
- [4] AUTOSAR Specification of Module Efficient COM for Large Data, Issue AUTOSAR Release 4.2.1, Publisher: AUTOSAR