
AMPLIFIER_L
AMPLIFIER_R
OFF
ON
3V3
GND
GND2
3.3V_TO_1.8V
TP_1V8
TP_3V3
25MHZ_CRYSTAL
32KHZ_CRYSTAL
TOF_SCL
TOF_SDA
BUCK_CONVERTER
MICROSD_CARD
PROGRAMMER
CAMERA_CONNECTOR
VOLUME_WHEEL
MICROUSB_HEADER
USB_ESD
FUSE
+VBAT
BATT1
BATT2
BATT_CONTROL
TP_5V_USB
RX
TX
SWCLK
POWER_SWITCH
PCB Edge