

SAFE OPERATING PROCEDURE

Angle Grinders

LOCATION: Multiple

PERSONAL PROTECTIVE EQUIPMENT



Version: 2	Key Contact: Workshop Managers
Effective Date: 18/09/2020	Speciality/Position: Workshop Manager
Review Date: December 2022	Contact number: N/A
Permits required: N/A	Confined space ☐ Hot Works ☐ Working at Heights ☐

HAZARDS ASSOCIATED WITH THIS EQUIPMENT

PERMANENT HAZARDS Remove as necessary	List	Control Method	Lock out Yes or No
Electric shock	Power cord	Test and tag, RCD if using outside or in damp conditions, check power cord condition if using.	If cord faulty, remove from service until repaired
Moving Machinery	Rotating disc and movement of work piece	Secure and fit disc correctly. Use safety glasses or full face guard Secure work piece if small	No
Noise	Machinery	Ear protection	No
Moving materials		Check disc is secure. Use eye protection. Ensure hair and long beards are tied back and secure loose clothing or jewellery.	No
Hot surfaces	Spinning disc and work surface	Allow equipment and work piece to cool before handling	No
Sharp objects	Sharp edges on work	Wear gloves	No
Dust	Inhalation of fumes and dust particles	Use Grinder in well ventilated areas, remove dust/particles as they accumulate	No
Vibration	Prolonged vibration	Take regular breaks. Avoid prolonged use	No
Fire	Flying sparks – ignition source	Ensure work area is free from inflammable material.	No

PURPOSE/PROCESS

Grinding

PROCEDURES:

DO NOT use this equipment unless you have been instructed on its safe use and operation and have been given permission to operate it.

Pre Start Check

1. Do not use this machine unless you have been shown its correct safe operation
2. Check operating area is uncluttered and well illuminated
3. Check power leads for damage, wear and tear
4. Inspect disc for cracks, cuts and do not use if damaged
5. Inspect work piece to ensure there are no pieces that might damage grinder or cause injury to operator

**Operation**

1. Ensure guards are on. Never use grinder with guard off.
2. Hold grinder in both hands. Turn on switch to start grinder
3. Allow grinder to reach operating speed before applying to work piece
4. Do not force grinder. The weight of the machine will provide adequate pressure to work piece.
5. Never make adjustments while grinding is running
6. Always use auxiliary handle if provided to provide maximum control over kickback or torque reaction during start up.
7. Hold grinder away from you to avoid flying sparks
8. Let grinder stop completely before putting down

Routine maintenance

Lock out and/or isolate any equipment before inspection or maintenance

	Name	Title/Position	Signature	Date
Author	George Fisher	Technician Engineering		
Reviewed by	Marie Dennis	HSW Manager		
Reviewed by	Tony Middlemiss	Health and safety rep		
Manager	Joe Nathan			

Document Control

Date	Revision number	Modifications	Revised by	Approved by
28/11/2019	1	New Template and photos	George Fisher	Marie Dennis
10.03.20	2	updated	George Fisher	