

SAFE OPERATING PROCEDURE

Bench Grinder

LOCATION: Various

TOI-OHOMAI
Institute of Technology

PERSONAL PROTECTIVE EQUIPMENT



Version: 3

Effective Date: 18/09/2020

Review Date: Sept 2022

Permits required

Key Contact: George Fisher

Speciality/Position: Technician

Contact number: 021 190 4236

Confined space ☐ Hot Works ☐ Working at Heights ☐

HAZARDS ASSOCIATED WITH THIS EQUIPMENT

PERMANENT HAZARDS	List	Control Method <i>Eliminate, isolate, minimise.</i>	Lock out Yes or no.
Electric shock	Power cord	Test and tag, RCD if using outside or in damp conditions	If cord faulty, remove from service until repaired
Moving machinery	Rotating stone and movement of work piece	Secure and fit stone correctly. Check for chips or cracks in wheel.	No
Noise	Machinery	Wear hearing protection if grinding for long periods	No
Moving materials	Flying sparks can lead to fire	Use eye protection and ensure there are no ignition material nearby when operating	No
Hot surfaces	Spinning stone and work surface	Allow equipment and work piece to cool before handling	No
Dust and fumes	Inhalation of fumes and dust particles	Ensure area is well ventilated.	No
Fire	Flying sparks – ignition source	Ensure work area is free from flammable material	No

Process/Purpose

The purpose of a bench grinder is to grind or polish metal

PROCEDURES:

DO NOT use this machine unless you have proven to your trainer that you are competent in its safe use and operation

Note: This Safe Operating Procedure must be reviewed annually and after any accident or incident; when training new staff; if adopted by a new work group; if equipment, substances or processes change or within 2 years of date of issue.

Pre Start Check

1. Check operating area is free from clutter and well illuminated
2. Check power leads for damage, wear and tear
3. Inspect stones for cracks, and do not use if damaged
4. Ensure that guards are secure and correctly fitted/adjusted before commencing operation and are not glazed or loaded
5. Ensure that the grinding wheels are properly 'dressed', the wheels are not touching the tool rest and that the gap between the wheel and rest is no greater than 1.5mm
6. Locate and ensure you are familiar with the operation of the ON/OFF start switch and the Emergency Stop button.



Operation

1. Stand to the side of the wheels when starting up.
2. Allow grinder to reach operating speed before applying the work piece to the stone.
3. Do not use unnecessary force when grinding
4. Do not grind on the side of the wheel.
5. Small objects must not be held by hand.
6. Workpiece must never be held with gloves, cloth, apron or pliers.
7. Never leave the machinery running unattended.
8. Do not bend down near the machine whilst running.
9. Slowly move the workpiece across the face of the wheel uniformly.
 10. Unplug bench grinder before making adjustments or replacing wheel.
 11. Switch off the grinder at the end of work and switch off at power point.

Routine maintenance

1. Lock out and/or isolate equipment before inspection or maintenance

	Name	Title/Position	Signature	Date
Author	George Fisher	Technician		
Reviewed by	Marie Dennis	HSW Manager		
Reviewed by	Tony Middlemiss	Health and safety rep		
Manager	Joe Nathan			

Document Control

Date	Revision number	Modifications	Revised by	Approved by
30/09/2019	1	New template and photos added	George Fisher	Marie Dennis
10.03.20	2	updated	George Fisher	Marie Dennis