


M-AHM-32-A

M-AHM-32-A is a processing expansion module for AHM-32. It provides multiple channels of AEC (Acoustic Echo Cancelling) for conferencing applications.


① Please refer to the AHM System Manager Help for information on how to set up and operate the module.

Installation


- Disconnect the power cable from the AHM-32.
- Use a Torx T8 screwdriver to remove the 12x screws on the top panel of the AHM-32, and remove the panel.
- Use a Torx T8 screwdriver to remove the 4x screws from the pillars of the M-AHM-32-A module, as shown below.



- Carefully slide the M-AHM-32-A module into the mating connector on the AHM-32 main board, pressing firmly, in the orientation shown on the next page.
- ① Do not apply any pressure to the module's heat sinks while inserting or removing the module. Hold the module by the edges of the PCB board.



- Secure the pillars in place with the 4x screws provided, through matching holes in the bottom panel of the AHM-32, as shown below.



- Replace the top panel and secure in place using the 12x screws.

ALLEN&HEATH

Copyright © 2021 Allen & Heath. All rights reserved.