RCC Development





RCC Worker Overview

- RCC Resource Constrained C/C++
- Supported GPP (x86-64 bit and Cortex A9)
- Supported OS (centos6, centos7, xilinx13_3)
- C and C++ language Workers
- Focus on C++ moving forward





Application Worker build steps

Open

- 1)OPS: Use pre-existing or create new
- 2)OCS: Use pre-existing or create new
- 3)Create new App Worker (Modify OWD, Makefile, and source code)
- 4) Build the App Worker for target device(s)
- 5)Create Unit Test (<component>-test.xml, generate, verify and view scripts)
- 6)Build Unit Test
- 7)Run Unit Test

Execution model


- Software Containers provide execution environment for Workers
 - Loads, executes, controls, and configures Workers
 - Moves data between Workers
 - Provides interfaces for local services
 - Including software watchdog timer
 - Evaluates data availability
 - Consumer's buffer has data
 - Producer's buffer has space
- Each RCC Container is a single thread





Execution model


Shared buffers between Workers that are in the same Container








Worker Life Cycle







Buffers and metadata







Run Method

- Open **⇔CPI**

- Called by Container when all ports are ready (input ports have data and output ports have a free buffer)
 - Other advanced use cases, e.g. timeouts

Return values to Container

```
    RCC_ADVANCE (good state + advance all ports)
    RCC_OK (good state)
    RCC_DONE (finished state)
    RCC_ADVANCE_DONE (finished + advance all ports)
    RCC_ERROR (bad state: recoverable; still operating)
    RCC_FATAL (bad state: unrecoverable)
```

Start/Initialize/Stop/Release





```
OWD XML:
```

```
<RCCWorker language="c++"
spec="myname_spec.xml"
ControlOperations="start, stop,
initialize, release"/>
```

C++:

Property Access





```
OCS XML:
```

```
cproperty name='myprop'
type='bool' writeable='true'
volatile='true'/>
```

```
C++:

if (properties().myprop == true)
{
   // do something
}

properties().myprop = false;
```

Port Access: Scalar Length





OCS XML:

```
<Port Name="myin" Producer="false"
Protocol="my_protocol"/>
<Port Name="myout" Producer="true"
Protocol="my_protocol"/>
```

OPS XML:

Input ports can be assumed based on the protocol, because there is no variable length data. As of 1.1, output port lengths no longer need to be set as long as all arguments are scalar:

```
C++:
```

// Nothing to do

Port Access: Scalar Data





OCS XML:

```
<Port Name="myin" Producer="false"
Protocol="my_protocol"/>
<Port Name="myout" Producer="true"
Protocol="my_protocol"/>
```

C++:

```
const bool inArg1 = myin.myOp().myArg1();
const bool inArg2 = myin.myOp().myArg2();
myout.myOp().myArg1() = false;
myout.myOp().myArg2() = true;
```

OPS XML:

```
<Protocol>
  <Operation name="myOp">
    <Argument name="myArg1" type="bool"/>
    <Argument name="myArg2" type="bool"/>
    <Operation/>
<Protocol/>
```

Port Access: Sequence Length

P. C.



OCS XML:

```
<Port Name="myin" Producer="false"
Protocol="my_protocol"/>
<Port Name="myout" Producer="true"
Protocol="my_protocol"/>
```

OPS XML:

C++:

```
// length in elements
const size_t length =
   myin.myOp().myArg1().size();

myout.myOp().myArg1().resize(length);

// length in bytes
myout.setDefaultLength(2*sizeof(bool));
```

Port Access: Sequence Data





OCS XML:

```
<Port Name="myin" Producer="false"
Protocol="my_protocol"/>
<Port Name="myout" Producer="true"
Protocol="my_protocol"/>
```

OPS XML:

```
<Protocol>
<Operation name="myOp">
    <Argument name="myArg1" type="bool"
        SequenceLength='2048'/>
        <Operation/>
<Protocol/>
```

C++:

```
const bool* inData =
   myin.myOp().myArg1().data();

bool*         outData =
   myout.myOp().myArg1().data();

for (int i = 0; length > i; i++)
{
   // do something with the data
   inData++;
   outData++;
}
```

Port Access: Opcode



OCS XML:

```
<Port Name="myin" Producer="false"
Protocol="my_protocol"/>
<Port Name="myout" Producer="true"
Protocol="my_protocol"/>
```

OPS XML:

```
<Protocol>
  <Operation name="MyOp1">
    <Argument name="myArg1" type="bool"/>
    <Argument name="myArg2" type="bool"/>
    <Operation/>
    <Operation name="MyOp2">
        <Argument name="otherArg1" type="bool"
        SequenceLength='2048'/>
    <Operation/>
    <Protocol/>
```

```
C++:
//for all outputs on this port
myout.setDefaultOpCode (My_protocolMyOp1_OPERATION)
// for the current output on this port
myout.setOpCode(My_protocolMyOp1_OPERATION);
switch (myin.opCode())
  case My_protocolMyOp1_OPERATION:
     // do something
     break;
  case My_protocolMyOp2_OPERATION:
    // do something different
    break;
  default:
    cout << "bad Opcode" << endl;</pre>
    break;
```

Port Access: Manually Advancing

OCS XML:

```
<Port Name="myin" Producer="false"
Protocol="my_protocol"/>
<Port Name="myout" Producer="true"
Protocol="my_protocol"/>
```

```
C++ advance all:

return RCC_ADVANCE;

C++ advance manually:

myin.advance();
myout.advance();
```

return RCC_OK;





Local Worker Variables



Define any local variables that you need as class variable.


OWD XML:

```
<RccWorker spec='myworker-spec.xml'
language='C++'>
</RccWorker>
```

C++:

```
class My_workerWorker :
  public My_workerWorker base {
  bool myLocalVar1;
  bool myLocalVar2;
  ...
  RCCResult run()
  {
     // use local variables
}
```

RCC Worker Creation via AV IDE



```
peak_detector.rcc/
    gen
     -- peak_detector_map.h
     -- peak_detector-build.xml
     -- peak_detector-params.mk
     -- peak_detector-skel.cc
     -- peak_detector-skel.cc.deps
     -- peak_detector-worker.hh
    `-- peak_detector-worker.hh.deps
 -- Makefile
 -- peak_detector.cc
 -- peak_detector.xml
```





Cross Building

- The only currently supported cross building target is Zyng-arm
- To enable cross build:
- % ocpidev build --rcc --rcc-platform xilinx13_3

- To enable build for x86:
- % ocpidev build --rcc

OR JUST USE THE IDE!





RCC Build Artifacts

- A built RCC worker is a Linux Shared Object file
 - Dynamically loadable on the platform that it is built for
- Info about the worker (XML) embedded in .so
 - \$ ocpixml get myworker.so







< Perform Lab 3 (PeakDetector) Now >



Advanced RCC Features and Functionality

Parameter Access



OWD XML:

```
<RccWorker spec='myworker-spec.xml'
language='C++'>
cproperty name='myparam' type='bool'
parameter='true'>
</RccWorker>
```

C++:


```
if (MYWORKER_MYPARAM == true)
{
   // do something
}
```

Property Write Notifications





Property Read Notifications







Optional Ports





```
OCS XML:
```

```
<Port Name="myout" Producer="true"
  optional='true'
  Protocol="rstream_protocol"/>
```

```
C++:
```

```
if (myout.isConnected())
{
   // output the data to the port
}
```

RCC Worker as a Control Proxy

- A C++ worker that can manipulate other workers' properties
 - Slave worker can be HDL or another RCC
 - Can be 1:1 or 1:many (workers and/or properties)
- Main use case is for platform development to simplify the user interface when developing a Board Support Package (BSP)

Running a worker in a debugger

Open

- Documented in RCC Development Guide
 - Gives directions on how to break gdb in your worker when trying to debug
 - Can be used in a standalone graphical debugger as well such, e.g.
 - It is possible to debug on the zynq as well using gdbserver (no documentation available yet)