# OpenCPI's Application Control Interface (ACI)



## Agenda

- Introduction
- Creating a new Application
- A Simple Example
- Compiling ACI Applications
- Control Plane
- Accessing the Data Plane
- Python Interface





#### Introduction

- The ACI is an API for executing XML-based OpenCPI applications within a C++ or Python context
- Useful when 'ocpirun' cannot supply the necessary programmatic and/or dynamic creation or control of an XMLbased application
  - The contents of the application XML (OAS) need to be constructed programmatically
  - The main program needs to directly connect to the ports of the running application
  - An XML-based application needs to be run repeatedly in the same process
  - Some attributes or properties of the XML application need to be dynamically configured or read throughout execution of the application
- Useful for standalone applications or test fixtures





## Creating a New Application

- ACI applications are placed under the applications/ subdirectory of an OpenCPI project
- New ACI applications can be created with the ocpidev tool as follows:
  - \$ ocpidev create application \${appname}
- If \${appname} was demo-aci-app, the following directory and files should be created as follows:





## A Simple Example

```
#include "OcpiApi.hh"
namespace OA = OCPI::API;
int main()
  try {
    OA::Application app("demo-aci-app.xml");
    app.initialize();
    app.start();
    app.wait();
  catch (std::string &e) {
    std::cerr << "Error: " << e << std::endl;</pre>
```





## Compiling ACI Applications

- Compiling an ACI application is similar to building other OpenCPI assets
- The '--rcc-platform' option can be used to build for various software platforms
- From the lower level directory:
  - \$ ocpidev build --rcc-platform centos7 --rcc-platform xilinx13\_3
- From top-level of directory:
  - \$ ocpidev build application demo-aci-app --rcc-platform xilinx13\_3





#### Using the Control Plane

- Control plane operations in OpenCPI consist of getting and setting properties of components
- In the ACI, there are a few different options for getting and setting properties depending on performance, accuracy, and simplicity requirements





## Getting Properties – Option 1

```
OA::Application app("demo-aci-app.xml");
  app.initialize();
  std::string value;
  app.getProperty("bias", "biasValue", value);
  std::cout << value << "\n";</pre>
  app.start();
 while (true) {
catch (std::string &e) {
  std::cerr << "Error: " << e << std::endl;
```

• Simplest interface but all string-based, so slowest for real-time processing.





## Getting Properties – Option 2

```
OA::Application app("demo-aci-app.xml");
    app.initialize();
    unsigned int ivalue = app.getPropertyValue("bias", "biasValue");
    std::cout << ivalue << "\n";
...
    app.start();
    while (true) {
        ...
    }
    catch (std::string &e) {
        std::cerr << "Error: " << e << std::endl;
    }
}</pre>
```

• Template based and simple, but can have C++ 'promoting' issues if you don't explicitly state the type using getPropertyValue<type>(). Gives proper native types, which is sometimes more convenient.





## Getting Properties – Option 3

```
OA::Application app("demo-aci-app.xml");
    app.initialize();
    OA::Property biasValue(app, "bias.biasValue");
    std::cout << biasValue.getULongValue();

...
    app.start();
    while (true) {
        ...
    }
    catch (std::string &e) {
        std::cerr << "Error: " << e << std::endl;
    }
}</pre>
```

• Fastest, lowest level, "I know exactly what to expect," with possible optimizations to direct memory-mapped access.





## **Setting Properties**

```
OA::Application app("myapp.xml");
  app.initialize();
  app.setProperty("bias", "biasValue", "15");
  app.setPropertyValue<unsigned int>("bias", "biasValue", 16);
  OA::Property biasValue(app, "bias.biasValue");
  biasValue.setULongValue(17);
  app.start();
 while (true) {
catch (std::string &e) {
  std::cerr << "Error: " << e << std::endl;
```





#### Accessing the Data Plane

- Data can be written into or read from External Ports of an OpenCPI application using the ACI's ExternalPort and ExternalBuffer classes
- Useful for interfacing with other applications external to OpenCPI that use a different protocol or transport layer
- Leaves the data formatting and opcode up to the user for increase flexibility





#### Accessing the Data Plane

```
#include "OcpiApi.hh"
namespace OA = OCPI::API;
int main()
 try {
   OA::Application app("demo-aci-app.xml");
    app.initialize();
   OA::ExternalPort &toApp = app.getPort("in");
   OA::ExternalPort &fromApp = app.getPort("out");
    app.start();
   while (true) {
 catch (std::string &e) {
    std::cerr << "Error: " << e << std::endl;
```





#### Example of Sending Data to an Application

```
size t sendBytesToApp(uint8 t *sendPtr, size t sendSize, ExternalPort &port)
 uint8 t *dataPtr = NULL;
 size t dataSizeBytes = 0;
 OA::ExternalBuffer *dataBuffer = NULL;
 // Get a buffer to fill
 do {
   dataBuffer = port.getBuffer(dataPtr, dataSizeBytes);
  } while(!dataBuffer);
  // Fill the buffer
 const size t transferSizeBytes = std::min(sendSize, dataSizeBytes);
 memcpy(dataPtr, sendPtr, transferSizeBytes);
 // Actually push N bytes on the port with opcode 0
 dataBuffer->put(transferSizeBytes, 0);
 return transferSizeBytes; // Tell caller
```





#### Example of Getting Data from an Application

```
size_t getBytesFromApp(uint8_t *recvPtr, size t recvSize, ExternalPort &port)
 uint8 t *dataPtr = NULL;
  size t dataSizeBytes = 0;
 uint8 t opCode;
 bool endOfData;
 OA::ExternalBuffer *dataBuffer = NULL;
 // Get a buffer of data
 do {
    dataBuffer = port.getBuffer(dataPtr, dataSizeBytes, opCode, endOfData);
  } while(!dataBuffer);
  // Fill the out buffer with the data
 const size t transferSizeBytes = std::min(recvSize, dataSizeBytes);
 memcpy(recvPtr, dataPtr, transferSizeBytes);
  // Release the buffer
 dataBuffer->release();
 return transferSizeBytes; // Tell caller
```



## SWIG Python Interface (Beta)

- OpenCPI has released SWIG bindings for the ACI in the 1.3 release which allows users to access the ACI from within a python interpreter
- The required libraries are provided in the opencpi-interfacepython package
- Once installed, the ACI can be imported into a python script:

  \$ python

  \$ python
- >>> import OcpiApi as OA
- It is mostly a 1:1 translation from C++ ACI functions to python
  - There are some exceptions due to differences in language features





## A Simple Python Example

```
import OcpiApi as OA
try:
    app = OA.Application("demo-aci-app.xml")
    app.initialize()
    app.start()
    app.wait()
except Exception as e:
    print "Error: " + str(e)
```



