



## Road Kings Switch Matrix

|                                      |                             |                                       |                                             |                                      |                                          |                             |                             |
|--------------------------------------|-----------------------------|---------------------------------------|---------------------------------------------|--------------------------------------|------------------------------------------|-----------------------------|-----------------------------|
| <b>01</b><br>01<br>PLUMB BOB TILT    | <b>09</b><br>09<br>R TARGET | <b>17</b><br>17<br>S TARGET           | <b>25</b><br>25<br>LEFT JET BUMPER          | <b>33</b><br>33<br>RIGHT TEN POINT   | <b>41</b><br>41<br>RIGHT ROUGH           | <b>49</b><br>49<br>NOT USED | <b>57</b><br>57<br>NOT USED |
| <b>02</b><br>02<br>BALL ROLL TILT    | <b>10</b><br>10<br>O TARGET | <b>18</b><br>18<br>LANE 1             | <b>26</b><br>26<br>RIGHT JET BUMPER         | <b>34</b><br>34<br>UPPER LEFT KICKER | <b>42</b><br>42<br>LEFT TROUGH           | <b>50</b><br>50<br>NOT USED | <b>58</b><br>58<br>NOT USED |
| <b>03</b><br>03<br>CREDIT BUTTON     | <b>11</b><br>11<br>A TARGET | <b>19</b><br>19<br>LANE 2             | <b>27</b><br>27<br>BOTTOM JET BUMPER        | <b>35</b><br>35<br>RIGHT ROLLUNDER   | <b>43</b><br>43<br>LEFT KICKER           | <b>51</b><br>51<br>NOT USED | <b>59</b><br>59<br>NOT USED |
| <b>04</b><br>04<br>RIGHT COIN CHUTE  | <b>12</b><br>12<br>D TARGET | <b>20</b><br>20<br>LANE 4             | <b>28</b><br>28<br>LEFT OUTLANE             | <b>36</b><br>36<br>LEFT ROLLUNDER    | <b>44</b><br>44<br>RIGHT KICKER          | <b>52</b><br>52<br>NOT USED | <b>60</b><br>60<br>NOT USED |
| <b>05</b><br>05<br>CENTER COIN CHUTE | <b>13</b><br>13<br>K TARGET | <b>21</b><br>21<br>LANE 3             | <b>29</b><br>29<br>RIGHT OUTLANE            | <b>37</b><br>37<br>LEFT EJECT        | <b>45</b><br>45<br>LEFT TEN POINT        | <b>53</b><br>53<br>NOT USED | <b>61</b><br>61<br>NOT USED |
| <b>06</b><br>06<br>LEFT COIN CHUTE   | <b>14</b><br>14<br>I TARGET | <b>22</b><br>22<br>RIGHT RAMP - ENTER | <b>30</b><br>30<br>DROP TARGET              | <b>38</b><br>38<br>CENTER EJECT      | <b>46</b><br>46<br>PLAYFIELD TILT        | <b>54</b><br>54<br>NOT USED | <b>62</b><br>62<br>NOT USED |
| <b>07</b><br>07<br>SLAM TILT         | <b>15</b><br>15<br>N TARGET | <b>23</b><br>23<br>RAMP RAISE (E O S) | <b>31</b><br>31<br>CENTER RAMP - ENTER      | <b>39</b><br>39<br>BALL SHOOTER      | <b>47</b><br>47<br>LEFT FLIPPER (E O S)  | <b>55</b><br>55<br>NOT USED | <b>63</b><br>63<br>NOT USED |
| <b>08</b><br>08<br>HIGH-SCORE RESET  | <b>16</b><br>16<br>G TARGET | <b>24</b><br>24<br>TOP JET BUMPER     | <b>32</b><br>32<br>CENTER RAMP - RIGHT EXIT | <b>40</b><br>40<br>OUTHOLE           | <b>48</b><br>48<br>RIGHT FLIPPER (E O S) | <b>56</b><br>56<br>NOT USED | <b>64</b><br>64<br>NOT USED |

Switch Matrix Charts for use with the [Pinitech 64 Switch Matrix Tester](#) diagnostic tool

Is your game still using batteries? Consider adding one of our [NVRAM Battery Eliminators!](#)

[www.pinitech.com](http://www.pinitech.com)