
Update the axis speed
On the target step?
No
Yes
Control mode?
Velocity
Position
Time to brake?
No
Yes
Aim for the commanded speed
Aim for the maximum speed
Aim for the landing speed
Ramp toward that speed and send it to the driver
Stop immediately
Return