

For repair and maintenance

**JOTEGO**


Sheet: /scroll/scrom\_memories/  
File: scrom\_memories.kicad\_sch






**Title: RENEGADE**

Size: A3 Date: 2022-07-08  
KiCad E.D.A. 8.0.8



Rev: José Tejada  
Id: 6/16





For repair and maintenance

JOTEGO


Sheet: /objects/

**Title:** BENECADE


Size: A3 Date: 2022-07-08

KiCad E.D.A. 8.0.8







# VERTICAL COUNTER



# HORIZONTAL COUNTER




# OBJECT STATE MACHINE




1 2 3 4 5 6


A



B



C



D



For repair and maintenance

JOTEGO

Sheet: /objects/obj\_draw/  
File: obj\_draw.kicad\_sch


Title: RENEGADE

Size: A4 Date: 2022-07-08  
KiCad E.D.A. 8.0.8




Rev: José Tejada  
Id: 11/16

1 2 3 4 5 6



Memorias volcadas



For repair and maintenance

**JOTEGO**

Sheet: /objects/obj\_draw/memories\_sprite.sch/  
File: memories\_sprite.kicad\_sch


Title: RENEGADE


Size: A3 Date: 2022-07-08  
KiCad E.D.A. 8.0.8




Rev: José Tejada

Id: 12/16







1 2 3 4 5 6

