











Rev:





JOTEGO

Sheet: /top/char/
File: char.kicad_sch

Title:


Size: A3




Date:

Rev:

KiCad E.D.A. 8.0.9

Id: 5/20





cambiar simbolo

JOTEGO

Sheet: /top/io/
File: io.kicad_sch

Title: CABINET I/O


Size: A3


Date:



Rev:

KiCad E.D.A. 8.0.9


Id: 7/20










Id: 10/20










-> CE
2 -> A16
cambiar posiciones de pines y cables



JOTEGO

Sheet: /bottom/object/object ROM/
File: objrom.kicad_sch

Title: Object ROM


Size: A3


Date:


Rev:

KiCad E.D.A. 8.0.9

Id: 15/20







JOTEGO

Sheet: /bottom/scroll/scroll RAM/
File: scrram.kicad_sch

Title: Scroll RAM

Size: A3

Date:

Rev:

KiCad E.D.A. 8.0.9

Id: 18/20

