



Selector Valve Reset Tool H-305149

| Selector Valve Reset Tool for Inert Suppression Solution


INSTRUCTIONS FOR USAGE

After activation the selector valve, it has to be reset by turning the valve manually back to the closed position. This is accomplished by inserting the H-305149 reset tool into the slot in front of the selector valve and turning it clockwise until the stop is reached.

The slot will be as indicated on the drawing at the bottom of the datasheet (closed position).



Closed (normal position)



Open (Activated position)