HD+ · GLANCE MODE

How your dashboard gets built

Glance reads your device list and lays out one screen you never scroll.
Here is how it decides.

01
Measure
How many cells fit your screen — a phone about 18, a tablet about 40.


02
Collect
Anything you have a lot of becomes one tile. 15 lights, one Lights tile.

03
Rank
Order by what matters in a home, not by how many you own.

04
Size
Spend the cells. Tiles shrink before anything gets dropped.

05
Fill
Whatever is left over collects into Other, so no device disappears.

WHAT COMES OUT



`2×2` the three that matter most `3×2` every camera, in one `2×1` a list worth reading `1×1` everything else

WHAT YOU GET

YOU HAVE	YOU GET
15 lights, 4 locks, 5 doors	One tile each — **Lights**, **Locks**, **Doors**
Two or more of anything else	One tile for all of them
Three or more cameras	One **Media Selector** you flip through
One or two cameras	A picture each
Weather, a calendar, a map	Its own tile, up to three of each
A device with no type set	A **Needs a type** tile
Anything left over	**Other**

Tap any tile to open it. A group opens its list, and you can act on any row from there.

WHAT GETS THE SPACE

This order is fixed, and it decides the whole dashboard. The first three categories your home actually has get the big tile; the rest follow in this order, however many of each you own — eight phones never outrank one garage door.

1	**Time**	Date / Time
2	**Weather**	Weather
3	**Security**	Lock · Garage Door · Door · Window · Safety Monitor
4	**Climate**	Thermostat · Temperature Sensor
5	**Lights**	Light · Dimmable Light · Dimmable RGB Light · Switch · Outlet · Fan
6	**Family**	Presence Sensor · Mobile Device · HD+ Device · Life 360 · OwnTracks · Location Tracking
7	**Calendar**	Calendar
8	**Media**	TV · Music Player · Speaker
9	**Energy**	Power Meter
–	**Everything else**	Motion Sensor · Water Sensor · Window Shade · Valve · Laundry · Dishwasher · Button · Mode · Battery · Variables · Pollen · Air Quality · Stock · Radar · …

Cameras, images and video sit apart from all of this — they collect into the Media Selector and go at the foot of the screen, where a photo doesn't break the row of flat tiles above it.

The layout never moves

A door opening changes a tile's colour, never its size or place. Amber means it needs you. The dashboard you learn stays the dashboard you have.

It rebuilds when you ask

Menu → Sort Order → Default builds it again, and picks up devices added since. Move or resize a tile yourself and the layout turns Custom — then it is left alone.