LA-4450 Presentation Room

If hardware or software problems occur during your use of this room, please notify the InfoSys Service Desk (LL-453, 46753). Service Desk personnel will notify their supervisor immediately and page technical staff to come to your aid.

We do ask that everyone using the LA-4450 Presentation Room help us by:

- Identifying themselves to the InfoSys Service Desk
- Giving the event name in progress
- Giving the room number (LA-4450)
- Describing the hardware/software problem

In this way technical staff will be better prepared to assist upon arrival.

Please use the procedures in this binder to assist you with operating the LA-4450 Presentation Room hardware and software.

Tab #1

- How to Use the Egan White Board
- How to Use the Mitsubishi LVP-X300 Projection System with Computer Display
- How to Use the Panasonic VCR and Sony Video Presentation Stand with the Mitsubishi LVP-X300 Projection System

Tab #2

Room Use Procedures

Tab #3

Presentation Room Facilities