How to Use the Mitsubishi LVP-X300 Projection System with Computer Display

To Power Up

1. Make the connection for the computer;

If you are using a PC Laptop or G3/G4 Powerbook, attach the long cable on the podium to the Laptop's monitor connection.

OR

If you are using an "old-pre G3" or "iBook" Macintosh Laptop, add the short cable to the long cable, and then attach it to the Laptop's monitor connection.

- 2. Power on the computer using the Laptop's power button and wait 10-15 seconds before powering on the Mitsubishi LVP-X300 Projection System via the remote.
- 3. The Mitsubishi LVP-X300 Projection System's remote has a **BLUE Power** button. Point the remote at either the projection screen or the projection system, and hold the button down for 2 seconds.
- 4. If a "**NO SIGNAL**" is displayed on the projection screen, press the WHITE button labeled *COMPUTER*. Press this until you see "**COMPUTER 2**" displayed on the projection screen in the upper right corner. This will allow what is on the Laptop to be seen on the projection screen.
- 5. Check and set the resolution on the Laptop to 1024 x 768 for True Color, or if needed, 640 x 480 for 256 colors:

If you are using a PC Laptop, select **SettingsControl Panel....Display....Settings** tab.

OR

If you are using a Macintosh Laptop, select **Control Panels.....Monitors and Sounds** panel.

- 6. If you want the Laptop's sound to emanate from the speakers -
 - A) Look inside the podium's lower shelf, find the **BLACK** RCA Amplifier box and turn on the **Power** button. Then check to see that the Phono Selector on the front of the box is pointing to **PC.** If it is not, turn it until it does.
 - B) Take the **RED**/WHITE cord from the **BLACK** RCA Amplifier and plug it into the speaker connection on the Laptop.

To Power Down

- 1. Shutdown the PC or Macintosh Laptop and disconnect the cable/adapter.
- 2. Turn of the Mitsubishi LVP-X300 Projection System via the remote. You must hold the **BLUE Power** button down for 3 seconds to turn the projection system off.
- 3. If you have used the **BLACK** RCA Amplifier, please turn the power to **OFF**.