



Channel Configuration Instructions: Each channel or pair has several configurable output modes.

All channels can do the  $-500\,\text{mA}$  and  $\pm 1.5\text{A}$  ranges. Only channel A can do the +10A with optional soft start range.

Never populate the dual MOSFET and the MOSFET driver on the same channel pair For the ±1.5A range: Populate the dual MOSFET driver only For the -500mA and +10A ranges:

Populate the dual MOSFET

JP22

JP23

SolderJumper 1 2

R19

The two channels in the pair may be configured independently For the -500mA range: Jump the 2 position jumper for that channel For the +10A range:

Populate the P-FET, the 10K resistor, and a 1k gate resistor

Jump the 3 position jumper to select the voltage To add soft start: Use a 680k gate resistor and populate the capacitor

For Banks B and C:

Never populate the dual MOSFET and the MOSFET driver on the same channel pair For the -500mA range: Populate the dual MOSFET only For the  $\pm 1.5$ A range: Populate the dual MOSFET driver only

Gate ResistorsRN13

JP26

JP27

SolderJumper 1 2

MOS\_A6

\_A6 \ 2 IN\_A

TC4427

GND

2 IN\_A OUT\_A 7 4 IN\_B 2 OUT\_B 5

Title: Rev:

> Contributors: \${CONTRIBUTOR} ld: 2/2

Bank A

Ranges: -500mA ±1.5A +10A

Bank B Ranges: -500mA ±1.5A

Bank C Ranges: -500mA ±1.5A

Sheet: /power\_switching/

