CARBON FILTRATION SOAKING PROCEDURE

V. 10/22/2026

CAUTION: Failure to follow procedure can result in possible clogging of plumbing and may void warranty

STEP 1

Carbon Pre-Soak and Preparation Instructions

1.) Pre-Soak the Carbon
- Begin by pre-soaking the carbon **24 to 48 hours** before installation.

2.) Fill the Carbon Tank with Water
- Complete this by taking off valve from mineral tank and filling the mineral tank 3/4 of the way.
- Do not fill the tank to the brim.

3.) Let the Tank Sit
- Allow the carbon tank to sit for **24 to 48 hours** to complete the pre-soak process. Once the system has finished soaking, reattach the valve to the mineral tank..

4.) Reducing Weight for Transport
- Reduce tank weight to make it easier for transport by blowing excess water out of the tank using an air compressor or the exhaust end of a shop vacuum. Place the air compressor hose or shop vacuum hose on the inlet side of the valve. The air will push the water through the tank and expel it through the outlet side. Continue blowing air through the tank for approximately 5–10 minutes, or until the excess water has been expelled.
- **Do Not** lay system down during transport.

5.) Preparing for Transport
- When transporting carbon system, put the system in bypass mode to allow safe transport.

STEP 2

Flushing Carbon Tank Before Installation

1.) Flush the Carbon Tank at the Customer's Home
- Before installing the equipment, it's important to flush out:
  - Any excess air trapped in the carbon tank
  - Any carbon shards that may still be in the distributor or system

2.) Connect a Water Hose to the Carbon Tank
- Use the downflow inlet port of the carbon tank, or connect to the inlet side of the valve. On backwashing filters, the inlet side is identified by the arrow indicating flow into the valve.
- Recommended attachments:
  - A ¾" female adapter for your garden hose
  - A short section of pipe
  - A 1" female adapter N.P.T. with a ¾" reducing bushing

Flushing Carbon Tank Before Installation (continued)

3.) Run Water Through the Tank

- Turn on the water and let it run for a few minutes.
- This helps to clear out:
  - Trapped air
  - Loose carbon particles

4.) Perform the Flush

- Best practice: Flush the tank outside before bringing it indoors.
- Alternatively: Plumb the system first and run the outlet side of the carbon tank to a drain to flush.

5.) Install the System

- Once flushing is complete and you've cleared out excess air and shards, proceed to proper installation procedure.

STEP 3

Preparing the Home's Plumbing for Installation

1.) Turn Off the Main Water Supply

- Shut off the main water line to the house before beginning installation.

2.) Open One Cold Water Line Inside the Home

- Choose one faucet to open—this could be:
  - A kitchen faucet, or
  - A bathroom faucet

3.) Run Cold Water Only

- Make sure you turn on the cold water only.
- This helps to drain any excess water from the plumbing lines.

4.) Let the Line Run Until It Drains

- Allow water to run and drain completely from the selected faucet.

5.) Proceed with Installation

- Once the plumbing lines have been drained, you are ready to install the equipment. Refer to the Backwashing Filter Installation Guide for the next steps.

STEP 4

Final System Flush and Homeowner Walkthrough

1.) Inform the Homeowner About Temporary Air in Lines

- Educate the homeowner on what to expect:
  - Air may remain in the plumbing for a few days
  - Toilets may make loud noises
  - Showers or faucets may sputter, especially in rarely used areas

2.) Encourage Continued Water Use

- Let the homeowner know:
  - The only way to remove the air is to use the water
  - The more they run the water, the faster the air will clear from the lines

3.) Set Expectations Clearly

- Help the homeowner feel confident by explaining:
  - This is normal after installation
  - Continued water use will resolve any lingering issues

Important Reminder About Air in the Plumbing:

Following this procedure will help get air out faster, but it doesn't eliminate it completely. Air is part of waters chemistry. This is to help get any excess air that was introduced by the installation of the water treatment equipment.

Failure to follow this procedure in its entirety may result in equipment, installation, or plumbing damage and could lead to additional service calls.