Calculator guidebook page one
Press 2nd then MODE to quit.

Page two: the toggle key switches fractions and decimals.