


Note: Cut QW1 and QW2 to disconnect Qwiic and allow A4/A5 as analog inputs.



Trace width calculation: 2A, 1oz. copper 10C rise in temperature 30.8 mil width https://www.eeweb.com/tools/external-pcb-trace-max-current

> Released under the Creative Commons Attribution Share-Alike 4.0 License https://creativecommons.org/licenses/by-sa/4.0/

TITLE: BlackBoard

open hardware Date: 6/29/2020 2:15 PM

Design by: Jim Lindblom, N. Seidle Based on Arduino by: M.Banzi, D.Cuartielles, T.Igoe, G.Martino, D.Mellis

Sheet: 1/1

88

**⊗** ⊗

REV: X04