

# **Use FPolicy for file monitoring and management on SVMs**

ONTAP 9

NetApp December 01, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap/nas-audit/two-parts-fpolicy-solution-concept.html on December 01, 2021. Always check docs.netapp.com for the latest.

# **Table of Contents**

Use FPolicy for file monitoring and management on SVMs	1
How FPolicy works	1
FPolicy configuration types	6
How FPolicy passthrough-read enhances usability for hierarchical storage management	8
Requirements, considerations, and best practices for configuring FPolicy	9
What the steps for setting up an FPolicy configuration are	10
Plan the FPolicy configuration	11
Create the FPolicy configuration	43
Modify FPolicy configurations	48
Display information about FPolicy configurations	49
Manage FPolicy server connections	52

# Use FPolicy for file monitoring and management on SVMs

# **How FPolicy works**

## What the two parts of the FPolicy solution are

FPolicy is a file access notification framework that is used to monitor and manage file access events on storage virtual machines (SVMs).

There are two parts to an FPolicy solution. The ONTAP FPolicy framework manages activities on the cluster and sends notifications to external FPolicy servers. External FPolicy servers process notifications sent by ONTAP FPolicy.

The ONTAP framework creates and maintains the FPolicy configuration, monitors file events, and sends notifications to external FPolicy servers. ONTAP FPolicy provides the infrastructure that allows communication between external FPolicy servers and storage virtual machine (SVM) nodes.

The FPolicy framework connects to external FPolicy servers and sends notifications for certain file system events to the FPolicy servers when these events occur as a result of client access. The external FPolicy servers process the notifications and send responses back to the node. What happens as a result of the notification processing depends on the application and whether the communication between the node and the external servers is asynchronous or synchronous.

## What synchronous and asynchronous notifications are

FPolicy sends notifications to external FPolicy servers via the FPolicy interface. The notifications are sent either in synchronous or asynchronous mode. The notification mode determines what ONTAP does after sending notifications to FPolicy servers.

#### Asynchronous notifications

With asynchronous notifications, the node does not wait for a response from the FPolicy server, which enhances overall throughput of the system. This type of notification is suitable for applications where the FPolicy server does not require that any action be taken as a result of notification evaluation. For example, asynchronous notifications are used when the storage virtual machine (SVM) administrator wants to monitor and audit file access activity.

If an FPolicy server operating in asynchronous mode experiences a network outage, FPolicy notifications generated during the outage are stored on the storage node. When the FPolicy server comes back online, it is alerted of the stored notifications and can fetch them from the storage node. The length of time the notifications can be stored during an outage is configurable up to 10 minutes.

#### Synchronous notifications

When configured to run in synchronous mode, the FPolicy server must acknowledge every notification before the client operation is allowed to continue. This type of notification is used when an action is required based on the results of notification evaluation. For example, synchronous notifications are used when the SVM administrator wants to either allow or deny requests based on criteria specified on the external FPolicy server.

#### Synchronous and asynchronous applications

There are many possible uses for FPolicy applications, both asynchronous and synchronous.

Asynchronous applications are ones where the external FPolicy server does not alter access to files or directories or modify data on the storage virtual machine (SVM). For example:

- · File access and audit logging
- · Storage resource management

Synchronous applications are ones where data access is altered or data is modified by the external FPolicy server. For example:

- · Quota management
- · File access blocking
- · File archiving and hierarchical storage management
- Encryption and decryption services
- · Compression and decompression services

You can use the SDK for FPolicy to identify and implement other applications as well.

## Roles that cluster components play with FPolicy implementation

The cluster, the contained storage virtual machines (SVMs), and data LIFs all play a role in an FPolicy implementation.

#### cluster

The cluster contains the FPolicy management framework and maintains and manages information about all FPolicy configurations in the cluster.

#### · SVM

An FPolicy configuration is defined at the SVM level. The scope of the configuration is the SVM, and it only operates on SVM resources. One SVM configuration cannot monitor and send notifications for file access requests that are made for data residing on another SVM.

FPolicy configurations can be defined on the admin SVM. After configurations are defined on the admin SVM, they can be seen and used in all SVMs.

#### · data LIFs

Connections to the FPolicy servers are made through data LIFs belonging to the SVM with the FPolicy configuration. The data LIFs used for these connections can fail over in the same manner as data LIFs used for normal client access.

# How FPolicy works with external FPolicy servers

#### How FPolicy works with external FPolicy servers overview

After FPolicy is configured and enabled on the storage virtual machine (SVM), FPolicy

runs on every node on which the SVM participates. FPolicy is responsible for establishing and maintaining connections with external FPolicy servers (FPolicy servers), for notification processing, and for managing notification messages to and from FPolicy servers.

Additionally, as part of connection management, FPolicy has the following responsibilities:

- Ensures that file notification flows through the correct LIF to the FPolicy server.
- Ensures that when multiple FPolicy servers are associated with a policy, load balancing is done when sending notifications to the FPolicy servers.
- Attempts to reestablish the connection when a connection to an FPolicy server is broken.
- Sends the notifications to FPolicy servers over an authenticated session.
- Manages the passthrough-read data connection established by the FPolicy server for servicing client requests when passthrough-read is enabled.

#### How control channels are used for FPolicy communication

FPolicy initiates a control channel connection to an external FPolicy server from the data LIFs of each node participating on a storage virtual machine (SVM). FPolicy uses control channels for transmitting file notifications; therefore, an FPolicy server might see multiple control channel connections based on SVM topology.

#### How privileged data access channels are used for synchronous communication

With synchronous use cases, the FPolicy server accesses data residing on the storage virtual machine (SVM) through a privileged data access path. Access through the privileged path exposes the complete file system to the FPolicy server. It can access data files to collect information, to scan files, read files, or write into files.

Because the external FPolicy server can access the entire file system from the root of the SVM through the privileged data channel, the privileged data channel connection must be secure.

#### How FPolicy connection credentials are used with privileged data access channels

The FPolicy server makes privileged data access connections to cluster nodes by using a specific Windows user credential that is saved with the FPolicy configuration. SMB is the only supported protocol for making a privileged data access channel connection.

If the FPolicy server requires privileged data access, the following conditions must be met:

- · A CIFS license must be enabled on the cluster.
- The FPolicy server must run under the credentials configured in the FPolicy configuration.

When making a data channel connection, FPolicy uses the credential for the specified Windows user name. Data access is made over the admin share ONTAP\_ADMIN\$.

#### What granting super user credentials for privileged data access means

ONTAP uses the combination of the IP address and the user credential configured in the

FPolicy configuration to grant super user credentials to the FPolicy server.

Super user status grants the following privileges when the FPolicy server accesses data:

· Avoid permission checks

The user avoids checks on files and directory access.

· Special locking privileges

ONTAP allows read, write, or modify access to any file regardless of existing locks. If the FPolicy server takes byte range locks on the file, it results in immediate removal of existing locks on the file.

· Bypass any FPolicy checks

Access does not generate any FPolicy notifications.

#### How FPolicy manages policy processing

There might be multiple FPolicy policies assigned to your storage virtual machine (SVM); each with a different priority. To create an appropriate FPolicy configuration on the SVM, it is important to understand how FPolicy manages policy processing.

Each file access request is initially evaluated to determine which policies are monitoring this event. If it is a monitored event, information about the monitored event along with interested policies is passed to FPolicy where it is evaluated. Each policy is evaluated in order of the assigned priority.

You should consider the following recommendations when configuring policies:

- When you want a policy to always be evaluated before other policies, configure that policy with a higher priority.
- If the success of requested file access operation on a monitored event is a prerequisite for a file request that is evaluated against another policy, give the policy that controls the success or failure of the first file operation a higher priority.

For example, if one policy manages FPolicy file archiving and restore functionality and a second policy manages file access operations on the online file, the policy that manages file restoration must have a higher priority so that the file is restored before the operation managed by the second policy can be allowed.

• If you want all policies that might apply to a file access operation to be evaluated, give synchronous policies a lower priority.

You can reorder policy priorities for existing policies by modifying the policy sequence number. However, to have FPolicy evaluate policies based on the modified priority order, you must disable and reenable the policy with the modified sequence number.

## What the node-to-external FPolicy server communication process is

To properly plan your FPolicy configuration, you should understand what the node-to-external FPolicy server communication process is.

Every node that participates on each storage virtual machine (SVM) initiates a connection to an external

FPolicy server (FPolicy server) using TCP/IP. Connections to the FPolicy servers are set up using node data LIFs; therefore, a participating node can set up a connection only if the node has an operational data LIF for the SVM.

Each FPolicy process on participating nodes attempts to establish a connection with the FPolicy server when the policy is enabled. It uses the IP address and port of the FPolicy external engine specified in the policy configuration.

The connection establishes a control channel from each of the nodes participating on each SVM to the FPolicy server through the data LIF. In addition, if IPv4 and IPv6 data LIF addresses are present on the same participating node, FPolicy attempts to establish connections for both IPv4 and IPv6. Therefore, in a scenario where the SVM extends over multiple nodes or if both IPv4 and IPv6 addresses are present, the FPolicy server must be ready for multiple control channel setup requests from the cluster after the FPolicy policy is enabled on the SVM.

For example, if a cluster has three nodes—Node1, Node2, and Node3—and SVM data LIFs are spread across only Node2 and Node3, control channels are initiated only from Node2 and Node3, irrespective of the distribution of data volumes. Say that Node2 has two data LIFs—LIF1 and LIF2—that belong to the SVM and that the initial connection is from LIF1. If LIF1 fails, FPolicy attempts to establish a control channel from LIF2.



#### How FPolicy manages external communication during LIF migration or failover

Data LIFs can be migrated to data ports in the same node or to data ports on a remote node.

When a data LIF fails over or is migrated, a new control channel connection is made to the FPolicy server. FPolicy can then retry SMB and NFS client requests that timed out, with the result that new notifications are sent to the external FPolicy servers. The node rejects FPolicy server responses to original, timed-out SMB and NFS requests.

#### How FPolicy manages external communication during node failover

If the cluster node that hosts the data ports used for FPolicy communication fails, ONTAP breaks the connection between the FPolicy server and the node.

The impact of cluster failover to the FPolicy server can be mitigated by configuring the LIF manager to migrate the data port used in FPolicy communication to another active node. After the migration is complete, a new connection is established using the new data port.

If the LIF manager is not configured to migrate the data port, the FPolicy server must wait for the failed node to come up. After the node is up, a new connection is initiated from that node with a new Session ID.



The FPolicy server detects broken connections with the keep-alive protocol message. The timeout for purging the session ID is determined when configuring FPolicy. The default keep-alive timeout is two minutes.

## How FPolicy services work across SVM namespaces

ONTAP provides a unified storage virtual machine (SVM) namespace. Volumes across the cluster are joined together by junctions to provide a single, logical file system. The FPolicy server is aware of the namespace topology and provides FPolicy services across the namespace.

The namespace is specific to and contained within the SVM; therefore, you can see the namespace only from the SVM context. Namespaces have the following characteristics:

- A single namespace exists in each SVM, with the root of the namespace being the root volume, represented in the namespace as slash (/).
- All other volumes have junction points below the root (/).
- · Volume junctions are transparent to clients.
- A single NFS export can provide access to the complete namespace; otherwise, export policies can export specific volumes.
- SMB shares can be created on the volume or on qtrees within the volume, or on any directory within the namespace.
- The namespace architecture is flexible.

Examples of typical namespace architectures are as follows:

- $\,{}^{\circ}\,$  A name space with a single branch off of the root
- A namespace with multiple branches off of the root
- A namespace with multiple unbranched volumes off of the root

# **FPolicy configuration types**

There are two basic FPolicy configuration types. One configuration uses external FPolicy servers to process and act upon notifications. The other configuration does not use external FPolicy servers; instead, it uses the ONTAP internal, native FPolicy server for simple file blocking based on extensions.

#### External FPolicy server configuration

The notification is sent to the FPolicy server, which screens the request and applies rules to determine whether the node should allow the requested file operation. For synchronous policies, the FPolicy server then sends a response to the node to either allow or block the requested file operation.

#### Native FPolicy server configuration

The notification is screened internally. The request is allowed or denied based on file extension settings configured in the FPolicy scope.

## When to create a native FPolicy configuration

Native FPolicy configurations use the ONTAP internal FPolicy engine to monitor and block file operations based on the file's extension. This solution does not require external FPolicy servers (FPolicy servers). Using a native file blocking configuration is appropriate when this simple solution is all that is needed.

Native file blocking enables you to monitor any file operations that match configured operation and filtering events and then deny access to files with particular extensions. This is the default configuration.

This configuration provides a means to block file access based only on the file's extension. For example, to block files that contain mp3 extensions, you configure a policy to provide notifications for certain operations with target file extensions of mp3. The policy is configured to deny mp3 file requests for operations that generate notifications.

The following applies to native FPolicy configurations:

- The same set of filters and protocols that are supported by FPolicy server-based file screening are also supported for native file blocking.
- Native file blocking and FPolicy server-based file screening applications can be configured at the same time.

To do so, you can configure two separate FPolicy policies for the storage virtual machine (SVM), with one configured for native file blocking and one configured for FPolicy server-based file screening.

- The native file blocking feature only screens files based on the extensions and not on the content of the file
- In the case of symbolic links, native file blocking uses the file extension of the root file.

# When to create a configuration that uses external FPolicy servers

FPolicy configurations that use external FPolicy servers to process and manage notifications provide robust solutions for use cases where more than simple file blocking based on file extension is needed.

You should create a configuration that uses external FPolicy servers when you want to do such things as monitor and record file access events, provide quota services, perform file blocking based on criteria other than simple file extensions, provide data migration services using hierarchical storage management applications, or provide a fine-grained set of policies that monitor only a subset of data in the storage virtual machine (SVM).

# How FPolicy passthrough-read enhances usability for hierarchical storage management

Passthrough-read enables the FPolicy server (functioning as the hierarchical storage management (HSM) server) to provide read access to offline files without having to recall the file from the secondary storage system to the primary storage system.

When an FPolicy server is configured to provide HSM to files residing on a CIFS server, policy-based file migration occurs where the files are stored offline on secondary storage and only a stub file remains on primary storage. Even though a stub file appears as a normal file to clients, it is actually a sparse file that is the same size of the original file. The sparse file has the CIFS offline bit set and points to the actual file that has been migrated to secondary storage.

Typically when a read request for an offline file is received, the requested content must be recalled back to primary storage and then accessed through primary storage. The need to recall data back to primary storage has several undesirable effects. Among the undesirable effects is the increased latency to client requests caused by the need to recall the content before responding to the request and the increased space consumption needed for recalled files on the primary storage.

FPolicy passthrough-read allows the HSM server (the FPolicy server) to provide read access to migrated, offline files without having to recall the file from the secondary storage system to the primary storage system. Instead of recalling the files back to primary storage, read requests can be serviced directly from secondary storage.



Copy Offload (ODX) is not supported with FPolicy passthrough-read operation.

Passthrough-read enhances usability by providing the following benefits:

- Read requests can be serviced even if the primary storage does not have sufficient space to recall requested data back to primary storage.
- Better capacity and performance management when a surge of data recall might occur, such as if a script or a backup solution needs to access many offline files.
- Read requests for offline files in Snapshot copies can be serviced.

Because Snapshot copies are read-only, the FPolicy server cannot restore the original file if the stub file is located in a Snapshot copy. Using passthrough-read eliminates this problem.

 Policies can be set up that control when read requests are serviced through access to the file on secondary storage and when the offline file should be recalled to primary storage.

For example, a policy can be created on the HSM server that specifies the number of times the offline file can be accessed in a specified period of time before the file is migrated back to primary storage. This type of policy avoids recalling files that are rarely accessed.

### How read requests are managed when FPolicy passthrough-read is enabled

You should understand how read requests are managed when FPolicy passthrough-read is enabled so that you can optimally configure connectivity between the storage virtual machine (SVM) and the FPolicy servers.

When FPolicy passthrough-read is enabled and the SVM receives a request for an offline file, FPolicy sends a notification to the FPolicy server (HSM server) through the standard connection channel.

After receiving the notification, the FPolicy server reads the data from the file path sent in the notification and sends the requested data to the SVM through the passthrough-read privileged data connection that is established between the SVM and the FPolicy server.

After the data is sent, the FPolicy server then responds to the read request as an ALLOW or DENY. Based on whether the read request is allowed or denied, ONTAP either sends the requested information or sends an error message to the client.

# Requirements, considerations, and best practices for configuring FPolicy

Before you create and configure FPolicy configurations on your storage virtual machines (SVMs), you need to be aware of certain requirements, considerations, and best practices for configuring FPolicy.

# Ways to configure FPolicy

FPolicy features are configured either through the command line interface (CLI) or through APIs. This guide uses the CLI to create, manage, and monitor an FPolicy configuration on the cluster.

## Requirements for setting up FPolicy

Before you configure and enable FPolicy on your storage virtual machine (SVM), you need to be aware of certain requirements.

- All nodes in the cluster must be running a version of ONTAP that supports FPolicy.
- If you are not using the ONTAP native FPolicy engine, you must have external FPolicy servers (FPolicy servers) installed.
- The FPolicy servers must be installed on a server accessible from the data LIFs of the SVM where FPolicy policies are enabled.
- The IP address of the FPolicy server must be configured as a primary or secondary server in the FPolicy policy external engine configuration.
- If the FPolicy servers access data over a privileged data channel, the following additional requirements must be met:
  - · CIFS must be licensed on the cluster.

Privileged data access is accomplished using SMB connections.

- A user credential must be configured for accessing files over the privileged data channel.
- The FPolicy server must run under the credentials configured in the FPolicy configuration.
- All data LIFs used to communicate with the FPolicy servers must be configured to have cifs as one of the allowed protocols.

This includes the LIFs used for passthrough-read connections.

# Best practices and recommendations when setting up FPolicy

When setting up FPolicy on storage virtual machines (SVMs), you need to be familiar with configuration best

practices and recommendations to ensure that your FPolicy configuration provides robust monitoring performance and results that meet your requirements.

- External FPolicy servers (FPolicy servers) should be placed in close proximity to the cluster with high-bandwidth connectivity to provide minimal latency and high-bandwidth connectivity.
- The FPolicy external engine should be configured with more than one FPolicy server to provide resiliency and high availability of FPolicy server notification processing, especially if policies are configured for synchronous screening.
- It is recommended that you disable the FPolicy policy before making any configuration changes.

For example, if you want to add or modify an IP address in the FPolicy external engine configured for the enabled policy, you should first disable the policy.

• The cluster node-to-FPolicy server ratio should be optimized to ensure that FPolicy servers are not overloaded, which can introduce latencies when the SVM responds to client requests.

The optimal ratio depends on the application for which the FPolicy server is being used.

# Passthrough-read upgrade and revert considerations

There are certain upgrade and revert considerations that you must know about before upgrading to an ONTAP release that supports passthrough-read or before reverting to a release that does not support passthrough-read.

#### **Upgrading**

After all nodes are upgraded to a version of ONTAP that supports FPolicy passthrough-read, the cluster is capable of using the passthrough-read functionality; however, passthrough-read is disabled by default on existing FPolicy configurations. To use passthrough-read on existing FPolicy configurations, you must disable the FPolicy policy and modify the configuration, and then reenable the configuration.

#### Reverting

Before reverting to a version of ONTAP that does not support FPolicy passthrough-read, the following conditions must be met:

- All the policies using passthrough-read must be disabled, and then the affected configurations must be modified so that they do not use passthrough-read.
- FPolicy functionality must be disabled on the cluster by disabling every FPolicy policy on the cluster.

# What the steps for setting up an FPolicy configuration are

Before FPolicy can monitor file access, an FPolicy configuration must be created and enabled on the storage virtual machine (SVM) for which FPolicy services are required.

The steps for setting up and enabling an FPolicy configuration on the SVM are as follows:

1. Create an FPolicy external engine.

The FPolicy external engine identifies the external FPolicy servers (FPolicy servers) that are associated with a specific FPolicy configuration. If the internal "native" FPolicy engine is used to create a native file-blocking configuration, you do not need to create an FPolicy external engine.

#### 2. Create an FPolicy event.

An FPolicy event describes what the FPolicy policy should monitor. Events consist of the protocols and file operations to monitor, and can contain a list of filters. Events use filters to narrow the list of monitored events for which the FPolicy external engine must send notifications. Events also specify whether the policy monitors volume operations.

### 3. Create an FPolicy policy.

The FPolicy policy is responsible for associating, with the appropriate scope, the set of events that need to be monitored and for which of the monitored events notifications must be sent to the designated FPolicy server (or to the native engine if no FPolicy servers are configured). The policy also defines whether the FPolicy server is allowed privileged access to the data for which it receives notifications. An FPolicy server needs privileged access if the server needs to access the data. Typical use cases where privileged access is needed include file blocking, quota management, and hierarchical storage management. The policy is where you specify whether the configuration for this policy uses an FPolicy server or the internal "native" FPolicy server.

A policy specifies whether screening is mandatory. If screening is mandatory and all FPolicy servers are down or no response is received from the FPolicy servers within a defined timeout period, then file access is denied.

A policy's boundaries are the SVM. A policy cannot apply to more than one SVM. However, a specific SVM can have multiple FPolicy policies, each with the same or different combination of scope, event, and external server configurations.

#### 4. Configure the policy scope.

The FPolicy scope determines which volumes, shares, or export-policies the policy acts on or excludes from monitoring. A scope also determines which file extensions should be included or excluded from FPolicy monitoring.



Exclude lists take precedence over include lists.

#### 5. Enable the FPolicy policy.

When the policy is enabled, the control channels and, optionally, the privileged data channels are connected. The FPolicy process on the nodes on which the SVM participates begin monitoring file and folder access and, for events that match configured criteria, sends notifications to the FPolicy servers (or to the native engine if no FPolicy servers are configured).



If the policy uses native file blocking, an external engine is not configured or associated with the policy.

# Plan the FPolicy configuration

# Plan the FPolicy external engine configuration

Before you configure the FPolicy external engine (external engine), you must understand what it means to create an external engine and which configuration parameters are available. This information helps you to determine which values to set for each parameter.

#### Information that is defined when creating the FPolicy external engine

The external engine configuration defines the information that FPolicy needs to make and manage connections to the external FPolicy servers (FPolicy servers), including the following information:

- · storage virtual machine (SVM) name
- · Engine name
- The IP addresses of the primary and secondary FPolicy servers and the TCP port number to use when making the connection to the FPolicy servers
- Whether the engine type is asynchronous or synchronous
- · How to authenticate the connection between the node and the FPolicy server

If you choose to configure mutual SSL authentication, then you must also configure parameters that provide SSL certificate information.

· How to manage the connection using various advanced privilege settings

This includes parameters that define such things as timeout values, retry values, keep-alive values, maximum request values, sent and receive buffer size values, and session timeout values.

The vserver fpolicy policy external-engine create command is used to create an FPolicy external engine.

#### What the basic external engine parameters are

You can use the following table of basic FPolicy configuration parameters to help you plan your configuration:

Type of information	Option
SVM	-vserver vserver_name
Specifies the SVM name that you want to associate with this external engine.	
Each FPolicy configuration is defined within a single SVM. The external engine, policy event, policy scope, and policy that combine together to create an FPolicy policy configuration must all be associated with the same SVM.	

Type of information		Option	
Engine name		-engine-name engine_name	
configura	the name to assign to the external engine tion. You must specify the external engine er when you create the FPolicy policy. This is the external engine with the policy.		
The name	e can be up to 256 characters long.		
i	The name should be up to 200 characters long if configuring the external engine name in a MetroCluster or SVM disaster recovery configuration.		
	e can contain any combination of the ASCII-range characters:		
• a thro	ough z		
• A thro	ough z		
• 0 thro	ough 9		
• "_", "_	", and "."		
Primary F	Policy servers	-primary-servers IP_address,	
node sen	the primary FPolicy servers to which the ds notifications for a given FPolicy policy. e is specified as a comma-delimited list of IPs.		
If more than one primary server IP address is specified, every node on which the SVM participates creates a control connection to every specified primary FPolicy server at the time the policy is enabled. If you configure multiple primary FPolicy servers, notifications are sent to the FPolicy servers in a round-robin fashion.			
SVM disa specify th source sit the FPolice	ernal engine is used in a MetroCluster or aster recovery configuration, you should e IP addresses of the FPolicy servers at the se as primary servers. The IP addresses of by servers at the destination site should be as secondary servers.		
Port num	ber	-port integer	
Specifies the port number of the FPolicy service.			

Type of information	Option
Specifies the secondary FPolicy servers to which to send file access events for a given FPolicy policy. The value is specified as a comma-delimited list of IP addresses.  Secondary servers are used only when none of the primary servers are reachable. Connections to secondary servers are established when the policy is enabled, but notifications are sent to secondary servers only if none of the primary servers are reachable. If you configure multiple secondary servers, notifications are sent to the FPolicy servers in a round-robin fashion.	-secondary-servers IP_address,
Specifies whether the external engine operates in synchronous or asynchronous mode. By default, FPolicy operates in synchronous mode.  When set to synchronous, file request processing sends a notification to the FPolicy server, but then does not continue until after receiving a response from the FPolicy server. At that point, request flow either continues or processing results in denial, depending on whether the response from the FPolicy server permits the requested action.  When set to asynchronous, file request processing sends a notification to the FPolicy server, and then continues.	-extern-engine-type external_engine_type The value for this parameter can be one of the following:  • synchronous  • asynchronous

Type of information	Option
SSL option for communication with FPolicy server  Specifies the SSL option for communication with the FPolicy server. This is a required parameter. You can choose one of the options based on the following information:  • When set to no-auth, no authentication takes place.  The communication link is established over TCP.  • When set to server-auth, the SVM authenticates the FPolicy server using SSL server authentication.  • When set to mutual-auth, mutual authentication takes place between the SVM and the FPolicy server; the SVM authenticates the FPolicy server, and the FPolicy server authenticates the SVM.  If you choose to configure mutual SSL authentication, then you must also configure the -certificate-common-name, -certificate -serial, and -certificate-ca parameters.	-ssl-option {no-auth server-auth mutual-auth}
Certificate FQDN or custom common name  Specifies the certificate name used if SSL authentication between the SVM and the FPolicy server is configured. You can specify the certificate name as an FQDN or as a custom common name.  If you specify mutual-auth for the -ssl-option parameter, you must specify a value for the -certificate-common-name parameter.	-certificate-common-name text
Certificate serial number  Specifies the serial number of the certificate used for authentication if SSL authentication between the SVM and the FPolicy server is configured.  If you specify mutual-auth for the -ssl-option parameter, you must specify a value for the -certificate-serial parameter.	-certificate-serial text

Type of information	Option
Certificate authority	-certifcate-ca text
Specifies the CA name of the certificate used for authentication if SSL authentication between the SVM and the FPolicy server is configured.  If you specify mutual-auth for the -ssl-option parameter, you must specify a value for the -certificate-ca parameter.	

# What the advanced external engine options are

You can use the following table of advanced FPolicy configuration parameters as you plan whether to customize your configuration with advanced parameters. You use these parameters to modify communication behavior between the cluster nodes and the FPolicy servers:

Type of information	Option
Timeout for canceling a request  Specifies the time interval in hours (h), minutes (m), or seconds (s) that the node waits for a response from the FPolicy server.  If the timeout interval passes, the node sends a cancel request to the FPolicy server. The node then sends the notification to an alternate FPolicy server. This timeout helps in handling an FPolicy server that is not responding, which can improve SMB/NFS client response. Also, canceling requests after a timeout period can help in releasing system resources because the notification request is moved from a down/bad FPolicy server to an alternate FPolicy	-reqs-cancel-timeout integer[h m s]
The range for this value is 0 through 100. If the value is set to 0, the option is disabled and cancel request messages are not sent to the FPolicy server. The default is 20s.	
Timeout for aborting a request  Specifies the timeout in hours (h), minutes (m), or seconds (s) for aborting a request.  The range for this value is 0 through 200.	-reqs-abort-timeout ` `integer[h m s]

Type of information	Option
Interval for sending status requests  Specifies the interval in hours (h), minutes (m), or seconds (s) after which a status request is sent to the FPolicy server.  The range for this value is 0 through 50. If the value is set to 0, the option is disabled and status request messages are not sent to the FPolicy server. The default is 10s.	-status-req-interval integer[h m s]
Maximum outstanding requests on the FPolicy server  Specifies the maximum number of outstanding requests that can be queued on the FPolicy server.  The range for this value is 1 through 10000. The default is 50.	-max-server-reqs integer
Timeout for disconnecting a nonresponsive FPolicy server  Specifies the time interval in hours (h), minutes (m), or seconds (s) after which the connection to the FPolicy server is terminated.  The connection is terminated after the timeout period only if the FPolicy server's queue contains the maximum allowed requests and no response is received within the timeout period. The maximum allowed number of requests is either 50 (the default) or the number specified by the max-server-reqs-parameter.  The range for this value is 1 through 100. The default is 60s.	-server-progress-timeout integer[h m s]
Interval for sending keep-alive messages to the FPolicy server  Specifies the time interval in hours (h), minutes (m), or seconds (s) at which keep-alive messages are sent to the FPolicy server.  Keep-alive messages detect half-open connections.  The range for this value is 10 through 600. If the value is set to 0, the option is disabled and keep-alive messages are prevented from being sent to the FPolicy servers. The default is 120s.	-keep-alive-interval-integer[h m s]

Type of information	Option
Maximum reconnect attempts  Specifies the maximum number of times the SVM attempts to reconnect to the FPolicy server after the connection has been broken.  The range for this value is 0 through 20. The default is 5.	-max-connection-retries integer
Receive buffer size  Specifies the receive buffer size of the connected socket for the FPolicy server.  The default value is set to 256 kilobytes (Kb). When the value is set to 0, the size of the receive buffer is set to a value defined by the system.  For example, if the default receive buffer size of the socket is 65536 bytes, by setting the tunable value to 0, the socket buffer size is set to 65536 bytes. You can use any non-default value to set the size (in bytes) of the receive buffer.	-recv-buffer-size integer
Specifies the send buffer size of the connected socket for the FPolicy server.  The default value is set to 256 kilobytes (Kb). When the value is set to 0, the size of the send buffer is set to a value defined by the system.  For example, if the default send buffer size of the socket is set to 65536 bytes, by setting the tunable value to 0, the socket buffer size is set to 65536 bytes. You can use any non-default value to set the size (in bytes) of the send buffer.	-send-buffer-size integer

Type of information O	Option
	-session-timeout[integerh][integer n][integer <b>s</b> ]

# Additional information about configuring FPolicy external engines to use SSL authenticated connections

You need to know some additional information if you want to configure the FPolicy external engine to use SSL when connecting to FPolicy servers.

#### SSL server authentication

If you choose to configure the FPolicy external engine for SSL server authentication, before creating the external engine, you must install the public certificate of the certificate authority (CA) that signed the FPolicy server certificate.

#### Mutual authentication

If you configure FPolicy external engines to use SSL mutual authentication when connecting storage virtual machine (SVM) data LIFs to external FPolicy servers, before creating the external engine, you must install the public certificate of the CA that signed the FPolicy server certificate along with the public certificate and key file for authentication of the SVM. You must not delete this certificate while any FPolicy policies are using the installed certificate.

If the certificate is deleted while FPolicy is using it for mutual authentication when connecting to an external FPolicy server, you cannot reenable a disabled FPolicy policy that uses that certificate. The FPolicy policy cannot be reenabled in this situation even if a new certificate with the same settings is created and installed on the SVM.

If the certificate has been deleted, you need to install a new certificate, create new FPolicy external engines that use the new certificate, and associate the new external engines with the FPolicy policy that you want to reenable by modifying the FPolicy policy.

#### Install certificates for SSL

The public certificate of the CA that is used to sign the FPolicy server certificate is installed by using the security certificate install command with the -type parameter set to client\_ca. The private key and public certificate required for authentication of the SVM is installed by using the security certificate install command with the -type parameter set to server.

# Certificates do not replicate in SVM disaster recovery relationships with a non-ID-preserve configuration

Security certificates used for SSL authentication when making connections to FPolicy servers do not replicate to SVM disaster recovery destinations with non-ID-preserve configurations. Although the FPolicy external-engine configuration on the SVM is replicated, security certificates are not replicated. You must manually install the security certificates on the destination.

When you set up the SVM disaster recovery relationship, the value you select for the -identity-preserve option of the snapmirror create command determines the configuration details that are replicated in the destination SVM.

If you set the -identity-preserve option to true (ID-preserve), all of the FPolicy configuration details are replicated, including the security certificate information. You must install the security certificates on the destination only if you set the option to false (non-ID-preserve).

# Restrictions for cluster-scoped FPolicy external engines with MetroCluster and SVM disaster recovery configurations

You can create a cluster-scoped FPolicy external engine by assigning the cluster storage virtual machine (SVM) to the external engine. However, when creating a cluster-scoped external engine in a MetroCluster or SVM disaster recovery configuration, there are certain restrictions when choosing the authentication method that the SVM uses for external communication with the FPolicy server.

There are three authentication options that you can choose when creating external FPolicy servers: no authentication, SSL server authentication, and SSL mutual authentication. Although there are no restrictions when choosing the authentication option if the external FPolicy server is assigned to a data SVM, there are restrictions when creating a cluster-scoped FPolicy external engine:

Configuration	Permitted?
MetroCluster or SVM disaster recovery and a cluster- scoped FPolicy external engine with no authentication (SSL is not configured)	Yes
MetroCluster or SVM disaster recovery and a cluster- scoped FPolicy external engine with SSL server or SSL mutual authentication	No

- If a cluster-scoped FPolicy external engine with SSL authentication exists and you want to create a
  MetroCluster or SVM disaster recovery configuration, you must modify this external engine to use no
  authentication or remove the external engine before you can create the MetroCluster or SVM disaster
  recovery configuration.
- If the MetroCluster or SVM disaster recovery configuration already exists, ONTAP prevents you from creating a cluster-scoped FPolicy external engine with SSL authentication.

### Complete the FPolicy external engine configuration worksheet

You can use this worksheet to record the values that you need during the FPolicy external engine configuration process. If a parameter value is required, you need to determine what value to use for those parameters before you configure the external engine.

#### Information for a basic external engine configuration

You should record whether you want to include each parameter setting in the external engine configuration and then record the value for the parameters that you want to include.

Type of information	Required	Include	Your values
storage virtual machine (SVM) name	Yes	Yes	
Engine name	Yes	Yes	
Primary FPolicy servers	Yes	Yes	
Port number	Yes	Yes	
Secondary FPolicy servers	No		
External engine type	No		
SSL option for communication with external FPolicy server	Yes	Yes	
Certificate FQDN or custom common name	No		
Certificate serial number	No		
Certificate authority	No		

#### Information for advanced external engine parameters

To configure an external engine with advanced parameters, you must enter the configuration command while in advanced privilege mode.

Type of information	Required	Include	Your values
Timeout for canceling a request	No		

Type of information	Required	Include	Your values
Timeout for aborting a request	No		
Interval for sending status requests	No		
Maximum outstanding requests on the FPolicy server	No		
Timeout for disconnecting a nonresponsive FPolicy server	No		
Interval for sending keep- alive messages to the FPolicy server	No		
Maximum reconnect attempts	No		
Receive buffer size	No		
Send buffer size	No		
Timeout for purging a session ID during reconnection	No		

# Plan the FPolicy event configuration

#### Plan the FPolicy event configuration overview

Before you configure FPolicy events, you must understand what it means to create an FPolicy event. You must determine which protocols you want the event to monitor, which events to monitor, and which event filters to use. This information helps you plan the values that you want to set.

#### What it means to create an FPolicy event

Creating the FPolicy event means defining information that the FPolicy process needs to determine what file access operations to monitor and for which of the monitored events notifications should be sent to the external FPolicy server. The FPolicy event configuration defines the following configuration information:

- storage virtual machine (SVM) name
- Event name

· Which protocols to monitor

FPolicy can monitor SMB, NFSv3, and NFSv4 file access operations.

· Which file operations to monitor

Not all file operations are valid for each protocol.

· Which file filters to configure

Only certain combinations of file operations and filters are valid. Each protocol has its own set of supported combinations.

• Whether to monitor volume mount and unmount operations

There is a dependency with three of the parameters (-protocol, -file-operations, -filters). The following combinations are valid for the three parameters:



- You can specify the -protocol and -file-operations parameters.
- · You can specify all three of the parameters.
- · You can specify none of the parameters.

#### What the FPolicy event configuration contains

You can use the following list of available FPolicy event configuration parameters to help you plan your configuration:

Type of information	Option
SVM	-vserver vserver_name
Specifies the SVM name that you want to associate with this FPolicy event.	
Each FPolicy configuration is defined within a single SVM. The external engine, policy event, policy scope, and policy that combine together to create an FPolicy policy configuration must all be associated with the same SVM.	

Type of i	nformation	Option
Event na	me	-event-name event_name
	the name to assign to the FPolicy event. When you create the olicy you associate the FPolicy event with the policy using the me.	
The name	e can be up to 256 characters long.	
i	The name should be up to 200 characters long if configuring the event in a MetroCluster or SVM disaster recovery configuration.	
The name	e can contain any combination of the following ASCII-range s:	
• a thro	ough z	
• A thro	ough Z	
• 0 thro	ough 9	
• " _ ",	"-", and "."	
Protocol		-protocol protocol
-	which protocol to configure for the FPolicy event. The list for old can include one of the following values:	
• cifs		
• nfsv	3	
• nfsv	4	
<u>(i)</u>	If you specify -protocol, then you must specify a valid value in the -file-operations parameter. As the protocol version changes, the valid values might change.	

Type of information	Option
File operations	-file-operations
Specifies the list of file operations for the FPolicy event.	file_operations,
The event checks the operations specified in this list from all client requests using the protocol specified in the <code>-protocol</code> parameter. You can list one or more file operations by using a comma-delimited list. The list for <code>-file-operations</code> can include one or more of the following values:	
• close for file close operations	
• create for file create operations	
• create-dir for directory create operations	
• delete for file delete operations	
• delete_dir for directory delete operations	
• getattr for get attribute operations	
link for link operations	
lookup for lookup operations	
• open for file open operations	
• read for file read operations	
• write for file write operations	
• rename for file rename operations	
<ul> <li>rename_dir for directory rename operations</li> </ul>	
• setattr for set attribute operations	
• symlink for symbolic link operations	
If you specify -file-operations, then you must specify a valid protocol in the -protocol parameter.	

# Type of information Option Filters -filters filter, ... Specifies the list of filters for a given file operation for the specified protocol. The values in the -filters parameter are used to filter client requests. The list can include one or more of the following: If you specify the -filters parameter, then you must also specify valid values for the -file-operations and -protocol parameters. • monitor-ads option to filter the client request for alternate data stream. • close-with-modification option to filter the client request for close with modification. • close-without-modification option to filter the client request for close without modification. • first-read option to filter the client request for first read. • first-write option to filter the client request for first write. • offline-bit option to filter the client request for offline bit set. Setting this filter results in the FPolicy server receiving notification only when offline files are accessed. • open-with-delete-intent option to filter the client request for open with delete intent. Setting this filter results in the FPolicy server receiving notification only when an attempt is made to open a file with the intent to delete it. This is used by file systems when the FILE DELETE ON CLOSE flag is specified. • open-with-write-intent option to filter client request for open with write intent.

Setting this filter results in the FPolicy server receiving notification only when an attempt is made to open a file with the intent to write something in it.

• write-with-size-change option to filter the client request for write with size change.

Type of information	Option
Filters continued	-filters filter,
<ul> <li>setattr-with-owner-change option to filter the client setattr requests for changing owner of a file or a directory.</li> </ul>	
<ul> <li>setattr-with-group-change option to filter the client setattr requests for changing the group of a file or a directory.</li> </ul>	
<ul> <li>setattr-with-sacl-change option to filter the client setattr requests for changing the SACL on a file or a directory.</li> </ul>	
This filter is available only for the CIFS and NFSv4 protocols.	
<ul> <li>setattr-with-dacl-change option to filter the client setattr requests for changing the DACL on a file or a directory.</li> </ul>	
This filter is available only for the CIFS and NFSv4 protocols.	
• setattr-with-modify-time-change option to filter the client setattr requests for changing the modification time of a file or a directory.	
<ul> <li>setattr-with-access-time-change option to filter the client setattr requests for changing the access time of a file or a directory.</li> </ul>	
<ul> <li>setattr-with-creation-time-change option to filter the client setattr requests for changing the creation time of a file or a directory.</li> </ul>	
This option is available only for the CIFS protocol.	
<ul> <li>setattr-with-mode-change option to filter the client setattr requests for changing the mode bits on a file or a directory.</li> </ul>	
<ul> <li>setattr-with-size-change option to filter the client setattr requests for changing the size of a file.</li> </ul>	
• setattr-with-allocation-size-change option to filter the client setattr requests for changing the allocation size of a file.	
This option is available only for the CIFS protocol.	
<ul> <li>exclude-directory option to filter the client requests for directory operations.</li> </ul>	
When this filter is specified, the directory operations are not monitored.	
Is volume operation required	-volume-operation {true
Specifies whether monitoring is required for volume mount and unmount operations. The default is false.	false}

List of supported file operation and filter combinations that FPolicy can monitor for SMB

When you configure your FPolicy event, you need to be aware that only certain

combinations of file operations and filters are supported for monitoring SMB file access operations.

The list of supported file operation and filter combinations for FPolicy monitoring of SMB file access events is provided in the following table:

Supported file operations	Supported filters
close	monitor-ads, offline-bit, close-with-modification, close-without-modification, close-with-read, exclude-directory
create	monitor-ads, offline-bit
create_dir	Currently no filter is supported for this file operation.
delete	monitor-ads, offline-bit
delete_dir	Currently no filter is supported for this file operation.
getattr	offline-bit, exclude-dir
open	monitor-ads, offline-bit, open-with-delete-intent, open-with-write-intent, exclude-dir
read	monitor-ads, offline-bit, first-read
write	monitor-ads, offline-bit, first-write, write-with-size- change
rename	monitor-ads, offline-bit
rename_dir	Currently no filter is supported for this file operation.
setattr	monitor-ads, offline-bit, setattr_with_owner_change, setattr_with_group_change, setattr_with_mode_change, setattr_with_sacl_change, setattr_with_sacl_change, setattr_with_modify_time_change, setattr_with_access_time_change, setattr_with_creation_time_change, setattr_with_size_change, setattr_with_size_change, setattr_with_allocation_size_change, exclude_directory

# Supported file operation and filter combinations that FPolicy can monitor for NFSv3

When you configure your FPolicy event, you need to be aware that only certain

combinations of file operations and filters are supported for monitoring NFSv3 file access operations.

The list of supported file operation and filter combinations for FPolicy monitoring of NFSv3 file access events is provided in the following table:

Supported file operations	Supported filters
create	offline-bit
create_dir	Currently no filter is supported for this file operation.
delete	offline-bit
delete_dir	Currently no filter is supported for this file operation.
link	offline-bit
lookup	offline-bit, exclude-dir
read	offline-bit, first-read
write	offline-bit, first-write, write-with-size-change
rename	offline-bit
rename_dir	Currently no filter is supported for this file operation.
setattr	offline-bit, setattr_with_owner_change, setattr_with_group_change, setattr_with_mode_change, setattr_with_modify_time_change, setattr_with_access_time_change, setattr_with_size_change, exclude_directory
symlink	offline-bit

#### Supported file operation and filter combinations that FPolicy can monitor for NFSv4

When you configure your FPolicy event, you need to be aware that only certain combinations of file operations and filters are supported for monitoring NFSv4 file access operations.

The list of supported file operation and filter combinations for FPolicy monitoring of NFSv4 file access events is provided in the following table:

Supported file operations	Supported filters
close	offline-bit, exclude-directory
create	offline-bit
create_dir	Currently no filter is supported for this file operation.
delete	offline-bit
delete_dir	Currently no filter is supported for this file operation.
getattr	offline-bit, exclude-directory
link	offline-bit
lookup	offline-bit, exclude-directory
open	offline-bit, exclude-directory
read	offline-bit, first-read
write	offline-bit, first-write, write-with-size-change
rename	offline-bit
rename_dir	Currently no filter is supported for this file operation.
setattr	offline-bit, setattr_with_owner_change, setattr_with_group_change, setattr_with_mode_change, setattr_with_sacl_change, setattr_with_sacl_change, setattr_with_modify_time_change, setattr_with_access_time_change, setattr_with_size_change, exclude_directory
symlink	offline-bit

## Complete the FPolicy event configuration worksheet

You can use this worksheet to record the values that you need during the FPolicy event configuration process. If a parameter value is required, you need to determine what value to use for those parameters before you configure the FPolicy event.

You should record whether you want to include each parameter setting in the FPolicy event configuration and then record the value for the parameters that you want to include.

Type of information	Required	Include	Your values
storage virtual machine (SVM) name	Yes	Yes	
Event name	Yes	Yes	
Protocol	No		
File operations	No		
Filters	No		
Is volume operation required	No		

# Plan the FPolicy policy configuration

### Plan the FPolicy policy configuration overview

Before you configure the FPolicy policy, you must understand which parameters are required when creating the policy as well as why you might want to configure certain optional parameters. This information helps you to determine which values to set for each parameter.

When creating an FPolicy policy you associate the policy with the following:

- The storage virtual machine (SVM)
- · One or more FPolicy events
- An FPolicy external engine

You can also configure several optional policy settings.

#### What the FPolicy policy configuration contains

You can use the following list of available FPolicy policy required and optional parameters to help you plan your configuration:

Type of information	Option	Required	Default
SVM name  Specifies the name of the SVM on which you want to create an FPolicy policy.	-vserver vserver_name	Yes	None

Type of i	nformation	Option	Required	Default
Policy nad Specifies FPolicy p	the name of the	-policy-name policy_name	Yes	None
	e can be up to acters long.			
i	The name should be up to 200 characters long if configuring the policy in a MetroClust er or SVM disaster recovery configuratio n.			
any comb	e can contain pination of the ASCII-range es:			
• a through z				
• A thro				
• 0 thro				
• "_", "-", and "."				

Type of information	Option	Required	Default
Event names  Specifies a commadelimited list of events to associate with the FPolicy policy.	-events event_name,	Yes	None
<ul> <li>You can associate more than one event to a policy.</li> </ul>			
<ul> <li>An event is specific to a protocol.</li> </ul>			
You can use a single policy to monitor file access events for more than one protocol by creating an event for each protocol that you want the policy to monitor, and then associating the events to the policy.			
The events must already exist.			

Type of information	Option	Required	Default
External engine name  Specifies the name of the external engine to associate with the FPolicy policy.	-engine engine_name	Yes (unless the policy uses the internal ONTAP native engine)	native
<ul> <li>An external engine contains information required by the node to send notifications to an FPolicy server.</li> </ul>			
You can configure     FPolicy to use the     ONTAP native     external engine for     simple file blocking or     to use an external     engine that is     configured to use     external FPolicy     servers (FPolicy     servers) for more     sophisticated file     blocking and file     management.			
<ul> <li>If you want to use the native external engine, you can either not specify a value for this parameter or you can specify native as the value.</li> </ul>			
<ul> <li>If you want to use FPolicy servers, the configuration for the external engine must already exist.</li> </ul>			

Type of information	Option	Required	Default
Is mandatory screening required	-is-mandatory {true   false}	No	true
Specifies whether mandatory file access screening is required.			
• The mandatory screening setting determines what action is taken on a file access event in a case when all primary and secondary servers are down or no response is received from the FPolicy servers within a given timeout period.			
<ul> <li>When set to true, file access events are denied.</li> </ul>			
<ul> <li>When set to false, file access events are allowed.</li> </ul>			

Type of information	Option	Required	Default
Allow privileged access  Specifies whether you want the FPolicy server to have privileged access to the monitored files and folders by using a privileged data connection.	-allow-privileged -access {yes no}	No (unless passthrough- read is enabled)	no
If configured, FPolicy servers can access files from the root of the SVM containing the monitored data using the privileged data connection.			
For privileged data access, CIFS must be licensed on the cluster and all the data LIFs used to connect to the FPolicy servers must be configured to have cifs as one of the allowed protocols.			
If you want to configure the policy to allow privileged access, you must also specify the user name for the account that you want the FPolicy server to use for privileged access.			

Type of information	Option	Required	Default
Privileged user name  Specifies the user name of the account the FPolicy servers use for privileged data access.  • The value for this	-privileged-user -name user_name	No (unless privileged access is enabled)	None
parameter should use the "domain\user name" format.			
• If -allow -privileged -access is set to no, any value set for this parameter is ignored.			

Type of information	Option	Required	Default
Allow passthrough-read  Specifies whether the FPolicy servers can provide passthrough-read services for files that have been archived to secondary storage (offline files) by the FPolicy servers:	-is-passthrough -read-enabled {true  false}	No	false
<ul> <li>Passthrough-read is a way to read data for offline files without restoring the data to the primary storage.</li> </ul>			
Passthrough-read reduces response latencies because there is no need to recall files back to primary storage before responding to the read request. Additionally, passthrough-read optimizes storage efficiency by eliminating the need to consume primary storage space with files that are recalled solely to satisfy read requests.			
<ul> <li>When enabled, the FPolicy servers provide the data for the file over a separate privileged data channel opened specifically for passthrough-reads.</li> <li>If you want to configure passthrough-read, the</li> </ul>			
policy must also be configured to allow privileged access.			

## Requirement for FPolicy scope configurations if the FPolicy policy uses the native engine

If you configure the FPolicy policy to use the native engine, there is a specific requirement for how you define the FPolicy scope configured for the policy.

The FPolicy scope defines the boundaries on which the FPolicy policy applies, for example whether the FPolicy applies to specified volumes or shares. There are a number of parameters that further restrict the scope to which the FPolicy policy applies. One of these parameters, <code>-is-file-extension-check-on-directories-enabled</code>, specifies whether to check file extensions on directories. The default value is false, which means that file extensions on directories are not checked.

When an FPolicy policy that uses the native engine is enabled on a share or volume and the <code>-is-file</code> <code>-extension-check-on-directories-enabled</code> parameter is set to <code>false</code> for the scope of the policy, directory access is denied. With this configuration, because the file extensions are not checked for directories, any directory operation is denied if it falls under the scope of the policy.

To ensure that directory access succeeds when using the native engine, you must set the -is-file -extension-check-on-directories-enabled parameter to true when creating the scope.

With this parameter set to true, extension checks happen for directory operations and the decision whether to allow or deny access is taken based on the extensions included or excluded in the FPolicy scope configuration.

### Complete the FPolicy policy worksheet

You can use this worksheet to record the values that you need during the FPolicy policy configuration process. You should record whether you want to include each parameter setting in the FPolicy policy configuration and then record the value for the parameters that you want to include.

Type of information	Include	Your values
storage virtual machine (SVM) name	Yes	
Policy name	Yes	
Event names	Yes	
External engine name		
Is mandatory screening required		
Allow privileged access		
Privileged user name		
Is passthrough-read enabled		

## Plan the FPolicy scope configuration

## Plan the FPolicy scope configuration overview

Before you configure the FPolicy scope, you must understand what it means to create a scope. You must understand what the scope configuration contains. You also need to understand what the scope rules of precedence are. This information can help you plan the values that you want to set.

### What it means to create an FPolicy scope

Creating the FPolicy scope means defining the boundaries on which the FPolicy policy applies. The storage virtual machine (SVM) is the basic boundary. When you create a scope for an FPolicy policy, you must define the FPolicy policy to which it will apply, and you must designate to which SVM you want to apply the scope.

There are a number of parameters that further restrict the scope within the specified SVM. You can restrict the scope by specifying what to include in the scope or by specifying what to exclude from the scope. After you apply a scope to an enabled policy, policy event checks get applied to the scope defined by this command.

Notifications are generated for file access events where matches are found in the "include" options. Notifications are not generated for file access events where matches are found in the "exclude" options.

The FPolicy scope configuration defines the following configuration information:

- SVM name
- · Policy name
- · The shares to include or exclude from what gets monitored
- The export policies to include or exclude from what gets monitored
- · The volumes to include or exclude from what gets monitored
- · The file extensions to include or exclude from what gets monitored
- · Whether to do file extension checks on directory objects



There are special considerations for the scope for a cluster FPolicy policy. The cluster FPolicy policy is a policy that the cluster administrator creates for the admin SVM. If the cluster administrator also creates the scope for that cluster FPolicy policy, the SVM administrator cannot create a scope for that same policy. However, if the cluster administrator does not create a scope for the cluster FPolicy policy, then any SVM administrator can create the scope for that cluster policy. If the SVM administrator creates a scope for that cluster FPolicy policy, the cluster administrator cannot subsequently create a cluster scope for that same cluster policy. This is because the cluster administrator cannot override the scope for the same cluster policy.

### What the scope rules of precedence are

The following rules of precedence apply to scope configurations:

- When a share is included in the -shares-to-include parameter and the parent volume of the share is included in the -volumes-to-exclude parameter, -volumes-to-exclude has precedence over -shares-to-include.
- When an export policy is included in the <code>-export-policies-to-include</code> parameter and the parent volume of the export policy is included in the <code>-volumes-to-exclude</code> parameter, <code>-volumes-to</code>

- -exclude has precedence over -export-policies-to-include.
- An administrator can specify both -file-extensions-to-include and -file-extensions-to-exclude lists.

The -file-extensions-to-exclude parameter is checked before the -file-extensions-to-include parameter is checked.

## What the FPolicy scope configuration contains

You can use the following list of available FPolicy scope configuration parameters to help you plan your configuration:



When configuring what shares, export policies, volumes, and file extensions to include or exclude from the scope, the include and exclude parameters can contain regular expressions and can include metacharacters such as "?" and "\*".

Type of information	Option
SVM	-vserver vserver_name
Specifies the SVM name on which you want to create an FPolicy scope.	
Each FPolicy configuration is defined within a single SVM. The external engine, policy event, policy scope, and policy that combine together to create an FPolicy policy configuration must all be associated with the same SVM.	
Policy name	-policy-name policy_name
Specifies the name of the FPolicy policy to which you want to attach the scope. The FPolicy policy must already exist.	
Shares to include	-shares-to-include
Specifies a comma-delimited list of shares to monitor for the FPolicy policy to which the scope is applied.	share_name,
Shares to exclude	-shares-to-exclude
Specifies a comma-delimited list of shares to exclude from monitoring for the FPolicy policy to which the scope is applied.	share_name,
Volumes to include Specifies a comma-delimited list of volumes to monitor for the FPolicy policy to which the scope is applied.	-volumes-to-include volume_name,
Volumes to exclude	-volumes-to-exclude
Specifies a comma-delimited list of volumes to exclude from monitoring for the FPolicy policy to which the scope is applied.	volume_name,

Type of information	Option
Export policies to include  Specifies a comma-delimited list of export policies to monitor for the FPolicy policy to which the scope is applied.	-export-policies-to -include export_policy_name,
Export policies to exclude  Specifies a comma-delimited list of export policies to exclude from monitoring for the FPolicy policy to which the scope is applied.	-export-policies-to -exclude export_policy_name,
File extensions to include  Specifies a comma-delimited list of file extensions to monitor for the FPolicy policy to which the scope is applied.	-file-extensions-to -include file_extensions,
File extension to exclude  Specifies a comma-delimited list of file extensions to exclude from monitoring for the FPolicy policy to which the scope is applied.	-file-extensions-to -exclude file_extensions,
Is file extension check on directory enabled  Specifies whether the file name extension checks apply to directory objects as well. If this parameter is set to true, the directory objects are subjected to the same extension checks as regular files. If this parameter is set to false, the directory names are not matched for extensions and notifications are sent for directories even if their name extensions do not match.  If the FPolicy policy to which the scope is assigned is configured to use the	-is-file-extension -check-on-directories -enabled {true  false }
native engine, this parameter must be set to true.	

# Complete the FPolicy scope worksheet

You can use this worksheet to record the values that you need during the FPolicy scope configuration process. If a parameter value is required, you need to determine what value to use for those parameters before you configure the FPolicy scope.

You should record whether you want to include each parameter setting in the FPolicy scope configuration and then record the value for the parameters that you want to include.

Type of information	Required	Include	Your values
storage virtual machine (SVM) name	Yes	Yes	
Policy name	Yes	Yes	

Type of information	Required	Include	Your values
Shares to include	No		
Shares to exclude	No		
Volumes to include	No		
Volumes to exclude	No		
Export policies to include	No		
Export policies to exclude	No		
File extensions to include	No		
File extension to exclude	No		
Is file extension check on directory enabled	No		

# **Create the FPolicy configuration**

# Create the FPolicy external engine

You must create an external engine to start creating an FPolicy configuration. The external engine defines how FPolicy makes and manages connections to external FPolicy servers. If your configuration uses the internal ONTAP engine (the native external engine) for simple file blocking, you do not need to configure a separate FPolicy external engine and do not need to perform this step.

## What you'll need

The external engine worksheet should be completed.

#### About this task

If the external engine is used in a MetroCluster configuration, you should specify the IP addresses of the FPolicy servers at the source site as primary servers. The IP addresses of the FPolicy servers at the destination site should be specified as secondary servers.

#### Steps

1. Create the FPolicy external engine by using the vserver fpolicy policy external-engine create command.

The following command creates an external engine on storage virtual machine (SVM) vs1.example.com. No authentication is required for external communications with the FPolicy server.

vserver fpolicy policy external-engine create -vserver-name vs1.example.com

```
-engine-name engine1 -primary-servers 10.1.1.2,10.1.1.3 -port 6789 -ssl-option no-auth
```

Verify the FPolicy external engine configuration by using the vserver fpolicy policy externalengine show command.

The following command display information about all external engines configured on SVM vs1.example.com:

vserver fpolicy policy external-engine show -vserver vs1.example.com

		Primary	Secondary	
External Vserver	Engine	Servers	Servers	Port Engine
Type				
vs1.example.com	engine1	10.1.1.2,	-	6789
synchronous		10.1.1.3		

The following command displays detailed information about the external engine named "engine1" on SVM vs1.example.com:

vserver fpolicy policy external-engine show -vserver vs1.example.com -engine
-name engine1

# Create the FPolicy event

As part of creating an FPolicy policy configuration, you need to create an FPolicy event. You associate the event with the FPolicy policy when it is created. An event defines which protocol to monitor and which file access events to monitor and filter.

### What you'll need

The FPolicy event worksheet should be completed.

## Steps

1. Create the FPolicy event by using the vserver fpolicy policy event create command.

```
vserver fpolicy policy event create -vserver-name vs1.example.com -event-name event1 -protocol cifs -file-operations open, close, read, write
```

2. Verify the FPolicy event configuration by using the vserver fpolicy policy event show command.

vserver fpolicy policy event show -vserver vsl.example.com

Vserver	Event Name	Protocols	File Operations	Filters	Is Volume Operation
vs1.example.com	event1	cifs	open, close, read, write	_	false

## **Create the FPolicy policy**

When you create the FPolicy policy, you associate an external engine and one or more events to the policy. The policy also specifies whether mandatory screening is required, whether the FPolicy servers have privileged access to data on the storage virtual machine (SVM), and whether passthrough-read for offline files is enabled.

## What you'll need

- The FPolicy policy worksheet should be completed.
- If you plan on configuring the policy to use FPolicy servers, the external engine must exist.
- At least one FPolicy event that you plan on associating with the FPolicy policy must exist.
- If you want to configure privileged data access, a CIFS server must exist on the SVM.

#### Steps

1. Create the FPolicy policy:

```
vserver fpolicy policy create -vserver-name vserver_name -policy-name
policy_name -engine engine_name -events event_name,... [-is-mandatory
{true|false}] [-allow-privileged-access {yes|no}] [-privileged-user-name
domain\user name] [-is-passthrough-read-enabled {true|false}]
```

- You can add one or more events to the FPolicy policy.
- By default, mandatory screening is enabled.
- If you want to allow privileged access by setting the -allow-privileged-access parameter to yes, you must also configure a privileged user name for privileged access.
- If you want to configure passthrough-read by setting the -is-passthrough-read-enabled parameter to true, you must also configure privileged data access.

The following command creates a policy named "policy1" that has the event named "event1" and the

external engine named "engine1" associated with it. This policy uses default values in the policy configuration: vserver fpolicy policy create -vserver vs1.example.com -policy -name policy1 -events event1 -engine engine1

The following command creates a policy named "policy2" that has the event named "event2" and the external engine named "engine2" associated with it. This policy is configured to use privileged access using the specified user name. Passthrough-read is enabled:

vserver fpolicy policy create -vserver vs1.example.com -policy-name policy2 -events event2 -engine engine2 -allow-privileged-access yes -privileged-user-name example\archive acct -is-passthrough-read-enabled true

The following command creates a policy named "native1" that has the event named "event3" associated with it. This policy uses the native engine and uses default values in the policy configuration:

vserver fpolicy policy create -vserver vs1.example.com -policy-name native1
-events event3 -engine native

2. Verify the FPolicy policy configuration by using the vserver fpolicy policy show command.

The following command displays information about the three configured FPolicy policies, including the following information:

- The SVM associated with the policy
- The external engine associated with the policy
- The events associated with the policy
- Whether mandatory screening is required
- Whether privileged access is required vserver fpolicy policy show

Vserver	Policy Name	Events	Engine	Is Mandatory	Privileged Access
vs1.example.com	policy1	event1	engine1	true	no
vs1.example.com	policy2	event2	engine2	true	yes
vs1.example.com	native1	event3	native	true	no

# **Create the FPolicy scope**

After creating the FPolicy policy, you need to create an FPolicy scope. When creating the scope, you associate the scope with an FPolicy policy. A scope defines the boundaries on which the FPolicy policy applies. Scopes can include or exclude files based on shares, export policies, volumes, and file extensions.

### What you'll need

The FPolicy scope worksheet must be completed. The FPolicy policy must exist with an associated external engine (if the policy is configured to use external FPolicy servers) and must have at least one associated

FPolicy event.

### **Steps**

1. Create the FPolicy scope by using the vserver fpolicy policy scope create command.

```
vserver fpolicy policy scope create -vserver-name vs1.example.com -policy-name policy1 -volumes-to-include datavol1,datavol2
```

2. Verify the FPolicy scope configuration by using the vserver fpolicy policy scope show command.

vserver fpolicy policy scope show -vserver vs1.example.com -instance

```
Vserver: vsl.example.com
Policy: policy1
Shares to Include: -
Shares to Exclude: -
Volumes to Include: datavol1, datavol2
Volumes to Exclude: -
Export Policies to Include: -
Export Policies to Exclude: -
File Extensions to Include: -
File Extensions to Exclude: -
```

# **Enable the FPolicy policy**

After you are through configuring an FPolicy policy configuration, you enable the FPolicy policy. Enabling the policy sets its priority and starts file access monitoring for the policy.

### What you'll need

The FPolicy policy must exist with an associated external engine (if the policy is configured to use external FPolicy servers) and must have at least one associated FPolicy event. The FPolicy policy scope must exist and must be assigned to the FPolicy policy.

### About this task

The priority is used when multiple policies are enabled on the storage virtual machine (SVM) and more than one policy has subscribed to the same file access event. Policies that use the native engine configuration have a higher priority than policies for any other engine, regardless of the sequence number assigned to them when enabling the policy.



A policy cannot be enabled on the admin SVM.

#### Steps

1. Enable the FPolicy policy by using the vserver fpolicy enable command.

```
vserver fpolicy enable -vserver-name vs1.example.com -policy-name policy1
-sequence-number 1
```

2. Verify that the FPolicy policy is enabled by using the vserver fpolicy show command.

		Sequence		
Vserver	Policy Name	Number	Status	Engine
vs1.example.com	policy1	1	on	engine1

# **Modify FPolicy configurations**

# Commands for modifying FPolicy configurations

You can modify FPolicy configurations by modifying the elements that make up the configuration. You can modify external engines, FPolicy events, FPolicy scopes, and FPolicy policies. You can also enable or disable FPolicy policies. When you disable the FPolicy policy, file monitoring is discontinued for that policy.

It is recommended to disable the FPolicy policy before modifying the configuration.

If you want to modify	Use this command
External engines	vserver fpolicy policy external-engine modify
Events	vserver fpolicy policy event modify
Scopes	vserver fpolicy policy scope modify
Policies	vserver fpolicy policy modify

See the man pages for the commands for more information.

# **Enable or disable FPolicy policies**

You can enable FPolicy policies after the configuration is complete. Enabling the policy sets its priority and starts file access monitoring for the policy. You can disable FPolicy policies if you want to stop file access monitoring for the policy.

### What you'll need

Before enabling FPolicy policies, the FPolicy configuration must be completed.

#### About this task

- The priority is used when multiple policies are enabled on the storage virtual machine (SVM) and more than one policy has subscribed to the same file access event.
- Policies that use the native engine configuration have a higher priority than policies for any other engine, regardless of the sequence number assigned to them when enabling the policy.

• If you want to change the priority of an FPolicy policy, you must disable the policy and then reenable it using the new sequence number.

### Step

1. Perform the appropriate action:

If you want to	Enter the following command
Enable an FPolicy policy	vserver fpolicy enable -vserver-name vserver_name -policy-name policy_name -sequence-number integer
Disable an FPolicy policy	<pre>vserver fpolicy disable -vserver-name vserver_name -policy-name policy_name</pre>

# Display information about FPolicy configurations

## How the show commands work

It is helpful when displaying information about the FPolicy configuration to understand how the show commands work.

A show command without additional parameters displays information in a summary form. Additionally, every show command has the same two mutually exclusive optional parameters, -instance and -fields.

When you use the <code>-instance</code> parameter with a <code>show</code> command, the command output displays detailed information in a list format. In some cases, the detailed output can be lengthy and include more information than you need. You can use the <code>-fields fieldname[, fieldname...]</code> parameter to customize the output so that it displays information only for the fields you specify. You can identity which fields that you can specify by entering? after the <code>-fields</code> parameter.



The output of a show command with the -fields parameter might display other relevant and necessary fields related to the requested fields.

Every show command has one or more optional parameters that filter that output and enable you to narrow the scope of information displayed in command output. You can identity which optional parameters are available for a command by entering? after the show command.

The show command supports UNIX-style patterns and wildcards to enable you to match multiple values in command-parameters arguments. For example, you can use the wildcard operator (\*), the NOT operator (!), the OR operator (|), the range operator (integer...integer), the less-than operator (<), the greater-than operator (>), the less-than or equal to operator (>=) when specifying values.

For more information about using UNIX-style patterns and wildcards, see the "Using the ONTAP command-line interface" section of the *System Administration Guide for SVM Administrators*.

# Commands for displaying information about FPolicy configurations

You use the fpolicy show commands to display information about the FPolicy configuration, including information about FPolicy external engines, events, scopes, and policies.

If you want to display information about FPolicy	Use this command
External engines	vserver fpolicy policy external-engine show
Events	vserver fpolicy policy event show
Scopes	vserver fpolicy policy scope show
Policies	vserver fpolicy policy show

See the man pages for the commands for more information.

# Display information about FPolicy policy status

You can display information about the status for FPolicy policies to determine whether a policy is enabled, what external engine it is configured to use, what the sequence number is for the policy, and to which storage virtual machine (SVM) the FPolicy policy is associated.

### About this task

If you do not specify any parameters, the command displays the following information:

- SVM name
- · Policy name
- Policy sequence number
- Policy status

In addition to displaying information about policy status for FPolicy policies configured on the cluster or a specific SVM, you can use command parameters to filter the command's output by other criteria.

You can specify the -instance parameter to display detailed information about listed policies. Alternatively, you can use the -fields parameter to display only the indicated fields in the command output, or -fields? to determine what fields you can use.

### Step

1. Display filtered information about FPolicy policy status by using the appropriate command:

If you want to display status information about policies	Enter the command
On the cluster	vserver fpolicy show
That have the specified status	vserver fpolicy show -status {on off}
On a specified SVM	vserver fpolicy show -vserver vserver_name
With the specified policy name	vserver fpolicy show -policy-name policy_name
That use the specified external engine	vserver fpolicy show -engine engine_name

## Example

The following example displays the information about FPolicy policies on the cluster:

cluster1::> vserve	r fpolicy show			
		Sequence		
Vserver	Policy Name	Number	Status	Engine
FPolicy	cserver_policy	_	off	eng1
vs1.example.com	v1p1	_	off	eng2
vs1.example.com	v1p2	_	off	native
vs1.example.com	v1p3	_	off	native
vs1.example.com	cserver_policy	_	off	eng1
vs2.example.com	v1p1	3	on	native
vs2.example.com	v1p2	1	on	eng3
vs2.example.com	cserver_policy	2	on	eng1

# Display information about enabled FPolicy policies

You can display information about enabled FPolicy policies to determine what FPolicy external engine it is configured to use, what the priority is for the policy, and to which storage virtual machine (SVM) the FPolicy policy is associated.

## About this task

If you do not specify any parameters, the command displays the following information:

- SVM name
- Policy name
- Policy priority

You can use command parameters to filter the command's output by specified criteria.

### Step

1. Display information about enabled FPolicy policies by using the appropriate command:

If you want to display information about enabled policies	Enter the command
On the cluster	vserver fpolicy show-enabled
On a specified SVM	vserver fpolicy show-enabled -vserver vserver_name
With the specified policy name	vserver fpolicy show-enabled -policy -name policy_name
With the specified sequence number	vserver fpolicy show-enabled -priority integer

### **Example**

The following example displays the information about enabled FPolicy policies on the cluster:

cluster1::> vserver	fpolicy show-enabled	
Vserver	Policy Name	Priority
vs1.example.com	pol_native	native
vs1.example.com	pol_native2	native
vs1.example.com	pol1	2
vs1.example.com	pol2	4

# **Manage FPolicy server connections**

# **Connect to external FPolicy servers**

To enable file processing, you might need to manually connect to an external FPolicy server if the connection has previously been terminated. A connection is terminated after the server timeout is reached or due to some error. Alternatively, the administrator might manually terminate a connection.

### About this task

If a fatal error occurs, the connection to the FPolicy server can be terminated. After resolving the issue that caused the fatal error, you must manually reconnect to the FPolicy server.

## Steps

- 1. Connect to the external FPolicy server by using the vserver fpolicy engine-connect command.
  - For more information about the command, see the man pages.
- 2. Verify that the external FPolicy server is connected by using the vserver fpolicy show-engine command.

For more information about the command, see the man pages.

# Disconnect from external FPolicy servers

You might need to manually disconnect from an external FPolicy server. This might be desirable if the FPolicy server has issues with notification request processing or if you need to perform maintenance on the FPolicy server.

## **Steps**

1. Disconnect from the external FPolicy server by using the vserver fpolicy engine-disconnect command.

For more information about the command, see the man pages.

2. Verify that the external FPolicy server is disconnected by using the vserver fpolicy show-engine command.

For more information about the command, see the man pages.

# Display information about connections to external FPolicy servers

You can display status information about connections to external FPolicy servers (FPolicy servers) for the cluster or for a specified storage virtual machine (SVM). This information can help you determine which FPolicy servers are connected.

### About this task

If you do not specify any parameters, the command displays the following information:

- SVM name
- Node name
- · FPolicy policy name
- · FPolicy server IP address
- · FPolicy server status
- · FPolicy server type

In addition to displaying information about FPolicy connections on the cluster or a specific SVM, you can use command parameters to filter the command's output by other criteria.

You can specify the <code>-instance</code> parameter to display detailed information about listed policies. Alternatively, you can use the <code>-fields</code> parameter to display only the indicated fields in the command output. You can enter ? after the <code>-fields</code> parameter to find out which fields you can use.

# Step

1. Display filtered information about connection status between the node and the FPolicy server by using the appropriate command:

If you want to display connection status information about FPolicy servers	Enter
That you specify	vserver fpolicy show-engine -server IP_address
For a specified SVM	<pre>vserver fpolicy show-engine -vserver vserver_name</pre>
That are attached with a specified policy	vserver fpolicy show-engine -policy -name policy_name
With the server status that you specify	vserver fpolicy show-engine -server -status status  The server status can be one of the following:  • connected • disconnected • connecting • disconnecting
With the specified type	vserver fpolicy show-engine -server -type type  The FPolicy server type can be one of the following:  • primary • secondary

If you want to display connection status information about FPolicy servers	Enter
That were disconnected with the specified reason	vserver fpolicy show-engine -disconnect-reason text
	Disconnect can be due to multiple reasons. The following are common reasons for disconnect:
	• Disconnect command received from CLI.
	<ul> <li>Error encountered while parsing notification response from FPolicy server.</li> </ul>
	* FPolicy Handshake failed.
	* SSL handshake failed.
	• TCP Connection to FPolicy server failed.
	<ul> <li>The screen response message received from the FPolicy server is not valid.</li> </ul>

# Example

This example displays information about external engine connections to FPolicy servers on SVM vs1.example.com:

<pre>cluster1::&gt; vserver fpolicy show-engine -vserver vs1.example.com</pre>					
FPolicy				Server-	Server-
Vserver	Policy	Node	Server	status	type
vs1.example.com	m policy1	node1	10.1.1.2	connected	primary
vs1.example.com	m policy1	node1	10.1.1.3	disconnected	primary
vs1.example.com	m policy1	node2	10.1.1.2	connected	primary
vs1.example.com	m policy1	node2	10.1.1.3	disconnected	primary

This example displays information only about connected FPolicy servers:

## Display information about the FPolicy passthrough-read connection status

You can display information about FPolicy passthrough-read connection status to external FPolicy servers (FPolicy servers) for the cluster or for a specified storage virtual machine (SVM). This information can help you determine which FPolicy servers have passthrough-read data connections and for which FPolicy servers the passthrough-read connection is disconnected.

#### About this task

If you do not specify any parameter, the command displays the following information:

- SVM name
- · FPolicy policy name
- · Node name
- · FPolicy server IP address
- FPolicy passthrough-read connection status

In addition to displaying information about FPolicy connections on the cluster or a specific SVM, you can use command parameters to filter the command's output by other criteria.

You can specify the <code>-instance</code> parameter to display detailed information about listed policies. Alternatively, you can use the <code>-fields</code> parameter to display only the indicated fields in the command output. You can enter ? after the <code>-fields</code> parameter to find out which fields you can use.

### Step

 Display filtered information about connection status between the node and the FPolicy server by using the appropriate command:

If you want to display connection status information about	Enter the command
FPolicy passthrough-read connection status for the cluster	vserver fpolicy show-passthrough-read- connection
FPolicy passthrough-read connection status for a specified SVM	vserver fpolicy show-passthrough-read- connection -vserver vserver_name
FPolicy passthrough-read connection status for a specified policy	vserver fpolicy show-passthrough-read- connection -policy-name policy_name

If you want to display connection status information about	Enter the command
Detailed FPolicy passthrough-read connection status for a specified policy	vserver fpolicy show-passthrough-read- connection -policy-name policy_name -instance
FPolicy passthrough-read connection status for the status that you specify	vserver fpolicy show-passthrough-read- connection -policy-name policy_name -server-status status The server status can be one of the following:  * connected  * disconnected

### **Example**

The following command displays information about passthrough-read connections from all FPolicy servers on the cluster:

<pre>cluster1::&gt; vserver fpolicy show-passthrough-read-connection</pre>					
			FPolicy	Server	
Vserver	Policy Name	Node	Server	Status	
				-	
vs2.example.com	pol_cifs_2	FPolicy-01	2.2.2.2	disconnected	
vs1.example.com	pol_cifs_1	FPolicy-01	1.1.1.1	connected	

The following command displays detailed information about passthrough-read connections from FPolicy servers configured in the "pol\_cifs\_1" policy:

```
cluster1::> vserver fpolicy show-passthrough-read-connection -policy-name pol_cifs_1 -instance

Node: FPolicy-01
Vserver: vs1.example.com
Policy: pol_cifs_1
Server: 1.1.1.1
Session ID of the Control Channel: 8cef052e-2502-11e3-
88d4-123478563412

Server Status: connected
Time Passthrough Read Channel was Connected: 9/24/2013 10:17:45
Time Passthrough Read Channel was Disconnected: -
Reason for Passthrough Read Channel Disconnection: none
```

## **Copyright Information**

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.