

LogiCORE IP Concat (v2.1)

PB041 (v2.1) April 6, 2016

Product Brief

Introduction

The Concat IP core is used for concatenating bus signals of varying widths.

Additional Information

See the product page

Features

- Configurable number of ports
- Configurable bit width of each port

LogiCORE IP Facts Table Core Specifics		
Supported User Interfaces	N/A	
	Provided with Core	
Design Files	VHDL	
Example Design	Not Provided	
Test Bench	Not Provided	
Constraints File	None	
Simulation Model	VHDL	
Supported S/W Driver	N/A	
•	Tested Design Flows(2)	
Design Entry	Vivado® Design Suite	
Simulation	For supported simulators, see the Xilinx Design Tools: Release Notes Guide.	
Synthesis	N/A	
Support		
Provided by	Xilinx at the Xilinx Support web page	

Notes:

- For a complete listing of supported devices, see the Vivado IP catalog.
- 2. For the supported versions of the tools, see the Xilinx Design Tools: Release Notes Guide.



Overview

The Concat IP core provides a mechanism to combine bus signals of varying width into a single bus.




Figure 1: Concat IP in a System

Block Diagram



Figure 2: Block Diagram



Using Concat in a Block Design

In a block design you instantiate the Concat IP core by right clicking in the block design canvas and selecting **Add IP** from the context menu.




Figure 3: Adding the Concat Block in the Block Design Canvas

In the Search field of the IP Catalog, type **Concat** and double-click the Concat IP core to instantiate it.




Figure 4: Search the Concat IP Core in the IP Catalog and instantiate

This instantiates the Concat IP core in the design as shown in Figure 5.






Figure 5: Concat IP Before Customization

Double-click the Concat block to open the Re-Customize IP dialog box.




Figure 6: Re-customize IP Dialog Box

In Figure 6, set the **Number of Ports** parameter to the number of input ports desired. To set the bit width of an input port, toggle the button to the left of the **Inx Width** field to **Manual** which makes the **Inx Width** field editable. Enter the bit width in the field. The output bit width is the combined bit widths of all the input ports and is shown in the **Dout Width** field.



I/O Signals

The I/O signals are listed and described in Table 1.

Table 1: I/O Signals

Port Name	Description
Inx[width-1:0]	Input bus with variable width. The number of input ports depends on the Number of Ports parameter. The "width" can be set to the desired number of bits.
dout[combined width – 1 : 0]	dout is the output port whose bit width equals the combined bit widths of all the input ports.

Design Parameters

The parameters are listed and described in Table 2.

Table 2: Design Parameters

Parameter	Description	Туре
Number of Ports	Number of Input ports desired.	Integer

Design Implementation

Design Tools

Note: This IP can only be used in Vivado® IP integrator. It is not designed to be used in an RTL-only design flow within the Vivado Design Suite.

HDL file is provided during generation in the Vivado IP integrator.

Target Technology

The target technologies are UltraScale+™, UltraScale™, Zynq®-7000, and 7 series devices.

Device Utilization and Performance Benchmarks

Using this block in the block design will not incur any resource usage of the FPGA.



Technical Support

Xilinx provides technical support at the Xilinx Support web page for this LogiCORE™ IP product when used as described in the product documentation. Xilinx cannot guarantee timing, functionality, or support if you do any of the following:

- Implement the solution in devices that are not defined in the documentation.
- Customize the solution beyond that allowed in the product documentation.
- Change any section of the design labeled DO NOT MODIFY.

To contact Xilinx Technical Support, navigate to the Xilinx Support web page.

Licensing and Ordering Information

This Xilinx LogiCORE™ IP module is provided at no additional cost with the Xilinx Vivado Design Suite under the terms of the Xilinx End User License. Information about this and other Xilinx LogiCORE IP modules is available at the Xilinx Intellectual Property page. For information about pricing and availability of other Xilinx LogiCORE IP modules and tools, contact your local Xilinx sales representative.

Revision History

The following table shows the revision history for this document:

Date	Version	Revision
04/06/2016	2.1	Initial Xilinx Release.

Please Read: Important Legal Notices

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at http://www.xilinx.com/legal.htm#tos; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at http://www.xilinx.com/legal.htm#tos.