PV-981 - 4 /8 /16 SDK (PCI Video & Audio Capture Card) Installation Guide

| A. Pre-installation | |
|---|-----|
| 1. PV-981 Product specification · · · · · · · · · · · · · · · · · · · | 2 |
| 2. PV-981 Hardware Equipment · · · · · · · · · · · · · · · · · · · | 2 |
| 3. PV-981 Connection · · · · · · · · · · · · · · · · · · · | . 3 |
| 4. Notice Before Installation · · · · · · · · · · · · · · · · · · · | 4 |
| 4.1 About Hardware · · · · · · · · · · · · · · · · · · · | 5 |
| 4.2 About Software · · · · · · · · · · · · · · · · · · · | 5 |
| B. Installation | |
| 1. How to plug PV-981 into PCI-E slot · · · · · · · · · · · · · · · · · · · | 5 |
| 2. How to install PV-981 drivers · · · · · · · · · · · · · · · · · · · | 5 |
| 3. How to use the SDK application of PV-981 · · · · · · · · · · · · · · · · · · · | 6 |
| C. Q&A · · · · · · · · · · · · · · · · · · · | S |

Version: 1.2

Date: 2006/03/23

A. Pre-installation:

Congratulation! You have purchased our PV-981 PCI-E Video/Audio Capture card, which using high quality chipset and offer the best video capture.

1. PV-981 Product specification:

| | PV-981 |
|--------------|---------------------------------------|
| Interface | |
| Bus | PCI-Express 1x |
| Video Input | 4 / 8 / 16 ports BNC |
| Audio Input | 4 ports BNC |
| Video Format | NTSC/PAL |
| Software | 1.Win 2K / XP |
| | 2.SDK included (DirectShow interface) |
| | Pentium IV 2.8Ghz or higher level PC |
| System | 512 MB RAM |
| System | 16X CD-ROM |
| Requirement | Windows™ 2K / XP OS |
| | AGP or PCI-E VGA card and Monitor |

Note: Recommended to use INTEL M/B to install the products.


2. PV-981 Hardware Equipment:

| I . PV-981-4/8/16 Capture Card · · · · · · · · · · · · · · · · · · · | 1pcs |
|--|------|
| $\scriptstyle\rm II.$ SDK CD \cdot | 1pcs |
| Ⅲ. User's Manual · · · · · · · · · · · · · · · · · · · | 1pcs |
| IV. Cable for "Watch Dog" · · · · · · · · · · · · · · · · · · · | 1pcs |
| V. D-Sub Video/Audio AUX Input Cable | |

2pin cable for "Watch Dog"




3. PV-981-4 Connection:




NOTE: Install two*PV-981-4 cards on one PC will be able to do 8 ports real-time video/audio capturing performance without any problem.

PV-981-8 Connection:



PV-981-16 Connection:



D-Sub Video/Audio AUX Input Cable:







Cable1 : RED : Audio Cable (AUD1-AUD4) CH1-CH4

BLUE : Video Cable(VID1-VID4)CH1-CH4

Cable2 : RED : Audio Cable (AUD1-AUD4) CH1-CH4

BLUE : Video Cable(VID1-VID4)CH1-CH4

GREEN : Video Cable(VID1-VID4)CH5-CH8

Cable3 : BLUE : VID1-VID4(CH9-CH12)

GREEN : VID1-VID4(CH13-CH16)

- 4. Notice before Installing:
 - 4.1 About Hardware:

For PV-981 is a PCI-E 1x slot only used video/audio capture card, please confirm there are available PCI-E 1x slots for PV-981 using.

4.2 About software:

Please make sure if Microsoft[™] DirectX8.1 or higher version already been installed in Windows[™] 2K/XP.


B. Installing Steps:

- 1. How to plug PV-981 into PCI-E 1x slot:
- 1.1: Please power off your PC.
- 1.2 : Open the casing.
- 1.3 : Insert PV-981 onto the available PCI-E 1x slot and tightly fasten the screws.
- 1.4 : Close the casing.
- 1.5 : Power on your PC.
- ★Notice: Please delete or uninstall the old drivers completely if you ever installed BT878 drivers or other video capture card before you install this brand-new PV-981. Or it will cause the compatibility problems with PV-981 drivers.
- 2. How to install PV-981 drivers within Microsoft™ Windows OS:
- 2.1 : Use Microsoft™ Windows 2K/XP for operating system.
- 2.2 : After you log on into PC, Windows will detect PV-981 already been inserted into PCI-E 1x slot(s).
- 2.3 : Please insert the CD of PV-981 product into the CD-ROM.
- 2.4 : Let Windows Hardware Detecting Wizard search the driver and nominate the route to the driver location of CD, X : \PV-981(SDK)\Drv (Assume CD-ROM to be X :) We took Windows 2K OS for example.






2.5 : After installing the drivers completely, go to 「Control Panel」->「System」->「Device Manager」check the 「Sound, video and game controllers」already been installed below marked hardware items.




- 2.6 : As above Picture, it means that all drivers already been installed well.
- 3. How to use the SDK application of PV-981:
 - 3.1 : Please insert the CD of PV-981 product into the CD-ROM, and find the X : PV-981(SDK)\ Bin\PAL(or NTSC).. Folder. Then copy whole folder to C : \(As below Picture)



3.2 : After copy the folder to C : \..., Please execute X : \PV-981(SDK)\DxFilter\InstallAx.bat at first.



And then install the codec of MPEG-4 under X: \PV-981(SDK)\MPEG4 as below diagram:




3.3 : Then execute Sample_NTSC.exe or Sample_PAL.exe according to your camera video mode for viewing the result. (As below Picture)




- 3.4 : Click [Capture AVI](As below Picture), and put checks on AV0, 1, 2, 3...for saving AVI files depends on camera numbers. (Ex. : AV0 = Camera1)
- ★ Notice: Taking the checks away can stop the function.
- ★ Notice: If you need the AVI file, please rename and move the file to other folder, or the earlier file will be covered by late one.
- ★ Notice: It will not save the files if execute Sample_NTSC.exe or Sample_PAL.exe by using CD.



3.5 : Click [GPIO]->[GPIO Control](As below Picture) for detecting or setting I/O card (Option).



- 3.6 Click [WDT](As below Picture), it can start, stop and test "Watch Dog" function.
 - 3.6.1 Start: When the system hang or appear error message, the system will auto re-boot in 7 seconds.
 - 3.6.2 Stop: Stop: "Watch Dog" function.
 - 3.6.3 Test: It will auto re-boot the system immediately to test "Watch Dog" function.



3.7 : Click [File]->[Exit](As below Picture), exit this program.



C. Q&A:

Q1: I already installed all drivers well, but why I cannot execute Sample_NTSC.exe or Sample_PAL.exe file?

A1 : Please execute InstallAx.bat before execute Sample_NTSC.exe or Sample_PAL.exe.

Q2 : After executing Sample_NTSC.exe or Sample_PAL.exe, why only see a blue screen but video ?

A2: I .Please confirm the VGA card supports Overlay Mode or not.

 $\scriptstyle\rm II$.Please install DirectX 8.1 or higher version.

Ⅲ.Please confirm that already install drivers completely.

Q3: Why I cannot execute SDK program under WinNT?

A3: We're sorry that PV-981 didn't support WinNT OS.

Q4: Did SDK program support Linux?

A4: Yes, PV-981 supports Linux's driver, but we didn't have technical support for using on Linux.