C152 GROUND PROCEDURES

| | Ш |
|--|---|
| DISPATCH | |
| Weather BRIEF | |
| NOTAMS CHECK W&B CHECK | |
| Perf. Reqs CHECK | |
| SquawksCHECK | |
| PREFLIGHT INSPECTION | Ī |
| Fuel DRAIN, CHECK | |
| AV1ATE CHECK | |
| AROWCHECK | |
| Avionics OFF | I |
| Master ON | ľ |
| Fuel Gauge TRUE | ľ |
| Flaps EXTEND | |
| Electrics TEST | |
| Electrics OFF | |
| Master OFF Oil 4.5-5 qts | |
| Exterior CHECK | |
| Ties/Chocks REMOVE | |
| BaggageCHECK | |
| Walkaround EXECUTE | |
| BEFORE START | |
| Preflight Complete | |
| Passengers BRIEF | |
| SeatsADJUST | |
| SeatbeltsLATCH Fuel SelectorON | |
| MixtureRICH | |
| Throttle OPEN 1/2" | |
| | |
| | |
| Carb Heat COLD | |
| | |
| Carb Heat COLD Circuit Breakers . CHECK Electrical Switches . OFF Beacon | |
| Carb Heat COLD Circuit Breakers .CHECK Electrical Switches .OFF BeaconON AvionicsOFF | |
| Carb Heat | |
| Carb HeatCOLD Circuit Breakers .CHECK Electrical Switches .OFF BeaconON AvionicsOFF ENGINE START Master SwitchON PrimeAS REQ'D Clear Prop .ANNOUNCE StarterENGAGE Throttle1000 RPM | |
| Carb Heat | |
| Carb HeatCOLD Circuit Breakers .CHECK Electrical Switches .OFF BeaconON AvionicsOFF ENGINE START Master SwitchON PrimeAS REQ'D Clear Prop .ANNOUNCE StarterENGAGE Throttle1000 RPM | |
| Carb Heat | |

AFTER START

| Flaps RETRACT | | |
|------------------------------|--|--|
| Mixture LEAN FOR TAXI | | |
| Radios SET | | |
| ATIS GET | | |
| BarometerSET | | |
| Taxi Diag OPEN | | |
| TAVI | | |

TAXI

Brakes TEST
Controls WIND
Taxi Turns EXECUTE

SWITCH TO FLIGHT

SHUTDOWN Brakes SET Avionics OFF Electrical OFF Beacon ON Throttle 1000 RPM Mixture IDLE C/O Mags OFF Master OFF Control Lock INSTALL

Flight Plan CLOSE

C152 FLIGHT PROCEDURES

| TAKEOFF BRIEF | BEFORE LANDING |
|--|---|
| Runway | Fuel Selector ON ATIS GET Barometer SET Tower CONTACT Mixture RICH Carb Heat AS REQ'D Landing Lights ON Seatbelts ADJUST/LOCK |
| Time NOTE Mixture BEST POWER | AFTER LANDING |
| BEFORE TAKEOFF | Flaps UP |
| Doors CLOSED Windows LATCHED Controls CORRECT Fuel Selector ON Trim TAKEOFF Mixture RICH | Mixture LEAN Carb Heat COLD Strobe OFF Nav Lights AS REQ'D Landing Light AS REQ'D Radios SET Taxi Diag. OPEN |
| Throttle 1700 RPM Carb Heat CHECK | SWITCH TO GROUND |
| Mags CHECK | TAKEOFF CFGS |
| Primer IN & LOCKED Vaccuum CHECK Low Vac Light OUT Low Volt Light OUT Ammeter CHECK | NORMAL Flaps UP Rotate .55 Climb .74 |
| Voltmeter CHECK Oil Temp CHECK Oil Pressure CHECK Fuel Quantity CHECK | SHORT Flaps 10 Brakes SET Climb 56 TO 50' Flaps UP |
| EGT CHECK Throttleldle 1000 RPM | SOFT |
| Flight Inst CHECK/SET Radios SET Transponder SET Flaps SET Strobe ON Landing Light ON | Flaps |
| TAKEOFF & CLIMB | NORMAL/SOFT |
| ThrottleFULL FlapsUP Engine Inst MONITOR | Flaps FULL Speed65 SHORT |
| CRUISE | Flaps FULL |
| ThrottleSET MixtureLEAN TrimADJUST Engine InstrCHECK | Speed 60 |