On the vertical layer do not draw any horizontal lines of any great length in the center of the board. Only at the very top or the very bottom may long horizontal lines be drawn on the vertical layer without causing drawing problems for vertical lines.

