BRANCH FALL THROUGH

- 5. The IB determines branch fall through conditions. The IB sends "branch fall through" to the IA. The IB drops "hold issues" to the JA.
- 6. The IA restores all pointers and continues outputting data. The JA continues issuing instructions.