- T13 IA Loads Barrel with new address (Best case).
 IA waiting for fetch data.
 Address and quad select move TA to TC.
 Reference package moves TA to QB.
- T14 Address in Quadrant Register on TC translates Bank in QB.
- T15 Address moves TC to first waystation.

 Go Bank signal QB to waystation.
- T16 Release signal moves QB to TA. Release signal moves QB to TC.
- T17 Address moves 2nd waystation to node Go Bank signal in node; SB timer TAB.
- T18 Address moves to Bank address register SB timer TAC.
- T19 Address in Bank address register.

T26 Memory Busy drops IB to JA.
Hold issue drops IB to JA.

T37 Destination code moves QB to TD.

T52 TD Code delay (NO Rank).
1st Data Packet SB to Node.

- T53 TD Code delay (NP Rank).
 1st Data Packet Node to waystation 1.
- T54 TD Code delay (NQ Rank).
 1st Data Packet waystation 1 to 2.
- T55 TD Code delay (NR Rank).
 1st Data Packet waystation 2 to TD.
- T56 TD Code delay (NS Rank).
 2nd Data packet waystation 2 to TD.
- T57 Destination code moves TD to IA.
 3rd. Data Packet waystation 2 to TD.