

AquaPress AP-210 Pressure Transmitter -- Quick Start Guide

QUICK START GUIDE FOR AQUAPRESS AP-210 PRESSURE TRANSMITTER

INSTALLATION STEPS

1. **Select Location**: Choose a vibration-free and easy-to-access location for installation. Ensure the mounting surface is clean and dry.
2. **Mounting**: Use the provided mounting bracket to secure the AP-210 vertically. Ensure the pressure port is at the lowest point to prevent air entrapment.
3. **Connect Pressure Line**: Attach the pressure line to the pressure port using a compatible fitting. Ensure the connection is leak-proof.
4. **Install Transmitter**: Secure the AP-210 to the mounting bracket, ensuring it is properly aligned and secured.

WIRING DIAGRAM DESCRIPTION

The AquaPress AP-210 features a 4-wire configuration: two wires for power supply and two for signal output.

- **Power Supply Wires**: Connect the positive (+) wire (red) to a DC power source ranging from 10 to 30 volts. Connect the negative (-) wire (black) to the common ground.
- **Signal Output Wires**: The signal output wires consist of a positive (green) and a negative (blue). Connect the positive signal wire (green) to the data acquisition system's input. Connect the negative signal wire (blue) to the common ground of the system. Ensure all connections are secure and insulated to prevent short circuits.

BASIC STARTUP CHECK

1. **Power On**: Turn on the power supply and check for any visible signs of damage or loose connections.
2. **Verify Output**: Using a multimeter, check the output voltage from the green signal wire. The output should correspond to the applied pressure (e.g., 4 mA at 0 psi and 20 mA at full scale).
3. **Calibration Check**: If necessary, perform a calibration check according to the detailed manual (available separately) to ensure accuracy.
4. **Leak Check**: Inspect the pressure line connections for any signs of leaks before proceeding to normal operation.

Your AquaPress AP-210 is now ready for operation!