

Configure components of Wireless LAN access for client , Connectivity Using ,GUI only such as WLAN creation ,Security settings ,QOS profiles ,and advanced WLAN Settings





```
Packet Tracer PC Command Line 1.0
C:\>
ipconfig
Bluetooth Connection: (default port)
  Connection-specific DNS Suffix ..:
  Link-local IPv6 Address ....:::
  IPv6 Address....: ::
  IPv4 Address..... 0.0.0.0
  Subnet Mask...... 0.0.0.0
  Default Gateway....: ::
                          0.0.0.0
WirelessO Connection:
  Connection-specific DNS Suffix ..:
  Link-local IPv6 Address..... FE80::290:CFF:FEC0:4533
  IPv6 Address....: ::
  Default Gateway....:
                          0.0.0.0
C:\>
```