
Change the physics owner component

You will change the physics owner component from the top assembly to the part file.

1. Open mcd01_training_plant_d.



- 2. On the Physics Navigator , under the Basic Physics node, click the Owner Component cell for the long conveyor: Rigid Body.
- 3. From the list, select MCD01_LONG_CONVEYOR.
- 4. Under the **Basic Physics** node, click the **Owner Component** cell for the **long conveyor : Collision Body**.
- 5. From the list, select MCD01_LONG_CONVEYOR.
- 6. Under the **Basic Physics** node, click the **Owner Component** cell for the **long conveyor : Transport Surface**.
- 7. From the list, select MCD01_LONG_CONVEYOR.
- 8. Run the simulation to see the results, and then stop the simulation.

The physics properties are now assigned to the **MCD01_LONG_CONVEYOR** part file. The physics are still applied in the top assembly.

9. Close the part without saving.

You completed the activity.