BENTOPAD PINOUT
TO STM32F104

3   6

2   5

1   4

B4
B5
B6
B7
B8
B9
GND

B1
B0

ENCH LEFT

B

GND

A