



Outer Frame Assembly/Alignment


CCC	(i)	Created by: Joshua Vasquez	last edited: 2/7/2022
		SCALE: 1:5	SHEET 1 OF 28



	Intro	
	Created by:	last edited:
BY	Joshua Vasquez	2/7/2022
	SCALE: 1:5	SHEET 2 OF 28




Slide in 4 Inside Corner brackets into each extrusion. Exact locations don't matter just yet.



ITEM NO.	DESCRIPTION	QTY.
1	604mm long TSlot Extrusion	2
2	Interior Inside Corner Bracket	8

	Upper Frame Squaring 1/5				
CC	(i) BY	Created by: Joshua Vasquez	last edited: 2/7/2022		
		SCALE: 1:3	SHEET 3 OF 28		

Slide two 74mm extrusions into the outermost brackets, but don't tighten anything.




These short red extrusions are for squaring the frame and will be removed later.


ITEM	NO.	DESCRIPTION	QTY.
3		74mm Temporary TSlot Extrusion for Squaring	2

Upper Frame Squaring 2/5			
CC	(i) BY	Created by: Joshua Vasquez	last edited: 2/7/2022
		SCALE: 1:3	SHEET 4 OF 28

Slide two Machinist Blocks into the frame on both ends and gently clamp the entire setup together as shown below.




Note that the red extrusions will be loose. This is intentional. In this configuration, the frame is "square" using the 1-2-3 Blocks as a reference.




ITEM NO.	DESCRIPTION	QTY.
3	25-50-75mm (or 1-2-3) Machinist Block	2
4	Adjustable Clamp	2

	Upper Frame Squaring 3/5				
<u></u>	(i) BY	Created by: Joshua Vasquez	last edited: 2/7/2022		
		SCALE: 1:3	SHEET 5 OF 28		





Using Calipers or a ruler as a reference, set the short extrusions such that they match the dimensions shown above. The Blocks should still be touching. When the dimensions are set, clamp firmly.


	Upper Frame Squaring 4/5				
CC	BY	Created by: Joshua Vasquez	last edited: 2/7/2022		
		SCALE: 1:3	SHEET 6 OF 28		



Inside Corner Brackets tend to shift as you tighten one of their two screws. When you are close to to tightening one screw, switch off to the other screw such that the clamped assembly sets the position, not the screw.









Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	604mm long TSlot Extrusion	2
2	Interior Inside Corner Bracket	16


Lower Frame Squaring 1/5			
(00)	(i)	Created by:	last edited:
	BY	Joshua Vasquez	2/7/2022
		SCALE: 1:3	SHEET 8 OF 28







ITEM NO.	DESCRIPTION	QTY.
1	74mm Temporary TSlot Extrusion for Squaring	2

	Lower Frame Squaring 2/5		
(0)	•	Created by: Joshua Vasquez	last edited: 2/7/2022
	BY	•	SHEET 9 OF 28




Push the loose extrusions into the Block. Ensure that the Block is fully contacting top and bottom red extrusions.






Lower Frame Squaring 4/5				
<u></u>	(i) BY	Created by: Joshua Vasquez	last edited: 2/7/2022	
		SCALE: 1:3	SHEET 11 OF 28	



Now unclamp, relocate the clamp to the outside ends, reclamp, and tighten the four inside screws.




Lower Frame Squaring 5/5				
CC	()	Created by: Joshua Vasquez	last edited: 2/7/2022	
		SCALE: 1:3	SHEET 12 OF 28	

The next few steps involve these M5 Drop-In T Nuts. Thes are directional.

These are actually a metallic color, not green.


The flared side should point into the extrusion.




Each time you install an M5 Stamped T Nut, install it with a backing spring. These springs will prevent the nuts from sliding around unpredictably when you move the assembly. It's also important for some T Nuts that need to be installed partway up a vertical slot.




Stamped T Nut Intro			
(CC)	(i) BY	Created by: Joshua Vasquez	last edited: 2/7/2022
		SCALE: 1:2	SHEET 13 OF 28






Exploded View





Assembled View


ITEM NO.	DESCRIPTION	QTY.
1	409mm TSlot Extrusion	1
2	Interior Inside Corner Bracket	2
3	M5 Stamped Slide-In T Nut	10
4	T Nut Backing Spring	10

Upper Frame Assembly 2/6			
(i)	Created by:	last edited:	
BY	Joshua Vasquez	2/7/2022	
	SCALE: 2:5	SHEET 15 OF 28	











All four connecting surfaces should completely touch each other without any noticeable air gap.\




Assuming your 409mm TSlot Exrusions were cut to identical lengths, your frame should now be square!


	Upper Frame Assembly 6/6			
<u></u>	(i) BY	Created by: Joshua Vasquez	last edited: 2/7/2022	
		SCALE: 1:4	SHEET 19 OF 28	







- 4 Stampted T Nuts on the bottom



Assembled View

Set these assemblies aside for now.

On the right side slide in:


- 1 Stamped T Nut on top
- 4 Stampted T Nuts on the bottom

Exact locations will be set later.

ITEM NO.	DESCRIPTION	QTY.
3	M5 Stamped Slide-In T Nut	11
4	T Nut Backing Spring	11

Lower Frame Loose Assembly 2/8

		Created by: last edited:	last edited:
CC	BY	Joshua Vasquez	2/7/2022
		SCALE: 1:4	SHEET 22 OF 28



ITEM NO.	DESCRIPTION	QTY.
1	409mm TSlot Extrusion	1
2	M5 Stamped Slide-In T Nut	6
3	T Nut Backing Spring	6

L	Lower Frame Loose Assembly 3/8			
	(i)	Created by:	last edited:	
CC	BY	Joshua Vasquez	2/7/2022	
		SCALE: 2:5	SHEET 23 OF 28	

Inner Front Extrusion Slide in: 2 Stamped T Nuts on top Exact locations will be set later. Exploded View Assembled View


ITEM NO.	DESCRIPTION	QTY.
1	409mm TSlot Extrusion	1
2	M5 Stamped Slide-In T Nut	2
3	T Nut Backing Spring	2

Lower Frame Loose Assembly 4/8			
(cc)	•	Created by:	last edited:
	ВҮ	Joshua Vasquez	· ·
		SCALE: 2:5	SHEET 24 OF 28

Inner Back Extrusion

Slide in:

• **2** Stamped T Nuts on **top** Exact locations will be set later.



ITEM NO.	DESCRIPTION	
1	409mm TSlot Extrusion	1
2	M5 Stamped Slide-In T Nut	2
3	T Nut Backing Spring	2


Lower Frame Loose Assembly 5/8			
60	(i)	Created by:	last edited:
	BY	Joshua Vasquez	2/7/2022
		SCALE: 2:5	SHEET 25 OF 28

Back Extrusion

Slide in:

- 2 Stamped T Nuts on **top** with 2 inside corner brackets in between back-to-back
- 2 Stamped T Nuts on the **bottom**
- 4 Stamped T Nuts in the back

Exact locations will be set later.




Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	409mm TSlot Extrusion	1
2	Interior Inside Corner Bracket	2
3	M5 Stamped Slide-In T Nut	8
4	T Nut Backing Spring	8

Lower Fra	ame Loos	se Assem	ibly 6/8
-----------	----------	----------	----------

			,
	Created by:	last edited:	
	BY	Joshua Vasquez	2/7/2022
		SCALE: 2:5	SHEET 26 OF 28



Fully tighten the outer two extrusions, but let the inner ones stay loose. They will be aligned and tightened later. Tighten Tighten Tighten Tighten Tighten / Tighten / Tighten Tighten Tighten \
Tighten \ √Tighten Tighten Tighten Tighten Tighten Tighten

The Lower Frame is Complete!

Lower Frame Loose Assembly 8/8			
(i)	Created by:	last edited:	
	Joshua Vasquez	2/7/2022	

SCALE: 1:4

<u>@</u>

SHEET 28 OF 28