
## Honeywell

# MN6105, MN6110, MN7505, MN7510 Non-Spring Return Direct Coupled Actuators

#### **INSTALLATION INSTRUCTIONS**


Disconnect power before installation.




MU1B-0314GE51 R0606B




## Mounting on Counterclockwise (CCW) or Clockwise (CW) Closing Damper



### Wiring



## Adjusting for Counterclockwise (CCW) or Clockwise (CW) Closing Damper/Synchronization




#### **Automation and Control Solutions**

Honeywell International Inc. 1985 Douglas Drive North Golden Valley, MN 55422 Honeywell Limited-Honeywell Limitée 35 Dynamic Drive Scarborough, Ontario M1V 4Z9 By using this Honeywell literature, you agree that Honeywell will have no liability for any damages arising out of your use or modification to, the literature. You will defend and indemnify Honeywell, its affiliates and subsidiaries, from and against any liability, cost, or damages, including attorneys' fees, arising out of, or resulting from, any modification to the literature by you.

Honeywell GmbH Böblinger Straße 17 D-71101 Schönaich

customer.honeywell.com

® U.S. Registered Trademark
© 2006 Honeywell International Inc.
MU1B-0314GE51 R0606B
62-0224—1 J.I. Rev. 06-06



Honeywell