
Voip-Info.org A reference guide to all things VOIP







Residential VoIP

Unlimited Calling!

Two Months FREE!

>Home >Quick Links >Business VOIP >Residential VOIP >SIP >Call Center Software >Wholesale VOIP >Forums

Leading Business Phone System Just Got BETTER! BIG SAVINGS | NO CONTRACT | FEATURE RICH | Click for Details

for Details Onage

Business Solutions

Asterisk ss7 configuration

Configuration of chan_ss7

The Asterisk configuration file for chan_ss7 is called **ss7.conf**. It should be placed with the other Asterisk configuration files, ie. typically **/etc/asterisk/**. The description here is applicable for version 1.1.

The config file contains a number of sections: [linkset-name] sections where linksets are defined, [link-name] sections where links are defined(ie. circuits with SS7 CICs) are set up, [host-name] sections where hosts are defined, and finally a [cluster] section defining the cluster configuration.

Linkset section

hunting_policy. This sets the hunting policy, ie. the algorithm used to allocate a circuit for outgoing calls. This should be configured appropriately at each end of the SS7 link to minimize the risk of call collision (both ends try to make an outgoing call on the same circuit at the same time). Possible values are odd_lru (allocate odd CICs in preference to even CICs, and within each group pick the least recently used CIC); and even_mru (allocate even CICs in preference to odd CICs, and within each group pick the most recently used CIC). The default is odd_lru.

enable_st. This is used to decide whether end-of-pulsing (ST) is not used to determine when incoming address is complete.

use_connect. This settings specifies whether to eply incoming call with CON rather than ACM and ANM

context. The asterisk context to use for incoming calls on this linkset. Defaults to **default**.

language. The asterisk language to use for incoming calls on this linkset. Defaults to the empty string. **noa** Nature of Address

Link section

linkset. The linkset that this link belongs to

channels. The speech/audio circuit channels on this link.

schannel. The signalling channel

firstcic. The first CIC on this link

rxgain. rxgain

txgain. txgain

auto_block. When set to yes, the CICs on that link are blocked when signalling on the link is lost.

echocancel can be one of: no, 31speech (enable only when transmission medium is 3.1Khz speech), allways

echocan_train specifies training period, between 10 to 100 msec

echocan taps specifies number of taps, 32, 64, 128 or 256





Sponsored

Last modif pages

- 1. Atcom
- 2. voip-info.org
- 3. New Software Releases
- 4. VOIP Service Providers Business Europe
- 5. VOIP Service Providers Residential
- 6. MapleLeaf Technologies
- 7. maple4VOIP
- 8. Synchronous ICT-SBO, SyncSwitch & CoolDialer.
- 9. VOIP Service Providers
- 10. Automatic Call Distributor Show More...

VoIP Speed Test



Get Help

Ask a question

IP PBX for small business by justme, warner Thu 24 of Jul. 2014

Re: Cisco 7941G Standalone SIP Registration Stuck by calum2014 Sat 19 of Jul,

Cisco 7941G Standalone SIP Registration Stuck by calum2014 Sat 19 of Jul, 2014

View More...

Host section

chan ss7 auto-configures by matching the machines host name with the host-<name> section in the configuration file. The same configuration file can thus be used on several hosts.

default_linkset. This sets the SS7 linkset that receives outgoing calll where no linkset is defined in the Dial command'.

opc. The point code for this SS7 signalling point

dpc. A list of linkset:point-code pairs that specifies the point code to use for the linkset.

If the link connected to an STP (with point code 0x123), you may use

dpc => siuc:0x3ff,l1:0x123

links. A list of link:connector-no pains that specifies which links are on which connectors.

Jitter section

```
[jitter]
jbenable = yes
jbmaxsize = 1000
jbresyncthreshold = 1000
jbimpl = adaptive
```

Cluster section

This section has an entry for each link that is monitored by another host. Each eantry has a list of host#address pairs.

All sections has an **enabled** entry; if this entry is **no**, chan ss7 disregards the section.

The source code distribution of chan ss7 comes with a number fo configuration templates.

	Created by: knielsen, Last modification: Mon 10 of May, 2010 (19:08 UTC) by cervais		
		Links to this page	K
-	Please update this page with new information, just login and click on the "Edit" or "Discussion" tab. Get a free login here: Register Thanks! - Find us on Google+		
	RSS Page Changes RSS Comments		
	Featured -		
	Search: Search		

Terms of Service Privacy Policy
© 2003-2014 VOIP-Info.org LLC

Powered by <u>bitweaver</u>