## playsms 使用 HTTP 接口连接 OpenVox GSM Gateway

## 安装 PlaySMS

```
推荐使用 CentOS6.x
1. 安装依赖:
   apache or nginx or lighttpd
   mysq1 >= 5
   php >= 5.3, php-mysql, php-cli, php-mbstring, php-gd, php-pear and pear install db
   gettext
2. 更改 mysql root 密码
   [~]# mysql
   mysql> set password=password('111111');
   mysql> flush privileges;
   mysql> quit
3. 解压 playsms 源码
4. 拷贝 install.conf.dist 为 install.conf, 并修改其中:
   DBPASS 为 mysql 密码
   WEBSERVERUSER="apache"(/etc/httpd/conf/httpd.conf: User apache)
   WEBSERVERUSER="apache"(/etc/httpd/conf/httpd.conf: Group apache)
5. playsmsd start
6. 浏览器登陆: YourServerIP/playsms
   username: admin
   password: admin
```

## 发送短信

```
1. Settings - Manage gateway and SMSC - openvox - add (注意, 不是 edit 按钮)
   SMSC name: openvox
   Gateway host: 172.16.179.1
   Gateway port: 80
   Username: admin
   配置参考: OpenVox GSM Gateway - SMS - SMS Settings - HTTP to SMS
2. Settings - Route outgoing SMS - Add route
   User: Administrator
   Destination name: openvox out
   SMSC: openvox
   注: Prefix 为号码前缀,如发送至号码为 66375,实际号码为 66375
3. My account - Send message
   Send to: 66375
   Message: test
4. My account - Outgoing messages
   黄色小圆点: 正在发送
   绿色小圆点:已发送
   红色小圆点: 发送失败
注: 分段发送长短信
```

## 接收短信

Settings - Route incoming SMS
 Route all sandbox SMS to users: Administrator
 Other: no

2. chmod 777 /var/www/html/playsms/plugin/gateway/openvox/callback.php(原始权限为 644)

3. 更改 OpenVox GSM Gateway - SMS - SMS Settings - SMS to HTTP 配置 URL: http://YourPlaySMS:80/playsms/plugin/gateway/openvox/callback.php?phonenumber=phonenumber&port=port&message=message

注: 分段接收长短信