AIRCRAFT AND SIMULATOR SETUP

a. A/C Position	Connect Import Flight Plan Initiate Connected
COCKPIT INSPECTION	
1. LDG Gear	•
COCKPIT PREPARATION	
	ON
1. BAT 1 & 2	
1. BAT 1 & 2	ON
1. BAT 1 & 2 2. EXT PWR	ON Set
1. BAT 1 & 2	ON Set Auto
1. BAT 1 & 2 2. EXT PWR 3. Overhead Panel a. STROBE Light	ON Set Auto As Desired
1. BAT 1 & 2 2. EXT PWR 3. Overhead Panel a. STROBE Light 4. PA & CAB Comms 5. Frequencies 6. MCDU	ON SetAutoAs DesiredSetDIFRIPPS
1. BAT 1 & 2 2. EXT PWR 3. Overhead Panel a. STROBE Light 4. PA & CAB Comms 5. Frequencies 6. MCDU a. SID / STAR	ONSetAutoAs DesiredSetDIFRIPPSCheck Constraints
1. BAT 1 & 2	ON Set Auto As Desired Set DIFRIPPS Check Constraints Check Quantity
1. BAT 1 & 2 2. EXT PWR 3. Overhead Panel a. STROBE Light 4. PA & CAB Comms 5. Frequencies 6. MCDU a. SID / STAR	ON Set Auto As Desired Set DIFRIPPS Check Constraints Check Quantity Set

BEFORE START

1.	Boarding	Completed
2.	APU	ON and AVAIL
3.	APU BLEED	ON
4.	EXT PWR	OFF
	ONCE IRS ALIGNED -	
5.	Push and Start Clearance	As Required / Obtained
	NAV & LOGO Lights	
7.	BEACON Lights	ON
8.	Off-Block Time	Noted
_	HOURAGE & ENGINE START	
Р	USHBACK & ENGINE START	
1	Pushback	Follow Instructions
	Engine 1 & 2	
	g	
В	EFORE TAXI	
	Flaps	•
	Spoilers	
3.	Weather Radar & PWS	ON
	PITCH TRIM	
	Flight Controls	
	NOSE Light	
	RWY TURN OFF Light	
	APU & APU BLEED	
	AUTO BRK	MAX
10		
	Taxi Clearance	As Required / Obtained
	.Taxi Clearance	As Required / Obtained
т.		As Required / Obtained
T	AXI	As Required / Obtained
		·

BEFORE TAKEOFF

1. PARKING BRK ON
2. TO CONFIGPushed
a. ECAM Memo No Blue
3. FD
4. QNH, FCU ALT SELECTOR, Frequencies, Squawk Verify
5. Crew Briefing Completed
6. XPDR ON
7. TCAS ABV & TA/RA
IF FLYING ON IVAO
a. IVAO Pilot Client XPDR Verify ALT and Squawk Correct
b. IVAO Pilot Client TCAS ON & ALL
8. NOSE Light TO
9. LAND Light ON
10. RWY TURN OFF Light OFF
11. PACKS 1 & 2 OFF
12. Takeoff Clearance As Required / Obtained
CLEARED FOR TAKEOFF
13. Start Time
14. Clock Start
15. PARKING BRK OFF
TAKEOFF
1. THR LVR FLEX or TOGA
2. Elevator Control Rotate at Vr (less than 9.5 degrees pitch)

AFTER TAKEOFF / CLIMB

LDG Gear (at positive rate of climb, max 220 KT)				
2. A/P (min 100 ft AGL)				
3. THR LVR (when prompted)	CLIMB			
4. PACKS 1 & 2	ON			
5. Flaps	Up according to speed			
6. Spoilers	RET			
7. QNH (at transition altitude)	STD			
8. LAND Lights, NOSE Lights (passing FL 100)	OFF			
9. PAX Signs (calm air and pitch < 7.5 degrees)	OFF			
CRUISE				
1. TOD	Monitor			
30 NM PRIOR TO TOD				
2. MCDU > F-PLN > Arrival Routing	Verify / Set			
3. MCDU > PERF > Destination Info	Set			
4. MCDU > NAV RAD > ILS Frequency	Verify / Set			
5. FCU ALT SELECTOR	Set Target Altitude			
6. Arrival Performance	Calculate			
a. Landing Weight = GW - (Current FOB - EFOB)				
7. AUTO BRK	As Required			
AT TOD	•			
8. FCU ALT SELECTOR KNOB	Initiate Descend			
	a. PUSH for Managed Descend (VNAV Profile According to Flight Plan)			
b. PULL for Open Descend (Vectoring by ATC)	.co.ag tog.nt r iairi			
5. I SEE for Open Descend (Vectoring by ATO)				
9. TCAS Mode	RI W			

DESCEND

1. VNAV / Descend Profile	Monitor				
ON PASSING FL 100	ON PASSING FL 100				
2. NOSE Lights, LAND Lights	ON				
3. PAX Signs	ON				
ON PASSING TRL -					
4. QNH	Set Local				
APPROACH					
1. LS	ON				
ON PASSING (DECEL) WAY	POINT				
2. APPR Phase	Verify Active				
CLEARED FOR APPROA	ACH				
3. LOC Mode	ON				
4. APPR Mode	ON				
5. Flaps	Set according to speed				
6. Spoilers	ARM				
7. LDG Gear (max 250 KT)	DOWN				
BEFORE LANDING (2000 ft AGL)					
1. LDG Gear	DOWN, 3 Green				
2. AUTO BRK					
3. Flaps	·				
4. Spoilers					
5. ECAM Memo					
6. A/P	As Required				
7. QNH	Local				
8. PAX Signs					
9. Landing Clearance	As Required / Obtained				

AFTER LANDING (CLEAR OF RUNWAY)

ON	. PARKING BRK
UP	. Flaps
RET	. Spoilers
OFF	. Weather Radar & PWS
STBY	. XPDR
ABV & STBY	. TCAS
OFF	. LS
Stop	. Clock
Noted	. Landing Time
OFF	0.LAND Lights
TAXI	1. NOSE Lights
ON	2. RWY TURNOFF Lights
START	3. APU
As Required / Obtained	4. Taxi Clearance
	PARKING
	. PARKING BRK
	On-Block Time
	. THR LVR
	NOSE Light
	. RWY TURNOFF Light
	. APU
	. ENG 1 & 2 Master
OFF	. All External Lights
OFF	
	. PAX Signs
Initiate	. PAX Signs
Initiate	PAX Signs
Initiate	PAX Signs

SHUTDOWN

Completed	Deboarding	1.
ritches except BAT 1 & 2 and EXT PWR OFF	OVERHEAD Panel	2.
ON	CHOCKS & CONES	3.
OFF	PARKING BRK	4.
OFF	EXT PWR	5.
OFF	BAT 1 & 2	6.
	IF FLYING ON IV	
Disconnect	a IVAO Pilot Client	