

AIRCRAFT AND SIMULATOR SETUP

1. Time / Weather / A/C Position **As Chosen**
 --- IF FLYING ON IVAO ---
 - a. A/C Position **Free of other traffic**
 - b. IVAO Pilot Client **Connect**
2. A/C Refueling / Boarding **Initiate**
3. Sidestick, Throttle, Rudders **Connected**

Cockpit Inspection

1. ENG MASTER SW 1 & 2 **OFF**
2. ENG START Selector **NORM**
3. Landing Gear Lever **DOWN**
4. Wipers **OFF**
5. BAT 1 & 2, BAT EMER 1 & 2 **Check Voltage**

Electrical Power-Up

1. BAT 1 & BAT EMER 1 **ON**
2. BAT EMER 2 & BAT 2 **ON**
3. EXT 2 & 1 **AUTO**
4. IRS 1, 2, 3 **NAV**

FMS Setup 1

1. EFB > FLT OPS > FLT OPS STS **Simbrief Import**
2. ACFT Status **Check Information**
3. INIT Page **Enter Flight Plan Information**
 - a. CPNY Flight Plan **Request, then Insert**

Aircraft Status Check

1. ECAM Control > RCL ALL **Press, Check No Messages**
 2. ECAM Control > DISPATCH **Press, Check No Messages**
 3. Radio Management Panels L & R **Both On**
 4. Fire Test **Perform**
 5. APU MASTER & START SW **ON**
-
- Once APU Available
-
6. APU BLEED **ON**
 7. EXT 1 & 2 **OFF**
 8. Oxygen **Check Quantity**
 9. ENG OIL QTY **Check**
 - a. ECAM **Open ENG Page**
 - b. ENG FADEC GND PWR 1 & 2 **ON**
 - c. Oil QTY **Confirm Sufficient**
 - d. ENG FADEC GND PWR 1 & 2 **OFF**
 10. HYD QTY **Check**
 - a. ECAM **Open HYD Page**
 - b. HYD QTY **Confirm in green box**
 11. FLAPS **UP & matches indication**
 12. Speed Brake Lever **Retract**
 13. Accumulator Pressure **Check**
 - a. Parking Brake **Confirm Set**
 - b. ECAM **Open WHEEL Page**
 - c. ACCU **Confirm Pressure**
 14. Oxygen **Test**

Cockpit Setup

1. OXYGEN CREW SUPPLY	ON
2. RCDR GND CTL	ON
3. STROBE Light	AUTO
4. NAV Lights	1
5. NO SMOKING	ON
6. NO MOBILE	AUTO
7. EMER EXIT Lights	ARM

Once Fuel Loaded

a. SEAT BELTS	ON
8. ANTI-ICE	AUTO
9. PROBE WINDOW HEAT	AUTO
10. Fuel Pumps	ON
11. AIR DATA	AUTO
12. FMS	NORM
13. ANTI-SKID	ON
14. BARO	Set QNH
15. XPDR	STBY

FMS Setup 2

1. IRS	Confirm NAV & Aligned
2. DEPARTURE	Enter SID Information
3. Route	Enter / Verify Correct
4. NAVAIDS	Set / Check
5. Fuel & Load	Enter Required Information
a. Fuel QTY	Verify Sufficient
6. T.O. PERF	Enter Required Information
7. Cockpit Preparation CL	Completed

Before Pushback

1. BARO	Check Local QNH
2. ALT	Set Initial Climb
3. WXR	Confirm AUTO
4. XPDR	Enter Squawk
5. XPDR Mode	AUTO
6. TCAS	STBY & ABV
7. Parking Brake	Confirm Set
8. Windows & Doors	Confirm Closed
9. External Equipment	Remove
10. Before Start CL	Completed
Once Cleared For Pushback	
11. BEACON Light	ON
Once Pushback Completed	
12. Parking Brake	ON

Engine Start

1. Thrust Levers	Confirm Idle
2. ENG START Selector	IGN START
3. ENG MASTER SW 1	ON
Once ENG 1 AVAIL	
4. ENG MASTER SW 2	ON
Once ENG 2 AVAIL	
5. ENG START Selector	NORM

After Start

1. APU BLEED	OFF
2. ANTI-ICE	As Required
3. APU MASTER SW	OFF
4. AUTO BRAKE RTO	ARM
5. GND Spoilers	Arm
6. Rudder Trim	Reset
7. Flaps	As Required for Takeoff
8. Trim	Check Automatically Set
9. Flight Controls	Check
10. After Start CL	Completed

Taxi

1. Nose Light	Taxi
2. Parking Brake	Off
3. Brakes	Test
4. Taxi CL	Completed

Before Takeoff

1. FMA Modes	Check CLB & NAV Armed
2. Speeds	Check
3. Initial Climb	Check
4. Flaps	Check
5. TCAS	TA/RA
6. TO Config	Pushed, No Blue
7. Before Takeoff CL	Completed

Once Cleared For Takeoff

8. Nose Light	TO
9. LDG Lights	ON
10. Strobe Lights	ON
11. Lineup CL	Completed

Takeoff

1. Pitch	Down Halfway
2. ENG 1 & 2	Set to 25%
Once Engines Stabilized	
3. Power	As Required For TO
4. Brakes	Release
Speed 80 - 100 kts	
5. Pitch	Neutral
At Vr	
6. Pitch	Around 15 Degrees

After Takeoff

1. Gear	Up on positive climb
2. Flaps	Up according to speed
Once Flaps UP	
3. GND Spoilers	Disarm
4. Nose Light	OFF

Climb

1. FMA Modes	Monitor
Once Passing FL100	
2. LDG Lights	OFF
3. SEAT BELTS	OFF

Cruise

1. TCAS	BLW
2. Fuel Checks	Perform at least every hour
3. Step Climbs	
a. FMS > PERF > CRZ Page	Open Step Alts Page

Before Descend

1. WX & Landing Information Obtain
 - a. A350 is landing category D
 - b. BARO Preselect local QNH
2. Perf > APPR Page Enter Information
3. Landing Performance Calculate
4. Arrival Routing Enter / Check

If flying ILS approach

 - a. FMS POSITION > NAVAIDS Page Check ILS Information
5. BTV Setup
 - a. EFIS PLAN & ZOOM
 - b. Landing RWY Confirm Green Arrow
 - c. RWY EXIT Select & Set As BTV Exit
 - d. AUTO BRAKE Enable
 - e. FMA Confirm BTV armed

Descend

1. Icing Conditions
 - a. Visible Moisture
 - b. SAT (static air temperature) > -40
 - c. TAT (total air temperature) < +10
 - d. With engines at idle TAT < -10

When Passing FL250
2. SEAT BELTS ON

When Passing FL100
3. Landing Lights ON

If flying ILS approach

 - a. LS ON

Approach

1. Approach Mode **Activate**
2. Configuration
 - a. Flaps 1 **12 DME THR / 4000 ft AGL**
 - b. Flaps 2 **8 DME THR / 3000 ft AGL**
 - c. Gear Down **6 DME THR / 2000 ft AGL**
 - d. Below 200 kt **10 DME THR**
- _____ **On FAF / FAP** _____
3. Flaps **Down according to speed**
4. Approach Checklist **Completed**
- _____ **On Passing 2000 ft AGL** _____
5. Gear **Down**
6. Speed Brakes **ARM**
7. Nose Light **TO**
8. Landing Checklist **Completed**

Landing

1. ECAM LDG Memo **No Blue**
- _____ **On Passing 1000 ft AGL** _____
2. Fully Stabilized
- _____ **At 40 ft AGL** _____
3. Flare **Initiate**
4. Thrust **Idle**
- _____ **At 70 kts** _____
5. Reverse Thrust **Idle**
- _____ **Before Leaving RWY** _____
6. Thrust Reversers **Stowed**

After Landing

1. Speed Brakes	Disarm
2. Flaps	UP
3. WXR	OFF
4. LDG Lights	OFF
5. Nose Light	Taxi
6. Strobe Lights	AUTO
7. APU	Start
8. TCAS	STBY
When Entering Apron	
9. Nose Lights	OFF

Parking

1. Parking Brake	Set
Once APU Running	
2. ENG MASTER SW 2 & 1	OFF
Once Engines Shutdown	
3. BEACON Light	OFF
4. Fuel Pumps	OFF
5. Parking CL	Completed

Shutdown

1. ADIRS	OFF
2. Crew Oxygen	OFF
3. Exterior Lights	OFF
4. EXT PWR	As Required
5. APU	OFF
6. EMER EXIT Lights	OFF
7. Signs	OFF
8. Securing CL	Completed