

Circuit Pattern

1. Pattern Altitude	1500ft AGL
2. MCDU	Prepared
a. Approach Page	Filled
Once Airborn	
3. FCU	RWY HDG
4. Approach Phase	Activate
5. FLAPS	1
Once Pattern Altitude reached	
6. FCU	Set Downwind HDG
Crosswind Leg	
7. Flight Plan	Sequence
Downwind Leg	
8. Prepare for Arrival	
a. Auto Brake	Set
b. Approach Phase	Confirm Activated
c. ND Mode	ROS NAV and Range 10
Once RWY in Sight	
9. AP	OFF
10. FD	OFF
11. Bird	ON
12. Displacement to RWY	Maintain 2.5 NM
Abeam Threshold	
13. Timer	Start and Monitor Downwind Extension Time
a. Downwind Extension Time	(Pattern Altitude x 3) / 100
b. Headwind / Tailwind	Add / Subtract 1 second per knot
10 Seconds to Go	
14. FLAPS	2
15. FCU	Set RWY Track
Once Turn to Base Started	
16. Bank	20 - 25 degree
17. Gear	Down
18. Spoilers	Arm
19. Flaps	3, then Full

Circuit Pattern - CONTINUED20. Lights **As Required**21. V/S **Maintain 200-300 fpm until PAPI in sight****Touch and Go**

1. If auto brakes or reverse thrust is used, a full stop landing has to be performed

Downwind Leg2. Auto Brakes **Off**3. Callout **No reverse****Final**4. Auto Brakes **Confirm Off**5. Callout **No reverse****After Landing**6. Spoilers **Disarm**7. FLAPS **2**8. Thrust Levers **Stand Up (4-5 cm)****Once Spoilers Retracted**9. Thrust Levers **TOGA**

10. Rotate at V Approach