

AIRCRAFT AND SIMULATOR SETUP

1. Time / Weather / A/C Position **As Chosen**
 - IF FLYING ON IVAO ---
 - a. A/C Position **Free of other traffic**
 - b. IVAO Pilot Client **Connect**
2. A/C Fuel & Weights **Set**

Cockpit Preparation

1. Cockpit and Cabin **Locked & Secured**
2. Forward Luggage Compartment **Closed**
3. PAX Oxygen SW **STBY**
4. Oxygen Master SW **ON**
5. Exterior Lights **OFF**
6. Interior Lights **As Needed**
7. Crash Bar **Down**
8. Starter **OFF**
9. Ignition **AUTO**
10. AUX BP **OFF**
11. FUEL SEL **MAN**
12. AP TRIM **OFF**
13. Air Conditioning **OFF**
14. Circuit Breaker Lights **OFF**
15. DE ICING **OFF**
16. INERT SEP **OFF**
17. PARK BREAK **Reset (OFF, then ON)**
18. LANDING GEAR **DOWN**
19. PRESS BLEED **OFF**
20. HOT AIR FLOW **FEET**
21. MAN OVRD **OFF (Lowest Position)**
22. FUEL TANK SELECTOR **L or R**
23. ALTERNATE STATIC SOURCE **Pushed In**
24. EMERGENCY RAM AIR **Pushed In**

ELECTRICAL POWER UP

1. Crash Bar	Up
2. SOURCE	BATT
3. GENERATOR	MAIN
4. DE ICING LTS TEST	Check
5. LANDING GEAR LIGHT TEST	Check
6. Fuel Quantity	Verify
7. Residual Inlet Temperature (ITT)	Check < 150 Celsius
8. BATT VOLTS	Check >= 24 V

ENGINE START

1. AUX BP	ON
2. Timer	Start
3. STARTER	ON for 2 Seconds, then OFF
Once NG at 13 %	
4. Throttle	LOW IDLE
Once NG at 52 %	
5. Throttle	HIGH IDLE, then FLIGHT IDLE

AFTER ENGINE START

1. CAS Messages	Verify
2. FUEL SEL	AUTO
3. AUX BP	AUTO
4. AP TRIM	ON
5. Air Conditioning	As Needed
6. PRESS DUMP	NORM
7. PRESS BLEED	AUTO

BEFORE TAXI

1. BARO	Set QNH
2. DE ICING	As Required
3. INERT SEP	ON
4. FLAPS	UP
5. Flight Controls	Free and Correct
6. Autopilot Panel	Set
a. Climb Speed	$V_y = 100 \text{ kt}$, $V_x = 124 \text{ kt}$
b. FD	ON
7. External Lights	
a. TAXI Light	ON
b. PULSE Light	ON
c. NAV Light	ON

BEFORE TAKEOFF

1. LANDING Light	ON
2. NAV Light	ON
3. STROBE Light	ON
4. PITOT HTR L & R	ON
5. FLAPS	TO

TAKEOFF

1. TORQUE	100%
2. $V_r = 90 \text{ kt}$	
3. Initial Pitch	10 degrees
At 115 kt	
4. FLAPS	UP
Once clear of ice or other debris	
5. INERT SEP	OFF

BEFORE LANDING

- | | |
|---------------------------|---------------|
| 1. Baro | Set Local QNH |
| 2. LANDING Light | ON |
| 3. INERT SEP | ON |
| 4. Vle and FLAPS TO | Below 178 kt |
| 5. Approach Speed | 85 kt |

LANDING

- | | |
|----------------------|-------------|
| 1. Flare Angle | 4-7 degrees |
|----------------------|-------------|

AFTER LANDING

- | | |
|-----------------------|-----|
| 1. TAXI Light | ON |
| 2. STROBE Light | OFF |
| 3. DE ICING | OFF |

SHUTDOWN

1. PARK BRAKE	Set
2. External & Internal Lights	OFF
3. Oxygen Master SW	OFF
4. FUEL SEL	MAN
5. AP TRIM	OFF
6. PRESS BLEED	OFF
7. Throttle	
a. IDLE for 2 minutes	
b. LOW IDLE for 15 seconds	
c. CUT OFF	
8. INERT SEP	OFF
9. AUX BP	OFF
10. GENERATOR	OFF
11. SOURCE	OFF
12. Crash Bar	Down