0x0000		
	ROM Supervisor $16384 \text{w} \approx 16 \text{kiw}$	
0x3fff		
0x4000		
	RAM Supervisor $16384 \text{w} \approx 16 \text{kiw}$	↑ Sup Stack
0x7fff		Sup Stack
0x8000		
	Bank 1 (User Programm) $16384w \approx 16$ kiw	
0xbfff		
0xc000		
	Bank 2 (User Data) $16384w \approx 16$ kiw	↑ User Stack
Oxffff		