




HF Interface



HFR Soft Starter




Latching Relay



INPUTS
12V
GND
BSPD_OKHS
IMD_OKHS
DIS_OKHS
BMS_OKHS
PRE_OKHS
SHUTDOWN_IN
HFR_BUTTON

OUTPUTS
SHUTDOWN_HFR
IMD_TEENSY
BMS_TEENSY
BSPD_TEENSY
PRE_TEENSY
DIS_TEENSY

10



TEENSY OUTPUTS

