

Physiology and Mathematics of Inhalational Anesthesia

Julian W. Landaw

Abstract

Inhalational anesthetics reach the brain through a coupled respiratory and circulatory system. Their speed of onset and recovery is determined not merely by a vaporizer setting, but by fresh-gas delivery, rebreathing, alveolar ventilation, blood solubility, cardiac output, and uptake by tissues. This document develops a teaching model with a breathing circuit, alveoli, and vessel-rich, muscle, and fat tissue groups. It documents the assumptions used by the accompanying interactive simulator and explains why it is not a clinical gas-delivery calculator.

1 Partial pressure, fraction, and potency

For an inert volatile anesthetic, pharmacologic effect is governed most directly by partial pressure (or tension), not by total anesthetic mass. At a fixed barometric pressure, gas fraction F and partial pressure P are proportional: $P = FP_B$. Thus fractions can be used as normalized partial pressures in a teaching model.

Minimum alveolar concentration (MAC) is a population reference for anesthetic potency: conventionally, the alveolar concentration preventing movement to a standard noxious stimulus in 50% of subjects. It is not a universal measure of adequate anesthesia in an individual, and it varies with age, temperature, concomitant drugs, and clinical context. A displayed MAC fraction in the simulator is therefore only F_A/MAC_{ref} .

2 The path from vaporizer to tissues

The model is deliberately physiologic rather than an IV-style mammillary model:

vaporizer $\rightarrow$ breathing circuit $\rightarrow$ alveoli $\rightarrow$ arterial blood $\rightarrow$ {vessel-rich, muscle, fat} $\rightarrow$ venous blood. (1)

The vessel-rich group is a composite teaching compartment representing highly perfused tissues, including the brain. It is not a measured brain concentration. Muscle and fat receive less blood flow but can become important reservoirs during long exposures.

3 Circuit and alveolar mass balances

Let F_V , F_I , and F_A be the vaporizer, circuit-inspired, and alveolar fractions. Let V_C be circuit volume, V_A functional residual capacity, $\dot{V}_{FGF}$ fresh-gas flow, and $\dot{V}_A$ alveolar ventilation. A well-mixed circuit gives

$$V_C \frac{dF_I}{dt} = \dot{V}_{FGF}(F_V - F_I) - \dot{V}_A(F_I - F_A). \quad (2)$$

The first term replaces circuit gas with fresh gas; the second transfers gas between circuit and alveoli. The alveolar balance is

$$V_A \frac{dF_A}{dt} = \dot{V}_A(F_I - F_A) - U_{pulm}, \quad (3)$$

where pulmonary uptake is approximated by

$$U_{pulm} = \dot{Q}\lambda_{b:g}(F_A - F_{\bar{v}}). \quad (4)$$

Here $\dot{Q}$ is cardiac output, $\lambda_{b:g}$ is the blood:gas partition coefficient, and $F_{\bar{v}}$ is mixed venous anesthetic partial-pressure fraction. Equation 4 summarizes the classic determinants of uptake: a greater alveolar-venous gradient, higher cardiac output, or greater blood solubility removes more anesthetic from alveoli and slows the rise of F_A/F_I .

4 Why fresh-gas flow and alveolar ventilation differ

Fresh-gas flow (FGF), $\dot{V}_{FGF}$, is a machine setting: the total flow of newly supplied carrier gas and volatile anesthetic into the breathing circuit. Alveolar ventilation, $\dot{V}_A$, is a patient variable: the portion of minute ventilation that reaches gas-exchanging alveoli. In a simple respiratory description,

$$\dot{V}_A = (V_T - V_D)f, \quad (5)$$

where V_T is tidal volume, V_D is dead-space volume, and f is respiratory frequency. Thus changing respiratory rate, tidal volume, or dead space can change $\dot{V}_A$ without changing FGF; changing the machine flowmeters can change FGF without changing patient ventilation.

The two flows need not be equal. In a circle system with functioning one-way valves and carbon-dioxide absorbent, FGF can be less than alveolar ventilation: part of each inspired breath is then carbon-dioxide-free rebreathed gas, mixed with newly delivered gas. This is the basic setting of low-flow anesthesia. When FGF is higher, a larger fraction of circuit gas is replaced and excess gas is vented to scavenging; the inspired fraction more quickly approaches the vaporizer fraction. The relationship is also affected by leaks, circuit compliance, ventilator design, patient uptake of oxygen and anesthetic, and the phase of ventilation, none of which are fully represented here.

In the simulator, the default FGF and alveolar-ventilation values are both 4 L/min for clarity, not because physiology requires equality. A useful comparison is to hold $\dot{V}_A = 4$ L/min and lower FGF to 1 L/min. The circuit-inspired fraction then approaches the vaporizer setting more slowly because the model has less newly delivered gas per minute. Conversely, holding FGF fixed while raising $\dot{V}_A$ accelerates gas exchange between the circuit and alveolar compartment. These controls are intentionally independent in Eq. 2; their separation is central to the model's representation of rebreathing and circuit wash-in.

5 Tissue groups and venous return

For a tissue group j with volume V_j , perfusion $\dot{Q}_j$, tissue:blood partition coefficient $\lambda_{j:b}$, and normalized tissue tension F_j , a perfusion-limited approximation is

$$\frac{dF_j}{dt} = \frac{\dot{Q}_j}{V_j\lambda_{j:b}}(F_A - F_j). \quad (6)$$

The model uses three groups: vessel-rich, muscle, and fat, with $\sum_j \dot{Q}_j = \dot{Q}$. Mixed venous fraction is perfusion weighted,

$$F_{\bar{v}} = \frac{1}{\dot{Q}} \sum_j \dot{Q}_j F_j. \quad (7)$$

The coupled system in Eqs. 2–7 produces familiar behavior. Early in an anesthetic, venous tension is low and uptake is high. Later, vessel-rich tissue equilibrates, decreasing uptake; muscle and fat can continue to accumulate anesthetic and contribute to delayed washout.

6 Wash-in, washout, and solubility

Low $\lambda_{b:g}$ means that little anesthetic must dissolve in blood before alveolar partial pressure rises. This produces a more rapid rise in F_A/F_I and, after vaporizer discontinuation, more rapid elimination. Higher ventilation accelerates circuit/alveolar replacement, whereas higher cardiac output increases uptake from alveoli and can slow alveolar wash-in. Fresh-gas flow is particularly important when circuit volume and rebreathing are represented: low flow delays the approach of F_I to the vaporizer fraction.

Vaporizer-off washout is not simply exponential with one time constant. Circuit replacement, pulmonary elimination, redistribution from vessel-rich tissue, muscle, and fat, and their different perfusion/solubility time constants all contribute. This is why a teaching model should display both end-tidal fraction and tissue-equivalent states.

7 Worked teaching example: sevoflurane wash-in and washout

Consider an illustrative, not patient-specific, controlled-ventilation scenario. Select sevoflurane in the simulator and use the inputs in Table 1. The values describe the simplified apparatus-and-patient model; they are not a prescription, a recommended vaporizer setting, or a substitute for monitored clinical care. In particular, clinical inspired and end-tidal concentrations must be selected and adjusted by qualified clinicians using the actual machine, patient, and monitoring context.

Table 1: Illustrative sevoflurane simulator inputs.

Simulator input	Example value
Agent	Sevoflurane ($\lambda_{b:g} = 0.65$; reference MAC = 2.1%)
Vaporizer fraction	2.0%
Fresh-gas flow	4.0 L/min
Alveolar ventilation	4.0 L/min
Functional residual capacity	2.5 L
Breathing-circuit volume	2.0 L
Cardiac output	5.0 L/min
Vaporizer off time	60 min
Total simulation time	120 min

At the start, F_I , F_A , and all tissue-equivalent fractions are zero. The 2.0% vaporizer setting first fills the circuit, so the inspired fraction rises before the alveolar fraction. In the current simulator implementation, the example produces approximately $F_A = 1.08\%$ at 5 minutes, 1.39% at 15 minutes, and 1.56% just before the 60-minute vaporizer-off time. The latter corresponds to about 0.74 of the displayed reference MAC (1.56/2.1). The vessel-rich equivalent rises rapidly behind F_A (about 1.56% at 60 minutes), whereas muscle and fat rise much more slowly (about 0.62% and 0.05%, respectively). These numerical values are outputs of this teaching model, not predicted clinical end-tidal concentrations.

At 60 minutes the simulator changes F_V from 2.0% to zero. Fresh gas and ventilation then clear the circuit and alveoli: in this example F_A falls to roughly 0.93% one minute later and approaches zero by about 75 minutes. The vessel-rich group follows during this early washout, while muscle and fat remain nonzero because they are slower compartments. The first plot therefore shows the delivery and rapid end-tidal response; the tissue plot makes the delayed reservoir behavior visible; and the uptake plot is highest early, when the alveolar–venous gradient is greatest, then declines as the compartments equilibrate.

Useful counterfactuals are to increase fresh-gas flow or alveolar ventilation, which shortens circuit/alveolar turnover in this model, and to increase cardiac output, which increases early pulmonary

uptake and tends to slow the rise of F_A . Changing only the vaporizer-off time demonstrates why a longer exposure loads the slower tissue groups more strongly. These are qualitative physiologic lessons; the exact sizes and time courses should not be extrapolated to clinical management.

8 Numerical implementation

The webpage integrates the five state variables $[F_I, F_A, F_{VRG}, F_{muscle}, F_{fat}]^T$ with fourth-order Runge-Kutta integration at a fixed short time step. Inputs are held constant across a step; after the chosen vaporizer-off time, F_V is set to zero. Fractions are constrained to nonnegative values. The implementation is intended to reveal causal relationships, not to reproduce a particular anesthesia machine or commercial gas analyzer.

9 Important omissions and safety limitations

The simulator omits airway dead space, spontaneous effort, V/Q mismatch, shunt, diffusion limitation, nonlinear tissue partitioning, metabolism, agent interaction, nitrous-oxide concentration and second-gas effects, altitude, humidification, ventilator mechanics, scavenging, vaporizer physics, and monitoring. It also uses generic tissue-group volumes and perfusion fractions rather than a patient-specific validated model. Therefore it must not be used to select vaporizer concentrations, judge anesthetic depth, manage emergence, or guide patient care.

References

- [1] B. I. Eger and colleagues. Clinical pharmacokinetics of inhalational anaesthetics. *Clinical Pharmacokinetics*. 1987. <https://pubmed.ncbi.nlm.nih.gov/3555939/>
- [2] S. L. Shafer and colleagues. Optimizing target control of the vessel rich group with volatile anesthetics. *Anesthesia & Analgesia*. 2018. <https://pmc.ncbi.nlm.nih.gov/articles/PMC6309525/>
- [3] DailyMed. Sevoflurane prescribing information: blood/gas solubility and reference MAC. <https://dailymed.nlm.nih.gov/dailymed/fda/fdaDrugXsl.cfm?setid=ea8bf997-2c71-4014-b18d-4f7ab45dfa19&type=display>