

Definitions of part origin

Part origin is a part characteristic and control for each part maturation stage.

It is described and controlled based on the definitions of “Elements” and “Part level” in the list of “Definition of part origin”.

Part origin is stated based on the description of part level in the list of “Definition of part origin”.

List of “Definitions of part origin”.

List of “Definitions of part origin”.											
Part Origin	Description	Elements									
		Tool	Part Dimension	Texture	Equipment	JIG	Inspection Fixture	Process	Material	Manpower	Build Location
Proto type (PR)	• Parts not produced on MP Tool. Prototype tooling is temporary tooling not intended for MP use.	Prototype	Meet drawing (Handwork allowed)	No texture Required	Temporary allowed	Temporary allowed	Temporary allowed	Temporary process and sequence	Temporary allowed	NM associate/ Engineer	Temporary allowed
T1	• Produce with MP tool	MP Tool (except blank, trim, pierce, bender)	↑	↑	↑	• MP jig available • Temporary allowed	• MP inspection fixture available • Temporary allowed	↑	MP material and country of origin	↑	↑
T2	• Produce with MP tool for all process.	MP Tool	↑	↑	↑	↑	↑	↑	↑	↑	↑
T3	• Performance is equivalent to MP and enables start of PV test • Enable a Texture-Go for texture parts	↑	Meet drawing (without handwork)	Texture Ready	Equivalent to MP	MP	MP	※Process equivalent to MP/Sequence is MP.	↑	↑	↑
T4 (Texture parts only)	• Texture applied and allows for appearance evaluation.	↑	↑	Texture Required	↑	↑	↑	↑	↑	↑	↑
LT	• MP condition for all process except mass production volume.	↑	↑	↑	MP	↑	↑	MP process and sequence.	↑	MP associate (any shift)	MP final location
MP	• MP assurance is guaranteed for both quality and quantity	↑	↑	↑	↑	↑	↑	MP process and cycle time.	↑	MP associate (all shift)	↑

(※) Mass production equivalent process: Process that is identical to mass-production.

Process that can produce products with quality and volume that is assured in mass-production.