

Opcode	Tipo
000	sistema
001	aritmetico
010	memoria
011	Control
100	Boveda - Key
101	boveda - shift

Key	Dir. Boveda
K0	0:31
K1	32:63
K2	64:95
K3	96:127

Registros [0:31]		Proposito
0000	R0	general
0001	R1	general
0010	R2	general
0011	R3	general
0100	R4	general
0101	R5	general
0110	R6	general
0111	R7	general
1000	R8	general
1001	R9	general
1010	R10	general
1011	R11	general
1100	R12	general
1101	R13	general
1110	R14	general
1111	R15	PC

Delta * 32	13C6EF3720	->C6EF3720
Delta * 1	9e3779b9	

Sistema			
	Tipo [31:29]	OP [28]	NULL [27:0]
END	000	1	0
NOP	000	0	0

Aritmetica (Registro - Registro)							
	Tipo [31:29]	OP [28:25]	I [24]	RD [23:20]	RS1[19:16]	RS2 [15:12]	RS3 [11:8] NULL [7:0]
MOV	001	0000	0	xxxx	xxxx	xxxx	0000 0
ADD	001	0001	0	xxxx	xxxx	xxxx	0000 0
SUB	001	0010	0	xxxx	xxxx	xxxx	0000 0
MUL	001	0011	0	xxxx	xxxx	xxxx	0000 0
XOR	001	0100	0	xxxx	xxxx	xxxx	0000 0
XOR3	001	0101	0	xxxx	xxxx	xxxx	xxxx 0
SHL	001	0110	0	xxxx	xxxx	xxxx	0000 0
SHR	001	0111	0	xxxx	xxxx	xxxx	0000 0
CMP	001	1000	0	xxxx	xxxx	0	0000 0

Aritmetica (Registro - Inmediato)					
	Tipo [31:29]	OP [28:25]	I [24]	RD [23:20]	RS1[19:16] Inmediato [15:0]
MOVI	001	0000	1	xxxx	xxxx x
ADDI	001	0001	1	xxxx	xxxx x
SUBI	001	0010	1	xxxx	xxxx x
MULI	001	0011	1	xxxx	xxxx x
XORI	001	0100	1	xxxx	xxxx x
SHLI	001	0110	1	xxxx	xxxx x
SHRI	001	0111	1	xxxx	xxxx x
CMPI	001	1000	1	xxxx	0 x

Memoria (Corregido)					
	Tipo [31:29]	OP [28]	I [27]	RD [26:23]	RS1 [22:19] Inmediato [18:0]
LDR	010	0	0	xxxx	xxxx x
LDRI	010	0	1	xxxx	---- x
STR	010	1	0	xxxx	xxxx x
STRI	010	1	1	xxxx	---- x

Boveda - Shift					
	Tipo [31:29]	OP [28]	RD [27:24]	RS [23:20]	KS [19:18] Inmediato [17:0]
BSHL	101	0	xxxx	xxxx	xx x
BSHR	101	1	xxxx	xxxx	xx x

Boveda - Key				
	Tipo [31:29]	KS [28:27]	H/L [26]	NULL [25:16] Inmediato [15:0]
BSTRH	100	xx	1	0 x
BSTRL	100	xx	0	0 x

Control			
	Tipo[31:29]	OP[28:26]	Inmediato[25:0]
BEQ	011	000	x
BNE	011	001	x
BLT	011	010	x
BGT	011	011	x
JUMP	011	110	x