Start Here: Know Your Alarm

Product facts, power source, and first-time setup



CARBON MONOXIDE ONLY

Battery-powered CO alarm

Uses 2 replaceable 1.5V alkaline AA (LR6) batteries. No AC outlet or hardwiring required.

10 years = ALARM LIFE, not battery life

IMPORTANT PRODUCT CLARIFICATIONS

01 NOT A PLUG-IN MODEL
Does not plug into a wall outlet and is not hardwired.

02 DETECTS CO, NOT CO2
Detects carbon monoxide (CO); not carbon dioxide (CO2), smoke, or fire.

03 NO ROOM TEMPERATURE
The LCD is for carbon monoxide information in ppm—not room temperature.

04 REPLACEABLE BATTERIES
Replace the AA batteries when the low-battery warning sounds. The alarm has a 10-year end-of-life warning.

FIRST-TIME STARTUP

1. Remove the battery insulation tab.
2. After about 5 seconds: one short beep.
3. LEDs alternate for about 100 seconds.
4. When LEDs go off: ready for use.

Decode the Beeps & Lights

Match the indicator color and audible pattern to the correct action

CO EMERGENCY

4 beeps + 4 red flashes every 5 seconds

MOVE TO FRESH AIR. CALL 911. DO NOT RE-ENTER.

WARM-UP GREEN + RED + YELLOW	Alternating lights for ~100 seconds. One short beep after ~5 seconds.	**WHAT TO DO** Wait for LEDs to turn off.
WEEKLY TEST RED	Red LED flashes 4 times per cycle; alarm gives 4 beeps per cycle, repeated twice.	**WHAT TO DO** Press and hold TEST/HUSH until the alarm sounds.
EARLY WARNING RED	Above 30 ppm for more than 35 minutes: one red flash + one beep every 60 seconds.	**WHAT TO DO** Check for possible CO exposure; do not ignore the warning.
LOW BATTERY YELLOW	One yellow flash + one beep every 60 seconds.	**WHAT TO DO** Replace the 2 specified AA batteries promptly.
MALFUNCTION YELLOW	Two yellow flashes + two beeps every 60 seconds.	**WHAT TO DO** Do not rely on the device. Contact support or replace it.
END OF LIFE YELLOW	Two yellow flashes + one long and one short beep every 60 seconds.	**WHAT TO DO** Replace the complete alarm, not just its batteries.

A slower alarm pattern after 4 minutes does NOT mean the danger has passed.

Solve Common Problems

Clear checks for sound, screen messages, and CO levels

1 NO SOUND DURING TEST?



- Check that the insulation tab was removed and the batteries are correctly installed.
- Allow the ~100-second warm-up to finish.
- Press and hold TEST/HUSH until the horn sounds. If it still fails, replace the alarm.

2 DISPLAY ERROR OR FAULT?

Err

If the LCD shows an unfamiliar message:

- The manual does not define an “Err” code.
- Check battery installation and perform a weekly test.
- If the display remains unusual or the test fails, do not rely on this alarm. Contact support.

3 WHY NO BEEP AT 30 PPM?

The manual specifies an early-warning signal only when CO concentration is ABOVE 30 ppm for MORE THAN 35 minutes.

CO ALARM RESPONSE TIMES

70 ppm	60–240 min
150 ppm	10–50 min
400 ppm	4–15 min

The response is not necessarily immediate. Never expose the device to CO to test it.

4 WHAT DOES THE LCD MEAN?

CO **20** PPM

PPM = parts per million. The value refers to carbon monoxide (CO), not room temperature or carbon dioxide (CO2).

A reading on the display does not automatically mean the audible alarm threshold has been reached.

Install, Maintain & Stay Safe

Reliable protection starts with correct placement and regular testing

IF THE CO ALARM SOUNDS

1. **Immediately move everyone to fresh air.**
2. **Call 911 or your local emergency service.**
3. **Do not re-enter until responders arrive, the space has aired out, and the alarm returns to normal.**

A PLACEMENT



- Install in or near sleeping areas and on each level of the home.
- Avoid garages, bathrooms, very drafty spots and dusty areas.
- Keep at least 5 ft (1.5 m) from cooking appliances.

B TEST & MAINTENANCE

- Test weekly with the TEST/HUSH button. Keep an arm's length away during testing.
- If the alarm fails the test after confirming battery power, replace it immediately.
- Clean annually using compressed air or a vacuum hose; never use water or solvents.
- Replace batteries promptly when the low-battery warning sounds.

WRONG ITEM, DAMAGED PACKAGING, OR UNEXPECTED MODEL?

Check the model number on the unit and the items supplied: CO alarm, mounting bracket, 2 AA batteries, 2 screws, 2 anchors, manual and 2 safety stickers. If anything is incorrect or damaged, contact the seller or customer support.