

FLOOR AREA RATIO

The floor area ratio, also referred to as FAR, is the principle bulk regulation controlling the size of buildings. FAR is the ratio of the total building floor area to the area of the zoning lot.

The FAR determines the maximum floor area allowed in a building on a zoning lot.

