Sony MA900 BSL2 Decontamination Standard Operating Procedure
UC Davis Flow Cytometry Shared Resource

Director: Bridget McLaughlin, bmclaughlin@ucdavis.edu
Manager: Jonathan Van Dyke, jvandyke@ucdavis.edu
Specialist: Ashley Karajeh, avcarlos@ucdavis.edu

This procedure ***must*** be followed after every BSL2 sort.

Part 1: Initial System Cleaning

1. Unload your sample from the sample station and retrieve your sorted cells.
    a. Recommend to place your cells back on ice to keep them happy.
2. Create a new empty sample tube
    a. If you are on the last sample in the sample list, just click “Next Tube” in MA900 Software.
3. Set the “Sample Pressure” to 10 in MA900 Software.
4. Prepare a 20% bleach solution in a normal 5mL FACS tube.
    a. Bleach + MilliQ water
5. Load the 20% Bleach 5mL FACS tube sample onto the sample port.
6. Click “Start” in MA900 Software.
7. Run the 20% bleach for 10min.
8. Remove the sort collection device from the sort chamber and set it inside the Biobubble.
    a. This will be cleaned on step 10-a.

Part 2: Final System clean and surface decontamination

1. ***Take note of the time***, and continue to the next step.
2. Prepare 20% bleach solution into **30mL Tube**
    a. ***Use bleach 1gal contain under sink***
    b. Bleach + MilliQ
3. Prepare 100% MilliQ water into **30mL Tube**
4. Remove the 5mL FACS tube holder from the instrument.
5. Install the 30mL tube holder into the instrument.
6. Place the 20% bleach 30mL tube into the instrument.
7. Click the “Cytometer” Button in the MA900 Software
8. On the upper right side of the tool bar click the “Software and Hardware Shutdown” button in the MA900 Software
    a. **Note: NEVER click the “Shutdown with Ethanol” button.**
9. Follow the wizard with the following note
    a. Make sure to select “Careful Cleaning”, this will note the required 30mL tubes.
10. While the first solution is running (20% Bleach) spray the following surfaces with Cavicide and allow to sit visibly wet for 5min.
    a. Sort collection device you used
    b. Computer desktop make sure to get under keyboard
    c. Keyboard and mouse
    d. Both lab bench surfaces along the wall on the opposite side of the room from the instrument.
    e. Inside and outside door handle/push bar

    f. Inside the MA900 Biobubble, directly in front of and around the instrument.
    g. Inside and outside Biobubble flap
11. After the 5min sit time, spray all surfaces once more with Cavicide and wipe dry with Kimwipe.
12. Spray 70% ETOH onto a Kimwipe and wipe the outside of the instruments push buttons
    a. Power, sort door, top access chamber.
13. Spray 70% ETOH onto a new Kimwipe and wipe down the inside of the sort chamber.
14. **Change your gloves**
15. Move back to the MA900 “Software and Hardware Shutdown” wizard in the software and continue to the next solution (DI Water).
    a. Note: Make sure the “Leave DI water Inside Sample Line” box is checked.
16. Finish the steps in the wizard to turn off the system.
17. Confirm the system power is off (Screen of instrument will be off).
18. Turn off the compressor.
19. Check the noted time, if it is >30min then remove the waste tank and dump its contents down the sink. Otherwise wait until sit time is >30min.