

Este mantenimiento se ha realizado siguiendo las instrucciones de operador que se adjuntan en los manuales del fabricante anexos y consta de los siguientes apartados.

- 1- Funcionamiento del freno.
- 2- Inspección visual de la cadena.
- 3- Suspensión de la caja de mando por el cable de acero.
- 4- Limpieza y aceitado de la cadena.
- 5- Funcionamiento del limitador.
- 6- Lubricación de la polea de cadenas de trócola.
- 7- Verificación de los tornillos de la brida de posicionamiento.

Se adjunta copia de parte del manual de mantenimiento del fabricante con las operaciones realizadas.



7 PREVENTATIVE MAINTENANCE

7.1 Maintenance and Inspection Table

Table 23. Maintenance Schedule

INSPECTION CHECK	INTERVAL	QUALIFIED PERSON
BRAKE OPERATION FOR HOLDING AND RELEASING	DAILY	OPERATOR
LOAD CHAIN FOR DAMAGE	DAILY	OPERATOR
POWER AND/OR CONTROL CABLE SUPPORTS	DAILY	OPERATOR
CLEANLINESS & LUBRICATION OF LOAD CHAIN	MONTHLY	OPERATOR
UPPER / LOWER LIMIT SWITCHES	MONTHLY	OPERATOR
CHECK LOAD CHAIN FOR WEAR - MEASURE AND RECORD	QUARTERLY	INSPECTOR
CHECK HOOKS FOR WEAR MEASURE AND RECORD	QUARTERLY	INSPECTOR
CHECK CHAIN HOOK BLOCK HARDWARE TO VERIFY TIGHTNESS	QUARTERLY	OPERATOR
CHECK TOP(BODY) HOOK / COUPLING HARDWARE FOR TIGHTNESS	QUARTERLY	OPERATOR
CHECK SLIP CLUTCH & HOIST BRAKE ADJUSTMENT	QUARTERLY	MAINTENANCE
CHECK LUBRICATION OF OPEN WHEEL GEARING	QUARTERLY	MAINTENANCE
CHECK WIRE TERMINALS TIGHTNESS	SEMI-ANNUALLY	MAINTENANCE
LUBRICATE 2-FALL CHAIN HOOK BLOCK SPROCKET	ANNUALLY	OPERATOR
CHECK ALL HARDWARE FOR TIGHTNESS AND CORROSION	ANNUALLY	MAINTENANCE
CLEAN MOTOR COOLING FINS	ANNUALLY	MAINTENANCE
LUBRICATE ALL GEARING	ANNUALLY	MAINTENANCE
INSPECT LOAD HOOK THRUST BEARING	ANNUALLY	MAINTENANCE

SATPRO S.L.U.

c/ Los Escribas nº1
Burguillos
41220 Sevilla
C.I.F. B91629879



CAUTION: Inspection and maintenance intervals should be adjusted based upon owner / user knowledge of application, environment, and frequency of use to prevent damage to people, equipment, and facilities.